

**SMARTDAC+ STANDARD
Hardware Configurator
User's Manual**

Introduction

This manual explains how to use SMARTDAC+ STANDARD Hardware Configurator. To ensure correct use, please read this manual thoroughly before beginning operation.

Notes

- The contents of this manual are subject to change without prior notice as a result of continuing improvements to the software's performance and functions.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without YOKOGAWA's permission is strictly prohibited.
- The TCP/IP software of this product and the document concerning the TCP/IP software have been developed/created by YOKOGAWA based on the BSD Networking Software, Release 1 that has been licensed from University of California.

Trademarks

- SMARTDAC+ and SMARTDACPLUS are registered trademarks of Yokogawa Electric Corporation.
- Microsoft, Windows, and Internet Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are registered trademarks or trademarks of Adobe Systems Incorporated.
- Pentium is a trademark of Intel Corporation in the United States and/or other countries.
- Bluetooth is a registered trademark or trademark of Bluetooth SIG, Inc.
- Company and product names that appear in this manual are registered trademarks or trademarks of their respective holders.
- The company and product names used in this manual are not accompanied by the registered trademark or trademark symbols (® and ™).

Revisions

December	2012	1st Edition
February	2013	2nd Edition
May	2013	3rd Edition
May	2014	4th Edition
December	2014	5th Edition
August	2015	6th Edition
December	2015	7th Edition
June	2017	8th Edition

Software License Agreement

IMPORTANT - PLEASE READ CAREFULLY BEFORE INSTALLING OR USING:

THANK YOU VERY MUCH FOR SELECTING SOFTWARE OF YOKOGAWA ELECTRIC CORPORATION ("YOKOGAWA") PROVIDED BY DOWNLOADING FROM YOKOGAWA'S WEB SITE, OR THE RECORDING MEDIUM (collectively, "Software Product"). BY INSTALLING OR OTHERWISE USING THE SOFTWARE PRODUCT, YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE, DO NOT INSTALL NOR USE THE SOFTWARE PRODUCT.

1. Scope

This Agreement applies to the Software Product and associated documentation of Yokogawa. Unless otherwise provided by Yokogawa, this Agreement applies to the updates and upgrades of the Software Product which may be provided by Yokogawa.

Software product: SMARTDAC+ STANDARD Hardware Configurator

2. Grant of License

- 2.1 Subject to the terms and conditions of this Agreement, Yokogawa hereby grants to you a non-exclusive and non-transferable right to use the Software Product for your internal operation use,
- 2.2 Unless otherwise agreed or provided by Yokogawa in writing, the following acts are prohibited:
 - a) to reproduce the Software Product, except for one archival copy for backup purpose, which shall be maintained with due care subject to this Agreement;
 - b) to sell, lease, distribute, transfer, pledge, sublicense, make available via the network or otherwise convey the Software Product or the license granted herein to any other person or entity;
 - c) to use the Software Product on any unauthorized computer via the network;
 - d) to cause, permit or attempt to dump, disassemble, decompile, reverse-engineer, or otherwise translate or reproduce the Software Product into source code or other human readable format, or to revise or translate the Software Product into other language and change it to other formats than that in which Yokogawa provided;
 - e) to cause, permit or attempt to remove any copy protection used or provided in the Software Product; or
 - f) to remove any copyright notice, trademark notice, logo or other proprietary notices or identification shown in the Software Product.
- 2.3 Any and all technology, algorithms, know-how and process contained in the Software Product are the property or trade secret of Yokogawa or licensors to Yokogawa. Ownership of and all the rights in the Software Product shall be retained by Yokogawa or the licensors and none of the rights will be transferred to you hereunder.
- 2.4 You agree to maintain the aforementioned property and trade secret of Yokogawa or licensors and key codes in strict confidence, not to disclose it to any party other than your employees, officers, directors or similar staff who have a legitimate need to know to use the Software Product and agreed in writing to abide by the obligations hereunder.
- 2.5 Upon expiration or termination of this Agreement, the Software Product and its copies, including extracts, shall be returned to Yokogawa and any copies retained in your computer or media shall be deleted irretrievably. If you dispose of media in which the Software Product or its copy is stored, the contents shall be irretrievably deleted.
- 2.6 The Software Product may contain software which Yokogawa is granted a right to sublicense or distribute by third party suppliers, including affiliates of Yokogawa ("Third Party Software"). If suppliers of the Third Party Software ("Supplier") provide special terms and conditions for the Third Party Software which differ from this Agreement, the special terms and conditions separately provided by Yokogawa shall prevail over this Agreement. Some software may be licensed to you directly by Supplier.
- 2.7 The Software Product may contain open source software ("OSS"), for which the special terms and conditions separately provided by Yokogawa shall take precedence over this Agreement.

3. Restrictions on Application

- 3.1 Unless otherwise agreed in writing between you and Yokogawa, the Software Product is not intended, designed, produced or licensed for use in relation to aircraft operation or control, ship navigation or marine equipment control, or ground facility or device for support of the aforesaid operation or control, or for use in relation to rail facility, nuclear related facility, radiation-related equipment, or medical equipment or facility, or under any other circumstances which may require high safety standards.
- 3.2 If the Software Product is used for the abovementioned purposes, neither Yokogawa nor assumes liability for any claim or damage arising from the said use and you shall indemnify and hold Yokogawa, Supplier, their affiliates, subcontractors, officers, directors, employees and agents harmless from any liability or damage whatsoever, including any court costs and attorney's fees, arising out of or related to the said use.

4. Limited Warranty

- 4.1 The Software Product shall be provided to you on an "as is" basis at the time of delivery, Yokogawa shall disclaim all of the warranties whatsoever, express or implied, and all liabilities therefrom. If any physical defect is found on the recording medium not later than twelve (12) months from delivery, Yokogawa shall replace such defective medium free of charge, provided that the defective medium shall be returned to the service office designated by Yokogawa at your expense within the said twelve (12) months. THIS LIMITED WARRANTY PROVIDED IN THIS CLAUSE IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND WHATSOEVER AND YOKOGAWA HEREBY DISCLAIMS ALL OTHER WARRANTIES RELATING TO THE SOFTWARE PRODUCT, WHETHER EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, NON-INFRINGEMENT, QUALITY, FUNCTIONALITY, APPROPRIATENESS, ACCURACY, RELIABILITY AND RECENCY. IN NO EVENT SHALL YOKOGAWA WARRANT THAT THERE IS NO INCONSISTENCY OR INTERFERENCE BETWEEN THE SOFTWARE PRODUCT AND OTHER SOFTWARE NOR SHALL BE LIABLE THEREFOR. The warranty provisions of the applicable law are expressly excluded to the extent permitted.
- 4.2 At the sole discretion of Yokogawa, Yokogawa may upgrade the Software Product to the new version number ("Upgrade") and make it available to you at your expense or free of charge as Yokogawa deems fit. In no event shall Yokogawa be obliged to upgrade the Software Product or make the Upgrade available to you.
- 4.3 Certain maintenance service may be available for some types of Software Product at Yokogawa's current list price. Scope and terms and conditions of the maintenance service shall be subject to those separately provided by Yokogawa. Unless otherwise provided in Yokogawa catalogues or General Specifications, maintenance services will be available only for the latest version and the immediately preceding version. In no event will service for the immediately preceding version be available for more than 5 years after the latest version has been released. In addition, no service will be provided by Yokogawa for the Software Product which has been discontinued for more than 5 years. Notwithstanding the foregoing, maintenance service may not be available for non-standard Software Product. Further, in no event shall Yokogawa provide any service for the Software Product which has been modified or changed by any person other than Yokogawa.

5. Infringement

- 5.1 If you are warned or receive a claim by a third party that the Software Product in its original form infringes any third party's patent (which is issued at the time of delivery of the Software Product), trade mark, copyright or other intellectual property rights ("Claim"), you shall promptly notify Yokogawa thereof in writing.
- 5.2 If the infringement is attributable to Yokogawa, Yokogawa will defend you from the Claim at Yokogawa's expense and indemnify you from the damages finally granted by the court or otherwise agreed by Yokogawa out of court. The foregoing obligation and indemnity of Yokogawa shall be subject to that i) you promptly notify Yokogawa of the Claim in writing as provided above, ii) you grant to Yokogawa and its designees the full authority to control the defense and settlement of such Claim and iii) you give every and all necessary information and assistance to Yokogawa upon Yokogawa's request.
- 5.3 If Yokogawa believes that a Claim may be made or threatened, Yokogawa may, at its option and its expense, either a) procure for you the right to continue using the Software Product, b) replace the Software Product with other software product to prevent infringement, c) modify the Software Product, in whole or in part, so that it become non-infringing, or d) if Yokogawa believes that a) through c) are not practicable, terminate this Agreement and refund you the paid-up amount of the book value of the Software Product as depreciated.
- 5.4 Notwithstanding the foregoing, Yokogawa shall have no obligation nor liability for, and you shall defend and indemnify Yokogawa and its suppliers from, the Claim, if the infringement is arising from a) modification of the Software Product made by a person other than Yokogawa, b) combination of the Software Product with hardware or software not furnished by Yokogawa, c) design or instruction provided by or on behalf of you, d) not complying with Yokogawa's suggestion, or e) any other causes not attributable to Yokogawa.
- 5.5 This section states the entire liability of Yokogawa and its suppliers and the sole remedy of you with respect to any claim of infringement of a third party's intellectual property rights. Notwithstanding anything to the contrary stated herein, with respect to the claims arising from or related to the Third Party Software or OSS, the special terms and conditions separately provided for such Third Party Software or OSS shall prevail.

6. Limitation of Liability

- 6.1 EXCEPT TO THE EXTENT THAT LIABILITY MAY NOT LAWFULLY BE EXCLUDED IN CONTRACT, YOKOGAWA SHALL NOT BE LIABLE TO ANY PERSON OR LEGAL ENTITY FOR LOSS OR DAMAGE, WHETHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES, OR OTHER SIMILAR DAMAGES OF ANY KIND, INCLUDING WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OR DESTRUCTION OF DATA, LOSS OF AVAILABILITY AND THE LIKE, ARISING OUT OF THE USE OR INABILITY TO USE OF THE SOFTWARE PRODUCT, OR ARISING OUT OF ITS GENERATED APPLICATIONS OR DATA, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, WHETHER BASED IN WARRANTY (EXPRESS OR IMPLIED), CONTRACT, STRICT LIABILITY, TORT (INCLUDING NEGLIGENCE), OR ANY OTHER LEGAL OR EQUITABLE GROUNDS. . If the Software Product delivered by Yokogawa is altered, modified or combined with other software or is otherwise made different from Yokogawa catalogues, General Specifications, basic specifications, functional specifications or manuals without Yokogawa's prior written consent, Yokogawa shall be exempted from its obligations and liabilities under this Agreement or law.
- 6.2 Any claim against Yokogawa based on any cause of action under or in relation to this Agreement must be given in writing to Yokogawa within three (3) months after the cause of action accrues.

7. Export Control

You agree not to export or provide to any other countries, whether directly or indirectly, the Software Product, in whole or in part, without prior written consent of Yokogawa. If Yokogawa agrees such exportation or provision, you shall comply with the export control and related laws, regulations and orders of Japan, the United States of America, and any other applicable countries and obtain export/import permit and take all necessary procedures under your own responsibility and at your own expense.

8. Audit; Withholding

- 8.1 Yokogawa shall have the right to access and audit your facilities and any of your records, including data stored on computers, in relation to the use of the Software Product as may be reasonably necessary in Yokogawa's opinion to verify that the requirements of this Agreement are being met.
- 8.2 Even after license being granted under this Agreement, should there be any change in circumstances or environment of use which was not foreseen at the time of delivery and, in Yokogawa's reasonable opinion, is not appropriate for using the Software Product, or if Yokogawa otherwise reasonably believes it is too inappropriate for you to continue using the Software Product, Yokogawa may suspend or withhold the license provided hereunder.

9. Assignment

If you transfer or assign the Software Product to a third party with Yokogawa's prior written consent, you shall expressly present this Agreement to the assignee to ensure that the assignee comply with this Agreement, transfer all copies and whole part of the Software Product to the assignee and shall delete any and all copy of the Software Product in your possession irretrievably. This Agreement shall inure to the benefit of and shall be binding on the assignees and successors of the parties.

10. Termination

Yokogawa shall have the right to terminate this Agreement with immediate effect upon notice to you, if you breach any of the terms and conditions hereof. Upon termination of this Agreement, you shall promptly cease using the Software Product and, in accordance with sub-clause 2.5, return or irretrievably delete all copies of the Software Product, certifying the same in writing. Clauses 2.4 and 2.5, 3, 5, 6 and 11 shall survive any termination of this Agreement.

11. Governing Law; Disputes

This Agreement shall be governed by and construed in accordance with the laws of Japan.

Any dispute, controversies, or differences which may arise between the parties hereto, out of, in relation to or in connection with this Agreement ("Dispute") shall be resolved amicably through negotiation between the parties based on mutual trust. Should the parties fail to settle the Dispute within ninety (90) days after the notice is given from either party to the other, the Dispute shall be addressed in the following manner:

(i) If you are a Japanese individual or entity, the Dispute shall be brought exclusively in the Tokyo District Court (The Main Court) in Japan.

(ii) If you are not a Japanese individual or entity, the Dispute shall be finally settled by arbitration in Tokyo, Japan in accordance with the Commercial Arbitration Rules of the Japan Commercial Arbitration Association. All proceedings in arbitration shall be conducted in the English language, unless otherwise agreed. The award of arbitration shall be final and binding upon both parties, however, each party may make an application to any court having jurisdiction for judgment to be entered on the award and/or for enforcement of the award.

12. Miscellaneous

- 12.1 This Agreement supersedes all prior oral and written understandings, representations and discussions between the parties concerning the subject matter hereof to the extent such understandings, representations and discussions should be discrepant or inconsistent with this Agreement.
- 12.2 If any part of this Agreement is found void or unenforceable, it shall not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms and conditions. The parties hereby agree to attempt to substitute for such invalid or unenforceable provision a valid or enforceable provision that achieves to the greatest extent possible the economic, legal and commercial objectives of the invalid or unenforceable provision.
- 12.3 Failure by either party to insist on performance of this Agreement or to exercise a right when entitled does not prevent such party from doing so at a later time, either in relation to that default or any subsequent one.

End of document

How to Use This Manual

Structure of the Manual


This manual contains the following six chapters.

Chapter	Title and Description
1	Before Using the Product Provides an overview of Hardware Configurator. It also explains the PC system requirements, how to start the software, the screen configuration, and the menus.
2	Creating Setup Data Explains how to display, create, edit, save, and print setup data as well as how to control the main unit using this software.
3	Connecting to the Main Unit Explains how to receive and send setup data as well as how to control the main unit using this software.
4	Creating Setup Data for GX/GP/GMs with the Advanced Security Function (/AS) Explains how to display, create, edit, and save setup data files (.GSL extension) for GX/GP/GMs with the advanced security function (/AS) as well as how to control the GX/GP/GM from this software.
5	Program Pattern Settings for GX/GP/GMs with the Program Control Function (/PG) Explains settings of GX/GP/GM program patterns with the loop control function (PID control module) and program control function (option, /PG).
6	Troubleshooting Provides a list of errors and messages.

Scope of This Manual

This manual does not explain the basic operations of your PC's operating system. For this information, read the Windows user's guide or related materials.

Conventions Used in This Manual

Unit	
K	Denotes 1024. Example: 768K (file size)
k	Denotes 1000.
Notes	
	<i>Improper handling or use can lead to injury to the user or damage to the instrument.</i> This symbol appears on the instrument to indicate that the user must refer to the user's manual for special instructions. The same symbol appears in the corresponding place in the user's manual to identify those instructions. In the manual, the symbol is used in conjunction with the word "WARNING" or "CAUTION."
WARNING	Calls attention to actions or conditions that could cause serious or fatal injury to the user, and precautions that can be taken to prevent such occurrences.
CAUTION	Calls attention to actions or conditions that could cause light injury to the user or cause damage to the instrument or user's data, and precautions that can be taken to prevent such occurrences.
Note	Calls attention to information that is important for the proper operation of the instrument.
Reference Item	
▶	Reference to related operation or explanation is indicated after this mark. Example: ▶ section 4.1
Conventions Used in the Procedural Explanations	
Bold characters	Indicates character strings that appear on the screen. Example: Volt
Procedure	Carry out the procedure according to the step numbers. All procedures are written under the assumption that you are starting operation at the beginning of the procedure, so you may not need to carry out all the steps in a procedure when you are changing the settings.
Explanation	The explanation section describes limitations and related information about the operation.

Images

The images used in this manual may differ from those that actually appear in the software. Such differences do not affect the procedural explanation.

Products That This Manual Covers

Product	Version
Paperless Recorders	GX10-1/GP10-1 GX20-1/GX20-2 GP20-1/GP20-2
Data Acquisition System	GM10-1/GM10-2
SMARTDAC+ STANDARD Hardware Configurator	

Note: When there is no need to distinguish between GX/GP and GM, "main unit" is used collectively to refer to them.

Revision History

Edition	Software Ver.	Explanation
1	R1.01	New edition
2	R1.02	Modified for version R1.02.xx. Added descriptions for the GX10, GP10, and GP20. Modified system requirements (support for IE9) and added descriptions for the multilingual display feature. Improvements to descriptions.
3	R1.03	Modified for version R1.03.xx. Improvements to descriptions.
4	R2.01	Modified to support setup data for GX/GP firmware version R2.01.xx (release number 2). <ul style="list-style-type: none"> Hardware models GX20-2 and GP20-2, I/O Base Unit (Expandable I/O), and the new mA module, DIO module, and IO module added to GX/GP R2. GX/GP advanced security function (/AS) New menus (Read comparison source, Load Changed Settings, and Validation print window) Modified system requirements (support for Windows 8.1, IE10, and IE11). Modified for functional and user-interface improvements. Improvements to descriptions.
5	R2.02	Modified to support GM10-1/GM10-2. <ul style="list-style-type: none"> Modified to support the GM10 system configuration. Added descriptions for Bluetooth communication and USB communication with the main unit. Added "Reconfiguration" to the description of the main unit operation. Other improvements to descriptions. Modified to support GX/GP firmware version R2.02.01. <ul style="list-style-type: none"> Modified to support the "Pulse" input range for DI module. Added "DARWIN" to the Receiver - Function of the serial communication..
6	R2.03	Modified to support GM firmware version R2.03.01. <ul style="list-style-type: none"> GM advanced security option (/AS) Added descriptions for the communication port detection function that is available when serial communication, USB communication, or Bluetooth communication is selected.
7	R3.01	Modified to support setup data for GX/GP/GM firmware version R3.01.xx (release number 3). Hardware and options that were added in GX/GP/GM R3 <ul style="list-style-type: none"> Pulse input module (GX90XP-10-11) Aero space heat treatment (/AH) Multi-batch function (/BT) OPC-UA server (/E3) SLMP communication (/E4).

Edition	Software Ver.	Explanation
8	R4.01	Modified to support setup data for GX/GP/GM firmware version R4.01.xx (release number 4). Hardware and options that were added in GX/GP/GM R4. <ul style="list-style-type: none"> • New modules (Analog output, High-speed AI, 4-wire RTD, PID control.) • Program control function (/PG) • Logic math function (/MT) • Measurement modes (High-speed AI , Dual interval)

Downloading the Latest Software and Manuals

Download the latest version of the Hardware configurator from the following URL:

www.smartdacplus.com/software/en/

Download the latest manuals of the Hardware configurator, and GX/GP from the following

URL: www.smartdacplus.com/manual/en/

Related Manuals

Manual Name	Manual No.
Model GX10/GX20/GP10/GP20 Paperless Recorder First Step Guide	IM 04L51B01-02EN
Model GX10/GX20/GP10/GP20 Paperless Recorder User's Manual	IM 04L51B01-01EN
Model GX10/GX20/GP10/GP20 Advanced Security Function (/AS) User's Manual	IM 04L51B01-05EN
Data Acquisition System GM First Step Guide	IM 04L55B01-02EN
Data Acquisition System GM User's Manual	IM 04L55B01-01EN
Data Acquisition System GM Advanced Security Function (/AS) User's Manual	IM 04L55B01-05EN
GX10/GX20/GP10/GP20/GM10 Multi-batch Function (/BT) User's Manual	IM 04L51B01-03EN
GX10/GX20/GP10/GP20/GM10 OPC-UA server (/E3) User's Manual	IM 04L51B01-20EN
GX10/GX20/GP10/GP20/GM10 SLMP Communication (/E4) User's Manual	IM 04L51B01-21EN
Model GX10/GX20/GP10/GP20/GM10 Loop Control Function, Program Control Function (/PG) User's Manual	IM 04L51B01-31EN

Contents

Introduction	i
Software License Agreement.....	ii
How to Use This Manual.....	iv

Chapter 1 Before Using the Product

1.1	Overview of Hardware Configurator	1-1
1.1.1	Hardware Configurator Features.....	1-1
1.1.2	Installation and Version Updating.....	1-2
1.2	PC System Requirements.....	1-3
1.2.1	Hardware.....	1-3
1.2.2	Operating System	1-3
1.2.3	Web Browser.....	1-3
1.2.4	Display Languages.....	1-3
1.2.5	Other Operating Conditions	1-4
1.2.6	Security Measures	1-4
1.3	Window and Menus.....	1-5
1.3.1	Window and Menu Configuration	1-5
1.3.2	Menu Operation and Basic Workflow	1-7
1.3.3	Control Setting and Program Pattern Setting.....	1-7
1.3.4	Workflow	1-8
1.4	Starting and Closing Hardware Configurator	1-9
1.4.1	Starting the Software.....	1-9
	System Configuration on the First Startup.....	1-10
	Running Multiple Instances.....	1-10
1.4.2	Setting the Display Language, Date Format, and Decimal Point Type	1-11
1.4.3	Specifying the HTTP port number	1-12
1.4.4	Closing the Software	1-12

Chapter 2 Creating Setup Data

2.1	Creating New Setup Data	2-1
2.1.1	Creating a File in Accordance with System Configuration	2-1
	Module Configuration Limitations	2-8
2.2	Displaying Setup Data.....	2-12
2.2.1	Opening a File.....	2-12
2.2.2	Opening the Comparison Source File	2-14
2.2.3	Opening an Update Source File.....	2-17
2.2.4	Opening a Configuration File Containing a Program Pattern (GX/GP/GM with the Program Control Function).....	2-19
2.2.5	Opening a Comparison Source of a Program Pattern (GX/GP/GM with the Program Control Function)	2-21

1

2

3

4

5

6

Index

2.3	Editing Setup Data	2-24
2.3.1	Basic Operation.....	2-24
	Using the Jump Function	2-25
2.3.2	Editing and Manipulating Values	2-27
	How to Use the Different Dialog Boxes	2-28
2.3.3	How to Register Users	2-36
2.3.4	Selecting a Range and Copying and Pasting.....	2-38
2.4	Saving Setup Data	2-47
2.4.1	Saving a Setup Data File	2-47
2.4.2	Saving a Configuration File Containing a Program Pattern (GX/GP/GM with the program control function).....	2-49
2.5	Initializing Setup Data	51
2.5.1	Viewing and Changing the System Configuration	51
2.5.2	Initializing Setup Data	52
2.6	Printing Setup Data	53
2.6.1	Setting the Print Options	53
2.6.2	Validation Print	57

Chapter 3 Connecting to the Main Unit

3.1	Receiving and Sending Setup Data	3-1
	Before Sending or Receiving Setup Data	3-1
	Sending and Receiving Security Settings and Data	3-1
3.1.1	Receiving Setup Data	3-2
3.1.2	Sending Setup Data	3-6
3.1.3	Sending User Settings	3-7
3.1.4	Changing the GX/GP's Security Settings (GX/GP with firmware version R1.xx.xx).....	3-8
3.1.5	Receiving a Program Pattern Configuration File (GX/GP/GM with the Program Control Function)	3-12
3.1.6	Sending a Program Pattern Configuration File (GX/GP/GM with the Program Control Function)	3-14
3.2	Controlling the Main Unit.....	3-16
3.2.1	Starting and Stopping Recording and Computing.....	3-16
3.2.2	Viewing the Hardware Information	3-17
3.2.3	Performing Reconfiguration (When the connected device is a GM)	3-20
3.2.4	Starting/Stopping Control (GX/GP/GM with the PID control module)	3-21
3.2.5	Starting/Stopping Program Control (GX/GP/GM with the Program Control Function).....	3-22
3.2.6	About Limitations on Operations by the Status of GX/GP/GM.....	3-23

Chapter 4 Setup Data for GX/GP/GM with Advanced Security Function (/AS)

4.1	Operation	4-1
4.2	User Authentication	4-4
4.2.1	When User Authentication Occurs	4-4
4.2.2	Entering Information in the User Authentication Dialog Box	4-5

Chapter 5 Program Pattern Setting for GX/GP/GMs with the Program Control Function (/PG)

5.1	Program Pattern Setting.....	5-1
5.1.1	Overview	5-1
5.1.2	Operating Environment	5-2
5.1.3	Other Operating Conditions, Security Measures.....	5-2
5.1.4	Starting the Software.....	5-2
5.1.5	Window and Menu Configuration	5-3
5.1.6	Setting the Display Language	5-4
5.1.7	Specifying the HTTP port number	5-5
5.1.8	Closing the Software	5-5
5.2	Creating a New Program Pattern File	5-6
5.3	Setting PV Range of the Program Pattern	5-8
5.3.1	Setting System/PV Range.....	5-8
5.3.2	Initializing Setup Data	5-11
5.4	Program Pattern Example.....	5-12
5.5	Opening a Program Pattern File	5-19
5.6	Saving a Program Pattern File	5-20
5.7	Receiving and Sending Program Patterns.....	5-21
5.7.1	Receiving Program Patterns	5-21
5.7.2	Sending Program Patterns.....	5-23
5.8	Controlling the Main Unit.....	5-25
5.8.1	Starting and Stopping Recording/Computing.....	5-25
5.8.2	Starting and Stopping Control	5-25
5.8.3	Starting and Stopping Program Control	5-25
5.8.4	Viewing the Hardware Information	5-25
5.8.5	Performing Reconfiguration (GM only).....	5-25
5.8.6	Deleting All Patterns.....	5-26

Chapter 6 Troubleshooting

6.1	Errors and Messages	6-1
-----	---------------------------	-----

1

2

3

4

5

6

Index

Blank

1.1 Overview of Hardware Configurator

1.1.1 Hardware Configurator Features

SMARTDAC+ STANDARD Hardware Configurator is a PC software application for creating setup data for the GX/GP Paperless Recorder and GM Data Acquisition System. You can use it to create, edit, save, and print setup data. You can also use it to exchange data with a GX/GP or GM and control it via communication.

Web-based Offline Application

You can use a Web browser (Internet Explorer) on your PC to create and edit setup data. You only need this software and a browser; you do not have to configure communication parameters.

Creating and Editing Setup Data

You can create new setup data by specifying the model and options. You can also edit existing setup data.

Loading Changed Settings into Setup Data

You can load the settings from a separate file and apply them to the current setup data.

Saving and Loading Setup Data

You can save the data that you create to your PC and load configuration files that have been saved on your PC.

Sending and Receiving Setup Data

You can send setup data to and receive data from a main unit via communication.

Printing Setup Data

You can print setup data.

Loading Comparison Source and Validation Printing ¹

You can load a reference configuration file or a program pattern ² and display a window for comparing and verifying the current setup data against the reference. The displayed screen can be printed and used for validation.

Controlling Main Unit

You can start and stop recording or computing on a main unit via communication.

Retrieving Information from Main Unit

You can retrieve information from a main unit via communication.

Program Pattern Setting ²

You can display, edit, or save program pattern files of GX/GP/GM with the PID control module and program control function (option, /PG). These program pattern files can be sent to or received from a main unit.

¹ The two sets of setup data that are compared must be of the same system configuration.

² Program pattern is used on GX/GP/GM with the PID control module and program control function (option, /PG). You can set a program pattern from the "Program pattern tab of the Hardware Configurator" or "Program Pattern Setting".

1.1.2 Installation and Version Updating

Download the latest installer from YOKOGAWA's website to install and update the software. From the **Help** tab, you can view the software version information and access the link to the website.

Note

- Before installing the software, check that your PC is not infected by a virus.
- Close all other software applications before installing this software.
- To reinstall the software, uninstall the current software first.
- The "Countries/regions except Japan" selection dialog box appears during installation. Select the country that you will use the software in.
- As this software uses a Web browser, a default value is set for the HTTP port number in advance. If the default port number is used, this software is started using a non-used port in 34443-65535. The default port numbers for the "Hardware Configurator" and "Program pattern setting" are as follows.
Hardware Configurator: 34443
Program pattern setting: 34503

1.2 PC System Requirements

1.2.1 Hardware

PC

A PC running Windows 7, Windows 8.1, or Windows 10.

CPU and Main Memory

PC Configuration	Requirements
CPU	Intel Pentium 4, 3 GHz or faster x64 or x86 processor.
Memory	2GB or more.
Hard Disk	Free space of at least 100 MB (depending on the amount of data, you may need more disk space). NTFS recommended.
Mouse	A mouse compatible with the OS.
Display	A display that is compatible with the OS, that has a resolution of 1024x768 or higher, and that can show 65,536 colors (16-bit, high color) or more.
Communication port	Ethernet port compatible with the OS and TCP/IP protocol.
Printer	A printer compatible with your Windows system (a printer driver for the OS is required)

1.2.2 Operating System

OS	Edition	Service pack	32-bit/64-bit
Windows 7	Home Premium	SP1	32- or 64-bit edition
	Professional	SP1	32- or 64-bit edition
Windows 8.1		update	32- or 64-bit edition
	Pro	update	32- or 64-bit edition
Windows 10	Home		32- or 64-bit edition
	Pro		32- or 64-bit edition

1.2.3 Web Browser

Compatible Browser	Version
Windows Internet Explorer	IE11 (Enable HTTP 1.1 and JavaScript.)

Note

- The Web browser that Hardware Configurator uses to display information is limited to Internet Explorer (IE). If IE is not installed on your PC, an error will appear when you start Hardware Configurator.
- Please use IE11 or above. This software cannot be started with IE10 or older versions.

1.2.4 Display Languages

Language	System Environment
Japanese	A web browser and an OS support Japanese characters.
English	A web browser and an OS support English characters.
German	A web browser and an OS support German characters.
French	A web browser and an OS support French characters.
Chinese	A web browser and an OS support Simplified Chinese characters.
Russian	A web browser and an OS support Cyrillic characters.
Korean	A web browser and an OS support Korean characters.

1.2.5 Other Operating Conditions

To view the user's manual of this software, you need to use Adobe Reader 7 or later by Adobe Systems (the latest version is recommended).

1.2.6 Security Measures


To deal with security threats, we recommend that you take security measures.

- Apply restrictions to PC network connections.
We recommend that you use an isolated network.
- Manage external media properly.
Prevent malware intrusion through external media, unauthorized file operations on external media, and information leakage due to misplacement.
- Set a strong password and manage it properly.
Use a password that is at least eight characters in length, and include three types of characters from uppercase letters, lowercase letters, numbers, and symbols. Change the password regularly.
- Install antivirus software.
This software has been verified to work on a PC running McAfee VirusScan Enterprise Ver. 4.8.0.887.

1.3 Window and Menus

1.3.1 Window and Menu Configuration

Hardware Configurator's menu consists of the tab, menu, and file name display area, as shown below.



Tab and Menu

The menu is tabular. Click a tab to activate it, and the menu will switch accordingly. Double-click a tab to hide or display the menu bar. The following table shows the menu items and their descriptions.

Setting GX10-1	Operation	System	Option	Help
New	Open	Save	Save As	Receive Settings
Send Settings	Send User Settings	Print Window	Read comparison source	Load Changed Settings
Validation print window				

Tab	Menu	What You Can Do
Setting ¹	New	Create a new setup data file.
	Open	Open a system configuration setting dialog for creating a new setup data file.
GX10-1	Open	Load a configuration file from a PC.
GX20-1	Save	Overwrite the file.
GX20-2	Save As	Save a new file to the PC.
GP10-1	Receive Settings	Receive the GX/GP setup data.
GP20-1	Send Settings	Send the current setup data to the GX/GP.
GP20-2	Send User Settings	Send only the user settings to the GX/GP via communication.
GM10-1	Print Window	Open a window used to print setup data.
GM10-2	Read comparison source	Load the comparison source data for comparing the setup data.
	Load Changed Settings	Load the settings from a separate configuration file and apply them to the data that is currently displayed.
	Validation print window	Display the window for printing validation information.

Tab	Menu	What You Can Do
Operation ¹	Start Recording	Start recording of a main unit.
	Stop Recording	Stop recording of a main unit.
	Start Computing	Start computation of a main unit.
	Stop Computing	Stop computation of a main unit.
	Run Control	Start control of a main unit.
	Stop Control	Stop control of a main unit.
	Run Program Control	Start program control of a main unit.
	Reset Program Control	Stop program control of a main unit.
	Hardware Info.	Receive and display the GX/GP/GM status and option information.
	Reconfiguraton	Reconfigure the GM system.
System	System Config.	View and change the system configuration.
	Initialize	Initialize the current setup data.
Option	Display	Specify the display option (Language, Date format, Decimal Point Type) of Hardware Configurator.
	Port No.	Specify the port number of Hardware Configurator.
Help	Instruction Manual ²	View the user's manual.*
	Version	View the Hardware Configurator version.
	Web to update	Visit the Website to download the latest version of Hardware Configurator.

- 1 From this tab, you can expand, save, and send/receive program pattern files of GX/GP/GM with the PID control module and program control function (option, /PG). For details of program pattern setting, read Chapter 5.
- 2 If the language displayed in the browser is English, Japanese, or Chinese, the user's manual in the corresponding language will be displayed. If another language is displayed, the English user's manual will be displayed.

File Name Display

The configuration file name is displayed in this area.

A specific file name or "New File" will be displayed.

A specific file name will be displayed under the following conditions.

- When a specific file is loaded and displayed.
- When a file is saved using the Save As command.

"New File" will be displayed under the following conditions.

- When Hardware Configurator starts.
- When you click **New**.
- When a connection is established with a main unit and the setup is received.

Content Selection Tree

The content selection tree is used to select the items (edit items) you want to edit.

When you click an item in the content selection tree, the items displayed in the content area (right side) change accordingly.

Content Area

The content area displays setup item details.

It displays the settings for the item selected in the content selection tree.

Immediately after Hardware Configurator starts, this area shows channel settings. If there are no channel settings, this area shows display settings.

Split Bar

You can use the split bar to change the window layout.

Drag the split bar to change the panel width of the content selection tree area and content area. Click the show/hide button in the center to show and hide the content selection tree.

Show/hide Button

You can use this button to show or hide the Content Selection Tree.

Copy and Paste Buttons

The Copy and Paste buttons are used to copy and paste settings when you edit setup items.

Operation: ► [Copying the Selected Range and Pasting](#)

Jump Navigation Button

You can use this button to jump to the specified setup item.

Operation: ► [Using the Jump Function](#)

Tool Buttons

You can use the tool buttons to collectively edit items according to the function assigned to each button.

Operation: ► [Editing Using Tool Buttons](#)

1.3.2 Menu Operation and Basic Workflow

The basic procedure for using Hardware Configurator is shown below.

For more details, see chapter 2, "Creating Setup Data."

Procedure

- 1** Start Hardware Configurator.
- 2** Click a tab (**Setting**, **Operation**, **System**, or **Option**).
- 3** Select a menu item (**New**, **Open**, **Start Recording**, **Stop Recording**, etc.).
- 4** Perform operations in the displayed dialog box.
- 5** To edit settings, select a title in the content selection tree. Edit the displayed settings.
- 6** Process the setup data file that you created or edited by selecting appropriate commands (**Save**, **Send Settings**, etc.) from the tab and menu.
- 7** Close Hardware Configurator.

1.3.3 Control Setting and Program Pattern Setting

On SMARTDAC+ Hardware Configurator (R4.01 or later), you can create settings of the loop control function (PID control module: GX90UT-02-11) and program control function (option, /PG) of GX/GP/GM.


- For the details of the control function, read the following user's manuals.
 "Model GX10/GX20/GP10/GP20/GM10 Loop Control Function, Program Control Function (/PG) User's Manual" (IM 04L51B01-31EN)

To configure control settings on the Hardware Configurator, you need to specify "PID control module" and "Program control" in System Config.: ► [2.1.1 Creating a File in Accordance with System Configuration](#)

For details of program pattern setting, see [Chapter 5 Program Pattern Setting for GX/GP/GMs with the Program Control Function \(/PG\)](#).

1.3.4 Workflow

The features and workflow of Hardware Configurator are illustrated below.




1.4 Starting and Closing Hardware Configurator

1.4.1 Starting the Software


Procedure

- 1 From the **Start** menu, select **All Programs - SMARTDAC+ STANDARD - Hardware Configurator**.

The first time Hardware Configurator starts after installation, the Windows Security Alert dialog box appears (the figure below is the Windows 7 screen capture). Click “Allow access.”



Hardware Configurator starts, and the following window appears.



Zoom Level button


Note

- Use Internet Explorer 11 or above. If you attempt to start this software with IE10 or an older version, an error message is displayed and startup fails.
- The default settings are the system configuration of the GX10.

Internet Explorer Zoom Level

Set the IE zoom level (on the **View** menu, or in the lower-right corner) to 100%. Otherwise, the layout may appear crooked.

If the following message appears when you start the software, click OK. Then, on the **View** menu of IE, click **Zoom** (or **Change the zoom level** at the lower right of the window) to select 100%.



System Configuration on the First Startup

The following table shows the system configuration (**System** tab > **System Config**) that is used the first time the software is started. Before creating a configuration file, use **System Config** to align the software configuration with the GX/GP configuration.

Details on system configuration: ► [2.1 Creating New Setup Data](#)

Item	Value
Model	GX10/GP10
Version	(The most recent version will be displayed.)
Module	AI module
Option	No options

Running Multiple Instances

You can run multiple instances of this software (version R2.01.01 and later).

To do so, repeat step 1 on the previous page.

The first instance starts with the port number that was in use when the software was closed the previous time.

The subsequent instances start with unused ports in the range of 34443 to 65535.

Note

To change the port number to a different number after starting the software, follow the procedure in [1.4.3 Specifying the HTTP port number](#).

1.4.2 Setting the Display Language, Date Format, and Decimal Point Type


You can set the display language to English, Japanese, German, French, Chinese, Russian or Korean. In addition, you can select the date format and decimal point type for printing according to the selected language.

Procedure

- 1 Click **Option** tab.
- 2 Click **Display**.



The **Display Option** dialog box appears.



- 3 Click **Language** arrow, and select from the list.
- 4 If necessary, select the **Date Format** and **Decimal Point Type**. The available options are shown in the following table.

Item	Available Format
Date Format: Format	[Month Day Year] [Year Month Day] [Day Month Year]
Date Format: Delimiter	[/] (Slash), [.] (Period) [-] (Dash)
Month Indicator	[Numerical] [Characters]
Decimal Point Type	[Point] [Comma]

- 5 Click **OK**.

Note

- The Date Format and the Decimal Point Type are applied only to the Print window and Validation print window.
- If Language is set to Japanese, Korean, or Chinese, Month Indicator is fixed to Numerical.

1.4.3 Specifying the HTTP port number

You can specify the HTTP port number for using the Web browser from this software.
The default HTTP port numbers are “34443” for the “Hardware Configurator” and “34503” for the “Program pattern setting”. To change the port number to a different number, follow the procedure below.


Procedure

1 Click **Option** tab.

2 Click **Port No.**



The Port No. dialog box appears.



3 Enter the port number (in the range of 34443 to 65535).

Note

To activate the new port number, restart the software.

The software will continue to use the old port number until you restart the software.

1.4.4 Closing the Software

Procedure

1 Close Internet Explorer by clicking the **Close** button or by clicking **Exit** on the **File** menu.

Note

If you change the setup data, the changes are stored and will appear the next time you start the software.


2.1 Creating New Setup Data

2.1.1 Creating a File in Accordance with System Configuration


This section explains how to use SMARTDAC+ STANDARD Hardware Configurator to create a new data file for configuring various GX/GP functions. Before editing channel or display settings, first create a file in accordance with system configuration of the main unit.

Procedure


- 1 Start Hardware Configurator.
The setup window appears.




- 2 Click **Setting** tab and then **New**.



A confirmation message is displayed for saving the file that is currently displayed.



- 3 To save the file, click **Yes**; otherwise, click **No**.
If you click **Yes**, a dialog box for saving the file (see the figure below) appears.
How to save files: ► [2.4 Saving Setup Data](#)




If you select **No**, the System Config. dialog box, shown in step 4, appears.

Note

- When creating a configuration file, first set system configuration in accordance with the main unit. You can also display the **System Config.** setting screen from **System** tab - **System Config.**
- If you change **System Config.**, the setup items that you have edited up to that point will be initialized.

4

Set the system configuration for GX/GP main unit.



Note


If you change the system configuration, the setup items that you have edited up to that point will be initialized. To save these items, click **Yes** in step 2.

5

Click the **GX10/GP10**, **GX20/GP20**, or **GM10** tab depending on the main unit that you are using.

6

Under **Basic Config.**, set the **Product Name**, **Version**, and **Model**.



The following table shows the **Basic Config.** settings of each tab page.

Tab	Item	Displayed value	Initial value
GX10/GP10	Product Name	GX10/GP10	GX10/GP10
	Version (Note)	R4.01, R3.02, R3.01, R2.02, R2.01, R1.03, R1.02	R4.01
	Model	GX10-1, GP10-1 (12V DC Power Supply)	GX10-1
GX20/GP20	Product Name	GX20/GP20	GX20/GP20
	Version	R4.01, R3.02, R3.01, R2.02, R2.01, R1.03, R1.02, R1.01	R4.01
	Model	GX20-1, GX20-2, GP20-1, GP20-2	GX20-1
GM10	Product Name	GM10	GM10
	Version	R4.01, R3.02, R3.01, R2.03, R2.02	R4.01
	Model	GM10-1, GM10-2	GM10-1

Note

From Hardware Configurator R4.01.01, the last two digits (hereafter sub revision) in the firmware version of a main unit are no longer displayed. However, if it is received from a main unit or a configuration file created by the main unit is read, the sub revision is displayed without omission. (Example: R4.01.01).

7 Set the items under **Option**.

Option	
Serial	<input checked="" type="radio"/> Not <input type="radio"/> RS-232 <input type="radio"/> RS-422/485
Fail output, 1 point	<input checked="" type="radio"/> Not <input type="radio"/> Use
Mathematical function (with report function)	<input checked="" type="radio"/> Not <input type="radio"/> Use
Comm. channel function	<input checked="" type="radio"/> Not <input type="radio"/> Use
USB interface (Host 2 ports)	<input checked="" type="radio"/> Not <input type="radio"/> Use
Advanced security function	<input checked="" type="radio"/> Not <input type="radio"/> Use
Log scale	<input checked="" type="radio"/> Not <input type="radio"/> Use
EtherNet/IP communication	<input checked="" type="radio"/> Not <input type="radio"/> Use
WT communication	<input checked="" type="radio"/> Not <input type="radio"/> Use
Aerospace heat treatment	<input checked="" type="radio"/> Not <input type="radio"/> Use
Multi-batch function	<input checked="" type="radio"/> Not <input type="radio"/> Use
OPC-UA server	<input checked="" type="radio"/> Not <input type="radio"/> Use
SLMP communication	<input checked="" type="radio"/> Not <input type="radio"/> Use
Program control	<input checked="" type="radio"/> Not <input type="radio"/> Use

The types of options that appear vary depending on the main unit and the firmware version. The following table shows the available options for different firmware versions.

Option	GX/GP		GM	
	Initial value	Firmware Version and Availability	Initial value	Firmware Version and Availability
Serial	Not	Displayed on R1.01.01 or later.	Not	Displayed on R2.02.01 or later.
Fail output, 1 point	Not	Displayed on R1.01.01 or later.		
Mathematical function (lwith report function)	Not	Displayed on R1.01.01 or later.		
Comm. channel function	Not	Displayed for R1.01.01 and later. For R2.01.01 and later, this option is fixed to Use when WT communication is set to Use.	Not	Displayed for R2.02.01 and later. This option is fixed to Use when WT communication is set to Use.
USB interface (Host 2 ports)	Not	Displayed on R1.01.01 or later.		
Advanced security function (Part 11)	Not	Displayed on R2.01.01 or later.		
Log scale	Not	Displayed on R2.01.01 or later.	Not	Displayed on R2.02.01 or later.
EtherNet/IP communication	Not	Displayed on R2.01.01 or later.	Not	Displayed on R2.02.01 or later.
WT communication	Not	Displayed on R2.01.01 or later.	Not	Displayed on R2.02.01 or later.
Bluetooth			Not	Displayed on R2.02.01 or later.
Aerospace heat treatment			Not	Displayed on R3.01.01 or later.
Multi-batch function ^(Note)	Not	Displayed on R3.01.01 or later.	Not	Displayed on R3.01.01 or later.
OPC-UA server	Not	Displayed on R3.01.01 or later.	Not	Displayed on R3.01.01 or later.
SLMP communication	Not	Displayed on R3.01.01 or later.	Not	Displayed on R3.01.01 or later.
Program control	Not	Displayed on R4.01.01 or later.	Not	Displayed on R4.01.01 or later.

Diagonal lines mean that the main unit does not have those options.

Note

- Advanced security function corresponds to the GX/GP/GM's advanced security function (/AS).
- Multi batch function corresponds to the GX/GP/GM's multi batch function (/BT).
- Program control corresponds to the GX/GP/GM's program control function (/PG).

8

In the option settings, if you set the advanced security function or multi batch function to “Use,” choose whether to enable or disable the function in **Option detail**.

Option detail	
Advanced security function On/Off	<input checked="" type="radio"/> Off <input type="radio"/> On
Multi batch function On/Off	<input checked="" type="radio"/> Off <input type="radio"/> On
Batch operation qty	6 <input type="button" value="▼"/>

Item	Options	Initial Value	Description
Advanced security function On/Off	On, Off	Off	On a GX/GP/GM with the advanced security function (/AS), to enable the function, select On.
Multi batch function On/Off	On, Off	Off	On a GX/GP/GM with the multi batch function (/BT), to enable the function, select On.
Batch operation qty	GX10-1 GX20-1 2 to 6 GM10-1	6	If you set the function to On, you can click ▼ to select the number of batches.
	GX20-2 2 to 12 GM10-2	12	

Note You cannot enable the advanced security function (/AS) and multi batch function (/BT) by sending settings from the Hardware Configurator software. In this step, choose whether to enable or disable the functions to create settings by taking system status in relation to the recorder main unit into account.

9


Select a measurement mode.
However, you cannot choose **High speed** or **Dual interval** if you set the advanced security function or multi batch function to enabled in step 8.

Measurement mode	
Mode	<input checked="" type="radio"/> Normal <input type="radio"/> High speed <input type="radio"/> Dual interval

Note For details of each optional function, see the following user's manuals.
You can download the latest manuals from the YOKOGAWA website (www.smartdacplus.com/manual/en/).

- Advanced Security Function User's Manual IM 04L51B01-05EN (for GX/GP)
IM 04L55B01-05EN (for GM)
- Multi-batch Function User's Manual IM 04L51B01-03EN (for all models)
- OPC-UA Server User's Manual IM 04L51B01-20EN (for all models)
- SLMP Communication User's Manual IM 04L51B01-21EN (for all models)
- Loop Control Function, Program Control Function (/PG) User's Manual IM 04L51B01-31EN (for all models)

- 10** Set the items under **Module**. Select IO modules.
The figure below shows an example of the GX10/GP10 tab.



Tab	Number of Displayed IDs (Slot Numbers)	Model
GX10/GP10	0 to 2	Selectable modules are displayed depending on the Version of the main unit (see the separate table).
GX20/GP20	0 to 9	
GM10	0 to 9	


When an IO expansion module (GX90EX-02-TP1) is in use

- GX10/GP10 can only be set for ID = 2.
- GX20/GP20 can only be set for ID = 9.
- GM10 can be set to any ID from 0 to 6. However, other modules cannot be set after the IO expansion module. (IO expansion modules do not appear in the selection list for ID = 7 to 9.)


The **Model** of each module is displayed according to the main unit **Version**. For a list of available IO module names, see the table below.

Module	Firmware version		Description
	GX/GP	GM	
None	R1.01.01 or later.	R2.02.01 or later.	No module is attached.
GX90XA-10-U2	R1.01.01 or later.	R2.02.01 or later.	AI module (Universal)
GX90XA-10-T1	R1.03.01 or later.	R2.02.01 or later.	AI module (Electromagnetic relay)
GX90XA-10-C1	R2.01.01 or later.	R2.02.01 or later.	AI module (Current)
GX90XA-10-L1	R2.01.01 or later.	R2.02.01 or later.	AI module (Low voltage type)
GX90XD-16-11	R1.01.01 or later.	R2.02.01 or later.	DI module
GX90YD-06-11	R1.01.01 or later.	R2.02.01 or later.	DO module
GX90WD-0806-01	R2.01.01 or later.	R2.02.01 or later.	DIO module
GX90EX-02-TP1	R2.01.01 or later.	R2.02.01 or later.	I/O expansion module
GX90XP-10-11	R3.01.01 or later.	R3.01.01 or later.	Pulse input module
GX90YA-04-C1	R3.02.01 or later.	R3.02.01 or later.	AO module
GX90XA-04-H0	R4.01.01 or later.	R4.01.01 or later.	AI module (High-speed universal type)
GX90XA-06-R1	R4.01.01 or later.	R4.01.01 or later.	AI module (4-wire RTD/resistance type)
GX90UT-02-11	R4.01.01 or later.	R4.01.01 or later.	PID control module

- 11** If an I/O base unit is installed, configure the modules. Click **Extended Unit** to display the page. The **Extended Unit** tab is to the right of the **Main Unit** tab.




- 12** Select the module configuration from Unit1 to Unit6 under **Extended Unit**.



The following table shows the available models. If the IO expansion module is not set to the main unit (Module on the Main unit tab), the item will be unselectable.

ID	Module	Initial value	Description
EXT	GX60/Not use or GX90EX-02-TP1/Not use	Not use	Base unit model (fixed) Displays "GX90EX-02-TP1" on the GM tab.
	None		
	GX90XA-10-U2		
	GX90XA-10-T1		
	GX90XA-10-L1		
	GX90XA-04-H0		
	GX90XA-10-C1		
0 - 5	GX90XA-06-R1	None	Installed module
	GX90XD-16-11		
	GX90XP-10-11		
	GX90YA-04-C1		
	GX90YD-06-11		
	GX90WD-0806-01		
	GX90UT-02-11		


- 13** After you set the items, click **OK**.
The system configuration is loaded, and setup items based on the configuration are created.




If you enable the PID control module (GX90UT) and program control function (option, /PG) in the setting of system configuration, the **Control setting** and **Program pattern** tabs are displayed.

- PID control module enabled: Displays the Control setting tab.
- PID control module + Program control function (/PG) enabled: Displays the Control setting + Program pattern tabs.

Even if the program control function is set to "Use", the Program pattern tab is not displayed unless the PID control module is attached.




Without control function



With control function

However, if the number of modules exceeds the limit, the following warning will appear. Correct the module settings according to the auxiliary message.



Auxiliary message

Limit to the number of modules and number of channels: ► [Module Configuration Limitations](#)
Message details: ► ["Warning Messages"](#) and ["W016 Auxiliary Messages"](#)

- 14** Edit the setup items in the new window to create the setup data.

How to edit setup items: ► [2.3 Editing Setup Data](#)

Program pattern setting: ► [Chapter 5 Program Pattern Setting for GX/GP/GMs with the Program Control Function \(/PG\)](#)

Operation complete

Module Configuration Limitations

In the Module settings of the Main unit and Extended Unit tabs, select modules so that the following limits are not exceeded. If you click **OK** when a limit is exceeded, a message will appear. If a message appears, correct the number of modules or channels specified by the message.

Message details: ▶ **“Warning Messages”** and **“W016 Auxiliary Messages”**

Number of channels for each module

Module	Model	Number of channels (per module)
AI module	Universal GX90XA-10-U2	10
	GX90XA-10-T1	10
	GX90XA-10-C1	10
	GX90XA-10-L1	10
	GX90XA-04-H0	4
	GX90XA-06-R1	6
DI module	GX90XD-16-11	16
DO module	GX90YD-06-11	6
DIO module	GX90WD-0806-01	8 inputs, 6 outputs
Pulse input module	GX90XP-10-11	10
AO module	GX90YA-04-C1	4
PID control module	GX90UT-02-11	8 inputs, 18 outputs

Limit to the entire system

Limit to the number of IO modules in the entire system

Model	Limitation
GX10-1	Up to ten IO modules in the entire system
GP10-1	
GX20-1	
GP20-1	
GX20-2	Up to forty-five IO modules in the entire system
GP20-2	
GM10-1	Up to ten IO modules in the entire system
GM10-2	Up to forty-two IO modules in the entire system

Limit to the number of DO/DIO modules in the entire system (Including the PID control module)

Model	Limitation
GX10-1	Up to ten DO/DIO modules in the entire system The PID control module is included as DO in the limited number shown above.
GP10-1	
GX20-1	
GP20-1	
GX20-2	
GP20-2	
GM10-1	
GM10-2	

Limit to the number of PID control modules in the entire system ¹

Model	Limitation
GX10-1	Up to three modules in the entire system
GP10-1	
GX20-1	
GP20-1	
GX20-2	Up to ten modules in the entire system
GP20-2	
GM10-1	Up to three modules in the entire system
GM10-2	Up to ten modules in the entire system

¹ If GX90YD or GX90WD (DO/DIO module) is set along with the module, up to 10 modules can be set.

Limit to the number of IO channels in the entire system

Model	Limitation
GX10-1	Up to 100 IO channels in the entire system
GP10-1	
GX20-1	
GP20-1	
GX20-2	Up to 500 IO channels in the entire system
GP20-2	
GM10-1	Up to 100 IO channels in the entire system
GM10-2	Up to 500 IO channels in the entire system

Note

- “In the entire system” means the total number of modules or the total number of channels specified on the Main unit and Extended Unit tabs of this software.

Limit to the main unit or units**Limit to the IO expansion module (GX90EX-02-TP1) of the main unit**

Model	Limitation
GX10-1	On the Main unit tab, the module can only be set to ID = 2.
GP10-1	
GX20-1	On the Main unit tab, the module can only be set to ID = 9.
GP20-1	
GX20-2	
GP20-2	
GM10-1	On the Main unit tab, a single module can be set in the range ID = 0 to 6. IO expansion modules do not appear in the selection list for 7 to 9.
GM10-2	
	In addition, the ID to which an IO expansion module is assigned is considered to be the end, and other modules cannot be set to later IDs.

Limit to the EMR module (GX90XA-10-T1) of the main unit

Model	Limitation
GX10-1	No limit. EMR modules can be set to any ID.
GP10-1	
GX20-1	
GP20-1	
GX20-2	
GP20-2	
GM10-1	On the Main unit tab, a module can be set in the range ID = 0 to 7. EMR modules do not appear in the selection list for 8 or 9.
GM10-2	
	In addition, only up to eight modules including an EMR module can be set.

Limit to the High-speed AI module (High-speed universal type: GX90XA-04-H0) of the main unit

Model	Limitation
GX10-1	No limit. High-speed AI modules can be set to any ID.
GP10-1	
GX20-1	
GP20-1	
GX20-2	
GP20-2	
GM10-1	On the Main unit tab, a module can be set in the range ID = 0 to 7. High-speed AI modules do not appear in the selection list for 8 or 9. Only up to eight modules can be set.
GM10-2	
	In addition, only up to seven modules can be set when in combination with an AO module.

Note

“Module of the main unit” means the total number of modules specified on the Main unit tab of this software.

Limit to the number of modules per unit

Model	Limitation
GX10-1	<ul style="list-style-type: none"> DIO module Only one module in a unit.
GP10-1	
GX20-1	<ul style="list-style-type: none"> AO module For GX10-1 and GP10-1: Only one module per unit. Other than the above (including an extended unit): Up to two modules per unit.
GP20-1	
GX20-2	However, if a PID control module is connected, the number of modules that can be implemented on each unit is limited.
GP20-2	
GM10-1	
GM10-2	

Limit to the number of modules of each unit if a PID control module (GX90UT-02-11) is installed

Model	Limitation
GX10-1	There is no limitation. However, for GP10-1 12 V DC Power Supply model, it is up to two modules per unit.
GP10-1	
GX20-1	
GP20-1	
GX20-2	Up to eight modules per unit.
GP20-2	
GM10-1	Up to five modules per unit.
GM10-2	

Limit to the number of IO channels of each unit

Model	Limitation
GX10-1	Up to 100 channels per unit.
GP10-1	
GX20-1	
GP20-1	
GX20-2	
GP20-2	
GM10-1	
GM10-2	

Note

- “A unit” refers to the main unit or an extended unit.

Limitations according to measurement mode

The following are limitations of module setting generated by selection of measurement mode.

- When **High speed** is selected, modules other than DI, DIO, high speed AI module cannot be set.
- When **Dual interval** is selected, the PID control module cannot be set.

Limitations about module attachment on GM

For GM, there are the following limitations concerning module attachment depending on the type and combination of modules. If the message W016 "There is a module that exceeds connection limitations" is displayed, check the position (slot=ID) and number of the attached modules.

Limitation (on GM main unit only)		Message
1	High speed AI module cannot be attached to slot 8 or 9.	(No message) (High speed AI module are not listed on slot 8 and 9.)
2	High speed AI module is attached to any slot from 0 to 7.	In addition, AO module is attached to any slot from 7 to 9.
3	AO module is attached to any slot from 0 to 9.	In addition, high speed AI module is attached to slot 7.
4	PID control module cannot be attached to slot from 5 to 9.	
5	EMR module is attached to any slot from 0 to 7.	In addition, an IO module is attached to slot 8 or 9.
6	High speed AI module is attached to any slot from 0 to 7.	In addition, an IO module is attached to slot 8 or 9.
7	High speed AI module is attached to any slot from 0 to 7. In addition, AO module is attached to any slot from 0 to 9.	an IO module is attached to slot from 7 to 9.
8	PID control module is attached to any slot from 0 to 4.	In addition, an IO module or IO expandable module is attached to slot from 5 to 9. Note: I/O expansion module can be attached only to slot from 0 to 6.

2.2 Displaying Setup Data


2.2.1 Opening a File

This section explains how to load and display an existing setup data file that has been saved to a PC.


Opening a Configuration file Containing a Program Pattern (GX/GP/GM with the Program Control Function) : ► 2.2.4

Procedure

- 1 Start Hardware Configurator.
The setup window appears.




- 2 Click **Setting** tab and then **Open**.




The **Open File** dialog box* appears.

* To display the setup data of a measurement data file (*.GSE or *.GSD), change the file type.



Click to select the file type.


3 Select the setup data file that you want to open, and click **Open**.



Click Open.

The data is loaded.

The name of the loaded file appears.



Note

- In the case of a setup data file of a GX/GP/GM with the advanced security function (/AS), authentication is necessary to display the Security settings. For details, see section **"4.2 User Authentication"**
- A setup data file (.GSL extension) of a GX/GP/GM with the advanced security function (/AS) cannot be overwritten after it is displayed and edited.
- If you specify a measurement data file, the configuration file data in the file will be loaded.
- The maximum file path length (including the file name) is 256 characters. If this limit is exceeded, an error will occur. Pay attention to the hierarchical depth and file name length.


2.2.2 Opening the Comparison Source File

This software has a validation print function, which can be used to compare and print settings, for verifying setup data. You can use the **Read comparison source** to load a reference comparison source file. The difference between the files can be verified on the **Validation print window**.

Opening a File Containing Comparison Source of a Program Pattern (GX/GP/GM with the Program Control Function) : ► **2.2.5**

Procedure

- 1 Start Hardware Configurator.
The setup window appears.



- 2 Before loading the comparison source configuration file, open the target configuration file that you want to compare.


How to open a file: ► **2.2.1 Opening a File**

Note


Make sure that the system configuration in the configuration file that is currently displayed is the same as that in the comparison source file. If they are not the same, you will not be able to load the comparison source file.

Setting the system configuration: ► **“Step 4” on page 2-2**


- 3 Click **Setting** tab and then **Read comparison source**.



The **Read comparison source** dialog box appears.




4 Select the comparison source file, and click **Open**.




When the comparison source file is loaded, two file names will appear in the upper right of the window. The left is the name of the configuration file that is currently displayed, and the right is the name of the comparison source file.



5 Click **Setting** tab and then **Validation print window**.




A separate window opens, and the window for printing is loaded.



The **Validation print** window appears.

6 On the left side of the **Validation print** window, click **ON(ALL)** of **Show Difference**.



"Show Difference"
Whether to include the difference

You can view the differences in the setup data in the print content on the right.

The screenshot shows the 'Validation Print' window. The left pane lists various setup categories like 'Print information settings', 'System information', 'Basic information', etc. The right pane displays the comparison results for a specific file.

Print Information Settings:

- Title: [Blank]
- Printed No.: [Blank]
- System Information: ☒ Display ☐ None
- Item list: ☒ Display ☐ None
- Show Difference: ☐ OFF ☒ ON(ALL) ☐ ON(Only change)

Print Name: Item name: [Blank] Show all / Hide all

Comparison Data:

Item name	Comparison source	Setting Number	File Data
AI channel settings	C:\Users\00113654\Desktop\GX_GP_R2_Setup\01.config\Twinfile\G/L\bas1.gst (Comparison source)		
DO channel settings	C:\Users\00113654\Desktop\GX_GP_R2_Setup\01.config\Twinfile\G/L\compars1.gst		
Math channel settings			

System Information:

Item name	Verified
Product Name	GX10 GP10
Firmware Version	R0.11.07
Model	GX10-1
Option	RS-422/485 / Tail output, I-gate / Mathematical f-unction (with report function) / Custom channel fu-unction / USB interface (Max 2 ports) / EtherNet/IP communication / W/T communication / Advanced re-curity function / Custom display function / Log s
Instrument tag	
Instrument tag No.	
Channel Information	AI 10Ch / DI 16Ch / DO 8Ch / Math 50Ch / Communi-cation 50Ch
Advanced security function	OFF

Recognized Module:

ID	Model	Serial No.	Version	Option	Custom	Input Ch.	Output Ch.	Verified
0	GX10LA-10-12	834807738	R0.09.04			10	0	
1	GX10LA-16-11		R0.09.04			16	0	
2	GX10LP-09-11		R0.09.04			0	0	

Print Settings:

- AI channel settings: ☒ 0001-0010
- DO channel settings: ☐ 0101-0110
- Math channel settings: ☐ 0201-0206
- Math channel settings: ☐ A001-A020 ☐ A021-A040 ☐ Contrast
- Math channel settings: ☐ A041-A050 ☐ Contrast
- Math channel settings: ☐ Contrast

For detailed information about "Validation print window": ► **2.6.2 Validation Print**

Note

The comparison source data is cleared when you perform any of the following operations.


- A new file with different system information is opened.
- Settings with different system information are received from the GX/GP.
- The system configuration is changed.
- A new file is created.

2.2.3 Opening an Update Source File

You can use the **Load Changed Settings** to load the setup data from a separate file and apply them to the current setup data. (The system configuration is not updated.)

Procedure

- 1 Start Hardware Configurator.
The setup window appears.




- 2 Open the target configuration file that you want to change.
How to open a file: ► [2.2.1 Opening a File](#)


- 3 Click the **Setting** tab and then **Load Changed Settings**.




The **Load Changed Settings** dialog box appears.



- 4 Select the update source file, and click **Open**.



The update source data is loaded, and the current setup data is changed.



- 5 If necessary, edit and save the changed data.
How to save a setup data file: ► [2.4 Saving Setup Data](#)

Note

Using the **Load Changed Settings** menu changes only the settings. It does not change the system configuration or the file name.

2.2.4 Opening a Configuration File Containing a Program Pattern (GX/GP/GM with the Program Control Function)


This section describes operations for opening a configuration file containing a program pattern of GX/GP/GM with the program control function (option, /PG). On the “Hardware Configurator”, you can open a file in the following methods.

- Opening a configuration file and a program pattern file together.
- Opening a configuration file only.

Using the “Program Pattern Setting”, you can edit a pattern by opening only a program pattern file.
▶ [Chapter 5 Program Pattern Setting for GX/GP/GMs with the Program Control Function \(/PG\)](#)


Procedure

- 1 Click **Setting** tab and then **Open**.



The **Open File** dialog box appears.


- 2 Select a configuration file, and click **Open**.
First, expand the setting.



The **Open pattern file by specifying a folder** dialog box appears.


However, in the following cases, “only settings” are displayed and operation is completed.

- The opened configuration file does not contain the program control function (/PG) or PID control module.




[Continue to the next page.](#)

If there is a folder named “ProgramPattern” (see Note) under the folder from which the configuration file was opened on your PC, the following dialog box appears. Choose whether to open **ProgramPattern** folder or specify and open a folder.




- If **Open all pattern files in the [ProgramPattern] folder.** is chosen: The program patterns are read and expanded from the folder, and operation is completed.
- If **Open the pattern files by specifying a folder.** is chosen: A dialog box for specifying a folder appears. (To Step 3)

3 Specify a folder ^(Note) and open program patterns contained in the folder.
Note: The folder is clicked and a line is selected.



Expand the program patterns in the folder and complete operation.



Note

If a program pattern is already shown on the Setting screen of the Hardware Configurator when another program pattern is expanded on the screen, the former pattern is deleted, and the new setting and program pattern are reflected on the screen of Setting software. If a pattern does not match system/PV range of setting, it is corrected to match them. After correction, a pattern number for the corrected pattern is notified by a message (W028).

Related item: [Example for the corrected pattern](#)

2.2.5 Opening a Comparison Source of a Program Pattern (GX/GP/GM with the Program Control Function)


This software has a validation print function, which can be used to compare and print settings, for verifying setup data. You can use the **Read comparison source** to load a reference comparison source file. The difference between the files can be verified on the **Validation print window**.

Related item : ► [“Opening the Comparison Source File” on page 2-14](#)


By opening a configuration file containing a program pattern of GX/GP/GM with the program control function (option, /PG) and then executing Read comparison source, you can compare program patterns.

Procedure

- 1 Before reading a comparison source setup file, open a configuration file containing a program pattern that is to be compared with the file.




- 2 Click **Setting** tab and then **Read comparison source**.



The **Read comparison source** dialog box appears.


- 3 Select a comparison source file (*.GNL), and click **Open**.



The **Read comparison source program pattern** dialog box appears.


[Continue to the next page](#)

- 4 Click **Open** the pattern files by specifying a folder.



The dialog box for specifying a folder appears.

- 5 Specify the **ProgramPattern** folder, then click **Open all pattern files in a folder**.




All program patterns in the folder are read and the names are listed.

- 6 Select a comparison source pattern file of a program pattern (*.GPT), and click **Read comparison source** located on the right side of the file name.


Pattern number	Current pattern name	Comparison source pattern name	File Name	Read comparison source
1	Pattern01	Pattern01	ProgPat01.GPT	Read comparison source
2	Pattern02		None	Read comparison source
3	Pattern03		None	Read comparison source

The comparison source program pattern file is read.

7 Click **Setting** tab and then **Validation print window**.




A separate window opens, and the window for printing is loaded.




The Validation print window appears.

8 On the left side of the **Validation print window**, click **ON(ALL)** of **Show Difference**.



“Show Difference”
Whether to include the difference

You can view the differences in the setup data in the print content on the right.



For detailed information about “Validation print window”: [▶ 2.6.2 Validation Print](#)

2.3 Editing Setup Data

2.3.1 Basic Operation

This section explains how to use Hardware Configurator to edit GX/GP's or GM's setup data. The setup data editing and display features are the same as those of the Web application on the main unit itself.


In addition, the setup items of this software are the same as those on the main unit. Therefore, this section will only cover typical operations and the unique features of this software.

- Setup item details:
- ▶ Chapter 1 "Configuring the GX/GP" in the *GX10/GX20/GP10/GP20 Paperless Recorder User's Manual* (IM 04L51B01-01EN).
 - ▶ Chapter 2 "Configuring the GM" in the *Data Acquisition System GM User's Manual* (IM 04L55B01-01EN).


Editing the Setup Data (*.GSL) of a GX/GP/GM with the Advanced Security Function (/AS)
Be sure to also read the precautions provided in "[Chapter 4 Setup Data for GX/GP/GM with Advanced Security Function \(/AS\)](#)"

Procedure

- 1 Display the file that you want to edit on the **Setting** tab.




- 2 From the content selection tree, which is on the left side of the window, select the name of the setup item you want to edit. (This example will show how to set DI channels.)



When you select a title, the setup items appear in the content area, which is on the right.

The channel settings content can be shown in Range, Alarm, Display settings, and Calibration correction groups. If you select All settings, all the setup items are displayed in the content area.



Items are displayed by each selected group.

- 3** Edit the channel settings.
Edit the setup items in the content area.

Channel number
1 line = 1 channel

Scroll right to view
more setup items. →

CH	Range					
	Type	Span Lower	Span Upper	Calculation	Reference channel	Decimal place
0101	DI	0	1	Off	0001	2
0102	DI	0	1	Off	0001	2
0103	DI	0	1	Off	0001	2
0104	DI	0	1	Off	0001	2
0105	DI	0	1	Off	0001	2
0106	DI	0	1	Off	0001	2
0107	DI	0	1	Off	0001	2
0108	DI	0	1	Off	0001	2
0109	DI	0	1	Off	0001	2
0110	DI	0	1	Off	0001	2

Note

The items and available settings that appear in the configuration window vary depending on the hardware system configuration. If an item that you want to edit does not appear, check the option and module configuration.

How to set the system configuration: ► [2.1 Creating New Setup Data](#)


Using the Jump Function

On setting edit windows in table format (e.g., channel setting window), you can jump to a specific position in the window.


- 1** Click  button in the upper right corner of the window.




A list of items that you can jump to appears. If the list is long, a scroll bar appears.



- 2** In the line number text box, enter the channel line number that you want to move to. The default value is the line number of the first line.



- 3** Select and click the jump destination item name on the list.



You can move to the specified setup item in the specified line.

- 4** To close the list, click the Close button in the upper right of the window.

Note





- If the line number text box is empty or the specified line number does not exist, the line will remain the same and only a horizontal movement will be made.
- The setup items that appear in the list are the parent title of each setup item. For example, Alarm level 1 will be displayed but not Value or Hysteresis.

2.3.2 Editing and Manipulating Values

From the content selection tree, select the title of the setup item that you want to edit, and edit the setup items that appear. Values are entered using the input controls and dialog boxes described below.

Input Controls

The following input controls are available.

Control Type	Display Example	Setup Procedure
Text box		Enter text or numbers.
Check box		When the check box is selected, the setting is "On" or enabled.
List box		Click the arrow, and select from the list that appears.
Option buttons		Click to select.

Dialog Boxes

The following dialog boxes are available. For details on how to use each dialog box, see the Operation Example in the table.

Dialog Box Type	Display Example	Setup Procedure
Channel selection button	Operation 1 Step 1, 2	Configure a specific channel such as an I/O channel.
Color selection	Operation 1 Step 3, 4	Select the display color of alarm marks and the like.
Channel selection string	Operation 2	Specify multiple channels such as when editing a display group.
Data selection	Operation 3	Specify internal switches and the like.
Special dialog box (calibration correction)	Operation 4	Use calibration correction.
Calculation expression input	Operation 5	Enter calculation expressions.

To configure a specific channel such as an I/O channel, click a channel number to specify the channel you want.

Click a color on the color selection palette in the dialog box. You can also enter the RGB values to specify any color.

When specifying multiple channels such as when editing a display group, click a channel number button to add the channel to the channel configuration. The added channel is displayed as a character string.

When specifying the internal switch or other item, click the displayed character string such as the switch number. (Same as channel selection.)

A dialog box for editing calibration correction values. Enter the correction value directly.

A dialog box for entering calculation expressions. Set calculation expressions by selecting operators and channels from the lists that appear.

How to Use the Different Dialog Boxes

Operation 1

Channel selection button, Color selection

- 1 Set the channel range.
This example shows how to set the reference channel for difference computation. Click the channel number under Reference channel.

Click here (▼) to show the available values.

CH	Range					
	Type	Span Lower	Span Upper	Calculation	Reference channel	Decimal
0101	DI	0	1	Linear scaling	0001	2
0102	DI	0	1	Delta	0001	2
0103	Skip DI	0	1	Delta	0001	2
0104	DI	0	1	Off	0001	2

Enter values within the selectable range.

Click to display the Channel selection dialog box.

The Channel selection dialog box appears.

- 2 Click the channel number under Reference channel.

DI channel[0102] Reference channel

Click the number to select the channel

Show or hide by channel type (when multiple channel types are available).

Clicking a number applies the output destination and closes the dialog box.

- 3 Scroll to the right, and set all necessary items.
- 4 If you want to change the alarm mark color, click a color.

CH	Alarm point mark					
	Indicate on Scale	Mark type	Alarm 1 color	Alarm 2 color	Alarm 3 color	Alarm 4 color
0001	<input checked="" type="checkbox"/>	Fixed				
0002	<input type="checkbox"/>	Alarm				

The color selection dialog box appears.

AI channel [0001] Alarm point mark Alarm 2 color

Current color Red

Key color

Recently used color

OK

Cancel

- 5** To create a color, enter values in the Current color boxes. To use a key color, select the color, and click **OK**.


The selected color is applied.

Operation 2

Channel selection string

This example shows how to assign channels to group 1.

- 1** On the content selection tree, click **Display settings** and then **Group settings**.
- 2** From the list of group numbers under **Group settings**, select the group numbers that you want to display. Here, select **1-20** (groups 1 to 20).



The **Group settings** dialog box appears.

- 3** Click **Channel set** of **Group number 1**.

Group number	Group settings			Scale image
	On/Off	Group name	Channel set	
1	<input checked="" type="checkbox"/>	GROUP 1	0001.0002.0003.0004.0005.0006.0007.0008.0009.0010	
2	<input checked="" type="checkbox"/>	GROUP 2	A001.C001	

The **Group number [1] Channel set** dialog box appears.

- 4** Select the check boxes of the channels that you want to include in group 1. To exclude a channel from group 1, clear the check box.

Channel order

Check to select the channel

On/Off for each channel


On/Off for selected channels

The selected channels are listed at the top area of the window.

- 5 The channel numbers at the top area of the window can be dragged to change their order.



If you drop the first number “0001” on the fifth number “C001,”



“0001” is moved there, and other channels are shifted to the left.


- 6 Click **OK**.
The channel numbers selected under Channel set are applied.

Operation 3

Data selection

This example shows how to set the alarm output destination.


- 1 On the content selection tree, click **Alarm**.



- 2 Under **Alarm Level 1**, select the **On/Off** check box of channel 1. Here, set **Output type** to **Internal switch**.

Alarm level 1								
CH	On/Off	Type	Value	Hysteresis	Logging	Output type	Output No.	
0001	<input checked="" type="checkbox"/>	H : High limit	0.0000	0.0005	<input checked="" type="checkbox"/>	Off	1	
0002	<input type="checkbox"/>	H : High limit	0.0000	0.0005	<input checked="" type="checkbox"/>	Internal switch	1	
0003	<input type="checkbox"/>	H : High limit	0.0000	0.0005	<input checked="" type="checkbox"/>	Off	2	

- 3 Click **Output No.**.
The **Output No.** dialog box appears.



- 4 Select the output Internal switch number.
The selected switch number is applied, and the setup window returns.


Note

- When the maximum number of selectable channels is reached, you will no longer be able to select additional channels.
- On dialog boxes that show check boxes and option buttons, you can select a range.
How to select a range: ► [2.3.4 Selecting a Range and Copying and Pasting](#)

Operation 4**Calibration Correction**

This example shows how to edit Calibration correction under AI channel settings.

- 1** On the content selection tree, click **Calibration correction**.



- 2** Set the **Mode** and **Number of set points**.

CH	Calibration correction		
	Mode	Number of set points	Edit correction points
0001	Off	2	Edit correction points
0002	Off	2	Edit correction points

- 3** Under Calibration correction, click **Edit correction points**.

CH	Calibration correction		
	Mode	Number of set points	Edit correction points
0001	Linearizer Approximation	12	Edit correction points
0002	Off	2	Edit correction points

The **Calibration correction** dialog box appears.

Calibration correction set points

AI channel[0001] Calibration correction			
CH	Mode	Linearizer input/output number	
0001	Linearizer Approximation	Linearizer input	Linearizer output
0002	Off	1	-2.0000
0003	Off	2	-1.6364
0004	Off	3	-1.2727
0005	Off	4	-0.9091
0006	Off	5	-0.5455
0007	Off	6	-0.1818
0008	Off	7	0.1818
0009	Off	8	0.5455
0010	Off	9	0.9091
		10	1.2727
		11	1.6364
		12	2.0000

Editing an input position causes the value to be checked against the upper and lower limits and the value to be corrected.

Editing an output position causes the value to be checked against the upper and lower limits.

Note


If you enter a value in any input position in the Calibration correction dialog box, the value is checked against the upper and lower limits and against the values of other positions and corrected. If you enter a value in any output position, the value is only checked against the upper and lower limits. For details on calibration correction, see the main unit's *User's Manual* (IM 04L51B01-01EN, or IM 04L55B01-01EN).

Operation 5

Calculation expression input

This example shows how to set a calculation expression in a math channel using the appropriate dialog boxes.

- 1 On the content selection tree, click **Math channel settings** and then **Calculation expression**.



- 2 Select the **On/Off** check box of the channel that you want to set a calculation expression in.

CH	On/Off	Calculation expression	Decimal place
A001	<input checked="" type="checkbox"/>	0001 Calculation expression	2
A002	<input type="checkbox"/>	0001 Calculation expression	2
A003	<input type="checkbox"/>	0001 Calculation expression	2
A004	<input type="checkbox"/>	0001 Calculation expression	2

The Calculation expression button becomes available.

- 3 Click **Calculation expression**.


CH	On/Off	Calculation expression
A001	<input checked="" type="checkbox"/>	0001 Calculation expression
A002	<input checked="" type="checkbox"/>	0001 Calculation expression
A003	<input checked="" type="checkbox"/>	0001 Calculation expression
A004	<input type="checkbox"/>	0001 Calculation expression

A **Calculation expression** dialog box appears. (Continued on the next page)

Note

You can also directly enter the expression (text) in Calculation expression of the setup window without using the dialog box.


a. Calculation expression edit box




The table below shows the details for the items.

Item	Description
a. Calculation expression edit box	The box for entering the calculation expression. You can directly enter text.
b. Input type list	The items in the list are the same as those of “c”, Input type tab. The list name that you select here becomes the tab name.
c. Input type tab	Tab pages containing operators, numbers, and the like used in calculation expressions. They are grouped by input type. Clicking a tab displays the operators and numbers for the input type in area “e.”
d. Tab scroll button	Click to scroll the tab position horizontally.
e. Operator/number button	Click to add the text shown on the button to the end of the “a” text string.


4 Enter the calculation expression in the calculation expression edit box. Click the Input type list arrow, and select the operator or channel that you want to display.




The selected operator is displayed.



You can also select the Input type tab to display in a similar manner.
In addition, clicking the channel list or tab displays channels.




5 Click the operator or channel that you want to enter in the calculation expression.



The appropriate characters are added at the cursor position.

6 When you are finished entering the calculation expression, click **OK**.



The dialog box closes, and the entered expression appears in **Calculation expression** in the setup window.

If the Calculation Expression Overflows

If the calculation expression is too long, it will not fit in the edit box.

In such a case, moving the cursor over the calculation expression in the setup window will show the entire expression in a pop-up.

- Pop-up display when the entered calculation expression fits in the edit box

CH	On/Off	Calculation expression	Decimal place
A001	<input checked="" type="checkbox"/>	0001+C001-K001 Calculation expression	2
A002	<input type="checkbox"/>	0001 0001+C001-K001 Calculation expression	2

- Pop-up display when the entered calculation expression does not fit in the edit box

CH	On/Off	Calculation expression	Decimal place
A001	<input checked="" type="checkbox"/>	0001+0002+0003+0004+0005+0006+0007+0008+0009+0010+A001+A002+A003	2
A002	<input type="checkbox"/>	0001	2
A003	<input type="checkbox"/>	0001	2
A004	<input type="checkbox"/>	0001	2

If an Invalid Calculation Expression Is Entered

If an invalid calculation expression is entered, the expression is displayed in red. The pop-up will display an error message and the entire calculation expression.

- Error message in the first line and the entire expression in the subsequent lines

CH	On/Off	Calculation expression	Decimal place
A001	<input checked="" type="checkbox"/>	0000+0002+0003+0004+0005+0006+0007+0008+0009+0010	2
A002	<input type="checkbox"/>	0001	
A003	<input type="checkbox"/>	0001	


Note

- The calculation expression that appears in the pop-up are updated when you finish entering the calculation expression. It is not updated while you are entering the calculation expression (while the cursor is in the text box).
- The pop-up does not appear in the calculation expression text box of the dialog box.


2.3.3 How to Register Users

This example shows how to register users when Advanced security function (/AS) is set to Off.

- 1 From the content selection tree, select **Security settings - Security basic settings**, and set **Security settings**.
Set **Login** to **Communication**.
User settings and User property are added to the tree content.



- 2 From the contents selection tree, select Security settings - User settings.



- 3 Register the user information for each user number.
User level of **User number** 1 is fixed to **Admin**. Register new users from the second user.

The first user is fixed to Admin.

Select the mode.

Click to register a password.


User number	User level	Mode	User name	Password
1	Admin	Touch operation + Communication	User01	**** Change
2	User	Touch operation + Communication	User02	**** Change
3	Off	Touch operation + Communication	User03	**** Change
4	Off	Touch operation + Communication	User04	**** Change
5	Off	Touch operation + Communication	User05	**** Change

To register a password, click **Change**.

If you change a password, the concealed characters (asterisks) will turn blue.



If you change the user name, the corresponding password will be initialized. In this case, "Initialize" will appear in blue.



4 To set **User property** *, select **On** and assign an **Authority number**.

User number	User level	Mode	User name	Password	User property	Authority number
1	Admin	Touch operation + Communication	User01	***** Change	Off	1
2	User	Communication	User02	***** Change	On	1
3	User	Touch operation	User03	***** Change	Off	1
4	Off	Touch operation + Communication	User04	***** Change	Off	1

* Limits are set using **Security settings > User property**. To restrict an operation, change **Free** to **Lock**.

- AI channel settings
 - 0001-0010
 - Range
 - Alarm
 - Display settings
 - Calibration correction
 - All settings
- Display settings
- Measurement settings
- Recording settings
- Data save settings
- Batch settings
- Timer settings
- Event action
- Communication (Ethernet) settings
- System settings
- Security settings
 - Security basic settings
 - User settings
 - User property

Authority number	Record	Data save	Message	Batch
1	Free	Free	Free	Free
2	Free	Free	Free	Free
3	Free	Free	Free	Free
4	Free	Free	Free	Free
5	Free	Free	Free	Free
6	Free	Free	Free	Free
7	Free	Free	Free	Free
8	Free	Free	Free	Free
9	Free	Free	Free	Free
10	Free	Free	Free	Free

- Note**
- Only Admin can be registered in user number 1.
 - Make a note of the administrator password, and do not lose it.
 - Enter the password using up to 20 characters. Single quotations, semicolons, and spaces are not allowed.
 - You can set User property only when the User level is User.

2.3.4 Selecting a Range and Copying and Pasting

This software enables you to select a range of setup items to edit them, copy them, and paste them.
This section explains how to select a range of items and how to use the Copy, Paste, and Tool buttons.

Selecting a Range

Procedure

- 1 To select a line, click an item name.
The example below is for **Display settings - Trend settings - List type**.

Trend settings	
Direction	<input checked="" type="radio"/> Vertical <input type="radio"/> Horizontal
Trend clear	<input checked="" type="radio"/> Off <input type="radio"/> On
Trend line	<input type="radio"/> Thick <input checked="" type="radio"/> Normal <input type="radio"/> Thin
Grid	Auto <input type="button" value="v"/>
Scale	
Digit	<input checked="" type="radio"/> Normal <input type="radio"/> Fine
Value indicator	<input checked="" type="radio"/> Mark <input type="radio"/> Bar graph
Digit of mark	3 digits <input type="button" value="v"/>
Partial	
On/Off	<input checked="" type="radio"/> Off <input type="radio"/> On
Message	
Write group	<input checked="" type="radio"/> Common <input type="radio"/> Separate
Power-fail message	<input checked="" type="radio"/> Off <input type="radio"/> On
Change message	<input checked="" type="radio"/> Off <input type="radio"/> On

Click the line name.

The line is selected.

- 2 To select multiple lines, drag the cursor and release the mouse at the last line you want to select.

Trend settings	
Direction	<input checked="" type="radio"/> Vertical <input type="radio"/> Horizontal
Trend clear	<input checked="" type="radio"/> Off <input type="radio"/> On
Trend line	<input type="radio"/> Thick <input checked="" type="radio"/> Normal <input type="radio"/> Thin
Grid	Auto <input type="button" value="v"/>
Scale	
Digit	<input type="radio"/> Normal <input checked="" type="radio"/> Fine
Value indicator	<input checked="" type="radio"/> Mark <input type="radio"/> Bar graph
Digit of mark	3 digits <input type="button" value="v"/>
Partial	
On/Off	<input checked="" type="radio"/> Off <input type="radio"/> On
Message	
Write group	<input checked="" type="radio"/> Common <input type="radio"/> Separate
Power-fail message	<input checked="" type="radio"/> Off <input type="radio"/> On
Change message	<input checked="" type="radio"/> Off <input type="radio"/> On

Drag across the line names to select multiple lines.

Multiple lines are selected.

Note When selecting a range, you cannot select multiple lines one by one. You cannot select columns individually.

Copying the Selected Range and Pasting

Procedure

- 1 To copy the selected range, click the **Copy** button, which is located in the lower right of the window. You can also press Ctrl+C on the keyboard.
When the range is copied to the Clipboard, the color of the range changes as shown below.

Trend settings	
Direction	<input checked="" type="radio"/> Vertical <input type="radio"/> Horizontal
Trend clear	<input checked="" type="radio"/> Off <input type="radio"/> On
Trend line	<input type="radio"/> Thick <input checked="" type="radio"/> Normal <input type="radio"/> Thin
Grid	Auto

- 2 You can paste the contents of the Clipboard to an Excel spreadsheet or a text file. The figure below shows an example in which the contents are copied to cell A1 of an Excel spreadsheet.

When pasting to an Excel spreadsheet, check the format of the cell that you are pasting to.

	A	B	C
1	Trend clear	Off	
2	Trend line	Normal	
3	Grid	Auto	
4	Digit	Normal	
5	Value indicator	Mark	
6	Digit of mark	3 digits	
7	On/Off	Off	
8			

- 3 The pasted contents can be edit on Excel or a text editor.

	A	B
1	Direction	Horizontal
2	Trend clear	Off
3	Trend line	Normal
4	Grid	Auto

➔

	A	B
1	Direction	Vertical
2	Trend clear	On
3	Trend line	Thin
4	Grid	5

Edit the values in the B column in Excel.

- 4 The edit contents can be pasted back to the setup items. Copy the edit results from the Excel spreadsheet. Copy not just the values but also the item names in row A.

	A	B
1	Direction	Vertical
2	Trend clear	On
3	Trend line	Thin
4	Grid	5
5		

- 5 Select the paste range in the configuration window. Make the paste range the same as the range of the copied data (the number of lines).

Trend settings	
Direction	<input checked="" type="radio"/> Vertical <input type="radio"/> Horizontal
Trend clear	<input checked="" type="radio"/> Off <input type="radio"/> On
Trend line	<input type="radio"/> Thick <input checked="" type="radio"/> Normal <input type="radio"/> Thin
Grid	Auto

- 6** Paste the data. Click the **Paste** button, which is located in the lower right of the window. You can also press Ctrl+V on the keyboard.

Trend settings	
Direction	<input checked="" type="radio"/> Vertical <input type="radio"/> Horizontal
Trend clear	<input type="radio"/> Off <input checked="" type="radio"/> On
Trend line	<input type="radio"/> Thick <input checked="" type="radio"/> Normal <input type="radio"/> Thin
Grid	5

The edit results from the Excel spreadsheet is pasted to the configuration window.

Note

- Depending on the format of the Excel cells that you are pasting to, the values may change when you paste the contents from the Clipboard. For example, if the format is set to **Number**, "0001" will change to "1". You can prevent pasted values from being automatically corrected by setting **Number** to **Text** in the Format Cells dialog box of the Excel sheet that you want to paste to.
- If the values cannot be pasted as they are to the Excel sheet even with the settings above, we recommend that you use a text editor for copying and pasting.
- If the values that you edit with Excel or a text editor are outside the setting range, when you paste the data back to the configuration window of the software, the values will be corrected in the same way as when you enter values directly.

Selecting a Range of Channels Whose Types Are Different and Copying and Pasting Them

The example below is an AI channel configuration window.

Procedure

- 1** Select a range of channels as shown below.

CH	Range					
	Type	Range	Span Lower	Span Upper	Calculation	Reference channel
0001	Skip	2V	-2.0000	2.0000	Off	0001
0002	Volt	2V	-2.0000	2.0000	Off	0001
0003	TC	K	-270.0	1370.0	Delta	0001
0004	RTD	Pt100	-200.0	850.0	Off	0001

Click the name of the line to select the entire line.
Drag down to select multiple lines.

- 2** Copy the channel information (lines).

CH	Range					
	Type	Range	Span Lower	Span Upper	Calculation	
0001	Skip	2V	-2.0000	2.0000	Off	
0002	Volt	2V	-2.0000	2.0000	Off	
0003	TC	K	-270.0	1370.0	Delta	
0004	RTD	Pt100	-200.0	850.0	Off	

Press Ctrl+C, or click Copy to copy the cells.

3 Paste to different channels.

CH	Range				
	Type	Range	Span Lower	Span Upper	Calculation
0001	Skip	2V	-2.0000	2.0000	Off
0002	Volt	2V	-2.0000	2.0000	Off
0003	TC	K	-270.0	1370.0	Delta
0004	RTD	Pt100	-200.0	850.0	Off
0005	Skip	2V	-2.0000	2.0000	Off
0006	Volt	2V	-2.0000	2.0000	Off
0007	TC	K	-270.0	1370.0	Delta
0008	RTD	Pt100	-200.0	850.0	Off
0009	Volt	2V	-2.0000	2.0000	Off
0010	Volt	2V	-2.0000	2.0000	Off

Copy Paste

Select the cells to paste to. Press Ctrl+V, or click Paste to paste to the cells.

The example below shows the configuration window that appears when you select **Display settings - Group settings - Channel set**.

Procedure

- 1 Select a range of channels as shown below.

AI channel									
<input checked="" type="checkbox"/> 0001	<input checked="" type="checkbox"/> 0002	<input checked="" type="checkbox"/> 0003	<input checked="" type="checkbox"/> 0004	<input checked="" type="checkbox"/> 0005	<input checked="" type="checkbox"/> 0006	<input checked="" type="checkbox"/> 0007	<input checked="" type="checkbox"/> 0008	<input checked="" type="checkbox"/> 0009	<input checked="" type="checkbox"/> 0010

DI channel									
<input type="checkbox"/> 0101	<input type="checkbox"/> 0102	<input type="checkbox"/> 0103	<input type="checkbox"/> 0104	<input type="checkbox"/> 0105	<input type="checkbox"/> 0106	<input type="checkbox"/> 0107	<input type="checkbox"/> 0108	<input type="checkbox"/> 0109	<input type="checkbox"/> 0110
<input type="checkbox"/> 0111	<input type="checkbox"/> 0112	<input type="checkbox"/> 0113	<input type="checkbox"/> 0114	<input type="checkbox"/> 0115	<input type="checkbox"/> 0116				

Click a label in a cell to select a single cell.

AI channel									
<input checked="" type="checkbox"/> 0001	<input checked="" type="checkbox"/> 0002	<input checked="" type="checkbox"/> 0003	<input checked="" type="checkbox"/> 0004	<input checked="" type="checkbox"/> 0005	<input checked="" type="checkbox"/> 0006	<input checked="" type="checkbox"/> 0007	<input checked="" type="checkbox"/> 0008	<input checked="" type="checkbox"/> 0009	<input checked="" type="checkbox"/> 0010

DI channel									
<input type="checkbox"/> 0101	<input checked="" type="checkbox"/> 0102	<input checked="" type="checkbox"/> 0103	<input checked="" type="checkbox"/> 0104	<input checked="" type="checkbox"/> 0105	<input type="checkbox"/> 0106	<input type="checkbox"/> 0107	<input type="checkbox"/> 0108	<input type="checkbox"/> 0109	<input type="checkbox"/> 0110
<input type="checkbox"/> 0111	<input checked="" type="checkbox"/> 0112	<input checked="" type="checkbox"/> 0113	<input checked="" type="checkbox"/> 0114	<input checked="" type="checkbox"/> 0115	<input type="checkbox"/> 0116				

Drag to select a rectangular area.

AI channel									
<input checked="" type="checkbox"/> 0001	<input checked="" type="checkbox"/> 0002	<input checked="" type="checkbox"/> 0003	<input checked="" type="checkbox"/> 0004	<input checked="" type="checkbox"/> 0005	<input checked="" type="checkbox"/> 0006	<input checked="" type="checkbox"/> 0007	<input checked="" type="checkbox"/> 0008	<input checked="" type="checkbox"/> 0009	<input checked="" type="checkbox"/> 0010

DI channel									
<input type="checkbox"/> 0101	<input checked="" type="checkbox"/> 0102	<input checked="" type="checkbox"/> 0103	<input checked="" type="checkbox"/> 0104	<input checked="" type="checkbox"/> 0105	<input type="checkbox"/> 0106	<input type="checkbox"/> 0107	<input type="checkbox"/> 0108	<input type="checkbox"/> 0109	<input type="checkbox"/> 0110
<input type="checkbox"/> 0111	<input checked="" type="checkbox"/> 0112	<input checked="" type="checkbox"/> 0113	<input checked="" type="checkbox"/> 0114	<input checked="" type="checkbox"/> 0115	<input type="checkbox"/> 0116				

Selection can be made across different setup item blocks.

- 2 While holding down Ctrl, click any of the check boxes in the selected range, or click the **On/Off** button to select or clear all the check boxes in the selected range.

Check boxes in the selected range will be On at once.

AI channel									
<input type="checkbox"/> 0001	<input checked="" type="checkbox"/> 0002	<input checked="" type="checkbox"/> 0003	<input type="checkbox"/> 0004	<input type="checkbox"/> 0005	<input type="checkbox"/> 0006	<input type="checkbox"/> 0007	<input type="checkbox"/> 0008	<input type="checkbox"/> 0009	<input type="checkbox"/> 0010

DI channel									
<input type="checkbox"/> 0101	<input checked="" type="checkbox"/> 0102	<input checked="" type="checkbox"/> 0103	<input type="checkbox"/> 0104	<input type="checkbox"/> 0105	<input type="checkbox"/> 0106	<input type="checkbox"/> 0107	<input type="checkbox"/> 0108	<input type="checkbox"/> 0109	<input type="checkbox"/> 0110
<input type="checkbox"/> 0111	<input checked="" type="checkbox"/> 0112	<input checked="" type="checkbox"/> 0113	<input type="checkbox"/> 0114	<input type="checkbox"/> 0115	<input type="checkbox"/> 0116				

Click while holding down Ctrl, or click On/Off.

Selected channels.

0002	0003	0102	0103	0112	0113
------	------	------	------	------	------

AI channel									
<input type="checkbox"/> 0001	<input checked="" type="checkbox"/> 0002	<input checked="" type="checkbox"/> 0003	<input type="checkbox"/> 0004	<input type="checkbox"/> 0005	<input type="checkbox"/> 0006	<input type="checkbox"/> 0007	<input type="checkbox"/> 0008	<input type="checkbox"/> 0009	<input type="checkbox"/> 0010

DI channel									
<input type="checkbox"/> 0101	<input checked="" type="checkbox"/> 0102	<input checked="" type="checkbox"/> 0103	<input type="checkbox"/> 0104	<input type="checkbox"/> 0105	<input type="checkbox"/> 0106	<input type="checkbox"/> 0107	<input type="checkbox"/> 0108	<input type="checkbox"/> 0109	<input type="checkbox"/> 0110
<input type="checkbox"/> 0111	<input checked="" type="checkbox"/> 0112	<input checked="" type="checkbox"/> 0113	<input type="checkbox"/> 0114	<input type="checkbox"/> 0115	<input type="checkbox"/> 0116				

Click again to clear all the check boxes.

3 The contents in the selected range can be pasted to other cells.

Select the cells to copy from, and press Ctrl+C to copy.

0002	1	0003	2	0102	3	0103	4	0112	5	0113	6								
AI channel																			
<input type="checkbox"/>	0001	<input checked="" type="checkbox"/>	0002	<input checked="" type="checkbox"/>	0003	<input type="checkbox"/>	0004	<input type="checkbox"/>	0005	<input type="checkbox"/>	0006	<input type="checkbox"/>	0007	<input type="checkbox"/>	0008	<input type="checkbox"/>	0009	<input type="checkbox"/>	0010
DI channel																			
<input type="checkbox"/>	0101	<input checked="" type="checkbox"/>	0102	<input checked="" type="checkbox"/>	0103	<input type="checkbox"/>	0104	<input type="checkbox"/>	0105	<input type="checkbox"/>	0106	<input type="checkbox"/>	0107	<input type="checkbox"/>	0108	<input type="checkbox"/>	0109	<input type="checkbox"/>	0110
<input type="checkbox"/>	0111	<input checked="" type="checkbox"/>	0112	<input checked="" type="checkbox"/>	0113	<input type="checkbox"/>	0114	<input type="checkbox"/>	0115	<input type="checkbox"/>	0116								
DO channel																			
<input type="checkbox"/>	0201	<input type="checkbox"/>	0202	<input type="checkbox"/>	0203	<input type="checkbox"/>	0204	<input type="checkbox"/>	0205	<input type="checkbox"/>	0206								



0002	1	0003	2	0102	3	0103	4	0112	5	0113	6								
AI channel																			
<input type="checkbox"/>	0001	<input checked="" type="checkbox"/>	0002	<input checked="" type="checkbox"/>	0003	<input type="checkbox"/>	0004	<input type="checkbox"/>	0005	<input type="checkbox"/>	0006	<input type="checkbox"/>	0007	<input type="checkbox"/>	0008	<input type="checkbox"/>	0009	<input type="checkbox"/>	0010
DI channel																			
<input type="checkbox"/>	0101	<input checked="" type="checkbox"/>	0102	<input checked="" type="checkbox"/>	0103	<input type="checkbox"/>	0104	<input type="checkbox"/>	0105	<input type="checkbox"/>	0106	<input type="checkbox"/>	0107	<input type="checkbox"/>	0108	<input type="checkbox"/>	0109	<input type="checkbox"/>	0110
<input type="checkbox"/>	0111	<input checked="" type="checkbox"/>	0112	<input checked="" type="checkbox"/>	0113	<input type="checkbox"/>	0114	<input type="checkbox"/>	0115	<input type="checkbox"/>	0116								
DO channel																			
<input type="checkbox"/>	0201	<input type="checkbox"/>	0202	<input type="checkbox"/>	0203	<input type="checkbox"/>	0204	<input type="checkbox"/>	0205	<input type="checkbox"/>	0206								



Select the cell to paste to and drag to select a range.

0002	1	0003	2	0102	3	0103	4	0112	5	0113	6								
AI channel																			
<input type="checkbox"/>	0001	<input checked="" type="checkbox"/>	0002	<input checked="" type="checkbox"/>	0003	<input type="checkbox"/>	0004	<input type="checkbox"/>	0005	<input type="checkbox"/>	0006	<input type="checkbox"/>	0007	<input type="checkbox"/>	0008	<input type="checkbox"/>	0009	<input type="checkbox"/>	0010
DI channel																			
<input type="checkbox"/>	0101	<input checked="" type="checkbox"/>	0102	<input checked="" type="checkbox"/>	0103	<input type="checkbox"/>	0104	<input type="checkbox"/>	0105	<input type="checkbox"/>	0106	<input type="checkbox"/>	0107	<input type="checkbox"/>	0108	<input type="checkbox"/>	0109	<input type="checkbox"/>	0110
<input type="checkbox"/>	0111	<input checked="" type="checkbox"/>	0112	<input checked="" type="checkbox"/>	0113	<input type="checkbox"/>	0114	<input type="checkbox"/>	0115	<input type="checkbox"/>	0116								
DO channel																			
<input type="checkbox"/>	0201	<input checked="" type="checkbox"/>	0202	<input checked="" type="checkbox"/>	0203	<input type="checkbox"/>	0204	<input type="checkbox"/>	0205	<input type="checkbox"/>	0206								



Press Ctrl+V to paste.

0002	1	0003	2	0102	3	0103	4	0112	5	0113	6	0202	7	0203	8				
AI channel																			
<input type="checkbox"/>	0001	<input checked="" type="checkbox"/>	0002	<input checked="" type="checkbox"/>	0003	<input type="checkbox"/>	0004	<input type="checkbox"/>	0005	<input type="checkbox"/>	0006	<input type="checkbox"/>	0007	<input type="checkbox"/>	0008	<input type="checkbox"/>	0009	<input type="checkbox"/>	0010
DI channel																			
<input type="checkbox"/>	0101	<input checked="" type="checkbox"/>	0102	<input checked="" type="checkbox"/>	0103	<input type="checkbox"/>	0104	<input type="checkbox"/>	0105	<input type="checkbox"/>	0106	<input type="checkbox"/>	0107	<input type="checkbox"/>	0108	<input type="checkbox"/>	0109	<input type="checkbox"/>	0110
<input type="checkbox"/>	0111	<input checked="" type="checkbox"/>	0112	<input checked="" type="checkbox"/>	0113	<input type="checkbox"/>	0114	<input type="checkbox"/>	0115	<input type="checkbox"/>	0116								
DO channel																			
<input type="checkbox"/>	0201	<input checked="" type="checkbox"/>	0202	<input checked="" type="checkbox"/>	0203	<input type="checkbox"/>	0204	<input type="checkbox"/>	0205	<input type="checkbox"/>	0206								

Note

- When you attempt to copy and paste values, Internet Explorer may show the message "Do you want to allow this webpage to access your clipboard?" Click **Allow** access to enable the copy and paste feature of this software. If you click **Don't allow**, you will not be able to use the copy and paste feature.
- If the cells whose check box is selected (on) reaches the maximum selectable number, cells whose check boxes are unselected become unavailable, and you will not be able to paste to them. You cannot paste to cells that do not have check boxes.
- Pasting is not possible to character strings that cannot be edited or passwords (concealed character strings).
- When option buttons or list boxes are selected, only the selected character strings can be copied and pasted.

Explanation

The configuration windows of this software can be classified into three window types. First is the list type, as in the **Trend settings** window. Second is the table type, as in the **AI channel settings** window. Third is the check box sheet type, as in the **Channel set** window of **Group settings**. The table below shows the differences in how you edit items for each window type.

Window Type	Selectable Range	Selection Method	Selection Cancellation Method	Limitations
List type	<ul style="list-style-type: none"> • By lines. • Multiple lines across different setup items can be selected. 	Click the name of the line to select the entire line. Drag across the names of lines to select multiple lines.	Click a location other than a line name and within the setup item edit area.	Multiple lines cannot be selected one by one. Columns cannot be selected individually.
Table type	<ul style="list-style-type: none"> • One or multiple lines. 	Click the name of the line to select the entire line. Drag across the names of lines to select multiple lines.	Click a location other than the line name.	If you click a cell in a different line, the selection of previously selected cells will be cleared.
Check box sheet type	<ul style="list-style-type: none"> • By cells. • A rectangular region can be selected. 	Click a label in a cell to select a single cell. Drag the cursor diagonally to select a rectangular area. Selection can be made across different setup item blocks.	Click an area within the check sheet without holding the Ctrl key.	If the cells that are On reaches the maximum selectable number, cells whose check boxes are not selected become unavailable.

Editing Using Tool Buttons

On table type configuration windows, you can use the tool buttons that are shown at the bottom of each table. Each tool button is assigned a function. You can use them to edit items collectively.

The available types of tool buttons are **Initialize**, **Paste to all lines**, **Increment**, **Minimize/Maximize**, and **Change all**.

Tool button types and functions: ► See the [table on the next page](#).

In the operation example below, the **Paste to all tool** button is used to set the **Type** of all selected channels to the same value.

Procedure

- 1 On the table type configuration window (the AI channel settings configuration window in this example), select the lines that contain the data that you want to copy. CH0001 is selected.

Select the line to copy from.

Data to copy

CH	Type	Range	Span Lower	Span Upper	Calculation
0001	Volt	2V	-2.0000	2.0000	Off
0002	GS	1-5V	1.0000	5.0000	Linear scaling
0003	GS	1-5V	1.0000	5.0000	Linear scaling
0004	GS	1-5V	1.0000	5.0000	Linear scaling
0005	Volt	2V	-2.0000	2.0000	Off
0006	Volt	2V	-2.0000	2.0000	Off

Paste destination

- 2 Drag the cursor to the last line that you want to assign the same type. CH0001 to CH0004 are selected.

CH	Type	Range	Span Lower	Span Upper	Calculation
0001	Volt	2V	-2.0000	2.0000	Off
0002	GS	1-5V	1.0000	5.0000	Linear scaling
0003	GS	1-5V	1.0000	5.0000	Linear scaling
0004	GS	1-5V	1.0000	5.0000	Linear scaling
0005	Volt	2V	-2.0000	2.0000	Off
0006	Volt	2V	-2.0000	2.0000	Off

- 3 Click the **Past to all** button on the tool bar.

CH	Type	Range	Span Lower	Span Upper	Calculation
0001	Volt	2V	-2.0000	2.0000	Off
0002	GS	1-5V	1.0000	5.0000	Linear scaling
0003	GS	1-5V	1.0000	5.0000	Linear scaling
0004	GS	1-5V	1.0000	5.0000	Linear scaling
0005	Volt	2V	-2.0000	2.0000	Off
0006	Volt	2V	-2.0000	2.0000	Off
0007	Volt	2V	-2.0000	2.0000	Off
0008	Volt	2V	-2.0000	2.0000	Off
0009	Volt	2V	-2.0000	2.0000	Off
0010	Volt	2V	-2.0000	2.0000	Off

Click here







The type of CH0002 to CH0004 is set to **Volt**.

CH	Range				
	Type	Range	Span Lower	Span Upper	Calculation
0001	Volt	2V	-2.0000	2.0000	Off
0002	Volt	2V	1.0000	2.0000	Linear scaling
0003	Volt	2V	1.0000	2.0000	Linear scaling
0004	Volt	2V	1.0000	2.0000	Linear scaling
0005	Volt	2V	-2.0000	2.0000	Off
0006	Volt	2V	-2.0000	2.0000	Off

Note

- When you use the tool button to paste data, the values are automatically corrected in the same way as when you enter values directly.
- Tool buttons are unavailable when no cells are selected (except for the **Change all** button).

The table below shows the different tool button types and their functions.

Button	Icon	Function
Past to all		Pastes the value in the first selected line to all other lines.
Increment		<ul style="list-style-type: none"> • For numeric input Pastes numbers to all selected lines by auto-incrementing the least significant digit, based on the number in the first selected line. • For character string input Pastes the character string of the first line appended with auto-incremented sequence numbers to all selected lines. If the character string of the first selected line ends with a number, this number will be used as the first sequence number. If the character string of the first selected line ends with a character, the sequence number 1 is appended to the character string of the first selected line.
Initialize		Initializes the values of the selected lines to their defaults.
Minimize		Sets the values of the selected lines to their minimum values.
Maximize		Sets the values of the selected lines to their maximum values.
Change all		<ul style="list-style-type: none"> • For check boxes Switches the check box values of the selected lines at once. If all the check boxes of the selected lines are selected, they are cleared. If they are cleared, they are selected. • For line name columns Selects or unselects all lines in the table.

2.4 Saving Setup Data


2.4.1 Saving a Setup Data File

This section explains how to save a setup data file to your PC.

Saving a Configuration File Containing a Program Pattern (GX/GP/GM with the program control function): ► 2.4.2


Procedure

- 1 Click **Setting** tab and then **Save As**.




The **Save As** dialog box* appears.

*: The subsequent times you open the dialog box, The first time you open this dialog box, Folder will be set to My Documents. Folder will show the last location that you opened or save to.



- 2 Specify the folder to save to, enter the file name, and click **Save**.



If a file with the same name exists in the folder, an overwrite confirmation message will appear. Click **OK** or **Cancel**.

If you click **OK**, the setup data file (.GSL, or .GSL extension) will be saved to the specified folder.

Note

- The GX/GP cannot load configuration files whose names contain non-alphabet characters (such as Japanese and Korean). Therefore, if you need to load such files in the GX/GP, do not use non-alphabetic characters.
- The maximum file path length (including the file name) is 256 characters. If this limit is exceeded, an error will occur. Pay attention to the hierarchical depth and file name length.
- The following characters cannot be used in file names or folder names.

Prohibited characters	Name
/	Slash
> <	Inequality signs
:	Colon
?	Question mark
"	Double quotation
'	Single quotation
\	Backslash
*	Asterisk
	Pipe
;	Semicolon

- You can enter up to 50 characters for the comment.

Save

Click **Setting** tab and then **Save** to save the edited contents to the current file.

If the file has not been saved yet, clicking **Save** will result in the same operation as clicking **Save As**.



A setup data file (.GSL extension) saved with GX/GP/GM with the advanced security function (/AS) cannot be overwritten. Save it to a new file (using Save As).

2.4.2 Saving a Configuration File Containing a Program Pattern (GX/GP/GM with the program control function)

This section describes operations for saving a configuration file containing a program pattern of GX/GP/GM with the program control function (option, /PG).

On the “Hardware Configurator”, you can save a file in the following methods.

- Saving a configuration file and a program pattern file together.
- Saving a configuration file only.


Using the “Program Pattern Setting”, you can save a program pattern file only.: ► [Chapter 5](#)

Procedure

- 1 Click the **Setting** tab and then **Save As**.




If there is no program pattern on the screen, you can save it using the same procedure as 2.4.1. If there is a program pattern, the following dialog appears.



- 2 Choose a saving method.
 Save setting parameters only: Proceeds to the dialog for saving only the settings. The procedure is the same as 2.4.1.
 Save setting parameters and all program patterns: Proceeds to the dialog for saving settings and program patterns (pattern number 01-99) together (Step 3).

- 3 Specify a saving location. Enter “Configuration file name” and “Program pattern folder name”, and click **Save**.

The default value of the Program pattern folder name is ProgramPattern. Some characters cannot be entered for a folder name. (See Note in the next page)



A folder containing a configuration file (*.GNL) and a program pattern file is saved.

Operation complete


Note

- If there is a program pattern folder with the same name in the saving location, an overwrite confirmation message (W005) appears. If you click Cancel, the folder is not overwritten.
- The following table shows the limitations of characters that can be entered for a program pattern folder name. If a character outside the range is entered, an error (E017) is shown, and the folder cannot be saved.

Limitations	Range
Number of characters	You can enter up to 32 characters.
Prohibited characters	<div>/</div> <div>Slash</div> <div>> <</div> <div>Inequality</div> <div>:</div> <div>Colon</div> <div>?</div> <div>Question mark</div> <div>"</div> <div>Double quotation marks</div> <div>'</div> <div>Single quotation marks</div> <div>\</div> <div>Backslash</div> <div>*</div> <div>Asterisk</div> <div> </div> <div>Vertical bar (pipe)</div> <div>;</div> <div>Semi-colon</div>
Prohibited words	<div>AUX, CON, PRN, NUL</div> <div>CLOCK\$, CLOCK</div> <div>COM0, COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9</div> <div>LPT0, LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9</div>
Other limitations	<div>You cannot begin/end the name of folder with a space or a point.</div> <div>Additionally, a blank name is not available.</div>
Path length	Up to 256 characters including the folder name.

Save

If you click **Save** to save a configuration file containing a program pattern, the program pattern folder is overwritten as well as the existing configuration file.



Overwrite of the program pattern folder is executed if one of the following is applicable.

- The program pattern folder for which **Save As** was executed the last time
- The program pattern folder opened by choosing **Open** and specifying the folder name.

If a configuration file has never been saved yet (NewFile is shown at the upper right of the screen), even if **Save** is clicked, the procedure is the same as saving a new file.

2.5 Initializing Setup Data

If you change the setup data on this software, the changes are stored and will appear the next time you start the software. If you want to view or change the current system configuration, follow the procedure in section 2.5.1.

If you do not want to change the current system configuration but initialize the setting value only, follow the procedure in section 2.5.2.

Note

If you change the system configuration, the current setup data will be initialized. If you want to save the setup data that is currently displayed, save the file before changing the system configuration.

2.5.1 Viewing and Changing the System Configuration

Procedure


- 1 Click **System** tab and then **System Config.**



The **System Config.** dialog box appears, showing the current system configuration.

- 2 If you just want to view the system configuration and not change it, click **Cancel**. To change it, select the option or module that you want to change.

How to set the System Config dialog box: ► [2.1.1 Creating a File in Accordance with System Configuration](#)



- 3 After you set the items, click **OK**. The system is reconfigured, and the setup items for the new system configuration will appear.


2.5.2 Initializing Setup Data

Procedure

- 1 Click **System** tab and then **Initialize**.



The initialization confirmation dialog box appears.



- 2 Click **OK** to initialize.
Initialization will take place.

2 Creating Setup Data

2

Creating Setup Data

Creating Setup Data

Creating Setup Data



Creating Setup Data

Creating Setup Data



Creating Setup Data

Creating Setup Data

Creating Setup Data



The selections that you make are applied immediately to the window.
In the example shown below, an header item is changed.

Before changing the setting area

Print information setting	
PC time	<input checked="" type="radio"/> Display <input type="radio"/> None
Comment	<input checked="" type="radio"/> Display <input type="radio"/> None
Comment	
System Information	<input checked="" type="radio"/> Display <input type="radio"/> None
Network Information	<input checked="" type="radio"/> Display <input type="radio"/> None
Item list	<input checked="" type="radio"/> Display <input type="radio"/> None

System Information is set to None



After changing the setting area

Print information setting	
PC time	<input checked="" type="radio"/> Display <input type="radio"/> None
Comment	<input checked="" type="radio"/> Display <input type="radio"/> None
Comment	
System Information	<input type="radio"/> Display <input checked="" type="radio"/> None
Network Information	<input checked="" type="radio"/> Display <input type="radio"/> None
Item list	<input checked="" type="radio"/> Display <input type="radio"/> None

Before changing the display area

Setting							
PC time	05/12/2014 10:00:28						
Comment							
System Information							
Product Name	GX10-GP10						
Firmware Version	R0.11.07						
Model	GX10-1						
Option	Fail output, Ipoint / Mathematical function (with report function) / Comm. channel function / USB interface (Host 2 ports) / W7 communication / Advanced security function / Log scale						
Instruments tag							
Instruments tag No.							
Channel Information	AI 10Ch / DI 16Ch / DO 6Ch / Math 30Ch / Communication 30Ch						
Advanced security function	OFF						
Recognized Module							
ID	Model	Serial No.	Version	Option	Custom	Input Ch.	Output Ch.
0	GX90XA-10-12	55M807738	R0.03.04		---	10	0
1	GX90XD-16-11		R0.03.04		---	16	0
2	GX90YD-09-11		R0.03.04		---	0	6
Network Information		No information					



After changing the display area

Setting			
PC time	05/12/2014 10:00:28		
Comment			
Network Information		No information	
Print setting			
AI channel settings	<input checked="" type="checkbox"/> 0001-0010		
DI channel settings	<input type="checkbox"/> 0101-0116		
DO channel settings	<input type="checkbox"/> 0201-0206		
Math channel settings	<input type="checkbox"/> A001-A020	<input type="checkbox"/> A021-A040	
	<input type="checkbox"/> A041-A050	<input type="checkbox"/> Constant	
Display settings	<input type="checkbox"/> Math action settings		
	<input type="checkbox"/> Trend interval	<input type="checkbox"/> Group settings	
	<input type="checkbox"/> Message settings	<input type="checkbox"/> Trend settings	
	<input type="checkbox"/> Screen display settings		
Measurement settings	<input type="checkbox"/> Scan interval	<input type="checkbox"/> Over-range	
	<input type="checkbox"/> Module settings		
Recording settings	<input type="checkbox"/> Recording basic settings	<input type="checkbox"/> Recording channel settings	

The System Information area is gone, and the AI channel settings have been shifted up.

- 3 When you have selected all the items that you want to print, click **Print** on the Web browser's **File** menu.
The Web browser's Print dialog box appears.
- 4 Click **OK**.
The setup data will be printed.

Note

- In the user settings of security settings, User ID and Password are printed with concealed characters (asterisks).
- To preview the print, on the **File** menu, click **Print Preview**.
- If you change settings while the Print window is displayed, to apply the changes to the window, click **Refresh** from the Internet Explorer's **View** menu.
- To set the page number, click Page Setup on the Internet Explorer's File menu.
- Configure the printer settings in accordance with your PC system.


Explanation

This section explains the print settings shown on the left side of the window.

Print information setting


The settings in this area specifies the printing of header items. The default values of all items are set to Display. Changing an item to None clears the title and information from the display area on the right.

- In the Comment box, you can directly enter a comment (text). When Comment is set to Display, this text is displayed.



- If Item list is set to Display, a list of settings to be printed is printed in the header area. This list reflects the items selected in Print item describe below.

The Item list is added to the print content when Item list is set to Display.



If you select the check boxes for the items you want to print, they are reflected in the Print item list.

Print item

Select the check boxes of the items to specify the settings to be printed.

By default, only the first item (e.g., AI channel settings) is selected. The check box conditions when you close the window are retained for the next time.

- Click **Show all/Hide all** to collectively select or clear all the Print item check boxes.

Print item	
Item name	Show all / Hide all
AI channel settings	<input checked="" type="checkbox"/> 0001-0010
DI channel settings	<input checked="" type="checkbox"/> 0101-0116
DO channel settings	<input checked="" type="checkbox"/> 0201-0206
Math channel settings	<input checked="" type="checkbox"/> A001-A020
	<input type="checkbox"/> A021-A040

- Clicking a title of the settings under Print item moves the display area on the right to the corresponding title.

Print information settings

PC time: ☒ Display ☐ None

Comment: ☒ Display ☐ None

System Information: ☐ Display ☒ None

Network Information: ☒ Display ☐ None

Item list: ☒ Display ☐ None

Print item

Item name: Show all / Hide all

AI channel settings: ☒ 0001-0010

DI channel settings: ☒ 0101-0116

DO channel settings: ☒ 0201-0206

Math channel settings: ☒ A001-A020

☐ A021-A040

☐ Constant

☐ Math action settings

CH	Type	Span Lower	Span Upper	Calculation	Reference channel	Decimal place	Lower	Upper	Unit
0101	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0102	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0103	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0104	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0105	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0106	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0107	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0108	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0109	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0110	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0111	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0112	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0113	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0114	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0115	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A
0116	DI	0	1	OFF	N/A	N/A	N/A	N/A	N/A

2.6.2 Validation Print

The Validation print window is used to compare the setup data that you created to a setup data reference.

You can use the **Read comparison source** to load a comparison source file, compare the differences, and print them.

Loading the Comparison Source File: ► [2.2.2 Opening the Comparison Source File](#)

Loading the Comparison Program Pattern File: ► [2.2.5 Opening a Comparison Source of a Program Pattern \(GX/GP/GM with the Program Control Function\)](#)

Procedure

- 1 Click **Setting** tab and then **Validation print window**.



A separate window for printing opens.

File Name	Setting Number	File Data	Verified
C:\Users\00113654\Desktop\GX_GP_R2_Software\01.config\Testfiles\GX_L_base1.gnl (Comparison source)			
C:\Users\00113654\Desktop\GX_GP_R2_Software\01.config\Testfiles\GX_L_base1.gnl			

Area for setting print conditions Area for displaying the content to be printed

- 2 In the print setting area shown on the left side of the window, select which items to print.
For the items that you want to print, select Display or select the check boxes. For the items that you do not want to print, select None or clear the check boxes.
- 3 If you want to display and print the differences between two files, under Print information setting, set Show Difference to Display.

“Show Difference”
Whether to include the difference

You can view the differences in the setup data in the print content on the right.

The procedure to set the print conditions is the same as that described in section [2.6.1 Setting the Print Options](#).

Explanation

This section explains the setting area shown on the left side of the Validation print window.

Print information setting

The settings in this area specifies the printing of header items.

Item	Selectable Range/Options	
Title	Text input (up to 64 characters)	The entered text is reflected in the header of the print display area.
Protocol No.	Text input (up to 32 characters)	Same as above
System Information	Display, None	Selecting Display shows the item in the display area on the right.
Item list	Display, None	Selecting Display prints a list of the print item settings in the header area. The items in this list are the same as those selected under Print item.
Show Difference (Note)	None	The difference is not displayed.
	ON (All)	Items that are different and those that are not are both displayed (printed).
	ON (Only changes)	The details of only the items that are different are displayed (printed). For items that are not different, only their titles are displayed.

Note

- Show Difference is valid only when a comparison source file has been specified.
- If Show Difference is set to ON (ALL), the comparison source settings are printed with strikethroughs. Items that are the same are printed in the same manner as normal printing.

0001-0010											
CH	Range					Scale					Verified
	Type	Range	Span Lower	Span Upper	Calculation	Reference channel	Decimal place	Lower	Upper	Unit	
0001	Volt	2V	-2.0000	2.0000	Delta Off	0001	N/A	N/A	N/A	N/A	
0002	TC	K	-270.0	1370.0	Off	N/A	N/A	N/A	N/A	N/A	
0003	Volt	200mV	-200.00	200.00	Off	N/A	N/A	N/A	N/A	N/A	
0004	RTD	Pt100	-200.0	850.0	Off	N/A	N/A	N/A	N/A	N/A	
0005	Volt	200mV	-200.00	200.00	Off	N/A	N/A	N/A	N/A	N/A	
0006	Skip Volt	N/A 2V	N/A -2.0000	N/A 2.0000	N/A Off	N/A N/A	N/A N/A	N/A N/A	N/A N/A	N/A N/A	
0007	Skip Volt	N/A 2V	N/A -2.0000	N/A 2.0000	N/A Off	N/A N/A	N/A N/A	N/A N/A	N/A N/A	N/A N/A	
0008	TC Volt	K 2V	-270.0 -2.0000	1370.0 2.0000	Off Off	N/A N/A	N/A N/A	N/A N/A	N/A N/A	N/A N/A	
0009	Volt	2V	-2.0000	2.0000	Off	N/A	N/A	N/A	N/A	N/A	
0010	Volt	2V	-2.0000	2.0000	Off	N/A	N/A	N/A	N/A	N/A	

- If Show Difference is set to ON (Only changes), only the lines with changes are printed as shown below. If all the items under a title have not changed, "No change" is printed under the title.

0001-0010											
CH	Range					Scale					Verified
	Type	Range	Span Lower	Span Upper	Calculation	Reference channel	Decimal place	Lower	Upper	Unit	
0001	Volt	2V	-2.0000	2.0000	Delta Off	0001	N/A	N/A	N/A	N/A	
0005	Volt	200mV	-200.00	200.00	Off	N/A	N/A	N/A	N/A	N/A	
0006	Skip Volt	N/A 2V	N/A -2.0000	N/A 2.0000	N/A Off	N/A N/A	N/A N/A	N/A N/A	N/A N/A	N/A N/A	
0007	Skip Volt	N/A 2V	N/A -2.0000	N/A 2.0000	N/A Off	N/A N/A	N/A N/A	N/A N/A	N/A N/A	N/A N/A	
0008	TC Volt	K 2V	-270.0 -2.0000	1370.0 2.0000	Off Off	N/A N/A	N/A N/A	N/A N/A	N/A N/A	N/A N/A	


Print Item

Select the check boxes for the items to specify the settings to be printed.
The procedure is the same as that described in "Print item" on page 56.

Print Contents

The following figure shows the structure of the print content shown on the right side of the Validation print window.

Of the item that are printed, those that are different from normal printing are described below.



Header

The header displays the title and protocol number entered under Print information setting and the PC timestamp of when the Validation print window was displayed. The timestamp is displayed in the format specified in the Display menu. The header appears at the top of each page in the print preview and in the actual print.

Protocol No.	Date 05/12/2014 13:13:48
Title	

Signature

The signature area is printed at the top of validation and for each content item name (e.g., AI channel settings, DI channel settings).

If the print item name is set to Hide all, it is only displayed at the top of validation. If all the settings under an item have not changed, only the item name and signature area are displayed.

	Printed Name	Signature	Date
Parameters Set			
Reviewed			
Approved			

File Name

The file path, Setting Number, File Date, and Verified are displayed in a table.

The following figure is for when Show Difference is set to Display. The top line is the comparison source file.

File Information			
File Name	Setting Number	File Date	Verified
C:\Users\... Desktop\GX_GP_R2_Software\01.config\Testfiles\GNL\compare1.gnl (Comparison source)			
C:\Users\... Desktop\GX_GP_R2_Software\01.config\Testfiles\GNL\base1.gnl			
Show Difference			
Show Difference	Verified		
ON(Only changes)			

Note

Setting Number and File Date are displayed only for configuration files that have been created on a GX/GP with the advanced security function (/AS) set to On. N/A is displayed if Setting Number is not available.

System Information

Displays the GX/GP system information. In the case of validation, a confirmation column is added to the right of the table.

System Information							
Basic Information							Verified
Product Name		GX10/GP10					
Firmware Version		R0.11.07					
Model		GX10-1					
Option		RS-422/485 / Fail output, 1point / Mathematical function (with report function) / Comm. channel function / USB interface (Host 2 ports) / EtherNet/IP communication / WT communication / Advanced security function / Custom display function / Log s					
Instruments tag							
Instruments tag No.							
Channel Information		AI 10Ch / DI 16Ch / DO 6Ch / Math 50Ch / Communication 50Ch					
Advanced security function		Off					

Recognized Module								Verified
ID	Model	Serial No.	Version	Option	Custom	Input Ch.	Output Ch.	
0	GX90XA-10-U2		R0.11.07		---	10	0	
1	GX90XD-16-11		R0.11.07		---	16	0	
2	GX90YD-06-11		R0.11.07		---	0	6	

Print Item

The settings of the items selected under Print item are printed. In the case of validation, a confirmation column is added to the right of the table. The following figure is for when Show Difference is set to ON (Only changes).

0001-0010											Verified
CH	Range					Scale					
	Type	Range	Span Lower	Span Upper	Calculation	Reference channel	Decimal place	Lower	Upper	Unit	
0001	Volt	2V	-2.0000	2.0000	Delta Off	0001	N/A	N/A	N/A	N/A	
0005	Volt	200mV	-200.00	200.00	Off	N/A	N/A	N/A	N/A	N/A	
0006	Skip	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
0007	Skip	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
0008	Temp	K	-270.0	1370.0	Off	N/A	N/A	N/A	N/A	N/A	

Security Settings

In the user settings of security settings, User name, User ID, and Password are left empty in the print.

- Difference display example for when the advanced security function (/AS) is not available or is set to Off

Security settings

Printed Name	Signature	Date
Parameters Set		
Reviewed		
Approved		

Security basic settings

Security function	Verified
Communication	Off
Login	

User settings

User number	User level	Mode	User name	Password	User property	Authority number	Verified
1	Normal Admin	Normal Touch operation + Communication			N/A	N/A	
2	Normal User	Normal Touch operation + Communication			Normal Off	N/A	
3	Normal User	Normal Touch operation			Normal Off	N/A	
4	Normal Off	N/A			N/A	N/A	

- Difference display example for when the advanced security function (/AS) is set to On

Security settings

	Printed Name	Signature	Date
Parameters Set			
Reviewed			
Approved			

Security basic settings

No change

User settings

User number	User level	Mode	User name	User ID	Password	Password expiration	Verified
4	User Off	Touch operation + Communication N/A				Off N/A	

User number	User property	Authority number	Sign in property	Authority of sign in	Verified
4	Off N/A	N/A	Off N/A	N/A	

User property

No change

Sign in settings

Data file transfer		Verified
FTP transfer timing	Sign in Data save	

Sign in property

No change

Note

Even if items in the comparison source data are set to off, some of them are displayed in the show difference window when the print setting is set to on.

In such a case, the difference is displayed by assuming the comparison source data to be invalid (N/A). The following figure is a display example for Batch text.

Batch text			
Text field number	Title of field	Characters	Verified
1	N/A abcdefg	N/A 0123456789	
2	N/A hijklmn	N/A 9876543210	
3	N/A	N/A	

Note

- To preview the print, on the **File** menu, click **Print Preview**.
- If you change settings while the Validation print window is displayed, to apply the changes to the window, click **Refresh** from the Internet Explorer's **View** menu.
- To set the page number, click **Page Setup** on the Internet Explorer's **File** menu.
- Configure the printer settings in accordance with your PC system.

Blank

3.1 Receiving and Sending Setup Data

You can connect to a GX/GP or GM and receive setup data from it and send setup data to it.

Before Sending or Receiving Setup Data

- Some operations are limited by the status of the connected main unit.
Limitation on **Operation** tab depending on the main unit status: ► [“Tables” on page 3-23](#)
- Before exchanging setup data with the main unit, check the system configuration. If the configuration between the main unit and the software is not the same, settings may not be set properly.
System configuration: ► [“Step 4” on page 2-2](#)
- Before sending or receiving setup data, we recommend that you reconfigure the main unit. Reconfiguration allows modules installed in the main unit to be detected and the system configuration to be confirmed.
- If a GM is connected, reconfiguration can be performed from this software. With a GX/GP, reconfiguration is possible only from the main unit screen.
Reconfiguring GM: ► [“Performing Reconfiguration \(When the connected device is a GM\)” on page 3-20](#)
Reconfiguring GX/GP: ► [“Reconfiguring the GX/GP” on GX10/GX20/GP10/GP20 Paperless Recorder First Step Guide \(IM 04L51B01-02EN\).](#)
- You cannot change the setting (On/Off) of the advanced security function (option, /AS), multi batch function (option, /BT), and “Measurement mode” by sending settings from the Hardware Configurator software.

Sending and Receiving Security Settings and Data

- If on the recorder, Security settings - Basic settings - Communication is set to Login, send data using an administrator user name. Otherwise, a portion of the data such as security settings will not be applied to the recorder.
- Whether setup data can be sent or received depends on the security settings as shown in the following table.

The GX/GP/GMs Security settings	Settings That Are Sent and Received			
	General settings (other than security settings)		Security settings	
	Reception	Transmission	Reception	Transmission
Security settings - Basic settings - Communication: Off	Yes	Yes	Yes	Yes
User level: Admin	Yes	Yes	Yes	Yes
User level: User, and User property not set ¹	Yes	Yes	Yes ¹	No ¹
User level: User, and User property and Setting operation are set to Lock ²	Yes	No ²	Yes	No ²

¹ If general settings can be sent but not security settings, “W013: Failed to set any settings.” will be displayed at the time of data transmission.

² If both general and security settings cannot be sent, “W014: Permission denied” will be displayed at the time of data transmission.

Receiving and sending when the advanced security function (/AS) is On: ► [Ch.4 Receiving and Sending Setup Data](#)

3.1.1 Receiving Setup Data

You can receive the current setup data from the main unit.


Receiving a Configuration File Containing Program Patterns (GX/GP/GM with the Program Control Function) : ► [3.1.5](#)

Procedure

- 1 Click the **Setting** tab and then **Receive Settings**.




A Communication dialog box appears.



Note

If the GX/GP/GM's Security settings - Basic settings - Communication is set to Login, you need to specify the user information. If set to Off, you only need to enter the communication information to establish a connection. For details on security settings, see the main unit user's manual (GX/GP: IM 04L51B01-01EN, GM: IM 04L55B01-01EN).

- 2 Enter the communication information for connecting to the main unit.
See **"Explanation"** on [page 3-3](#) for the details.
- 3 Enter the information, and click **OK**.
A confirmation message for receiving data appears.



- 4 To start receiving, click **OK**.
Settings are received from the recorder and displayed. The file name display shows "NewFile."

Explanation

The items in the Communication dialog box are described below.

User Name and Password

Enter the user information to log in to the recorder via communication. You do not have to enter this information if the main unit's Security settings > Communication is set to Off. If the main unit's Security settings - Communication is set to Login, enter the user name and password registered in the main unit. When logging in for the first time, enter the default password.*

The subsequent times, the user name that you entered previously will appear, so you will only need to enter the password.

- You can enter up to 20 characters. If you exceed this limit, the exceeded portion will be cut.
- The characters that you can enter are ASCII characters other than single quotation, semicolon, or space.
 - * The default password is the password that you use when you log in for the first time. It is provided in the main unit user's manual.

User ID

If the advanced security function (/AS) is enabled, use the user ID in combination with the user name and password shown above. You must enter the user ID if the main unit's advanced security function (/AS) is set to On, Security settings > Communication is set to Login, and User ID is in use.

User authentication when the advanced security function is On: ► **“Setup Data for GX/GP/GM with Advanced Security Function (/AS)”**

Comm.

Select the communication type from Ethernet, serial communication (RS-232 or RS-422/485), USB, or Bluetooth. Bluetooth can be used only when the main unit is a GM with the /C8 option.

Ethernet

IP address and host name that you enter will be stored and will appear the next time you open the dialog box.

- You can enter up to 128 characters. If you exceed this limit, the exceeded portion will be cut.
- The characters that you can enter are the alphabet (A to Z, a to z), numbers (0 to 9), hyphens, and dots.

The port number is the port number of the recorder that you want to connect to. If you have changed the recorder port number, enter that port number.

- Default value: 34434 (selectable range: 1 to 65535)

RS-232, RS-422/485

Set the RS-232 and RS-422/485 parameters from the **Port No.**, **Baud rate**, and **Parity** lists. (Enter the RS-422/485 address in the **Address** box.) These values are also stored and will appear the next time you open this dialog box.

Communication	Setup Item	Default Value	Selectable Range
RS-232 RS-422/485	Port No.	The first number in the port number list in the selectable range.	A list of available COM port numbers is displayed. If none are available, COM1 to COM20 is displayed.
	Baud rate	9600	9600/19200/38400/57600/115200 bps
	Parity	EVEN	ODD/EVEN/NONE
RS-422/485	Address	1	1 to 99

- * “Available COM port numbers” are the numbers of ports recognized by Windows Device Manager (PC).

USB

This setting is for connecting through a USB cable. Select the **Port No.**

- Selectable range: A list of available COM port numbers.
 - Default value: The first number in the port number list in the selectable range.
- Specify the COM port number for USB Serial Port.

Note

- If your PC is connected to the Internet, the appropriate USB driver is downloaded automatically.
- If you make USB connection for the first time in the environment without Internet, install the driver to your PC beforehand. Check the download link for the driver at [our website](#).

Bluetooth (GM)

This setting is for Bluetooth communication. Select the Port No.

To check the COM port number of the GM you want to connect to, see "Checking the COM Port for Bluetooth Connection (Windows 7 example)," explained later.

- Selectable range: A list of available COM port numbers.
- Default value: The first number in the port number list in the selectable range.

Enter the password for Bluetooth if the main unit's Bluetooth connection password is set to On. This is not necessary if it is set to Off. (See the Note below.)

- Default value: 1234

Note

Note the following points when you connect GM to your PC via Bluetooth.


- The GM's Bluetooth connection password is set to on by default. If you connect for the first time, you need to enter the default password (1234).
- Press the USER1 key of the GM for 3 seconds. "BT" LED (orange) is lit to indicate the GM is ready for the connection. If it does not lit, the Bluetooth function is off.
- Bluetooth driver may be necessary depending on the PC. For details, refer to the instruction manual of your PC or the Bluetooth interface.

Checking the COM Port for Bluetooth Connection (Windows 7 example)

The following procedure assumes that the GM has already been added as a Bluetooth device on the PC (the GM and PC are already communicating through a Bluetooth connection). Use it as a reference when checking the COM port number of the GM you want to connect.

Procedure

- 1 Click the Windows Start button, and on the start menu, click **Devices and Printers**. The GM appears under Devices.
- 2 Right-click the GM icon, and click **Properties**. The Properties window appears.
- 3 Click the **Hardware** tab.
- 4 Check the COM port number shown in the **Name** column under **Device Functions**.



Note

- USB and Bluetooth connections are handled as serial communication inside the PC. When the appropriate driver is installed in the PC and the PC is connected to a GM, the connection appears as a COM port in the Windows Device Manager.
- If you change the COM port number from Windows Device Manager, restart the PC. Otherwise, the new setting may not take effect.
- The serial communication parameters in this software are fixed at 8-bit data lengths and 1-bit stop bit.

COM Port When Serial Communication, USB, or Bluetooth Is Selected

If you set the communication type to serial communication, USB, or Bluetooth, available COM port numbers are detected and displayed in the Port No. list. If available ports are not detected, COM1 to COM20 are displayed in the list (software version R2.03 and later). The following are possible reasons why ports may not be detected.

- The ports that you want to use are disabled in Windows Device Manager.
- The driver for the relevant connection type is not installed in the PC.

The method to check ports and drivers varies depending on the PC or operating system that you are using.

For details, see the PC or interface user's manual, support website, or the like.

3.1.2 Sending Setup Data

You can send the current setup data to the main unit. This is not possible if the recorder is recording. To send or receive setup data to/from the main unit, check system configuration of the main unit, and reconfigure it as necessary. For details, see [“Before Sending or Receiving Setup Data” on page 3-1](#).

Sending a Configuration File Containing Program Patterns (GX/GP/GM with the Program Control Function): ► [3.1.6](#)

Procedure

- 1 Click the **Setting** tab and then **Send Settings**.



A dialog box for entering communication information appears.

- 2 Enter the information, and click **OK**.
Items in the Communication dialog box: ► [“Explanation \(Communication dialog box\)” on page 3-3](#)
- 3 To start sending, click **OK**.
The setup data will be sent.

Note

- If the Security settings - Basic settings - Communication is set to Login, only registered users will be able to send data.
- If you change the GX/GP's (firmware version R1.xx.xx) **Security settings - Basic settings - Communication** from **Off** to **Login** and send setup data, be sure to follow the procedure in [3.1.4 Changing the GX/GP's Security Settings \(GX/GP with firmware version R1.xx.xx\)](#)
- If settings are sent from Hardware Configurator when the Web application is monitoring data (e.g., trend monitor), the setting changes may not be communicated properly to the Web application. In such a case, restart the Web application (Internet Explorer).


3.1.3 Sending User Settings

You can send only the user settings to the main unit via communication. You can perform this operation even when the recorder is recording or computing.

Details on user settings: ► GX/GP: Section 1.9 in the *Models GX10/GX20/GP10/GP20 Paperless Recorder User's Manual* (IM 04L51B01-01EN), GM: Section 2.22 in the *Data Acquisition System GM User's Manual* (IM04L55B01-01EN).

Procedure

- 1 Click **Setting** tab and then **Send User Settings**.



A dialog box for entering communication information appears.

- 2 Enter the information, and click **OK**.
Items in the Communication dialog box: ► **“Explanation (Communication dialog box)” on page 3-3**
- 3 To start sending, click **OK**.
The setup data will be sent.

Note

If you are logged in and you change the user information and send it to the GX/GP with firmware version R1.xx.xx, errors will occur when you send subsequent setup commands. To change your user information in the GX/GP from the software via communication, be sure to follow the procedure in **“Changing User Information in the GX/GP via Communication”** of section 2.5.4.

3.1.4 Changing the GX/GP's Security Settings (GX/GP with firmware version R1.xx.xx)

The procedure described in this section is necessary if you are using GX/GP firmware version R1.xx.xx. If you are using R2.xx.xx or later, you can set the login function according to section [3.1.2 Sending Setup Data](#) and send user information according to section [3.1.3 Sending User Settings](#).

You can download the latest firmware from the [YOKOGAWA website](#).


Changing the GX/GP Communication Login Function from Off to Login

The procedure below is for enabling the GX/GP communication login function from Hardware Configurator. Follow the procedure below to change the GX/GP's Security settings - Basic settings - Communication from Off to Login from the software via communication. This allows only registered users to access the GX/GP via communication.

To change the GX/GP communication login function from Login to Off: ► [3.1.2 Sending Setup Data](#)

Procedure

- From the content selection tree, select **Security settings - Security basic settings**, and set **Communication** under **Security function** to **Login**.
User settings and User property are added to the tree content.



- From the contents selection tree, select **Security settings - User settings**, and register a user.

The first user is fixed to Admin.


Select the mode.

Click to register a password.

User number	User level	Mode	User name	Password
1	Admin	Touch operation + Communication	User01	***** Change
2	User	Touch operation + Communication	User02	***** Change
3	Off	Touch operation + Communication	User03	***** Change
4	Off	Touch operation + Communication	User04	***** Change
5	Off	Touch operation + Communication	User05	***** Change

To register a password, click **Change**.

- 3 Click **Send User Settings** to send the user information.



A Communication dialog box appears.

- 4 Enter the information, and click **OK**.
The user information will be sent.

- 5 Click **Send Settings**.



A Communication dialog box appears.

- 6 A dialog box for entering communication information appears. From the user settings sent in step 3, enter the **User Name** and **Password** for the **Admin** user level.

User Name and Password
for the Admin user level


- 7 Click **OK** to send the settings.
The setup data will be sent.

Changing User Information in the GX/GP via Communication

Follow the procedure below to change the user information of a logged-in user from this software.

How to change the user information of other users (excluding your own): ► [3.1.2 Sending Setup Data](#), or [3.1.3 Sending User Settings](#)


- 1 From the contents selection tree, select **Security settings - User settings**.



- 2 Change the user registration information, such as the user name and password.

User number	User level	Mode	User name	Password
1	Admin	Touch operation + Communication	User01	***** Change
2	User	Touch operation + Communication	User02	***** Change
3	Off	Touch operation + Communication	User03	***** Change
4	Off	Touch operation + Communication	User04	***** Change
5	Off	Touch operation + Communication	User05	***** Change

- 3 From the content selection tree, select **Security settings - Security basic settings**, and set **Communication** under **Security function** to **Off**.



- 4 For this step, use the user name and password for the Admin user level that were valid before you edited them in step 1. Click **Send Settings**.



A Communication dialog box appears.

5 Enter the old Admin user level information.

User Name and Password
for the old Admin user level

The GX/GP's **Security settings - Basic settings - Communication** is set to **Off**. At the same time, the user information edited in step 1 is set in the GX/GP.

6 From the content selection tree, select **Security settings - Security basic settings**, and change **Communication** under **Security function** to **Login**.

7 Enter the user name and password for the Admin user level that you edited in step 1, and click **Send Settings** again.

The GX/GP's **Security settings - Basic settings - Communication** returns to **Login**. This completes the updating of the user information.

3.1.5 Receiving a Program Pattern Configuration File (GX/GP/GM with the Program Control Function)

You can receive from the main unit a configuration file containing program patterns of GX/GP/GM with the program control function (option, /PG).

On the “Hardware Configurator”, you can receive a file in the following methods.

- Receiving a configuration file and a program pattern file together.
- Receiving a configuration file only.

Using the “Program Pattern Setting”, you can receive a program pattern file only. ► [“Receiving Program Patterns” on page 5-21](#)

Procedure

- 1 Click the **Setting** tab and then **Receive Settings**.



A Communication dialog box appears.

Function selected from the menu.

Set user information.

Select the communication type from the right.


Enter the communication information.

Note

If the GX/GP/GM's Security settings - Basic settings - Communication is set to Login, you need to specify the user information. If set to Off, you only need to enter the communication information to establish a connection. For details on security settings, see the main unit user's manual (GX/GP: IM 04L51B01-01EN, GM: IM 04L55B01-01EN).

- 2 Enter the communication information for connecting to the main unit.
See [“Explanation” on page 3-3](#) for the details.
- 3 Enter the information, and click **OK**.
A message is displayed to confirm received contents.

4 Choose a receiving method.



Choose **Receive setting parameters only** to receive only the settings

Choose **Receive setting parameters and all program patterns** to receive the settings and program patterns (pattern number 01-99).

Note



If you choose Receive setting parameters and all program patterns and a program pattern is displayed on the setting screen, the program pattern is overwritten with the received program pattern.

Explanation

The following shows details of the "File receiving method" described in the above dialog box. Clicking each button operates the Hardware Configurator as described in the table below.

Button	Operation result
Receive setting parameters and all program patterns	Collectively receives settings and program patterns (pattern number 01-99) of the main unit, and expands them on the setting screen of the Hardware Configurator. If a program pattern is shown on the Setting screen at this point, the pattern is deleted. Instead, the received settings and program patterns are reflected on the screen of Setting software. Configuration of the program pattern number 01 to 99 of the main unit are reproduced on the screen.
Receive setting parameters only	Receives only settings from the main unit and expands them on the setting screen of the Hardware Configurator. If there are program patterns displayed on the setting screen, those not matching System/PV Range of received settings are corrected to match System/PV Range. (They are not deleted.) After correction, a pattern number for the corrected pattern is notified by a message (W028). By clicking Detailed information, you can check changed items in the dialog box.

Example for pattern correction



Cancel

Close the dialog box

Note

If the main unit is in the following conditions, program patterns cannot be received. An error message (E021) is displayed.

- Other setting software is receiving program patterns.
- On the main unit screen of GX/GP, the setting screen for the program pattern is opened.

3.1.6 Sending a Program Pattern Configuration File (GX/GP/GM with the Program Control Function)

You can send to the main unit a configuration file containing program patterns of GX/GP/GM with the program control function (option, /PG). On the "Hardware Configurator", you can send a file in the following methods.

- Sending a configuration file and a program pattern file together.
- Sending a configuration file only.

Using the "Program Pattern Setting", you can send only a program pattern file.► **"Sending Program Patterns" on page 5-23**

Note

- On the Hardware Configurator, "Send Settings" cannot be performed if the main unit is Recording/Computing/Running control/Running program control. However, using Program Pattern Setting software, you can send only program patterns even when the main unit is Recording/Computing. For details of sending only program patterns, read **"Sending Program Patterns"**.
- To send or receive setup data to/from the main unit, check system configuration of the main unit, and reconfigure it as necessary.

Procedure

- 1 Click the **Setting** tab and then **Send Settings**.



A Communication dialog box appears.

- 2 Enter the communication information for connecting to the main unit.
See **"Explanation" on page 3-3** for the details.

- 3 Enter the information, and click **OK**.
A message is displayed to confirm sent contents. (To Step 4).

If the connected main unit is not equipped with the program control function (option, / PG) or the program control function is not enabled on the Setting software, a different message is displayed. (It is determined that there is no program pattern on the receiver and sender.) Click OK to send settings only.



4 Choose a sending method.

- Choose **Send setting parameters only** to send the settings only.
- Choose **Send setting parameters and all program patterns** to send the settings and program patterns (pattern number 01-99).

Note

If you fail to send program pattern setting, an error message (E029) and the numbers of the program patterns that could not be reflected are shown.

- The pattern numbers shown in this case are the pattern number used on the "Hardware Configurator's screen".
- "The program patterns that could not be reflected" means there are differences between the following items on the main unit and the settings: the location of the PID control module, location of decimal place in PV range, lower limit, upper limit.

3.2 Controlling the Main Unit

You can use this software to start and stop the recording and computing function, and display the hardware information of the main unit.

* Computation is an option.

3.2.1 Starting and Stopping Recording and Computing

Procedure


- 1 Click **Operation** tab and then **Start Recording**, **Stop Recording**, **Start Computing**, or **Stop Computing**.

If the main unit has the multi batch function (/BT): See "Note" below.




A Communication dialog box appears.

When you select a command on the Operation tab, a dialog box for setting communication parameters first appears. For details on the settings of the Communication dialog box, see the procedure in section [3.1.1 Receiving Setup Data](#). If the main unit's Security settings - Basic settings - Communication is set to **Login**, enter the user name and password registered in the main unit.



- 2 Enter the information, and click **OK**.
A confirmation message for starting or stopping appears.



- 3 To execute the operation, click **OK**.
The recorder will start or stop recording or computing.


Note

If you click Start Recording or Start Computing when the multi batch function is enabled (On), recording and computing of all batches will start. Likewise, if you click Stop Recording or Stop Computing, recording and computing of all batches will stop. You cannot start or stop each batch separately.

3.2.2 Viewing the Hardware Information

Procedure

1 Click **Operation** tab and then **Hardware Info.**



A Communication dialog box appears.

The dialog box titled 'Communication [Hardware Info.]' contains the following fields and options:

- User Name: [Text Field]
- User ID: [Text Field]
- Password: [Text Field]
- Comm.: ☒ Ethernet ☐ RS-232 ☐ RS-422/485 ☐ USB ☐ Bluetooth
- ☒ Ethernet
 - IP Address/Host Name: [Text Field]
 - Port No.: 34434
- Buttons: OK, Cancel

2 Enter the information, and click **OK**.

The 'Hardware Information' dialog box displays the following data:

Basic Information									
Product Name	GX10-GP10								
Serial No.	[Serial Number]								
MAC Address	[MAC Address]								
Firmware Version	R2.0.0.0								
Main Program	R2.0.0.0								
Web Program	R2.0.0.0								
Model	GX10-1								
Option	RS-422/485 / Fail output, Ipoint / Mathematical function (with report function) / Comm. channel function / USB interface (Host 2 ports) / EtherNet/IP communication / WT communication / Advanced security function / Custom display function / Log scale								
Instruments tag									
Instruments tag No.									
Channel Information	AI 10Ch / DI 0Ch / DO 0Ch / Math 50Ch / Communication 50Ch								
Advanced security function	Off								

Recognized Module									
ID	Status	Model	Serial No.	Version	Option	Custom	Input Ch.	Output Ch.	
0	<input checked="" type="checkbox"/>	GX90XA-10-U2	[Serial Number]	R2.0.0.0			10	0	
1	<input type="checkbox"/>								
2	<input type="checkbox"/>								

Status: [Text Field]

Buttons: OK

Annotations: A red bracket on the right groups the 'Basic Information' and 'Recognized Module' sections. A red arrow points to the 'Status' label and its corresponding text field.

The Hardware Information dialog box appears.
About displayed Information: ► **“Explanation” on page 3-18**

3 After you confirm, click **OK**.
Dialog box will close.

Explanation

The Hardware Information dialog box shows the following information.

Basic Information

- Product name: “GX20/GP20”, “GX10/GP10”, or “GM10”
- Serial No.
- MAC address
- Firmware version
- Model: GX20-1, GX10-1, GP20-1, GP20-2, GM10-1, GM10-2
- Option: The options detected by the recorder are listed in order.

Option	Displayed Characters	
Serial communication interface	/C2	RS-232
	/C3	RS-422/485
VGA output	/D5	VGA output
Fail output	/FL	Fail output, 1point
Mathematical function with report function	/MT	Mathematical function (with report function)
Communication channel functions	/MC	Communication channel function
24 V DC/AC power supply	/P1	24VDC/AC power supply
USB interface (Host 2 ports)	/UH	USB interface (Host 2 ports)
Pre-installed modules	/Uxx0	Model pre-installed with analog (universal) input module
	/CRxx	Model pre-installed with digital output module(s) and/or digital input module(s)
EtherNet/IP communication	/E1	EtherNet/IP communication
WT communication	/E2	WT communication
Advanced security function	/AS	Advanced security function
Custom display function	/CG	Custom display function
LOG scale	/LG	Log scale
Bluetooth (GM only)	/CB	Bluetooth
Aerospace heat treatment	/AH	Aerospace heat treatment
Multi-batch function	/BT	Multi-batch function
OPC-UA server	/E3	OPC-UA server
SLMP communication	/E4	SLMP communication
Program control function	/PG	Program Control

- Instruments tag: Displays the instruments tag assigned to the GX/GP.
- Instruments tag No.: Displays the instruments tag number assigned to the GX/GP.
- Channel Information: Displays the number of AI, DI, DO, math, communication, and pulse channels.
- Advanced security function: Displays the status (On or Off) of the advanced security function (/AS) if the options is installed.
- IP Address: Displays the IP address of the main unit. When the GM's DHCP is set to On, you can check the IP address that has been obtained automatically by connecting through a communication interface other than Ethernet.
- BD address: The Bluetooth BD address is displayed if the connected device is a GM with a Bluetooth option.
- Multi-batch function: If the main unit has the multi batch function (/BT), the state (Off or On) is displayed.
- Multi operation qty: If the multi batch function on the connected device is enabled (On), the number of batches is displayed.
- Measurement mode: Displays the measurement mode currently selected (Standard, High speed, or Dual interval)

Recognized Module

- ID:
GX20, GP20: 0 to 9
GX10, GX20: 0 to 2
GM10: 0 to 9
- Status: Displays the recorder output status by icons and tooltips.

Display	Description (text appears on each tooltip)
None	No information
Light blue	GOOD
Yellow	WARNING
Red	ERROR
Blue(?)	INVALID
Yellow(!)	UNMATCH

- Model: Model name of the module. "-----" if it does not exist.
- Serial No.
- Version: Module firmware version
- Option
- Custom: Customization information. "-----" if it is standard.
- Input Ch.: Number of input channels
- Output Ch.: Number of output channels

Status

Display	Status	Note
Recording	The recorder is recording.	If the multi batch function (/BT) is enabled and any of the batches is recording, "Recording" is displayed.
Computing	The recorder is computing.	
Accessing Media	The recorder is accessing a storage medium.	
Running control (Lxxx)	Displayed when a loop is in RUN status. (Lxxx): Loop number	
Running program control (xx)	Displayed if there is any pattern number in the process of program control. (xx): Running pattern number	


3.2.3 Performing Reconfiguration (When the connected device is a GM)

Reconfiguration of a GM can be performed from this software.

There are limitations to users that can perform reconfiguration. Note that reconfiguration of a GX/GP is not possible through communication from this software. (See Note.)

Procedure


- 1 Click **Operation** tab and then **Reconfiguration**.



A Communication dialog box appears.


- 2 Enter the information, and click **OK**.

When a connection is established with the GM, a reconfiguration confirmation message appears.



- 3 Click **OK**.

When the reconfiguration is complete, a message appears.



View the reconfiguration results: ► [3.2.2 Viewing the Hardware Information](#)


Note

- If user permission is set on the GM main unit, only the following users can perform reconfiguration.
 - Admin users
 - Users whose System operation of User property is set to Free
- If you do not have permission to perform reconfiguration or if the main unit is not in a condition to be reconfigured, the error message “E021 This function is not possible at this time” appears. Related topic:
- Reconfiguration of a GX/GP is not possible through communication from this software. Reconfigure a GX/GP from the main unit screen. Operation: “Reconfiguring the GX/GP” on *GX10/GX20/GP10/GP20 Paperless Recorder First Step Guide* (IM 04L51B01-02EN).


3.2.4 Starting/Stopping Control (GX/GP/GM with the PID control module)

You can start or stop loop control of the main unit (individual loop or all loops). Even when the main unit is being controlled, you can suspend the control from the Hardware Configurator, send settings, and then resume control.

- 1 Select the **Operation** tab and then **Run Control** (or **Stop Control**)




A **Communication** dialog box appears.




- 2 Enter the communication information for connecting to the main unit.
See **“Explanation” on page 3-3** for the details.
The operation dialog box appears.

- 3 Select a loop from the list of loop numbers, and click **OK**.



A dialog box for starting (or stopping) the specified loop appears.




Note

- A loop in PROGRAM status cannot run.
 - A loop that was run by program control is placed in PROGRAM status after program control is stopped.
- A loop in PROGRAM status cannot be stopped by individual loop specification.
 - Individual loop specification means specifying “Lxxx (Running control)”.
 - A loop running by program control is placed in PROGRAM status unless it is changed to LOCAL status via the GX screen or WEB application.
- If you perform “Stop all control loops” during program control, program control is stopped.


3.2.5 Starting/Stopping Program Control (GX/GP/GM with the Program Control Function)

You can start and stop program control on the main unit. Even when the main unit is in the process of program control, you can suspend the controlled pattern from the Hardware Configurator, send settings, and then resume operation of the suspended pattern.


- 1 Receive "Hardware Info." from the main unit and check the pattern number in the process of program control in advance.
Checking method: ► ["Viewing the Hardware Information" on page 3-17](#)
- 2 Select the **Operation** tab and then **Run Program Control** (or **Reset Program Control**).




A **Communication** dialog box appears.



- 3 Enter the communication information for connecting to the main unit.
See ["Explanation" on page 3-3](#) for the details.
The operation dialog box appears.
- 4 Select a program pattern number from the list, and click **OK**.
To "Stop" a pattern, check the pattern number in the process of program control, and click **OK**.



Run program control



Reset program control

A dialog box for starting (or stopping) operation of the specified pattern appears.

Note

- If you attempt to **Run Program Control** on the main unit for which program control is already started, an error message (E021) and the pattern number in the process of program control are displayed.
- If you attempt to **Reset Program Control** on the main unit for which program control is already stopped, an error message (E021) is displayed.

3.2.6 About Limitations on Operations by the Status of GX/GP/GM

Limitation is placed on sending and receiving of settings and using the Operation menu depending on the status of the connected main unit. The following table shows the relationship between the status of main unit and availability of operations in each status.

GX/GP

Operation of Setting software \ GX/GP Status	Recording	Computation	Running control	Running program control	Reconfiguration ³	A/D calibration Encryption Update
Receive Settings	Yes	Yes	Yes	Yes	Yes ¹	No
Send Settings	No	No	No	No	Yes ¹	No
Send User Settings	Yes	Yes	Yes	Yes	Yes	No
Start Recording	Yes ²	Yes	Yes	Yes	No	No
Stop Recording	Yes	Yes	Yes	Yes	No	No
Start Computing	Yes	Yes ²	Yes	Yes	No	No
Stop Computing	Yes	Yes	Yes	Yes	No	No
Run Control	Yes	Yes	Yes ²	Yes ³	No	No
Stop Control	Yes	Yes	Yes	Yes ³	See 4	No
Run Program Control	Yes	Yes	Yes	No	No	No
Reset Program Control	Yes	Yes	Yes	Yes	See 4	No
Hardware Info.	Yes	Yes	Yes	Yes	Yes ¹	No
Reconfiguration ³	No	No	No	No	No	No

Yes: Operation is possible. No: Operation is not possible (an error message will appear).

- 1 May be executed in a condition in which module configuration has not been confirmed. If this happens, the settings and hardware information will be different from the actual.
- 2 The recording, computing, running control, or running program continues because it is already in progress. (Nothing happens even if start is executed.)
- 3 Reconfiguration of a GX/GP is not possible from this software.
- 4 You cannot start or stop control on loops in the process of program control.
- 5 You cannot reconfigure the main unit during control or program control.

GM

Operation of Setting software \ GM Status	Recording	Computation	Running control	Running program control	Reconfiguration ¹	A/D calibration Encryption Update
Receive Settings	Yes	Yes	Yes	Yes	No	No
Send Settings	No	No	No	No	No	No
Send User Settings	Yes	Yes	Yes	Yes	No	No
Start Recording	Yes ¹	Yes	Yes	Yes	No	No
Stop Recording	Yes	Yes	Yes	Yes	No	No
Start Computing	Yes	Yes ²	Yes	Yes	No	No
Stop Computing	Yes	Yes	Yes	Yes	No	No
Run Control	Yes	Yes	Yes ²	Yes ³	No	No
Stop Control	Yes	Yes	Yes	Yes ³	See 4	No
Run Program Control	Yes	Yes	Yes	No	No	No
Reset Program Control	Yes	Yes	Yes	Yes	See 4	No
Hardware Info.	Yes	Yes	Yes	Yes	No ¹	No
Reconfiguration ¹	No	No	No	No	No	No

Yes: Operation is possible. No: Operation is not possible (an error message will appear).

- 1 Operation from this software is not possible when the GM is reconfiguring.
- 2 The recording, computing, running control, or running program continues because it is already in progress. (Nothing happens even if start is executed.)
- 3 You cannot start or stop control on loops in the process of program control.
- 4 You cannot reconfigure the main unit during control or program control.

Blank

4.1 Operation

This chapter explains how to use setup data files (.GSL extension)* for GX/GP/GM with the advanced security function (/AS).

- * Refers to setup data files that have been created on GX/GP/GM with the advanced security function (/AS) enabled. It also includes setup data created with Advanced security function On/Off under System config set to On in this software.

Note

For details on how to use and configure the advanced security function (/AS), see the *Advanced Security Function (/AS) User's Manual* (GX/GP: IM 04L51B01-05EN, GM: IM 04L55B01-05EN).

Creating Setup Data

For the procedure, see section [2.1 Creating New Setup Data](#)

Displaying Setup Data

You can load an existing setup data file (*.GSL) or measurement data file (*.GSE, *.GSD) from a PC and display the settings.

For the procedure, see section [2.2 Displaying Setup Data](#)

To display Security settings including user settings, authentication is required. For details, see section [4.2 User Authentication](#)

Editing Setup Data

For the procedure, see section [2.3 Editing Setup Data](#)

To edit Security settings including user settings, authentication is required. For the procedure, see section [4.2 User Authentication](#)

Note the following points when you edit settings with the advanced security function set to On. If you make a mistake in the settings, you may no longer be able to log in to the GX/GP/GM.

1. When using the password management function (KDC)
 - For Certification key under Communication (Ethernet) settings > KDC client settings, be particularly careful when entering Host principal and the password of the host user.
 - Be sure to include users that are registered on the KDC server side in the User settings of the GX/GP and GM.
 - Store the root user password in safe keeping.
 - If you forget or lose it, you will not be able to set Login back to Off in an emergency (such as when you can no longer log in due to an KDC setting error).
 - You can use the root user also to log in via communication from this software.
2. If On/Off under Security basic settings > User ID is changed, the User ID and Password in user settings are initialized.
3. If On/Off under Security basic settings > Password management is changed, the User ID and Password in user settings are initialized.
4. If Security basic settings > Password management is set to On, the User name setting is not shown in this software.

Saving Setup Data

For the procedure, see section [2.4 Saving Setup Data](#)

Note that overwriting is not possible.

Receiving and Sending Setup Data

For the procedure, see section [3.1.1 Receiving Setup Data](#) and section [3.1.2 Sending Setup Data](#)

Note

Before sending settings, check that an SD memory card is installed in the main unit. If the advanced security function is enabled, settings will not be sent if an SD memory card is not available.

Sending and Receiving on the Advanced Security Function

Even if the advanced security function is enabled, if the main unit's Security settings - Basic settings - Communication is set to **Off**, you can connect without entering the user information (user name and password).

Whether setup data can be sent or received depends on the security settings.

If the advanced security function is enabled, it is as shown in the following table.

Security settings - Basic settings of the main unit (The advanced security function: On)		Settings That Are Sent and Received			
		General settings (other than security settings)		Security settings	
		Reception	Transmission	Reception	Transmission
Touch operation and Communication are both set to Off		Yes	Yes	Yes	Yes
Touch operation is set to Login, and Communication is set to Off <small>(Note)</small>		Yes	No	Yes	No
Touch operation and Communication are both set to Login or Touch operation is set to Off and Communication is set to Login	Admin	Yes	Yes	Yes	Yes
	User User property not set	Yes	Yes	Yes	No
	User User property and Setting operation are set to Lock	Yes	No	Yes	No
	Monitor	Yes	No	Yes	No

Note

- If the main unit is the GM, the only login type is **Communication**.
- For the GX/GP whose advanced security function is set to **On**, **Touch operation** is set to **Login**, and **Communication** is set to **Off**, **Send Settings** is not possible from this software. (**Receive Settings** is possible.) If you want to apply the settings edited with this software to the main unit, save the configuration file from the software. Then, log in to the main unit using touch operation, and load the file.

Starting and Stopping Recording and Computing

For the procedure, see section [3.2.1 Starting and Stopping Recording and Computing](#), [3.2.2 Viewing the Hardware Information](#), or [3.2.3 Performing Reconfiguration \(When the connected device is a GM\)](#).

Even if the advanced security function is enabled, if the main unit's Security settings - Basic settings - Communication is set to **Off**, you can connect without entering the user information (user name and password).

If the main unit's Security settings - Basic settings - Communication is set to **Login**, enter the user name and password registered in the main unit.

However, depending on the user level, there are limitations to controlling the main unit from this software.

- When the user level is **User**
 - If **User property - Record** is set to **Lock**, Start Recording and Stop Recording are not available.
 - If **User property - Math** is set to **Lock**, Start Computing and Stop Computing are not available.
 - If **User property - System** operation is set to **Lock**, Reconfiguration is not available.
- When the user level is **Monitor**
 - Only acquiring and viewing **Hardware Information** is possible. Other main unit operations are not possible.

Initializing Setup Data

Only the settings that are being edited are initialized.

For the procedure, see section [2.5 Initializing Setup Data](#)

Printing Setup Data

You can print setup data.

However, if the advanced security function is enabled, User name, User ID, and Password are printed with concealed characters (asterisks).

For the procedure, see section [2.6 Printing Setup Data](#)

Printing Validation Data

You can load a reference configuration file, compare with the current setup data, and print the results.

For instructions on how to load a reference file, see [2.2.2 Opening the Comparison Source File](#)


For information on how to configure validation printing, see section [2.6.2 Validation Print](#)

4.2 User Authentication

If the security function is in use in a system configuration where the advanced security function (/AS) is enabled, attempting to display the content under Security settings may trigger User authentication.

This section explains user authentication.

The following figure is an example of a window for when you select Security basic settings in a condition in which authentication is assumed to occur.



4.2.1 When User Authentication Occurs

When you open a configuration file or execute Receive Settings, a User authentication dialog box appears if all the following conditions are met.

1. In System config, Advanced security function On/Off is set to On.
2. Under Security basic settings - Security function, Touch operation or Communication is set to Login.
3. An item belonging to Security settings is selected for displaying.
 - Security basic settings
 - User settings
 - User property
 - Sign in settings
 - Sign in property

4.2.2 Entering Information in the User Authentication Dialog Box

This section describes the procedure to perform when a User authentication dialog box appears. If authentication is successful, you will be able to display and edit the items in Security settings.

User Name	
User ID	
Password	
<input type="button" value="OK"/> <input type="button" value="Cancel"/>	

Procedure

- 1 When a User authentication dialog box appears, enter the information of an “Admin” user in the **User name**, **User ID**, and **Password** boxes.

User Name	User001
User ID	*****
Password	*****
<input type="button" value="OK"/> <input type="button" value="Cancel"/>	

Note


- The “Admin” user refers to an “Admin” user in the user settings within the setup data that is opened.
- In some cases, User ID and Password may not appear. (See the explanation on the next page.)

2


Click **OK**.

The dialog box closes, and authentication takes place.

If the entered user information matches that of any “Admin” user in the setup data, the selected settings will appear.



If authentication fails, the message “Permission denied” will appear in the content area.



- 3 To retry authentication, select other items under Security settings. A User authentication dialog box will appear.

Explanation

The items in the User authentication dialog box are described below.

User name

Enter the user name of an “Admin” user in the user settings within the setup data.

User ID

Enter the user ID of an “Admin” user in the user settings within the setup data. The text that you enter will not be displayed. This is displayed only when Security basic settings > User ID is set to On in the setup data.

Password

Enter the password of an “Admin” user in the user settings within the setup data. The text that you enter will not be displayed. This is displayed only when Security basic settings > Password management is set to Off in the setup data.

Note

- Authentication will be successful when the information entered in the dialog box matches the user information (User name, User ID, and Password) of an “Admin” user in the user settings within the setup data.
- Once authentication is successful, you can display various security settings without authentication until the conditions for triggering authentication described earlier are met again.
- If user authentication fails, an error will appear. There is no limit on the number of times you can fail.


5.1 Program Pattern Setting

5.1.1 Overview


This chapter explains “Program pattern setting”¹ of GX/GP/GM with the PID control module and program control function (option, /PG).

¹ For details of control functions and each setting item of GX/GP/GM, read “Model GX10/GX20/GP10/GP20/GM10 Loop Control Function, Program Control Function (/PG) User’s Manual (IM 04L51B01-31EN)”.

SMARTDAC+ Hardware Configurator supports the loop control function and program control function for GX/GP/GM from R4.01. Therefore, if you enable the PID control module (GX90UT-02-11) and program control function (option, /PG) in system configuration of the connected main unit, the Program Pattern tab is added on the Setting screen. On this tab, you can create, display, edit, save, and send/receive program patterns to/from the main unit.



When you install Hardware Configurator (R4.01 or later), Program pattern setting is installed simultaneously by default.



The “Program pattern tab” of the Hardware Configurator and “Program Pattern Setting” have almost the same configuration and features. On the “Hardware Configurator”, you can configure program patterns as well as the setting of main unit. In contrast, the “Program Pattern Setting” is designed so that users can easily set and edit only program patterns. To open, save, or send/receive not only program patterns but a configuration file at the same time, operate “Hardware Configurator”.

5.1.2 Operating Environment

The required PC system environment is the same as that for the Hardware Configurator.

► [“PC System Requirements” on page 1-3](#)

5.1.3 Other Operating Conditions, Security Measures

Same as the Hardware Configurator. Read the following sections.


► [“Other Operating Conditions”, “Security Measures” on page 1-4](#)

5.1.4 Starting the Software

Procedure

- 1 From Start menu, select All Programs - SMARTDAC+ STANDARD - Program pattern setting.

Program pattern setting starts, and the following window appears.




5.1.5 Window and Menu Configuration

The screen structure of the Program Pattern Setting is the same as the Hardware Configurator. It consists of tabs, menus, and file name display area, as shown in the figure below.

The split bar and buttons can be used in the same way as the Hardware Configurator. See the following page for details.

About the split bar and buttons for display change, copy and paste, and jump display: ► [page 1-6](#)



Note

With the “Program Pattern Setting”

- The “File Name” on the upper right of the screen is not displayed.
- Sending/receiving of settings (GNL) and expansion/saving of files are not possible.
- There are no setting screen displays other than program pattern setting.

The structure of tabs and menus of the Program Pattern Setting are shown in the figure below.

Program pattern	Operation	System/PV Range	Option	Help
New	Open Pattern Files (Specification folder)	Save Pattern Files (Specification folder)	Receive Pattern Settings	Send Pattern Settings

Tab	Menu	What You Can Do
Program pattern	New	Creates a new program pattern file. Opens a System/PV Range dialog box for creating a new program pattern file
	Open Pattern Files (Specification folder)	Specifies a folder and expands program pattern files collectively.
	Save Pattern Files (Specification folder)	Specifies a folder and saves program pattern files collectively.
	Receive Pattern Settings	Receives program pattern settings collectively from the main unit.
	Send Pattern Settings	Sends program pattern settings collectively to the main unit.


Tab	Menu	What You Can Do
Operation	Start Recording	Starts recording of the main unit.
	Stop Recording	Stops recording of the main unit.
	Start Computing	Start computation of a main unit.
	Stop Computing	Stop computation of a main unit.
	Run Control	Start control of a main unit.
	Stop Control	Stop control of a main unit.
	Run Program Control	Start program control of a main unit.
	Reset Program Control	Stop program control of a main unit.
	Hardware Info.	Receive and display the GX/GP/GM status and option information.
	Reconfiguration	Reconfigure the GM system.
System/PV Range	Delete All Patterns	Initializes all program patterns in the main unit.
	System/PV Range	Configures system configuration and PV range required for configuring program patterns.
Option	Initialize	Initializes program patterns in the software.
	Display Option	Specify the display language of Program pattern setting..
Help	Port No.	Specify the port number of Program pattern setting.
	Instruction Manual	View the user's manual.
	Version	View the Program pattern setting's version.
	Web to update	Visit the Website to download the latest version of Hardware Configurator (including Program pattern setting).

5.1.6 Setting the Display Language


You can set the display language to English, Japanese, German, French, Chinese, Russian or Korean. With the Program Pattern Setting, data display format and the decimal point type cannot be set.

Procedure

- 1 Click **Option** tab and then **Display Option**.



Display Option dialog appears.




- 3 Click **Language** arrow, and select from the list.
- 4 Click **OK**.

5.1.7 Specifying the HTTP port number


You can specify the HTTP port number for using the Web browser from this software.
The default HTTP port number is "34503" for the "Program pattern setting". To change the port number to a different number, follow the procedure below.

Procedure

- 1 Click **Option** tab.
- 2 Click **Port No.**



The **Port No.** dialog box appears.



- 3 Enter the port number (in the range of 34443 to 65535).

Note

To activate the new port number, restart the software.
The software will continue to use the old port number until you restart the software.

5.1.8 Closing the Software


Procedure

- 1 Close Internet Explorer by clicking the **Close** button or by clicking **Exit** on the **File** menu.

[Operation complete](#)

5.2 Creating a New Program Pattern File


The following shows the operation flow for creating a program pattern file.




To create a program pattern file, a dialog box for configuring “System Config.” and “PV range” of the program pattern are opened.

Procedure

- 1 Click the Program pattern tab and then New.



The System/PV Range dialog box opens.



- 2 Set system/PV range.

▶ Go to step 2 on the next page.

- For details of the method of setting system/PV range, see the next section “5.3.1 Setting System/PV Range”
- For the procedure of creating program patterns according to the flow, refer to “5.4 Example of Program Pattern Setting”.

5.3 Setting PV Range of the Program Pattern

From the System/PV Range tab, you can display or change the settings that are used as master settings on the Program Pattern Setting. The “System Config.” of the Program Pattern Setting contains only the settings required for creating program patterns.


Note

- When setting system configuration and PV range on the Hardware Configurator
System configuration: **System** tab > **System Config.**: ► [page 2-1](#)
PV range: **Control settings** tab > **Setup parameters** > **PV/RSP settings** > **Control PV input range**
- For details of control settings and control PV range, read the following user’s manual.
“Model GX10/GX20/GP10/GP20/GM10 Loop Control Function, Program Control Function (/PG) User’s Manual (IM 04L51B01-31EN)”

5.3.1 Setting System/PV Range

Procedure


- 1 Click the **System/PV Range** tab and then **System/PV range**.



The **System/PV Range** dialog box appears

When New is clicked in a program pattern, the System/PV Range dialog box appears in the same way.

- 2 Select a tab of the product name.



3 Select a model.

Tab	Model	Number of Control Loop
GX20/GP20	GX20-1, GP20-1, GX20-2, GP20-2	-1 model: 10 loops
GX10/GP10	GX10-1, GP10-1, GP10-1 (12VDC Power Supply)	-2 model: 20 loops
GM10	GM10-1, GM10-2	

4 Set the location of PID module.

In the Program Pattern Setting, only PID module (GX90UT-02-11) and expansion module (GX90EX-02-TP1) can be set.

ID	Model
0	-
1	GX90UT-02-11
2	-
3	-
4	-
5	-
6	-
7	-
8	-
9	GX90EX-02-TP1

Tab	Number of ID (Slot number)
GX10/GP10	0 to 2
GX20/GP20	0 to 9
GM10	0 to 9 You cannot choose PID module for the main unit slot 5 to 9 of GM. Also, you cannot choose I/O expansion module for 7 to 9.

If you are using an I/O expansion module (GX90EX-02-TP1)

- GX10/GP10 can only be set to "2" of "ID"
- GX20/GP20 can only be set to "9" of "ID"
- With GM10, it can be set to "0" to "6" of "ID". However, you cannot set other modules after the I/O expansion module.

Related items and details : ► ["Module Configuration Limitations" on page 2-8](#)

5 Set PV range. Click **Proceed to PV range settings** or **Import System/PV range from the setting file**.

- When choosing **Proceed to PV range settings**
The **System/PV Range** dialog box opens.
- When choosing **Import System/PV range from the setting file**
The **Open File** dialog box appears. When a file is selected and opened, range settings are read on the **System/PV Range** window.

Regardless of which options are selected, a warning message may appear depending on the position of attached module, etc. (See Note)

Note

You can configure PV range settings on the Program Pattern Setting in the following methods.

- Specify values on a dialog box
- Read PV range from an existing file
- Read PV range by receiving program patterns from the main unit : ► **“5.7 Receiving and Sending Program Patterns”**

To specify values in the window in step 5, choose Proceed to PV range settings. However, if you click Proceed to PV range settings while there is no PID control module, a message (W031) is displayed, and you cannot proceed to PV range setting.

To read PV range from a configuration file, choose Retrieve system/PV range from configuration file. Note that the following types of files cannot be correctly read.

- Configuration files below R4.01 cause a read error (E003).
- When files applicable to the following are read, they are opened in the initial state.
 - A configuration file without the program control function
 - A configuration file without a PID control module
 - A configuration file containing a system that cannot coexist with the program control function (advanced security function, high-speed/dual measurement mode)

6

Specify or check the value in the **System/PV Range** dialog box, and click **OK**.

Loop number	Decimal point	Minimum value of input range	Maximum value of input range	Unit
L091	1	0.0	100.0	℃
L092	3	0.000	1.000	℃

The displayed PV range setting is applied.

Operation complete

Note

Even though a configuration file is read, if PV range cannot be read for a loop, the initial value is input.

5.3.2 Initializing Setup Data

Initialize all values in the Program Pattern Setting (on PC).


Initialize all program patterns in the main unit: ► [“Deleting All Patterns” on page 5-26](#)

- 1 Click the **System/PV Range** tab and then **Initialize**.



A confirmation message (W010) is displayed.


- 2 Click **OK**.



All pattern numbers are set to Not use, and all setting values are returned to initial values.

5.4 Program Pattern Example

This section explains how to set the program pattern shown in the following figure. The explanation is given only for Loop 1, but other loops can be set in the same way as well.



Set the target setpoint and segment time for segments 1 to 6 as follows:


- (1) The operation start temperature is 50.0°C. The temperature is increased to 100.0°C over 50 minutes.
 - (2) When the temperature reaches 100.0°C, this temperature is maintained for 30 minutes.
 - (3) The temperature is increased to 200.0°C over 60 minutes.
 - (4) When the temperature reaches 200.0°C, this temperature is maintained for 30 minutes.
 - (5) The temperature is decreased to 50.0°C over 50 minutes.
 - (6) When the temperature reaches 50.0°C, this temperature is maintained for 30 minutes.
- Segment PID number and junction code are set for each segment.
PV event and time event are set after setting the program pattern.

Note

- Before creating program patterns, be sure to check the control PV input range and decimal place. Changing these after you create patterns will cause the values in the program patterns to be changed. (The patterns' range and scale ratios will be changed.)
- The time axis of each loop set in a program pattern will be the same.
- Each program pattern is assigned to a single loop. You cannot set the same loop number to a single program pattern.
- When you are creating a program, if you change the segment time to 00:00:00 in the middle and save it, the program pattern after this segment will be discarded.


Procedure

- 1 Click the Program pattern tab and then New.



- 2 Set system/PV range.


How to set system/PV range.: ▶ [“Setting PV Range of the Program Pattern” on page 5-8](#)




Note

- In the Program Pattern Setting, this “System/PV Range” is used as master settings. The master settings are the same for all program patterns (program pattern number 1-99). You cannot set individual master settings for each program pattern number.
 - Be sure to check control PV range and decimal place before creating a pattern. If they are changed during creation of a program pattern, it may cause the pattern to collapse.
 - If PV range is changed during creation of a program pattern, although it is not deleted and remains on the screen of the Program Pattern Setting, it may be corrected in accordance with the System/PV Range after the change. A message (W028) is displayed after correction.
- Related item: ▶ [“Example for the corrected pattern” on page 3-13](#)


- 3 Check "Use" on the program pattern number for use.
The pattern number is displayed in the tree.



- 4 Click **Pattern number**.
The setting items for the program pattern are displayed.




- 5 Click **Initial settings** and then **Pattern initial settings**.
Pattern initial settings and **Action loop** are displayed.



6 Configure settings as per the setting table.

Setting items	Description
Pattern name	Sample program
Number of loops used	1
Segment Add/Delete	L091 (Main unit, Slot 09, Loop 1)


7 Click **Program starting conditions**.
Starting target setpoint and **Other settings** are appears.



8 Configure settings as per the setting table.









Setting items	Menu (tree)	Description
Starting target setpoint	Initial settings > Program starting condition	50.0 °C
Start code	Initial settings > Program starting condition	Starting target setpoint

9 Click **Segment settings** and then **Program pattern setting**.



- Clicking the segment display selects the segment (background color turns blue) and the setting input field for the segment is displayed in the setting input section.
- The segment display can show only one segment at a time. You cannot choose more than one segment.
- The section for entering values can be edited using copy and paste.


Operation buttons on the segment setting screen

Buttons and Tooltips		Description
	Add	Adds a new segment after the last segment. The added segment takes over only the target setpoints for each loop that are set for the last segment. Initial values are used for other settings.
	Insert	Inserts a new segment in the location of the currently selected segment. The added segment takes over the settings of the last segment.
	Delete	Deletes the currently selected segment.
	Zoom in/out	Enlarges and shrinks the time axis.
	Display in linear time scale	The time axis changes to equal interval or actual time ratio.
	Target setpoint	Displays the target setpoint of the selected segment.
	Split display	Splits the pattern vertically.
	Loop display	Displays the pattern of the clicked loop number. Up to 20 loops can be displayed.

10 Set the setup items (i.e. Segment number, Target setpoint, Segment time) according to the following table.


Segment	Setup Item	Value
1	Target setpoint	100.0°C
	Segment time	00:50:00
	Segment PID number selection	1
	Junction code	Switching for continuation
2	Target setpoint	100.0°C
	Segment time	00:30:00
	Segment PID number selection	2
	Junction code	Switching for continuation
3	Target setpoint	200.0°C
	Segment time	01:00:00
	Segment PID number selection	3
	Junction code	Switching for continuation
4	Target setpoint	200.0°C
	Segment time	00:30:00
	Segment PID number selection	4
	Junction code	Switching for continuation
5	Target setpoint	50.0°C
	Segment time	00:50:00
	Segment PID number selection	3
	Junction code	Switching for continuation
6	Target setpoint	50.0°C
	Segment time	00:30:00
	Segment PID number selection	2
	Junction code	Switching for continuation

To add a segment, click **Add**



The basic pattern is created.

- 11 Set time event. Click **Time event settings**.
The setting screen in table format is displayed on the right side



Note When entering values in the table, you can easily do it by copying and pasting values. The editing operation can be done in the same way as the Hardware Configurator software.
Editing operation: ► **“Editing and Manipulating Values” on page 2-27**

- 12 Set the setup items according to the following table.

Segment	Time event	Setup item	Value
1	Time event 1	Start Condition	OFF start
		On time	00:25:00
		Off time	00:00:00
	Time event 2	Start Condition	OFF start
		On time	00:00:00
		Off time	00:00:00
2	Time event 1	Start Condition	OFF start
		On time	00:00:00
		Off time	00:00:00
	Time event 2	Start Condition	ON start
		On time	00:00:00
		Off time	00:00:00
3	Time event 1	Start Condition	ON start
		On time	00:00:00
		Off time	00:20:00
	Time event 2	Start Condition	OFF start
		On time	00:00:00
		Off time	00:00:00
4	Time event 1	Start Condition	OFF start
		On time	00:00:00
		Off time	00:00:00
	Time event 2	Start Condition	ON start
		On time	00:00:00
		Off time	00:00:00
5	Time event 1	Start Condition	ON start
		On time	00:00:00
		Off time	00:20:00
	Time event 2	Start Condition	OFF start
		On time	00:00:00
		Off time	00:00:00
6	Time event 1	Start Condition	OFF start
		On time	00:00:00
		Off time	00:00:00
	Time event 2	Start Condition	ON start
		On time	00:00:00
		Off time	00:00:00

13 You can also set PV event and event display group as necessary.

Segment	PV event	Setup item	Value
1	PV event 1	Loop number	Loop 1
		Type	DVH: Deviation high limit
		Value	5.0°C
2	PV event 1	Loop number	Loop 1
		Type	PVH: PV high limit
		Value	110.0°C
3	PV event 1	Loop number	Loop 1
		Type	DVH: Deviation high limit
		Value	5.0°C
4	PV event 1	Loop number	Loop 1
		Type	PVH: PV high limit
		Value	210.0°C
5	PV event 1	Loop number	Loop 1
		Type	DVL: Deviation low limit
		Value	-5.0°C
6	PV event 1	Loop number	Loop 1
		Type	PVL: PV low
		Value	10.0°C

Event display	Setup item	Value
1	Display	On
	Event type	PV event
	Event number	1
2	Display	On
	Event type	Time event
	Event number	1
3	Display	On
	Event type	Time event
	Event number	2

14 When the pattern is created, save the file by selecting **Save pattern files** under the **Program pattern** tab on the menu bar.
A folder is created and a program pattern file (*.GPT) is saved.

[Operation complete](#)

Note

For details of the setting items required for creating a program pattern and details of the control function, read the following user's manual.
"Model GX10/GX20/GP10/GP20/GM10 Loop Control Function, Program Control Function (/PG)
User's Manual (IM 04L51B01-31EN)"


5.5 Opening a Program Pattern File

This section describes operations required for expanding program pattern files (*.GPT) collectively by specifying a folder containing the program patterns on your PC. You can edit the patterns by setting any values for system/PV range regardless of the settings in the configuration file.

Opening a configuration file (GNL) containing program patterns on the Hardware Configurator: ► [Section 2.2.4 on page 2-19](#)


Procedure

- 1 Click the **Program pattern** tab and then **Open Pattern Files (Specification folder)**.




The **Open pattern files by specifying a folder.** dialog box appears.

- 2 Specify a folder ^(Note) and open program patterns contained in the folder.
Note: The folder is clicked and a line is selected.



Expand the program patterns in the folder and complete operation.
If there is any program pattern displayed on the screen, it is deleted, and System/PV Range is also replaced.



Operation complete

Note

- When program patterns are expanded on the screen, the system/PV range settings of the program pattern that is read first are used as new system/PV range settings.
- If there is a pattern in the selected folder that does not match System/PV Range, it is corrected to match them. After correction, the pattern number for the corrected pattern is notified by a message (W028). : ► [“Example for the corrected pattern” on page 3-13](#)


5.6 Saving a Program Pattern File

This section describes operations to save program pattern files (*.GPT) collectively by specifying a folder.

Saving a configuration file containing program patterns on the Hardware Configurator: ► [Section 2.4.2 on page 2-49](#)

Procedure

- 1 Click the **Program pattern** tab and the **Save Pattern Files (Specification folder)**.



- 2 Specify a saving location. Enter "Program pattern folder name", and click Save. The default value of the Program pattern folder name is ProgramPattern. Some characters cannot be entered for a folder name. (See Note)



A folder containing the program pattern file is saved.

[Operation complete](#)

Note

- If there is a program pattern folder with the same name in the saving location, an overwrite confirmation message (W005) appears. If you click Cancel, the folder is not overwritten.
- The following table shows the limitations of characters that can be entered for a program pattern folder name. If a character outside the range is entered, an error (E017) is shown, and the folder cannot be saved.

Limitations	Range
Number of characters	You can enter up to 32 characters.
Prohibited characters	/ Slash > < Inequality : Colon ? Question mark " Double quotation marks ' Single quotation marks \ Backslash * Asterisk Vertical bar (pipe) ; Semi-colon
Prohibited words	AUX, CON, PRN, NUL CLOCK\$, CLOCK COM0, COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9 LPT0, LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9
Other limitations	You cannot begin/end the name of folder with a space or a point. Additionally, a blank name is not available.
Path length	Up to 256 characters including the folder name.

5.7 Receiving and Sending Program Patterns

You can receive and send ^(Note) program patterns to/from the GX/GP/GM with the program control function (option, /PG) by connecting GX/GP/GM via communication.

Note: There are some limitations on sending patterns in the process of program control. See the description later.


5.7.1 Receiving Program Patterns

With the Program Pattern Setting, you can receive program patterns only. To receive settings at the same time, use the Hardware Configurator.

Receiving a configuration file containing program patterns on the Hardware Configurator ▶ [Section 3.1.5 on page 3-12](#)


Procedure

- 1 Click the **Program pattern** tab and the **Receive Pattern Settings**.



Communication dialog box appears.

- 2 Enter the communication information for connecting to the main unit.
See [“Explanation” on page 3-3](#) for the details.




Note

If the GX/GP/GM's Security settings - Basic settings - Communication is set to Login, you need to specify the user information. If set to Off, you only need to enter the communication information to establish a connection. For details on security settings, see the main unit user's manual (GX/GP: IM 04L51B01-01EN, GM: IM 04L55B01-01EN).

3

Click **OK**.

If the "Program control function (/PG)" of the connected main unit is enabled, the following message (W030) is displayed.




If the program control function (/PG) of the connected main unit is disabled (or it is not equipped with the option), an error (E021) is displayed.

4

Click **OK**.

The receipt of program patterns is completed.



Note

- If a program pattern is already displayed on the setting screen when a program pattern is received, the former program pattern is overwritten with the received program pattern.
- When program patterns are expanded on the screen, the system/PV range settings of the program pattern that is read first are used as new system/PV range settings.
- If there is a pattern in the selected folder that does not match System/PV Range, it is corrected to match them. After correction, the pattern number for the corrected pattern is notified by a message (W028).

Related item: ► ["Example for the corrected pattern" on page 3-13](#)

5.7.2 Sending Program Patterns

With the Program Pattern Setting, you can send program patterns only. To send settings at the same time, use the Hardware Configurator.


Sending a configuration file containing program patterns on the Hardware Configurator :▶
[“Sending a Program Pattern Configuration File \(GX/GP/GM with the Program Control Function\)” on page 3-14](#)

Before Sending Program Patterns

- You cannot send program patterns to pattern numbers in the process of program control on the main unit.
- When sending program patterns, even if pattern numbers that are not used (Off) in the “Program pattern file” screen on the software are sent to the main unit, they are not reflected. Patterns that are used on the main unit (On) are retained. (If patterns are sent from the Hardware Configurator, sending results are reflected on the main unit.)
- Before sending patterns, you can initialize program patterns that already exist in the main unit.: ▶ [“Deleting All Patterns” on page 5-26](#)


Procedure

- 1 Click the **Program pattern** tab and the **Send Pattern Settings**.



Communication dialog box appears.

- 2 Enter the communication information for connecting to the main unit.
 See [“Explanation” on page 3-3](#) for the details.



Note

If the GX/GP/GM's Security settings - Basic settings - Communication is set to Login, you need to specify the user information. If set to Off, you only need to enter the communication information to establish a connection.

- 3 Click **OK**.
 If the program control function (/PG) of the connected main unit is enabled, program patterns are sent.



Note

If the program control function (/PG) of the connected main unit is disabled (or it is not equipped with the option), an error (E021) is displayed.


Explanation

When using Send Pattern Settings from the Program Pattern Configurator, you can send patterns without limitations even when the main unit is Recording or Computing. However, when the main unit is Running control or Running program control, the following limitations apply.

- When the main unit is Running control
If the loop included in the pattern setting subject to sending is not associated with the pattern in process of program operation, it can be sent without limitations.
- When the main unit is in process of program operation
You cannot send program patterns to pattern numbers in the process of program control on the main unit. (You can send program patterns to pattern numbers that are not under program control.) You cannot change the status of patterns that are used (On) on the main unit to Not use (Off) from software. The pattern numbers that failed to be sent are shown by the following message (W011).


The message may be different depending on the sending condition. The following are examples.

- If a pattern under program control is included in the connected main unit (W026)



The first line of this message means that the pattern number not used on the program pattern file screen (Use Off) on software will not be reflected even if it is sent to the main unit. The second line means that the pattern is not sent because the pattern number is under program control.

- If a program pattern sent to the main unit could not be reflected because its System/PV Range did not match that of the main unit (W011).



The second line of this message means that the pattern could not be sent because the pattern number is under program control.

5.8 Controlling the Main Unit

You can operate GX/GP/GM with the program control function (option, /PG) from the Operation tab. The structure and functions of the Operation tab are almost the same as those of the Hardware Configurator software. A unique function of Program Pattern Setting is "Delete All Patterns".



5.8.1 Starting and Stopping Recording/Computing

You can start and stop recording or computing on the main unit via communication. The operation method is the same as the Hardware Configurator. Read the following sections.

► [3.2.1 Starting and Stopping Recording and Computing](#)

5.8.2 Starting and Stopping Control

You can operate the control of the main unit. The operation method is the same as the Hardware Configurator. Read the following sections.

► [3.2.4 Starting/Stopping Control \(GX/GP/GM with the PID control module\)](#)

5.8.3 Starting and Stopping Program Control

You can start and stop program control on the main unit. The operation method is the same as the Hardware Configurator. Read the following sections.

► [3.2.5 Starting/Stopping Program Control \(GX/GP/GM with the Program Control Function\)](#)

5.8.4 Viewing the Hardware Information

You can retrieve the hardware information from the main unit. The operation method is the same as the Hardware Configurator. Read the following sections.

► [3.2.2 Viewing the Hardware Information](#)

5.8.5 Performing Reconfiguration (GM only)

You can reconfigure the GM from this software. The operation method is the same as the Hardware Configurator. Read the following sections.

► [3.2.3 Performing Reconfiguration \(When the connected device is a GM\)](#)

5.8.6 Deleting All Patterns

This section describes operations for initializing all program patterns by connecting with GX/GP/GM with the program control function (option, /PG) from the Program Pattern Setting via communication. By deleting all program patterns with this function, you can “Send Pattern Settings” while the main unit is in a clean slate.


Procedure

- 1 Click the **Program pattern** tab and the **Delete All Patterns**.



Communication dialog box appears.


- 2 Enter the communication information for connecting to the main unit.
See “[Explanation](#)” on page 3-3 for the details.



Note

If the GX/GP/GM's Security settings - Basic settings - Communication is set to Login, you need to specify the user information. If set to Off, you only need to enter the communication information to establish a connection.

- 3 Click **OK**.
If the program control function (/PG) of the connected main unit is enabled and all program controls are stopped, the following dialog box appears.



- 4 Click **OK** to delete all program patterns.
All program patterns (pattern number 1-99) loaded on the main unit are deleted.

Operation complete

6.1 Errors and Messages

Message

Code	Message	Description and Corrective Action
None	The current password has expired. Input the new password.	This message appears if the password has not been changed from its default value or if the password has expired. To continue operation, change the password.
M001	Save changes to xxx?	File name confirmation.
M002	Receiving finished.	Reception completed successfully.
M003	Sending finished.	Transmission completed successfully.
M004	Recording started.	The recorder started recording.
M005	Recording stopped.	The recorder stopped recording.
M006	Computing started.	The recorder started computing.
M007	Computing stopped.	The recorder stopped computing.
M008	Completed Reconfiguration.	Main unit reconfiguration completed successfully.
M008 Auxiliary Messages	Refer to the Hardware Info.	You can view the results (current hardware information) of reconfiguration performed according to 3.2.2 Viewing the Hardware Information .
M009	Control started.	The main unit started control operation.
M010	Control stopped.	The main unit stopped control operation.
M011	Program control started.	The main unit started program control operation.
M012	Program control reset.	The main unit stopped program control operation.
M013	[ProgramPattern] folder exists in the same directory.	This message appears if there is a folder whose name is the same as the pattern file folder (ProgramPattern) on the same directory on your PC.
M014	Executed successfully.	This message appears when processing is normally performed.

Warning Messages

Code	Message	Description and Corrective Action
No code	Input value is invalid. It is returned before the change.	An invalid value may have been entered in a setup item. Check the settings below. • User name of user registration (when a duplicate user name is entered)
W001	Receive settings from connecting hardware.	Reception confirmation. To continue, click OK . To cancel, click Cancel .
W002	Send settings to connecting hardware. If user level is not "Admin", some settings can not be set on the device.	Transmission confirmation. To continue, click OK . To cancel, click Cancel .
W002 Auxiliary Messages	The hardware will delete unused pattern number.	This message appears when a user attempts to send settings from setting software on which the program pattern setting function is enabled to GX/GP/GM on which the PID control module and program control function are enabled.
W003	Hardware and software configurations don't match. Continue sending data?	Transmission confirmation. To continue, click OK . To cancel, click Cancel .
W004	System configuration has been changed. The input configuration and data will be initialized. Continue?	If you change the system configuration, the displayed setup data will be initialized. To continue changing, click OK . To cancel, click Cancel .
W005	Overwrite the file?	Confirmation for overwriting a file with the same name. To continue, click OK . To cancel, click Cancel .
W005 Auxiliary Messages	• File Name: • Program pattern folder name	This message appears only when a user attempts to save both the settings and program patterns. • File name: Displayed if a configuration file name is subject to be overwritten. • Program pattern folder name: Displayed if a program pattern folder name is subject to be overwritten.
W006	Start recording.	Recording start confirmation. To continue, click OK . To cancel, click Cancel .
W007	Stop recording.	Recording stop confirmation. To continue, click OK . To cancel, click Cancel .
W008	Start computing.	Computing start confirmation. To continue, click OK . To cancel, click Cancel .
W009	Stop computing.	Computing stop confirmation. To continue, click OK . To cancel, click Cancel .
W010	Initialize current settings.	Initialization confirmation. To continue, click OK . To cancel, click Cancel .

6.1 Errors and Messages

Code	Message	Description and Corrective Action
W011	Failed to store any settings.	Some of the setup data have not been applied to the recorder due to differences in the system configuration. Check the system settings.
W011 Auxiliary Messages	<ul style="list-style-type: none"> • Pattern number xx • Pattern number xx 	The program pattern numbers that could not be sent to the main unit and those running on the main unit are displayed.
W012	Number of channels is over the maximum value.	The module configuration setting exceeds the maximum number of channels. Check the modules and the maximum number of channels, and reconfigure.
W013	Failed to set any settings.	Some of the setup data have not been applied to the software. Check the system configuration or user level.
W014	Permission denied.	You do not have permission to send settings. Increase the user level, or grant permissions to allow it.
W015	All extended units settings will be discarded. OK?	This message appears when in system configuration, an IO expansion module of the GX/GP is changed from specified to not specified. To proceed with the change, click OK.
W016	Exceed the module limit.	In the system configuration, the unit and module configuration or the number of channels is exceeding the upper limit. Check the number of modules or channels specified by the auxiliary message, which is described in a separate table.
Refer to the following table for the auxiliary messages of W016.		
W017	Reconfigure modules ?	This message appears when you try to perform reconfiguration.
W018	Chattering filter may not function. Please update module to R1.04.01 or later.	This message appears in the pulse input setting of the GX/GP with DI module. The module version R1.04.01 or later is the supported version for the pulse input. Check the version of DI module on a GX/GP.
W019	Layout may be displayed incorrectly in case of zoom is not 100%.	If this message appears when you start the software, click OK. Then, on the View menu of IE, click Zoom (or Change the zoom level at the lower right of the window) to select 100%. Press F5 key or restart the software to refresh the screen.
W020	Run control.	A confirmation message for starting loop control. You can start control operation on the main unit by choosing a loop number or "Run all control loops". Select OK to start, and Cancel to cancel operation.
W021	Stop control.	A confirmation message for stopping loop control. You can stop control operation on the main unit by choosing a loop number.
W022	Run program control.	A confirmation message for starting program control. You can start program control on the main unit by choosing a program pattern number.
W023	Reset program control.	A confirmation message for stopping program control. Displays the pattern number under program control. Click OK to stop program control.
W024	Are you sure you want to clear the pattern settings in this pattern no?	Displayed when the existing pattern is deleted and a new pattern is read.
W025	Receive program pattern settings.	A confirmation message for receiving program patterns. You can receive a program pattern on the main unit by choosing program pattern numbers.
W026	Send program pattern settings.	A confirmation message for receiving program patterns. You can send program pattern control on the main unit by choosing program pattern numbers.
W026 Auxiliary Messages	The hardware will maintain unused pattern number.	Displayed when program patterns are sent to the main unit. Pattern settings are not sent to "pattern numbers under program control" that are shown in this message.
W027	Initialize program pattern settings.	A confirmation message for initializing a program pattern file. Click OK to continue and Cancel to cancel operation.
W027 Auxiliary Messages	<ul style="list-style-type: none"> • Pattern number xx 	Displays the pattern numbers to be initialized.
W028	Program pattern settings has been adjusted.	Displayed when a program pattern is corrected by operations such as changes to system configuration or PV range.

Code	Message	Description and Corrective Action
W028 Auxiliary Messages	• Pattern number xx	Displays the corrected pattern number.
W029	The hardware will delete all program patterns.	Click OK to delete all program patterns loaded in the main unit.
W030	Receive program pattern settings.	Click OK to receive program patterns from the main unit.
W030 Auxiliary Messages	• All of current program pattern settings will be cleared. • System/PV range settings of the program pattern will be applied.	The system/PV range settings of currently loaded program patterns are all deleted and changed.
W031	Configure one or more PID control modules.	Displayed if the user attempts to set PV range while a PID control module is not attached to the main unit.
W032	Duplicated loop number.	Displayed if the user attempts to set a loop number that is already set for another loop. The value that the user attempted to change returns to the original value.
W033	Exceeded maximum PID group number.	If you specify a value exceeding the minimum number of PID groups when choosing the segment PID number on the Program Pattern Setting, this message is displayed as a warning.
W034	If segment time is set to 0, this segment will be deleted.	A confirmation message for deleting a segment. Click OK to delete a segment for which 0:0:0 is entered for Segment time. If it is canceled, segment time does not change to 0, and it returns to the original value.
W034 Auxiliary Messages	• All subsequent segments will be also deleted.	If there is a segment after "Segment for which 0:0:0 is set for Segment time", this auxiliary message is displayed.
W035	System configuration has been changed.	Displayed if the user changes system configuration and proceeds to PV range settings on the Program Pattern Setting. Even if system configuration is changed, pattern setting is not initialized.
W036	Reconfigure pattern data related to control loops (Starting target setpoint, wait settings, and segment settings)	Displayed if the loop number of an action loop is changed in "Pattern initial settings" of the Program Pattern Setting.

W016 Auxiliary Messages

Depending on the condition, warning W016 is accompanied by an auxiliary message from the following table. (The number shown in the No. column is not displayed.) For module limitations, also refer to "Module Configuration Limitations" on page 2-8 of this document.

No.	Message	Description and Corrective Action
1	Exceeded the number of IO modules which can be set.	The total number of IO modules installed in the entire system (Main unit tab and Extended Unit tab) exceeds the upper limit. Check the number of IO modules specified under Module. • GX/GP10, GX/GP20-1, GM10-1: Up to 10 • GM10-1: Up to 42 • GX/GP20-2, GM10-2: Up to 45
2	Exceeded the number of DO modules which can be set.	The total number of DO/DIO modules installed in the entire system (Main unit tab and Extended Unit tab) exceeds the upper limit. Check the number of DO/DIO modules specified under Module. Up to 10 DI/DIO modules are allowed in the system. This limitation counts the PID control module as a DO module.
3	Exceeded the number of IO channels which can be set.	The total number of channels of the IO modules installed in the entire system (Main unit tab and Extended Unit tab) exceeds the upper limit. Check the number of channels of IO modules specified under Module. For GX/GP10, GX/GP20-1, and GM10-1, up to 100 channels can be set in the entire system. For GX/GP20-2 and GM10-2, up to 500 channels can be set in the entire system.
4	Exceeded the number of IO expansion modules which can be set.	This message appears in relation to GM module settings. There are multiple IO expansion modules selected under Module on the Main unit tab. Set only a single IO expansion module in the range ID = 0 to 6. Or, under Module on the Main unit tab, there is a module selected after the IO expansion module. Other modules cannot be set after the IO expansion module.

6.1 Errors and Messages

No.	Message	Description and Corrective Action
5	Exceeded the number of EMR modules which can be set.	This message appears in relation to GM module settings. There are 9 or 10 IO modules including an EMR module selected under Module on the Main unit tab. When an EMR is installed, only up to eight IO modules (including the EMR) can be installed.
6	Exceeded the number of DIO modules which can be set.	In the entire system (Main unit tab and Extended Unit tab), there is a unit in which multiple DIO modules are installed. Check the number of DIO modules in each unit.
7	Exceeded the number of AO modules which can be set.	The total number of AO modules attached in the entire system (Main unit tab and Extended Unit tab) exceeds the upper limit. Check the number of AO modules selected in Module.
8	Exceeded the number of High-speed AI modules which can be set.	The total number of attached high speed AI modules exceeds the upper limit. The limit value varies by the model or combination with the AO module. Check the number of modules selected in Module.
9	Exceeded the number of PID control modules which can be set.	The total number of PID control modules attached in the entire system (Main unit tab and Extended Unit tab) exceeds the upper limit. Check the number of PID control modules selected in Module.
10	System includes unavailable modules when Advanced security function is On.	If the advanced security function is enabled, a PID control module cannot be used. Set the advanced security function to disabled, or change the setting of the PID control module to Not use.
11	System includes unavailable modules when Measurement mode is High speed.	When High speed is selected in Measurement mode, modules other than the high speed AI module and DI/DIO modules cannot be used. As the I/O expansion module also cannot be used, extended unit configuration is not available in high speed mode.
12	Exceeded the number of DI modules which can be set.	Only one DI module can be used when High speed is selected in Measurement mode.
13	System includes unavailable modules when Measurement mode is Dual interval.	When "Dual interval" is selected in Measurement mode, the PID control module cannot be used.

Error Messages

Code	Message	Description and Corrective Action
E001	Communication error occurred.	Communication error occurred with the recorder. Check communication parameters (such as IP addresses and port numbers), network cables, and settings on the recorder. Moreover, if the version of the Hardware configurator is old, and the firmware version of the main unit is not supported, E001 occurs. Check the versions and update if it is old. You can download the latest version from the Help - Web to update .
E002	Failed to save the file.	Failed to save the file. Check the folder and file properties.
E003	Failed to read the file.	Cannot open the file. Check the file name.
E003 Auxiliary Message 1	• No pattern	There are no program pattern files in the specified folder.
E003 Auxiliary Message 2	• Configuration file Rx.xx.xx	The version of the configuration file read by selecting Retrieve system/PV range from configuration file in System/PV Range dialog of the Program Pattern Setting does not support this feature. (The version of the configuration file with which the user attempted to read system/PV range settings on the Program Pattern Setting is below R4).
E004	Internet Explorer is not installed.	Internet Explorer is not installed. Install Internet Explorer.
E005	Now recording. Can't store settings.	Execution is not possible during recording. Try again after stopping the recording.
E006	Now computing. Can't store settings.	Execution is not possible during computing. Try again after stopping the computation.
E007	The file is read-only.	Attempting to save to a read-only file. Make the file writable, or save to a different file.
E008	Access to the file is denied.	Check the access privileges to the file. Check whether the file system limit has been exceeded.
E009	The disk is full.	Check the free space in the save destination.
E010	The directory is full.	Check the number of files in the save destination.

Code	Message	Description and Corrective Action
E011	The file is invalid.	A file format error. Likewise, E011 occurs if the version of the Hardware Configurator is old and does not support the firmware version of the main unit. The latest version of this software can be downloaded by selecting the Help tab and then Web to update.
E012	Sharing violation occurred.	The file is already opened in another application. Close the file.
E013	Error occurred.	An error other than those above (001 to 012) occurred.
E014	The directory does not exist.	The directory may have been deleted.
E015	PDF file reader is not installed.	Install Adobe Reader.
E016	The directory already exists.	Check whether the path and folder name have been specified correctly.
E017	Bad file path is specified.	The file path length has exceeded the limit (256 characters), or an invalid character has been used. Shorten the file path, or correct the file name.
E017 Auxiliary Message	Program pattern folder name	The program folder name exceeds the character limits of E017 (described above) or an unusable character is used.
E018	Failed to open program files.	This error occurs when a browser other than the browser started by this software was used to access the software, or Internet Explorer was refreshed consecutively. Close all browsers, and restart Hardware Configurator.
E019	Please delete temporary internet files from the browser, close the browser and restart the application.	This error occurs when temporary internet files affect the software. Delete temporary files in Internet Explorer, then restart Hardware Configurator.
E020	Login inputs are incorrect.	Enter a valid user name and password in the communication condition dialog box. Enter the User ID only on devices whose /AS function is enabled. There is no need to enter it on devices whose /AS function is disabled or those that do not have the function. If the GX/GP firmware version is R1.xx.xx, this message appears when the user logged in changes his or her own user information and sends it or when the user sends setup data that changes the "Security setting > basic settings > communication" setting on the GX/GP from Off to Login. In these cases, resend the command with the new valid user name and password.
E021	This function is not possible at this time.	The following conditions may be causing the message to be displayed. • The main unit does not have the optional function required for the operation. • The main unit is sending or receiving settings or is in a condition in which the operation cannot be executed (e.g., recording, computation, or control in progress). (Operation limitations depending on the main unit conditions: page 3-23) • The GX/GP advanced security function is enabled, the Touch operation is set to Login, and communication is set to Off. • The user does not have permission to perform the main unit operation.
E022	Failed to open due to difference in system configuration.	You are trying to use Read comparison source to open a file whose system configuration is different from the settings that are currently displayed. Differences can be shown only when the system configurations match. Select a file whose system configuration matches the settings that are currently displayed.
E023	Failed to overwrite due to advanced security file.	An advanced security file with the same name already exists. Save to a different name, or delete the file first before saving.
E024	Cannot execute. Hardware reconfiguration in progress.	Sending and receiving settings and operating the main unit are not possible on a GM that is reconfiguring.

6.1 Errors and Messages

Code	Message	Description and Corrective Action
E025	This operation is not permitted in this mode.	<p>Sending and receiving settings and operating the main unit are not possible when the main unit is in a mode that does not allow normal operation (such as A/D calibration, Encryption, and Update.) Wait until the main unit returns to normal operation mode.</p> <p>If you need to force the main unit back to normal operation mode, follow the procedure below.</p> <p>However, note that if another user is operating through the Web application, for example, the operation results may be disposed because the operation will be terminated.</p> <ul style="list-style-type: none"> •If a Web connection can be established with the main unit, return the main unit to normal operation mode using the Web application. •If a Web connection cannot be established with the main unit, restart the main unit. (Start in normal operation mode.)
E026	Cannot execute to GX/GP.	Reconfigure a GX/GP from the main unit screen.
E027	Now running control. This function cannot be executed at this time.	On the Hardware Configurator software, when the main unit is under control operation (at least one loop is in RUN status), settings cannot be sent.
E028	Now running program control. This function cannot be executed at this time.	On the Hardware Configurator software, when the main unit is under program control operation (at least one pattern is under program control), settings cannot be sent.
E029	Failed to send program pattern settings.	The sent program pattern setting does not match the current setting of the main unit. The location of the PID control module, decimal place, lower limit, or upper limit of PV range set on the main unit is different from the settings.
E029 Auxiliary Message	<ul style="list-style-type: none"> • Check PID module position, PV range settings. • Pattern number xx 	An auxiliary message for E029. Displays the (software) pattern number that failed to be sent and is not reflected on the main unit.
E030	The input numerical value exceeds the set range.	In Dual interval measurement mode, the limited number of channels that can be set to measurement group 1 with a measurement interval of 50ms or below on the report channel setting screen is exceeded.

Index

A

Admin 3-1
advanced security function 2-13, 2-48, 59, 3-1, 3-18, 4-1, 6-5
Aerospace heat treatment 2-3, 3-18

B

Basic Config 2-2
Bluetooth 3-4

C

calculation expressions 2-27, 2-33
calibration correction 2-31
Change all 2-46
Channel selection button 2-27
Channel selection string 2-27
Check box sheet type 2-44
Closing software 1-12
Color selection 2-27, 2-28
comparison source file 2-14, 57
COM port 3-4
connect 3-1
Content area 1-6
Content selection tree 1-6
Controlling main unit 3-16
Copy and Paste buttons 1-6, 1-7
Copying and Pasting 2-38

D

Data selection 2-27
date format 1-11
decimal point type 1-11
default password 3-3
dialog boxes 2-27
display language 1-11
display setup data files 2-12

E

Ethernet communication 3-3
expression 2-27, 2-32, 2-33, 2-34, 2-35
Extended Unit 2-6, 2-8, 2-9, 6-3, 6-4

F

File Name Display 1-6
firmware version v, 2-3, 3-6, 3-8, 3-19, 6-5

H

Hardware information 3-17

I

icon 3-19
Icon 2-46
Increment 2-45, 2-46
Initialize 2-46
Initializing setup data 52
input controls 2-27

J

Jump Function 2-25
Jump Navigation Button 1-7

L

Limitation 2-8, 2-10, 2-44, 3-1, 3-23
List type 2-44
Load Changed Settings v, 1-5, 2-17, 2-18
Login 2-36, 3-1, 3-6, 3-8, 3-11, 4-1, 6-5

M

Mathematical function 3-18
Maximize 2-46
Minimize 2-46
module 2-5, 3-18
Module configuration limitations 2-8
Multi-batch function v, 2-3, 3-18

N

New file 1-6

O

OPC-UA server v, 2-3, 3-18

P

Password 54, 60, 3-3, 3-9, 4-1, 4-5
password management function 4-1
Port No. 1-6, 1-12, 3-3
Printing 53
Print Options 53
Program Pattern Setting 1-1, 5-1
PV Range 3-13, 5-8

R

Receive Settings 1-5, 3-2, 3-12, 3-14, 3-23, 4-2
Reconfiguration 1-6, 3-1, 3-20, 5-25, 6-1
Running multiple instances 1-10

S

save 2-47
Security measures 1-4
Security setting 2-13, 2-36, 3-1, 3-8, 3-10, 4-1, 4-6, 6-5
Sending and Receiving 1-1, 3-1
Send Settings 1-5, 3-6, 3-23, 4-2
Serial communication 3-3
SLMP communication v, 2-3, 3-18
Software License Agreement ii
Split bar 1-6
Start computing 3-16
Starting the software 1-9
Start recording 3-16
Stop computing 3-16
Stop recording 3-16
System config 1-6

T

Table type 2-44
Tool buttons 1-7, 2-45

U

USB 2-3, 3-4, 3-5, 3-18
User Authentication 4-4
User ID 54, 60, 3-3, 4-5

Index

User registration 2-36

V

validation 1-1
validation print2-14, 2-15, 2-21, 57