

**WT1801R, WT1802R, WT1803R,
WT1804R, WT1805R, WT1806R**

Precision Power Analyzer

U S E R ' S M A N U A L

Thank you for purchasing the WT1801R, WT1802R, WT1803R, WT1804R, WT1805R, or WT1806R Precision Power Analyzer. This User's Manual explains how to use the instrument. To ensure correct use, please read this manual thoroughly before beginning operation. After reading this manual, keep it in a safe place. The manuals for this instrument are listed on the next page. Please read all manuals.

Contact information of Yokogawa offices worldwide is provided on the following sheet.

Document No.	Description
PIM 113-01Z2	List of worldwide contacts

Notes

- The contents of this manual are subject to change without prior notice as a result of improvements to the product's performance and functionality. Refer to our website to view our latest manuals.
- The figures given in this manual may differ from those that actually appear on your screen.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without the permission of YOKOGAWA is strictly prohibited.
- The TCP/IP software of this product and the documents concerning it have been developed/created by YOKOGAWA based on the BSD Networking Software, Release 1 that has been licensed from the Regents of the University of California.

Trademarks

- Microsoft, MS-DOS, Windows, Windows 10, and Windows 11 are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are either registered trademarks or trademarks of Adobe Systems Incorporated.
- Modbus is a registered trademark of Schneider Electric USA, Inc.
- In this manual, the ® and TM symbols do not accompany their respective registered trademark or trademark names.
- Other company and product names are registered trademarks or trademarks of their respective holders.

Revisions

- 1st Edition: October 2024

Manuals

The following manuals, including this one, are provided as manuals for this instrument. Please read all manuals.

Manuals included with the product

Manual Title	Manual No.	Description
WT1801R, WT1802R, WT1803R, WT1804R, WT1805R, WT1806R Precision Power Analyzer Getting Started Guide	IM WT1801R-03EN	This guide explains the handling precautions and basic operations of this instrument.
WT1801R, WT1802R, WT1803R, WT1804R, WT1805R, WT1806R Precision Power Analyzer Request to Download Manuals	IM WT1801R-73Z2	Describes the manuals provided on the website.
WT1801R, WT1802R, WT1803R, WT1804R, WT1805R, WT1806R Precision Power Analyzer	IM WT1801R-92Z1	Document for China
Safety Instruction Manual	IM 00C01C01-01Z1	Safety manual (European languages)

Manuals provided on the website

Download the following manuals from the YOKOGAWA website.

Manual Title	Manual No.	Description
WT1801R, WT1802R, WT1803R, WT1804R, WT1805R, WT1806R Precision Power Analyzer Features Guide	IM WT1801R-01EN	Explains all the instrument's features other than the communication interface features.
WT1801R, WT1802R, WT1803R, WT1804R, WT1805R, WT1806R Precision Power Analyzer User's Manual	IM WT1801R-02EN	This document. Explains how to operate this instrument.
WT1801R, WT1802R, WT1803R, WT1804R, WT1805R, WT1806R Precision Power Analyzer Communication Interface User's Manual	IM WT1801R-17EN	Explains the functions of this instrument's communication interface, how to configure it, and the commands used to control this instrument from a PC through the interface.

For details on downloading manuals, see Request to Download Manuals (IM WT1801R-73Z2). To view the PDF data, you need Adobe Acrobat Reader or a software application that can open PDF data.

The "EN," "E," "Z1," and "Z2" in the manual numbers are the language codes.

Conventions Used in This Manual

Notes and cautions

The notes and cautions in this manual are categorized using the following symbols.



Improper handling or use can lead to injury to the user or damage to the instrument. This symbol appears on the instrument to indicate that the user must refer to the user's manual for special instructions. The same symbol appears in the corresponding place in the user's manual to identify those instructions. In the manual, the symbol is used in conjunction with the word "WARNING" or "CAUTION."

WARNING

Calls attention to actions or conditions that could cause serious or fatal injury to the user, and precautions that can be taken to prevent such occurrences.

CAUTION

Calls attention to actions or conditions that could cause light injury to the user or cause damage to the instrument or user's data, and precautions that can be taken to prevent such occurrences.

French

AVERTISSEMENT

Attire l'attention sur des gestes ou des conditions susceptibles de provoquer des blessures graves (voire mortelles), et sur les précautions de sécurité pouvant prévenir de tels accidents.

ATTENTION

Attire l'attention sur des gestes ou des conditions susceptibles de provoquer des blessures légères ou d'endommager l'instrument ou les données de l'utilisateur, et sur les précautions de sécurité susceptibles de prévenir de tels accidents.

Note

Calls attention to information that is important for proper operation of the instrument.

Unit

k	Denotes 1000. Example: 100 kHz
K	Denotes 1024. Example: 720 KB (file size)

Contents

Manuals	ii
Conventions Used in This Manual	iii

Chapter 1 Common Operations

1.1	Key Operation and Functions.....	1-1
1.2	Entering Values and Strings.....	1-4
1.3	Using USB keyboards and mouse devices and Setting the USB Keyboard Language	1-6
1.4	Setting the Message and Menu Languages.....	1-12
1.5	Synchronizing the Clock.....	1-14
1.6	Initializing the Settings	1-16
1.7	Displaying Help	1-17

Chapter 2 Basic Measurement Conditions

2.1	Configuring the Wiring System Settings.....	2-1
2.2	Setting the Voltage and Current Ranges.....	2-2
2.3	Setting the External Current Sensor Range (option).....	2-4
2.4	Setting the External Current Sensor Conversion Ratio (option).....	2-6
2.5	Setting the Display Format of the External Current Sensor Range (option)	2-7
2.6	Setting the scaling feature when using a VT or CT	2-8
2.7	Setting the Valid Measurement Range.....	2-11
2.8	Setting the Efficiency Formula	2-15
2.9	Turning the Independent Input Element Configuration On and Off	2-16
2.10	Setting the Delta Calculation.....	2-17
2.11	Setting the Crest Factor	2-18
2.12	Setting Measurement Periods.....	2-19
2.13	Setting Line Filters	2-20
2.14	Setting Frequency Filters	2-21
2.15	Setting the Data Update Interval	2-22
2.16	Setting Averaging	2-23
2.17	Displaying the Menu for Configuring All Elements	2-24
2.18	Viewing Setup Parameters.....	2-25

Chapter 3 Harmonic Measurement Conditions (option)

3.1	Setting Harmonic Measurement Conditions.....	3-1
-----	--	-----

Chapter 4 Motor Evaluation Conditions (option)

4.1	Setting Motor Evaluation Conditions.....	4-1
-----	--	-----

Chapter 5 Auxiliary Input Conditions (option)

5.1	Setting Auxiliary Input Conditions.....	5-1
-----	---	-----

Chapter 6 Holding Measured Values and Performing Single Measurements

6.1	Holding Measured Values	6-1
6.2	Performing Single Measurements.....	6-1

Chapter 7	Power Measurement (numeric data display)	
7.1	Setting the Display Format.....	7-1
7.2	Switching the Displayed Page.....	7-2
7.3	Changing the Displayed Items on the 4 Items, 8 Items, and 16 Items Displays	7-4
7.4	Changing the Displayed Items on the Matrix Display.....	7-6
7.5	Changing the All Items Display	7-9
7.6	Changing the harmonics list display (option)	7-10
7.7	Setting the Custom Display.....	7-12
Chapter 8	Computation	
8.1	Setting User-Defined Functions	8-1
8.2	Setting User-Defined Events.....	8-2
8.3	Setting Apparent Power, Reactive Power, and Corrected Power Formulas.....	8-3
8.4	Setting the Sampling Frequency	8-4
8.5	Setting the Phase Difference Display Format	8-5
8.6	Setting Master and Slave Synchronous Measurement	8-6
8.7	Setting the Voltages or Currents Whose Frequencies Will Be Measured	8-6
Chapter 9	Integrated Power (watt hours)	
9.1	Setting Independent Integration	9-1
9.2	Setting Integration Conditions	9-2
9.3	Starting, Stopping, and Resetting Integration.....	9-5
9.4	Setting the Integration Resume Action at Power Failure Recovery	9-6
Chapter 10	Waveform Display	
10.1	Setting the Display Format.....	10-1
10.2	Turning the Display of Waveforms On and Off and Setting the Vertical Zoom Factors and Vertical Positions.....	10-4
Chapter 11	Trend Display	
11.1	Setting the Display Format.....	11-1
11.2	Turning the Trend Display On and Off and Setting the Measurement Functions to Display and the Vertical Scales.....	11-3
Chapter 12	Bar Graph Display (Option)	
12.1	Setting the Display Format.....	12-1
12.2	Setting the Measurement Function to Display and the Vertical Scale.....	12-2
Chapter 13	Vector Display (Option)	
13.1	Setting the Display Format.....	13-1
13.2	Setting the Element and Wiring Unit to Display and the Zoom Factor	13-2
Chapter 14	Split Display	
14.1	Configuring the Split Display	14-1
Chapter 15	Cursor Measurement	
15.1	Performing Cursor Measurements on Waveforms	15-1
15.2	Performing Cursor Measurements on Trends	15-2
15.3	Performing Cursor Measurements on Bar Graphs.....	15-3

Chapter 16 High Speed Data Capturing

16.1	Setting the Number of Data Captures and Configuring the Capture Control Settings .	16-1
16.2	Configuring the Save Conditions of Captured Numeric Data	16-5
16.3	Changing the Displayed Items for High Speed Data Capturing	16-8
16.4	Starting and Stopping High Speed Data Capturing.....	16-11

Chapter 17 Storing Data

17.1	Configuring Storage Control.....	17-1
17.2	Setting the Numeric Data Items to Store.....	17-5
17.3	Configuring the Save Conditions of Stored Numeric Data	17-6
17.4	Starting, Stopping, and Resetting Storage.....	17-8

Chapter 18 Saving and Loading Data

18.1	Connecting USB Memory Devices	18-1
18.2	Saving Setup Data	18-3
18.3	Saving Waveform Display Data.....	18-5
18.4	Saving Numeric Data	18-6
18.5	Loading Setup Data	18-8
18.6	File Operations	18-9

Chapter 19 Saving Screen Images

19.1	Saving Screen Images	19-1
------	----------------------------	------

Chapter 20 Ethernet Communication

20.1	Connecting the Instrument to a Network.....	20-1
20.2	Configuring the TCP/IP Settings	20-3
20.3	Accessing the Instrument from a PC (FTP Server).....	20-4
20.4	Monitoring the Instrument's Display from a PC (Web Server).....	20-5
20.5	Connecting to a Network Drive	20-7
20.6	Using SNTP to Set the Date and Time.....	20-8

Chapter 21 Other Features

21.1	Viewing System Information (Overview)	21-1
21.2	Setting the Screen Brightness and Configuring the Display Color Settings.....	21-2
21.3	Configuring the Environment Settings.....	21-3
21.4	Configuring D/A Output Items (Option)	21-4
21.5	Carrying Out Self-Tests	21-5
21.6	Performing Zero-Level Compensation	21-6
21.7	Using the NULL Feature.....	21-7
21.8	Locking the Keys.....	21-8

Appendix

Appendix 1	
Messages and Corrective Actions.....	App-1


Index

1.1 Key Operation and Functions

Key operation

How to use setup menus that appear when keys are pressed

The operation after you press a key varies depending on the key that you press.



A: Press the soft key to use the cursor keys to configure this setting. Use the cursor keys to set the value or select an item.

B: A related setup menu appears when you press the soft key.

C: The selected setting switches each time you press the soft key.

D: A dialog box or the keyboard appears when you press the soft key. Use the cursor keys and the SET key to configure the settings.

E: Press the soft key to display a selection menu. Press the soft key that corresponds to the appropriate setting.

F: Press the soft key to use the cursor keys to configure this setting. After you configure the setting, the status of the selected setting switches each time you press the soft key.

G: Press the soft key to execute the specified feature.

H: Press the soft key to apply the value assigned to the key.

How to display the setup menus that are written in purple below the keys

In the explanations in this manual, "SHIFT+key name (written in purple)" is used to indicate the following operation.

1. Press **SHIFT**. The SHIFT key lights to indicate that the keys are shifted. Now you can select the setup menus written in purple below the keys.
2. Press the key that you want to display the setup menu of.

ESC key operation

If you press **ESC** when a setup menu or available options are displayed, the screen returns to the menu level above the current one. If you press **ESC** when the highest level menu is displayed, the setup menu disappears.

RESET key operation

If you press **RESET** when you are using the cursor keys to set a value or select an item, the setting is reset to its default value (depending on the operating state of the instrument, the setting may not be reset).

SET key operation

The operation varies as indicated below depending on what you are setting.

- For a soft key menu that has two values that you use the cursor keys to adjust
Press **SET** to switch the value that the cursor keys adjust.
- For a menu that has the cursor keys + SET mark (◀+▶) displayed on it
Press **SET** to confirm the selected item.

Cursor keys operations

The operation varies as indicated below depending on what you are setting.

- When setting a value
 - Up and down cursor keys: Increases and decreases the value
 - Left and right cursor keys: Changes which digit to set
- When selecting the item to set
 - Up and down cursor keys: Moves the cursor between settings

How to enter values in setup dialog boxes

1. Use the keys to display the appropriate setup dialog box.
2. Use the cursor keys to move the cursor to the item that you want to set.
3. Press **SET**. The operation varies as indicated below depending on what you are setting.
 - A selection menu appears.
 - A check box is selected or cleared.
 - An item is selected.
 - A table of settings is selected.

Displaying a selection menu and selecting an item

Select OFF or ON.

Displays the selection menu

After selecting an item with the cursor keys, press SET to confirm it.

Setting items in a table

After moving the cursor to the table, press SET to select the setting that you want to change.

Use the cursor keys and the SET key to select a table entry.

How to clear setup dialog boxes

Press **ESC**. The setup dialog box is cleared from the screen.

1.2 Entering Values and Strings

Entering values

Using the cursor keys

Select the appropriate item using the soft keys, and change the value using the cursor keys and the SET key. This manual sometimes describes this operation simply as “using the cursor keys.”



Note

Some items that you can set using the cursor keys are reset to their default values when you press the RESET key.

Entering character strings


Use the keyboard that appears on the screen to enter character strings such as file names and comments. Use the cursor keys and the SET key to operate the keyboard and enter a character string.

How to operate the keyboard


1. After bringing up the keyboard, use the jog dial to move the cursor to the character that you want to enter.
2. Press **SET** to enter the character.
 - If a character string has already been entered, use the arrow soft keys to move the cursor to the position you want to insert characters into.
 - To switch between uppercase and lowercase letters, move the cursor to **CAPS** on the keyboard, and then press **SET**.
 - To delete the previous character, press the **Back Space** soft key.
 - To delete all the characters, press the **All Clear** soft key.
3. Repeat steps 1 and 2 to enter all of the characters in the string.
 - Select  on the keyboard or press the **History** soft key to display a list of character strings that you have entered previously. Use the cursor keys to select a character string, and press **SET** to enter the selected character string.
 - Select  on the keyboard to display a list of preset character strings. The following operands and expressions, which are used with user-defined functions, are included as preset character strings.

ABS(PPK(HVF(RMS(
SQR(MPK(HCF(MN(
SQRT(CF	KFACT(RMN(
LOG(TI(EAU(DC(
LOG10(THD(EAI(AC(
EXP(THF(PLLFRQ(PC(
NEG(TIF(
SIN(COS(TAN(
4. Press the **ENTER** soft key, or move the cursor to ENTER on the keyboard, and press **SET** to confirm the character string and clear the keyboard.

Use the cursor keys to select a character string, and press **SET** to enter the selected character string.



Input history: a list of previously entered character strings



After selecting an item with the cursor keys, press SET to confirm it.

Note

- @ cannot be entered consecutively.
- File names are not case-sensitive. Comments are case-sensitive. The following file names cannot be used due to MS-DOS limitations:
AUX, CON, PRN, NUL, CLOCK, COM1 to COM9, LPT1 to LPT9
- For details on file name limitations, see the Features Guide, IM WT1801R-01EN.

1.3 Using USB keyboards and mouse devices and Setting the USB Keyboard Language

► [“USB keyboard language \(USB Keyboard\)” in the features guide](#)

Connecting a USB keyboard

You can connect a USB keyboard and use it to enter file names, comments, and other items.

Compatible keyboards

You can use the following keyboards that conform to USB Human Interface Devices (HID) Class Ver. 1.1.

- When the USB keyboard language is English: 104-key keyboards
- When the USB keyboard language is Japanese: 109-key keyboards

Note

- Do not connect incompatible keyboards.
- The operation of USB keyboards that have USB hubs or mouse connectors is not guaranteed.
- For USB keyboards that have been tested for compatibility, contact your nearest YOKOGAWA dealer.

USB ports for peripherals

Connect a USB keyboard to one of the USB ports for peripherals on the front panel of the instrument.

Connection procedure

Connect a USB keyboard directly to the instrument using a USB cable. You can connect or remove the USB cable regardless of whether the instrument is on or off (hot-plugging is supported).

Connect the type A connector of the USB cable to the instrument, and connect the type B connector to the keyboard. When the power switch is on, the keyboard is detected and enabled approximately 6 seconds after it is connected.


Note

- Only connect compatible USB keyboards, mouse devices, or memory devices to the USB ports for peripherals.
- Do not connect multiple keyboards. You can connect one keyboard and one mouse to the instrument.
- Do not connect and disconnect multiple USB devices repetitively. Wait for at least 10 seconds after you plug or unplug one USB device before you plug or unplug another USB device.
- Do not remove USB cables from the time when the instrument is turned on until operation becomes available (about 20 seconds).

Setting the USB keyboard language

UTILITY System Config menu


Press **UTILITY** and then the **System Config** soft key. The following menu appears.



Entering file names, comments, and other items

When a keyboard is displayed on the screen, you can enter file names, comments, and other items using the USB keyboard.

Entering values from a USB keyboard

You can use the USB keyboard to enter values for settings in which the  mark is displayed on the menu.

- ↑ key or "8" on the numeric keypad: Increases the value
- ↓ key or "2" on the numeric keypad: Decreases the value
- → key or "6" on the numeric keypad: Moves the digit cursor to the next digit on the right.
- ← key or "4" on the numeric keypad: Moves the digit cursor to the next digit on the left.

Using a USB mouse

You can connect a USB mouse and use it to perform the same operations that you can perform with the keys of this instrument. Also, by clicking a menu item, you can perform the same operation that you can perform by pressing the menu item's soft key or selecting the menu item and pressing the SET key.

Compatible USB mouse devices

You can use mouse devices (with wheels) that are compliant with USB HID Class Version 1.1.

Note

- For USB mouse devices that have been tested for compatibility, contact your nearest YOKOGAWA dealer.
- Some settings cannot be configured by a mouse without a wheel.

1.3 Using USB keyboards and mouse devices and Setting the USB Keyboard Language

USB ports for peripherals

Connect a USB mouse to one of the USB ports for peripherals on the front panel of the instrument.

Connection procedure

To connect a USB mouse to this instrument, use one of the USB ports for peripherals. You can connect or disconnect a USB mouse at any time regardless of whether the instrument is on or off (hot-plugging is supported). When the power switch is on, the mouse is detected about 6 seconds after it is connected, and the mouse pointer (☞) appears.

Note

- Only plug compatible USB keyboards, mouse devices, or memory devices to the USB ports for peripherals.
- Even though there are two USB ports for peripherals, do not connect two mouse devices to the instrument.

Controlling the instrument using a USB mouse

• Controls that correspond to the front panel keys (top menu)


Displaying the top menu

Right-click on the screen. A menu appears showing the instrument's front panel keys (the top menu).

Selecting an item from the top menu

Click the item that you want to select. A setup menu corresponding to the selected item appears on the right side of the screen. The top menu disappears.

To display an item's submenu, click the item. To select an item on a submenu, click it, just as you would to select an item on the top menu.



* ops. : operations

Note

- The following keys are not displayed on the top menu:
ESC, RESET, SET

• Setup menu operations (Same as soft key operations)


Selecting a setup menu item

Click the setup menu item that you want to select.

If a selection menu appears after you select an item, click the selection menu item that you want to choose.

If an item has available options such as ON and OFF, click the item to change its setting.

For menu items that are usually selected using the cursor keys and the SET key, clicking on the item that you want to select will confirm your selection and close the dialog box.









Clearing the menu


To clear the menu, click outside of it.

1.3 Using USB keyboards and mouse devices and Setting the USB Keyboard Language

- **Specifying values**

The following description explains how to specify values for menu items that have a  icon next to them.


- When a menu item has two  icons, click the top or bottom half of the menu item to select the corresponding setting.
- To decrease a value, rotate the mouse wheel backward.
- To increase a value, rotate the mouse wheel forward.
- To increase a value, move the pointer above the value so that the pointer becomes a , and then click above the value.
- To decrease a value, move the pointer below the value so that the pointer becomes a , and then click below the value.
- To move the digit cursor between digits, point to the left or right of the value you want to set so that the pointer becomes a  or a , and then click the point that you moved the pointer to. The digit cursor will move one digit to the left or right each time you click.



**Click within this area to select the item that you want to set with the cursor keys.
Change the value by clicking and using the mouse wheel.**

- **Selecting check boxes in dialog boxes**

To select an item, click it. A check mark appears next to the item that you selected. To clear an item's check box, click the item again.



To select an item, click it.

Note


To close a dialog box, click outside of it.

- **Selecting a file, folder, or storage device from the file list window**

Click on a file, folder (directory), or storage device to select it.

Rotate the mouse wheel to scroll through the file list.

To cancel your selection, click outside of the file list window. The file list window will close when you cancel your selection.




1.4 Setting the Message and Menu Languages

This section explains how to set the language that is used to display the menus and messages on the screen. The factory default setting is ENG (English).

► “Language (Language)” in Features Guide


UTILITY System Config menu

Press **UTILITY** and then the **System Config** soft key. The following menu appears.



Setting the language

Press the **Language** soft key. The following menu appears.



Setting the menu language (Menu Language)

You can choose to display menus in any of the following languages.

- English
- Japanese
- Chinese
- German

Setting the message language (Message Language)

Error messages appear when errors occur. You can choose to display these messages and the help (see section 1.7) using one of the following languages. The error codes for error messages are the same for all languages. For more information about error messages, see Appendix 1.

- English
- Japanese
- Chinese
- German

Note

- Even if you set the menu or message language to a language other than English, some terms will be displayed in English.
 - You can set different languages for the menu language and message language. However, you cannot set Japanese and Chinese to the menu language and the message language at the same time. For example, if you specify Japanese as the menu language and Chinese as the message language, the menu language will also be set to Chinese.
-

1.5 Synchronizing the Clock

This section explains how to set the instrument's clock, which is used to generate timestamps for measured data and files. The instrument is factory shipped with a given date and time. You must set the clock before you start measurements.

► [“Date and time setting” in the features guide](#)

UTILITY System Config menu

Press **UTILITY**, the **System Config** soft key, and then the **Date/Time** soft key to display the following screen. The following screen appears.

The screenshot shows the 'Date/Time' configuration screen. It has a title bar 'Date/Time'. Below it are four rows of controls: 'Display' with 'OFF' and 'ON' buttons; 'Type' with 'Manual' and 'SNTP' buttons; 'Date' with three input fields showing '2024 / 10 / 14'; and 'Time' with three input fields showing '10 : 38 : 00'. At the bottom is a 'Set' button. Four lines with arrows point to the 'ON' button, 'SNTP' button, the date fields, and the time fields, each with a text label.

Display	OFF	ON	Turns the date and time display on or off			
Type	Manual	SNTP	Set the setup type.			
Date	2024	/	10	/	14	Set the date (year/month/day).
Time	10	:	38	:	00	Set the time (hour:minute:second).
<button>Set</button>						

Setting the setup type (Type)

- If you select Manual, set the Date and Time values, and then select Set.
- If you select SNTP, the instrument uses an SNTP server to set its date and time. This setting is valid when Ethernet communications have been established. For details on SNTP, see section 20.6. If you select SNTP, set the time difference from Greenwich Mean Time (the Time Diff. GMT values), and then select Set.

Time difference from Greenwich Mean Time (Time Difference from GMT)

This setting is valid when the method for setting the date and time is set to SNTP.

Set the time difference between the region where you are using the instrument and Greenwich Mean Time in the following range.

–12 hours 00 minutes to 13 hours 00 minutes

For example, Japan standard time is ahead of GMT by 9 hours. In this case, set Hour to 9 and Minute to 00.

The screenshot shows the 'Time Difference From GMT' configuration screen. It has a title bar 'Date/Time'. Below it are three rows of controls: 'Display' with 'OFF' and 'ON' buttons; 'Type' with 'Manual' and 'SNTP' buttons; and 'Time Difference From GMT' with 'Hour' and 'Minute' input fields showing '9' and '0' respectively. At the bottom is a 'Set' button. Two lines with arrows point to the 'Hour' and 'Minute' fields, each with a text label.

Display	OFF	ON
Type	Manual	SNTP
Time Difference From GMT		
Hour	9	Set the hours.
Minute	0	Set the minutes.
<button>Set</button>		

Checking the standard time

Using one of the methods below, check the standard time of the region where you are using the instrument.

- Check the Date, Time, Language, and Regional Options on your PC.
- Check the website at the following URL: <https://www.worldtimeserver.com/>

Note

-
- This instrument does not support Daylight Saving Time. To set the Daylight Savings Time, reset the time difference from Greenwich Mean Time.
 - Date and time settings are backed up using an internal lithium battery. They are retained even if the power is turned off.
 - This instrument manages leap-year information.
 - The Time Difference From GMT setting is shared with the same setting found in the SNTP settings in the Ethernet communication (Network) settings. If you change this setting in the date and time settings, the Time Difference From GMT in the Ethernet communication (Network) settings also changes.
-


1.6 Initializing the Settings

You can reset the instrument settings to their factory default values. This feature is useful when you want to cancel all the settings that you have entered or when you want to redo measurements from scratch. For information about the initial settings, see appendix 8, “List of Initial Settings and Numeric Data Display Order” in the Features Guide, IM WT1801R-01EN.

► [“Initializing Settings \(Initialize Settings\)” in the features guide](#)

UTILITY System Config menu

Press **UTILITY**, the **System Config** soft key, and then the **Initialize Settings** soft key to display the following screen.



Settings that cannot be reset to their factory default values

- Date and time settings
- Communication settings
- Menu and message language settings

To reset all settings to their factory default values

While holding down the RESET key, turn the power switch on. All settings except the date and time settings (display on/off setting will be reset) will be reset to their factory default values.

Note

Only initialize the instrument if you are sure that it is okay for all of the settings to be returned to their default values. You cannot undo an initialization. We recommend that you save the setup data before you initialize the instrument.

1.7 Displaying Help

► [“Online help” in the features guide](#)

Displaying help

Press **HELP** to display the help screen.

The table of contents and index appear in the left frame, and text appears in the right frame.

Switching between frames

Press the left and right cursor keys to change the frame you want to control.

Moving cursors and scrolling

Press the up and down cursor keys to scroll the screen and to move the cursor in the table of contents or index.

- Press PAGE ▲ or PAGE ▼ to scroll through the screen by approximately half a page in the specified direction.
- Press SHIFT+PAGE ▲ (▲) to display the first entry.
- Press SHIFT+PAGE ▼ (▼) to display the last entry.

Moving to the link destination

Move the cursor to a blue text and press SET to move to an explanation of the blue text in this document. Move the cursor to an item in the table of contents or index and press SET to move to the corresponding explanation.

Displaying panel key descriptions

With the help file displayed, press a panel key to display an explanation of it.

Returning to the previous screen

Press RESET to return to the previous screen.

Hiding help

Press HELP or ESC to hide the help screen.

2.1 Configuring the Wiring System Settings

This section explains the following wiring system settings:

- Wiring system
- Wiring unit
- Wiring pattern


► “Wiring system (Wiring)” in the features guide

Wiring settings (Wiring Settings)

Press **WIRING** and then the **Wiring** soft key. The following screen appears.

Set the wiring system (1P2W, 1P3W, 3P3W, 3P4W, 3P3W(3V3A)).

When you select an input element, the wiring systems that you can select are displayed. Select the wiring system from those displayed.



Wiring system pattern

- If you select 1P3W, 3P3W, 3P4W, or 3P3W (3V3A) for the wiring system, the wiring unit is set with the two or three input elements adjacent to the selected element whose element numbers are larger than the selected element.
- On models that have six input elements installed, up to three wiring units (ΣA, ΣB, and ΣC) are automatically set. The wiring unit symbols ΣA, ΣB, and ΣC are attached to the element numbers in order, starting with the smallest number.

Note

- Because the wiring system with the largest element number is automatically determined according to the settings of the wiring system with the smallest element number, the element with the largest element number cannot be selected.
- You cannot set the wiring units for larger element numbers before the wiring units for smaller element numbers.
- To measure voltage, current, and active power Σ functions using high speed data capturing, set the wiring system to 3P4W or 3P3W (3V3A). When the wiring system is set to 1P3W or 3P3W, voltage, current, and active power Σ functions are not measured.

2.2 Setting the Voltage and Current Ranges

This section explains the following settings for the voltage and current ranges:

- Input element
- Auto range
- Fixed range
 - ▶ “Voltage range (RANGE UP/DOWN (V))” and “Current range (RANGE UP/DOWN (A))” in the features guide

Voltage range (VOLTAGE RANGE)

1. Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the voltage range of.
 - While the setup menu is displayed, press **ESC** twice. Information corresponding to the input elements or wiring units will be displayed highlighted on the menu. You can also use the soft keys corresponding to the highlighting to select the input element or wiring unit.
 - Press **SHIFT** and the ELEMENT (ALL) key for setting ranges to collectively configure all the input elements for which the following conditions are met.
 - The input element type (for 5 A or for 50 A) is the same.
 - The valid measurement range setting (see section 2.7) is the same.
2. Follow the instructions below to set the voltage range.

Using auto range


Press the voltage range's **AUTO** key.

Using a fixed range

Press the voltage range's fixed range keys (▲ and ▼) to set the voltage range.

Available voltage range options

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
1.5V, 3V, 6V, 10V, 15V, 30V, 60V, 100V, 150V, 300V, 600V, 1000V	0.75V, 1.5V, 3V, 5V, 7.5V, 15V, 30V, 50V, 75V, 150V, 300V, 500V



Note

When Element Independent (see section 2.9) is set to OFF, the voltage ranges of input elements that are assigned to the same wiring unit are set to the same range. When Element Independent is set to ON, you can set the voltage range of input elements that are assigned to the same wiring unit separately.

Current range (CURRENT RANGE)

1. Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the current range of.
 - While the setup menu is displayed, press **ESC** twice. Information corresponding to the input elements or wiring units will be displayed highlighted on the menu. You can also use the soft keys corresponding to the highlighting to select the input element or wiring unit.
 - Press **SHIFT** and the ELEMENT (ALL) key for setting ranges to collectively configure all the input elements for which the following conditions are met.
The input element type (for 5 A or for 50 A) is the same.
The valid measurement range setting (see section 2.7) is the same.
2. Follow the instructions below to set the current range.

Using auto range

Press the current range's **AUTO** key.

Using a fixed range

Press the current range's fixed range keys (**▲** and **▼**) to set the current range.


Available current range options

• 5 A input element

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
10mA, 20mA, 50mA, 100mA, 200mA, 500mA, 1A, 2A, 5A	5mA, 10mA, 25mA, 50mA, 100mA, 250mA, 500mA, 1A, 2.5A

• 50 A input element

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
1A, 2A, 5A, 10A, 20A, 50A	500mA, 1A, 2.5A, 5A, 10A, 25A



Note

When Element Independent (see section 2.9) is set to OFF, the current ranges of input elements that are assigned to the same wiring unit are set to the same range. When Element Independent is set to ON, you can set the current range of input elements that are assigned to the same wiring unit separately.

2.3 Setting the External Current Sensor Range (option)

This section explains the following settings for external current sensor ranges (current ranges that are used when external current sensors are being used): This feature is available on models with the /EX1 to /EX6 option.

- Input element
- External current sensor
- Auto range
- Fixed range

► “External current sensor range (EXT SENSOR, option)” in the features guide

1. Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the external current sensor range of.
 - While the setup menu is displayed, press **ESC** twice. Information corresponding to the input elements or wiring units will be displayed highlighted on the menu. You can also use the soft keys corresponding to the highlighting to select the input element or wiring unit.
 - Press **SHIFT** and the **ELEMENT (ALL)** key for setting ranges to collectively configure all the input elements for which the following conditions are met.
The input element type (for 5 A or for 50 A) is the same.
The valid measurement range setting (see section 2.7) is the same.
2. Press **EXT SENSOR**. The EXT SENSOR key lights.
Press **EXT SENSOR** again to turn the EXT SENSOR key off. In this state, you can set the current range that is used when current is applied directly to the instrument (see section 2.2).
3. Follow the instructions below to set the external current sensor range.

Using auto range

Press the current range's **AUTO** key.


Using a fixed range

Press the external current sensor range's fixed range keys (**▲** and **▼**) to set the current range.

Available external current sensor range options

When the display format of the external current sensor range is set to **DIRECT**, you can select the range from the available options shown in the following table (the unit is mV or V). When the display format is set to **MEAS**, the setup range is set to the value from the following table divided by the external current sensor conversion ratio (the unit is A). For instructions on how to set the display format of the external current sensor range, see section 2.5.

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
50mV, 100mV, 200mV, 500mV, 1V, 2V, 5V, 10V	25mV, 50mV, 100mV, 250mV, 500mV, 1V, 2.5V, 5V



Note

When Element Independent (see section 2.9) is set to OFF, the external current sensor ranges of input elements that are assigned to the same wiring unit are set to the same range. When Element Independent is set to ON, you can set the external current sensor range of input elements that are assigned to the same wiring unit separately.

2.4 Setting the External Current Sensor Conversion Ratio (option)


This section explains the following settings for the external current sensor conversion ratio: This feature is available on models with the /EX1 to /EX6 option.

- Conversion ratio
- Copying the conversion ratio

► “External current sensor conversion ratio (SENSOR RATIO, option)”
in the features guide

Sensor Ratio menu

Press **SHIFT+EXT SENSOR**(SENSOR RATIO). The following menu appears.



The screenshot shows a menu titled "Sensor Ratio" with six elements. Each element is labeled "Element 1" through "Element 6" and has a unit "[mV/A (m?)]". The conversion ratios are displayed in blue boxes: Element 1 is 0.0000, Element 2 is 10.0000, Element 3 is 10.0000, Element 4 is 10.0000, Element 5 is 10.0000, and Element 6 is 10.0000. A cursor is positioned over the value 0.0000 for Element 1. At the bottom of the menu is an option "Exec Copy Σ".

Cursor (use the ◀▶ cursor keys to move it)

Set the conversion ratio (0.0001 to 99999.9999).

Copies the conversion ratio

The conversion ratio of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

Note

When using the dedicated shunt box or dedicated voltage output CT, you can select an external current sensor conversion ratio preset in the menu for configuring all elements (see section 2.17).

Example of external current sensor range and conversion ratio configuration

When you measure a current with a maximum value of 100 A using a current sensor that produces 10 mV when 1 A of current is running, the maximum voltage that the current sensor produces is $10 \text{ mV/A} \times 100 \text{ A} = 1 \text{ V}$. Therefore, configure the settings as follows:

- External current sensor range: 1 V
- External current sensor conversion ratio: 10 mV/A


2.5 Setting the Display Format of the External Current Sensor Range (option)

This section explains the following setting for the external current sensor range: This feature is available on models with the /EX1 to /EX6 option.

- Display format

► “External current sensor range display format (DIRECT/MEASURE, option)”
in the features guide

1. Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the external current sensor range of.
 - If you press **ESC** to clear the setup menu from the screen, soft keys corresponding to the input elements or wiring units will be displayed on the menu. You can use these soft keys to select the input element or wiring unit.
 - Press **SHIFT** and the ELEMENT (ALL) key for setting ranges to collectively configure all the input elements for which the following conditions are met.
 - The input element type (for 5 A or for 50 A) is the same.
 - The valid measurement range setting (see section 2.7) is the same.
2. Press **EXT SENSOR**. The EXT SENSOR key lights.
Press **EXT SENSOR** again to turn the EXT SENSOR key off.
3. Press **SHIFT** and the current range's **CONFIG** (DIRECT/MEASURE) key. The DIRECT indicator or MEAS indicator, which indicates the display format, lights. The external current sensor range is displayed in the indicated display format.
Press **SHIFT** and the current range's **CONFIG** (DIRECT/MEASURE) key again to switch the display format. The indicators turn on or off appropriately.



2.6 Setting the scaling feature when using a VT or CT


This section explains the following settings for measuring voltage through an external VT (voltage transformer) and current that through an external CT (current transformer):

- Turning the scaling feature on and off
- VT ratio
- CT ratio
- Power coefficient

► “Scaling (SCALING)” in the features guide


Scaling menu

Press **SCALING**. The following menu appears.



Setting the VT ratio (VT Scaling)

Press the **VT Scaling** soft key. The following menu appears.



The screenshot shows a menu titled "VT Scaling" with six elements, each with a diamond icon and a blue input field. Element 1 has a cursor pointing to its input field, which displays "8.0000". Elements 2 through 6 display "1.0000". At the bottom is a button labeled "Exec Copy Σ".


Cursor (use the ◀▶ cursor keys to move it)

Set the VT ratio (0.0001 to 99999.9999).

Copies the VT ratio
The VT ratio of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

Setting the CT ratio (CT Scaling)

Press the **CT Scaling** soft key. The following menu appears.



The screenshot shows a menu titled "CT Scaling" with six elements, each with a diamond icon and a blue input field. Element 1 has a cursor pointing to its input field, which displays "8.0000". Elements 2 through 6 display "1.0000". At the bottom is a button labeled "Exec Copy Σ".

Cursor (use the ◀▶ cursor keys to move it)

Set the CT ratio.

Copies the CT ratio
The CT ratio of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

Note

When using the dedicated CT, you can select a CT ratio preset in the menu for configuring all elements (see section 2.17).

Setting the power coefficient (SF Scaling)

Press the **SF Scaling** soft key. The following menu appears.

SF Scaling

◊ Element 1

8.0000

◊ Element 2

1.0000

◊ Element 3

1.0000

◊ Element 4

1.0000

◊ Element 5

1.0000

◊ Element 6

1.0000

Exec Copy Σ

Cursor (use the ◀▶ cursor keys to move it)

Set the power coefficient.

Copies the power coefficient

The power coefficient of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

2.7 Setting the Valid Measurement Range

This section explains the following settings for the valid measurement range:

- Valid measurement range
- Measurement range to switch to when a peak over-range occurs
 - ▶ “valid measurement range (CONFIG (V)/CONFIG (A))” in the features guide

Setting the valid voltage measurement range (Voltage Range Configuration)

Press the voltage range’s **CONFIG** key. The following screen appears.

Valid measurement range

- The measurement range switches (in order) between the selected ranges.
- Ranges that are not selected are skipped.
- When Element Independent (see section 2.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

Available voltage range options

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).

If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in blue.

For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which an input element is not installed

Available options for the measurement ranges that the instrument can switch to when a peak over-range occurs


Measurement range to switch to when a peak over-range occurs

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing AUTO), the instrument operates as follows:
 - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
 - When the measurement range to switch to when a peak over-range occurs has not been selected, the measurement range increases in the order specified by the measurement ranges that have been selected.

	Element1	Element2	Element3	Element4	Element5	Element6
1000V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
600V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
300V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
150V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
100V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
60V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
30V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
15V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
10V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
6V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
3V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
1.5V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
Peak Over Jump	OFF	1000V	1000V	OFF	OFF	OFF

Setting the valid current measurement range (Current Range Configuration)

Press the current range's **CONFIG** key. The following menu appears.



Setting the valid measurement range of 50 A input elements (50 A Input Element)—direct input range

Valid measurement range

- The measurement range switches (in order) between the selected ranges.
- Ranges that are not selected are skipped.
- When Element Independent (see section 2.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

Available voltage range options

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).

If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in blue.

For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which a 50 A input element is not installed

Available options for the measurement ranges that the instrument can switch to when a peak over-range occurs

Measurement range to switch to when a peak over-range occurs

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing AUTO), the instrument operates as follows:
 - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
 - When the measurement range to switch to when a peak over-range occurs has not been selected, the measurement range increases in the order specified by the measurement ranges that have been selected.

	Element1	Element2	Element3	Element4	Element5	Element6
50A	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
20A	-	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
10A	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
5A	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
2A	-	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	-
1A	-	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	-
Peak Over Jump	OFF	50A	50A	OFF	OFF	OFF

50A 5A ExtSensor

Setting the valid measurement range of 5 A input elements (5 A Input Element)—direct input range

Valid measurement range

- The measurement range switches (in order) between the selected ranges.
- Ranges that are not selected are skipped.
- When Element Independent (see section 2.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

Available voltage range options

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).

If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in blue.

For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which a 5 A input element is not installed

Available options for the measurement ranges that the instrument can switch to when a peak over-range occurs

Measurement range to switch to when a peak over-range occurs

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing AUTO), the instrument operates as follows:
 - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
 - When the measurement range to switch to when a peak over-range occurs has not been selected, the measurement range increases in the order specified by the measurement ranges that have been selected.

Current Range	Element1	Element2	Element3	Element4	Element5	Element6
5A	<input checked="" type="checkbox"/>	-	-	-	-	-
2A	<input type="checkbox"/>	-	-	-	-	-
1A	<input checked="" type="checkbox"/>	-	-	-	-	-
500mA	<input checked="" type="checkbox"/>	-	-	-	-	-
200mA	<input type="checkbox"/>	-	-	-	-	-
100mA	<input checked="" type="checkbox"/>	-	-	-	-	-
50mA	<input type="checkbox"/>	-	-	-	-	-
20mA	<input type="checkbox"/>	-	-	-	-	-
10mA	<input type="checkbox"/>	-	-	-	-	-
Peak Over Jump	5A	-	-	-	-	-

50A 5A 5A Sensor

5A 2A 1A 500mA 200mA 100mA 50mA 20mA 10mA

Setting the valid measurement range of external current sensors (Ext Sensor Input Element)

Valid measurement range

- The measurement range switches (in order) between the selected ranges.
- Ranges that are not selected are skipped.
- When Element Independent (see section 2.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

Available external current sensor range options

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).

If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in blue.

For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which an input element is not installed

Available options for the measurement ranges that the instrument can switch to when a peak over-range occurs

Measurement range to switch to when a peak over-range occurs

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing **AUTO**), the instrument operates as follows:
 - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
 - When the measurement range to switch to when a peak over-range occurs has not been selected, the measurement range increases in the order specified by the measurement ranges that have been selected.

	Element1	Element2	Element3	Element4	Element5	Element6
10V	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
5V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
2V	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
1V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
500mV	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
200mV	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
100mV	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
50mV	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
Peak Over Jump	OFF	10V	10V	OFF	OFF	-

50A 5A ExtSensor

2.8 Setting the Efficiency Formula

This section explains the following settings for the efficiency formula:

- Efficiency formula
- Summation of the active power and motor output³

► [“Efficiency formula \(η Formula\)” in the features guide](#)

Setting the efficiency formula (η Formula)

Press **WIRING** and then the **η Formula** soft key. The following screen appears.

The screenshot shows the **η Formula** configuration screen. It has a title bar with the text **η Formula**. Below the title bar, there are two rows of buttons labeled **Element**. The first row contains buttons [1], [2], [3], [4], [5], and [6]. The second row contains buttons [1P2W], [3P3WΣ A], [1P2W], and [1P3WΣ B]. To the right of the first row, an annotation points to these buttons with the text **Installed input elements**. Below the **Element** buttons, there are four formula input fields labeled $\eta 1$, $\eta 2$, $\eta 3$, and $\eta 4$. Each field has a denominator and a numerator, both with **OFF** buttons. An annotation points to these **OFF** buttons with the text **Set the denominator and numerator of the efficiency formula to the active power and motor output measurement functions. (P1 to P6¹, PΣA to PΣC², Pm³, Udef1, Udef2)**. Below the formula fields, there are two rows of buttons labeled **Udef1 =** and **Udef2 =**. Each row has buttons **P1**, **+**, **None**, **+**, **None**, **+**, and **None**. An annotation points to these buttons with the text **Define Udef1 and Udef2. (P1 to P6¹, PΣA to PΣC², Pm³)**.

To add active powers and motor output and use them in efficiency formulas, use Udef1 and Udef2.

- 1 Can be set within the range of the installed input elements.
- 2 Can be set within the range of the wiring unit that is automatically determined by the installed input elements.
- 3 Can be set on models with the /MTR option.


2.9 Turning the Independent Input Element Configuration On and Off

This section explains how to turn the independent input element configuration on and off.

► [“Independent input element configuration \(Element Independent\)” in the features guide](#)

Wiring menu

Press **WIRING**. The following menu appears.



— Turns independent input element configuration on and off

2.10 Setting the Delta Calculation


This section explains the following settings for the delta calculation:

- Delta calculation type
- Delta calculation mode

► “Delta calculation (Δ Measure)” in the features guide

Setting the delta calculation (Δ Measure)

Press **WIRING** and then the **Δ Measure** soft key. The following screen appears.



The screenshot shows the **Δ Measure** screen with the following elements:

- Installed input elements:** A row of six buttons labeled [1], [2], [3], [4], [5], and [6].
- The set wiring systems:** A row of three buttons labeled [1P2W], [3P3W- Σ A], and [3P3W(3V3A)- Σ B].
- Set the delta calculation type:** A row of two buttons labeled [----] and [3P3W:3V3A].
- Set the delta calculation mode:** A row of five buttons labeled **rms**, mean, dc, r-mean, and ac. The **rms** button is highlighted.

Set the delta calculation mode
(rms, mean, dc, r-mean, ac).

Set the delta calculation type.
The available options vary depending on the set wiring systems.

Wiring system	Delta calculation type
1P3W	Difference, 3P3W>3V3A
3P3W	Difference, 3P3W>3V3A
3P4W	Star>Delta
3P3W(3V3A)	Delta>Star

2.11 Setting the Crest Factor

This section explains how to set the crest factor.

► [“Crest factor \(Crest Factor\)” in the features guide](#)

System Config menu

Press **UTILITY** and then the **System Config** soft key. The following menu appears.



— Set the crest factor (CF3, CF6, CF6A).


2.12 Setting Measurement Periods

This section explains how to set the sync sources that determine the measurement period.

► “Measurement period (SYNC SOURCE)” in the features guide

Sync Src menu

Press **SYNC SOURCE**. The following menu appears.



Setting the sync source for when the data update interval is Auto (Sync Source Setting)

Press **SYNC SOURCE** and then the **Sync Src Setting** soft key. The following screen appears.

To set all elements to the same setting at once, change the settings in the All column.

Turn on or off the sync source rectifier for voltage, current, and external current sensor signals.

Sync Source Settings						
All	Element 1	Element 2	Element 3	Element 4	Element 5	Element 6
Voltage Rectifier	OFF	OFF	OFF	OFF	OFF	OFF
Voltage Level	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%
Current Rectifier	OFF	OFF	OFF	OFF	OFF	OFF
Current Level	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%
Ext. Sensor Rectifier	OFF	OFF	OFF	OFF	OFF	OFF
Ext. Sensor Level	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%

Set the sync source level for voltage, current, and external current sensor signals.

- When the rectifier function is off: –100.0 % to 100.0 %
- When the rectifier function is on: 0.0 % to 100.0 % (absolute value)

2.13 Setting Line Filters


This section explains the following settings for line filters:

- Turning line filters on and off
- Cutoff frequency

► “Line filter (LINE FILTER)” in the features guide

Line Filter menu

Press **LINE FILTER**. The following menu appears.



Line Filter

Element 1
OFF ON
Cutoff 0.5kHz

Element 2
OFF ON
Cutoff 0.5kHz

Element 3
OFF ON
Cutoff 0.5kHz

Element 4
OFF ON
Cutoff 0.5kHz

Element 5
OFF ON
Cutoff 0.5kHz

Element 6
OFF ON
Cutoff 0.5kHz

Exec Copy Σ

Cursor (use the ◀▶ cursor keys to move it)

Configure the line filter.

- Turn the line filter on or off.
- Set the cutoff frequency (OFF, 0.1kHz to 100.0kHz in steps of 0.1 kHz, 300kHz, 1MHz).

Copies the line filter settings

The line filter setting of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

2.14 Setting Frequency Filters


This section explains how to set the frequency filter.

► “Frequency filter (FREQ FILTER)” in the features guide

Freq Filter menu

When the data update interval is not Auto


Press **SHIFT+LINE FILTER**(FREQ FILTER). The following menu appears.



Freq Filter (A) menu

When the data update interval is Auto

Press **SHIFT+LINE FILTER**(FREQ FILTER) and then the **Freq Filter at Update Rate Auto** soft key. The following menu appears.



* The menu item is displayed, but the function is invalid.


2.15 Setting the Data Update Interval

This section explains how to set the data update interval.

► “Data update interval (UPDATE RATE)” in the features guide

Update Rate menu

Press **UPDATE RATE**. The following menu appears.



1 You can set this when the data update interval is not Auto.

2 You can set this when the data update interval is Auto.

2.16 Setting Averaging


This section explains the following settings for averaging:

- Turning averaging on and off
- Averaging type
- Attenuation constant
- Averaging count

► [“Averaging \(AVG\)” in the features guide](#)

Averaging menu

Press **AVG**. The following menu appears.



2.17 Displaying the Menu for Configuring All Elements

This section explains how to set the settings for all elements.

► “Settings of all elements (All Elements Setup)” in the features guide

All Elements Setup menu

1. Press **WIRING** and then the **All Elements Setup** soft key. The following menu appears.

Use the **cursor** keys to select the setting that you want to change, and then press **SET** to display the available options or an input box. You can also press **INPUT SET** to display the following menu.

All Elements Setup						
Element	[1]	[2]	[3]	[4]	[5]	[6]
	3P4W:Σ A			3P4W:Σ B		
U Auto Range	OFF	OFF	OFF	OFF	OFF	OFF
U Range	1000V	1000V	1000V	1000V	1000V	1000V
Ext Sensor	OFF	OFF	OFF	OFF	OFF	OFF
I Auto Range	OFF	OFF	OFF	OFF	OFF	OFF
I Range	5A	5A	5A	5A	5A	5A
Sensor Preset	Others	Others	Others	Others	Others	Others
Sensor Ratio [mV/A (m?)]	10.0000	10.0000	10.0000	10.0000	10.0000	10.0000
CT Preset	Others	Others	Others	Others	Others	Others
Scaling	OFF	OFF	OFF	OFF	OFF	OFF
VT Scaling	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
CT Scaling	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
SF Scaling	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
Line Filter	OFF	OFF	OFF	OFF	OFF	OFF
- Cutoff	1.4kHz	0.5kHz	0.5kHz	0.5kHz	0.5kHz	0.5kHz
Freq Filter	OFF	OFF	OFF	OFF	OFF	OFF
Freq Filter (A)	OFF	OFF	OFF	OFF	OFF	OFF
- Cutoff	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz
Sync Source	I1	I1	I1	I4	I4	I4

Use the cursor keys to select the item that you want to set.

2.18 Viewing Setup Parameters

This section explains how to display a list of setup parameters.

► “Setup parameter list (INPUT INFO)” in the features guide

Info Form menu

1. Press **INPUT INFO**. The INPUT INFO key lights and the split display appears.
The top half of the screen displays the setup parameter list. Press INPUT INFO again to clear the setup parameter list and display the previous screen.
2. Hold down **FORM** until the Info Form menu appears.
Input element or measurement range settings are displayed.

Input element settings list

Power Element Settings						
	Element 1 [1000V-5A]	Element 2 [1000V-5A]	Element 3 [1000V-5A]	Element 4 [1000V-5A]	Element 5 [1000V-5A]	Element 6 [1000V-5A]
Wiring	1P2W	1P2W	1P2W	1P2W	1P2W	1P2W
Voltage Range	1000V	1000V	1000V	1000V	1000V	1000V
Current Range	5A	5A	5A	5A	5A	5A
Sensor Ratio [mV/A (mΩ)]	10.0000	10.0000	10.0000	10.0000	10.0000	10.0000
Scaling	Off	Off	Off	Off	Off	Off
VT Ratio	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
CT Ratio	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
Scaling Factor	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
Sync Source	I1	I2	I3	I4	I5	I6
Line Filter	Off	Off	Off	Off	Off	Off
Freq Filter	Off	Off	Off	Off	Off	Off

Press INPUT INFO to exit this display.

Info Form

Power Element Settings

Range Settings

Select Power Element Settings.

Measurement range settings list

Voltage Range Settings						Current Range Settings					
U1	U2	U3	U4	U5	U6	I1	I2	I3	I4	I5	I6
1000	1000	1000	1000	1000	1000	5	5	5	5	5	5
600	600	600	600	600	600	2	2	2	2	2	2
300	300	300	300	300	300	1	1	1	1	1	1
150	150	150	150	150	150	500m	500m	500m	500m	500m	500m
100	100	100	100	100	100	200m	200m	200m	200m	200m	200m
60	60	60	60	60	60	100m	100m	100m	100m	100m	100m
30	30	30	30	30	30	50m	50m	50m	50m	50m	50m
15	15	15	15	15	15	20m	20m	20m	20m	20m	20m
10	10	10	10	10	10	10m	10m	10m	10m	10m	10m
6	6	6	6	6	6						
3	3	3	3	3	3						
1.5	1.5	1.5	1.5	1.5	1.5						

Press INPUT INFO to exit this display.

Info Form


Power Element Settings

Range Settings

Select Range Settings.

Info Items menu

3. Press **ITEM**. A Info Items menu appears.



← Turns the display frame on and off

3.1 Setting Harmonic Measurement Conditions

This section explains the following settings for harmonic measurement conditions: This feature is available on models with the /G5 or /G6 option.


- Input element groups
- PLL source
- Measured harmonic
- Distortion factor formula

► “Harmonic measurement conditions (option)” in the features guide

Harmonics menu

Press **HRM SET**. The following menu appears.

**Menu on a model with the /G6 option
(dual harmonic measurement)**



Configure the input element groups.¹

Group Hrm1

Set the PLL source (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk).


Set the minimum value of the measured harmonic order (0, 1).

Set the maximum value of the measured harmonic order (1 to 500).

Set the distortion factor formula (1/Total, 1/Fundamental).

Set the number of FFT points when the data update interval is Auto.²(1024, 8192)

Configure Group HHrm2.¹



Group Hrm2


Set the PLL source (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk).

Set the minimum value of the measured harmonic order (0, 1).

Set the maximum value of the measured harmonic order (1 to 500).

Set the distortion factor formula (1/Total, 1/Fundamental).

Menu on a model with the /G5 option




¹ You can set this when the data update interval is not Auto.

² You can set this when the data update interval is Auto.

Setting the input element group (element settings)

Press the **Element Settings** soft key. The following menu appears.



Set the group of the input element (Hrm1, Hrm2).

Input elements that are assigned to the same wiring unit are set to the same group.

4.1 Setting Motor Evaluation Conditions

This section explains the following settings for motor evaluation conditions: This feature is available on models with the /MTR option.

- Scaling factor
- Unit
- Input signal type
- Analog input range
- Analog input linear scale
- Line filter
- Sync source
- Pulse input range
- Torque signal pulse rating
- Number of pulses per revolution of the revolution signal
- Motor's number of poles for calculating the sync speed
- Voltage or current whose frequency is measured to calculate the sync speed
- Electrical angle measurement
- Motor efficiency and total efficiency calculations

► “Motor evaluation conditions (option)” in the features guide

Setting motor evaluation conditions (MOTOR Settings)

Press **SHIFT+SCALING**(MOTOR/AUX SET). The following screen appears.

On models with the /AUX option, the auxiliary input conditions setup screen is displayed. See section 5.1.

Set the scaling factor (0.0001 to 99999.9999).

Set the scaling factor that is used to convert the signal from the revolution sensor or torque meter to speed (rotating speed), torque, and Pm (motor output).

Enter the unit using up to 8 characters.

Set the speed, torque, and Pm units.

Set the input signal type (Analog, Pulse).

Set the type of the speed or torque revolution sensor and the type of the torque meter.

The screenshot shows the 'MOTOR Settings' screen with three columns for Speed, Torque, and Pm. The settings are as follows:

Parameter	Speed	Torque	Pm
Scaling	1.0000	1.0000	1.0000
Unit	rpm	Nm	W
Sense Type	Analog	Analog	
Analog Auto Range	OFF	OFF	
Analog Range	20V	20V	
Linear Scale A	1.000	1.000	
Linear Scale B	0.000	0.000	
	Calculation	Calculation	
Line Filter	OFF		
Sync Source	None		
Pulse Range Upper	10000.0000	50.0000	
Pulse Range Lower	0.0000	-50.0000	
Rated Upper		50.0000	15000Hz
Rated Lower		-50.0000	5000Hz
Pulse N	60		
Sync Speed	Pole 2	Source I1	
Electrical Angle Measurement	ON		
Electrical Angle Correction			

Turns electrical angle measurement on and off

Configure the electrical angle correction.

You can configure the electrical angle correction when Electrical Angle Measurement is set to ON.

When sense type is set to analog:

- Turns auto range on and off
- Set the fixed range (20V, 10V, 5V, 2V, 1V).
- Set the linear scale (A: 1.000 m to 1.000 M; B: -1.000 M to 1.000M). Set A (the slope) and B (the offset).
- Calculates A and B
- Set the line filter (OFF, 100Hz, 1kHz).
- Set the sync source (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk, None). Even if Sense Type is set to Pulse, correctly setting the sync source improves measurement accuracy.

When sense type is set to pulse:

- Set the upper and lower limits.
Revolution signal: 0.0000 to 99999.9999 [rpm]
Torque signal: -10000.0000 to 10000.0000 [N·m]
- Set the positive and negative rated torque signal pulse frequencies (1 to 100000000 [Hz]).
- Set the positive and negative rated torque signal values (-10000.0000 to 10000.0000[N·m]).
- Set the number of pulses per revolution of the revolution signal (1 to 9999).
- Set the voltage or current whose frequency will be measured to compute the sync speed (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6).
- Set the number of motor poles that will be used to compute the sync speed (1 to 99).

4.1 Setting Motor Evaluation Conditions

Calculating A and B (Calculation)

A (the slope) and B (the offset) are calculated from two points on the characteristics graph of a revolution sensor or torque meter.

Rotating speed's A and B

On the motor evaluation condition setup screen, select Calculation under Speed.

The following screen appears.

Calculation

$Y=AX+B[\text{rpm}/\text{V}]$

Point1X[V] 0.000

Point1Y[rpm] 0.000

Point2X[V] 0.000

Point2Y[rpm] 0.000

Cancel Execute

Set the first X-axis value [V] and Y-axis value [rpm] (–1.000 T to 1.000 T).

Set the second X-axis value [V] and Y-axis value [rpm] (–1.000 T to 1.000 T).

Calculates A and B

Cancels the calculation

Torque's A and B

On the motor evaluation condition setup screen, select Calculation under Torque.

The following screen appears.

Calculation

$Y=AX+B[\text{Nm}/\text{V}]$

Point1X[V] 0.000

Point1Y[Nm] 0.000

Point2X[V] 0.000

Point2Y[Nm] 0.000

Cancel Execute

Set the first X-axis value [V] and Y-axis value [Nm] (–1.000 T to 1.000 T).

Set the second X-axis value [V] and Y-axis value [Nm] (–1.000 T to 1.000 T).

Calculates A and B

Cancels the calculation

Setting the electrical angle correction value (Electrical Angle Correction)

On the motor evaluation condition setup screen, select Electrical Angle Correction under Speed. The following screen appears.

Electrical Angle Correction

Correction Value 0.00

Clear Correction

Auto Enter Correction Execute

Auto Enter Target U1

Set the correction value (–180.00 to 180.00).

Clears the correction value

Automatically calculates the correction value

Correction Value is set to the calculated value.

Set the voltage or current to automatically compute the correction value of (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6).

Calculating the motor efficiency and total efficiency

This instrument can calculate the motor efficiency (the ratio of power consumption to motor output) and total efficiency from the active power and motor output that it measures.

For how to set the formula, see section 2.8.

5.1 Setting Auxiliary Input Conditions

This section explains the following settings for auxiliary input conditions: This feature is available on models with the /AUX option.

- Input signal name
- Scaling factor
- Unit
- Input signal range
- Input signal linear scale
- Line filter

► “Auxiliary input conditions (option)” in the features guide

Setting auxiliary input conditions (Aux Settings)

Press **SHIFT+SCALING**(MOTOR/AUX SET). The following screen appears.

On models with the /MTR option, the motor evaluation conditions setup screen is displayed. See section 4.1.

You can configure up to two input signals.

Aux Settings	
Aux Name	AUX1, AUX2
Scaling	1.0000, 1.0000
Unit	kW/m2, kW/m2
Analog Auto Range	OFF, OFF
Analog Range	20V, 20V
Linear Scale	A: 1.000, 1.000; B: 0.000, 0.000; Calculation, Calculation
Line Filter	OFF

- Set the input signal name (up to 8 characters).
- Set the scaling factor (0.0001 to 99999.9999).
- Enter the unit using up to 8 characters.
- Turns auto range on and off
- Set the fixed range (20V, 10V, 5V, 2V, 1V, 500mV, 200mV, 100mV, 50mV).
- Set the linear scale (A: 1.000 m to 1.000 M; B: -1.000 M to 1.000M). Set A (the slope) and B (the offset).
- Calculates A and B
- Set the line filter (OFF, 100Hz, 1kHz).

Calculating A and B (Calculation)

A (the slope) and B (the offset) are calculated from two points on the characteristics graph of the input signal.

On the auxiliary input condition setup screen, select **Calculation**. The following screen appears.

Calculation

$Y=AX+B[\text{Unit}/V]$

Point1X[V]: 0.000

Point1Y[Unit]: 0.000

Point2X[V]: 0.000

Point2Y[Unit]: 0.000

Cancel, Execute

- Set the first X-axis value [V] and Y-axis value [Unit] (-1.000 T to 1.000 T).
- Set the second X-axis value [V] and Y-axis value [Unit] (-1.000 T to 1.000 T).
- Calculates A and B

Cancels the calculation

6.1 Holding Measured Values


This section explains how to hold measured values.

► [“Holding measured values \(HOLD\)” in the features guide](#)

Press **HOLD**. The HOLD key lights, and the displayed measured value is held.

- Values such as D/A output and communication output are also held.
- Pressing **HOLD** again turns the HOLD key off. This releases the hold, and the updating of the measured value resumes at the data update interval (see section 2.15).

If you hold the measured value, the data update count in the lower left of the screen stops increasing.



6.2 Performing Single Measurements

This section explains how to perform single measurements.

► [“Single measurement \(SINGLE\)” in the features guide](#)

1. Press **HOLD**. The HOLD key lights, and the displayed measured value is held.
2. Press **SINGLE**. A single measurement is performed at the specified data update interval, and the instrument then holds the measured value.

Note

- If, while the HOLD key is lit, you press **HOLD** again, the HOLD key will turn off, and the hold feature will be released. If you press **SINGLE** while the hold feature is released, the measured value is updated (re-measured) when the time specified by the data update interval elapses after you press the key.
- When the data update interval is set to Auto, single measurement is not possible.

7.1 Setting the Display Format

This section explains how to set the numeric data display format. To set the display format, you can:

- Select it from the Numeric Form menu.
- Set it directly by pressing **NUMERIC**.

► [“Numeric data display format” in the features guide](#)

Numeric Form menu

Press **NUMERIC** and then **FORM**. The following menu appears.

If the setup parameter list is being displayed (the **INPUT INFO** key is lit), the Info Form menu may be displayed. If this happens, press **FORM** again.

Numeric Form	
4 Items	Select the 4 Items display.
8 Items	Select the 8 Items display.
16 Items	Select the 16 Items display.
Matrix	Select the matrix display. You can select four or six columns (see section 7.4).
All Items	Select the All Items display.
Hrm List	Select the harmonics list display (/G5 or /G6 option).
Single Dual	The instrument switches between the single and dual list displays each time you press this soft key.
Custom	Select the custom display. You can load the background and customize the numeric data display (see section 7.7).

NUMERIC key

Each time that you press **NUMERIC**, the display format switches, in order, between 4 Items, 8 Items, 16 Items, Matrix, All Items, Hrm List Single, Hrm List Dual, and Custom.

7.2 Switching the Displayed Page

This section explains how to switch the displayed numeric data page.

► [“Switching the displayed page \(PAGE UP/PAGE DOWN\)” in the features guide](#)

1. Follow the procedure in section 7.1 to select the numeric data display format.

4 Items, 8 Items, 16 Items, Matrix, All Items, and Custom displays

2. Press **PAGE▲** to display the previous page.


Press **PAGE▼** to display the next page.

Press **SHIFT+PAGE▲** (▲) to jump to the first page.

Press **SHIFT+PAGE▼** (▼) to jump to the last page.

- You can switch the displayed page separately for the 4 Items, 8 Items, 16 Items, Matrix, All Items, and Custom displays.
- For the All Items display, the first page is always displayed in the top half of the screen, and the currently selected page from pages 2 to 12 is displayed in the bottom half of the screen. On the split display, you can switch between pages 1 to 12.
- For the Custom display, you can switch between pages when the display is set so that the total number of displayed items is more than the number of items that can be displayed on one page (see section 7.7).


Example of the 4 Items display



Hrm List Single and Hrm List Dual displays (/G5 or /G6 options)

2. Press **ESC** to clear the menu.
3. Press the cursor keys (**◀▶**) to select either the measurement function side (the left side of the screen) or the harmonic order data side (the right side of the screen).
4. Press **PAGE ▲** to display the previous page.
Press **PAGE ▼** to display the next page.

Press **SHIFT+PAGE ▲** (**⏮**) to jump to the first page.
Press **SHIFT+PAGE ▼** (**⏭**) to jump to the last page.



Note

If you do not perform step 2 to clear the menu, you cannot switch between the measurement function and the harmonic order data sides.

7.3 Changing the Displayed Items on the 4 Items, 8 Items, and 16 Items Displays

This section explains the following settings for the displayed items on the 4 Items, 8 Items, and 16 Items displays:

- Item number
- Measurement function
- Element and wiring unit
- Harmonic order
- Resetting the displayed items
- Turning the display frame on and off

To change the displayed items, you can:

- Set the items on the Numeric (4), Numeric (8), or Numeric (16) menu.
- Set items directly by pressing the function select keys and ELEMENT.
 - ▶ “4-, 8-, and 16-value displays (4 Items/8 Items/16 Items)” in the features guide

1. Follow the procedure in section 7.1 to set the numeric data display format to the 4 Items, 8 Items, or 16 Items display.


Numeric (4), Numeric (8), and Numeric (16) menus

2. Press **ITEM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the Numeric (4), Numeric (8), or Numeric (16) menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**.

Example of the Numeric (4) menu



The screenshot shows the Numeric (4) menu with the following options and annotations:


- Item No.**: Select the item number that you want to set. (4 Items display: 1 to 48, 8 Items display: 1 to 96, 16 Items display: 1 to 192)
- Function**: Set the measurement function (None, other functions—for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).
- Element/Σ**: Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC).
- Order**: Set the harmonic order (Total, 0 to 500) (/G5 or /G6 option). You can set this setting only when you have selected a measurement function that includes a harmonic order.
- Reset Items**: Set the resetting of displayed items.
- Display Frame**: Turns the display frame on and off.

Switching the page

To set items that are not on the current page, switch the page. For how to switch the page, see section 7.2.

Reset Items menu

Press the **Reset Items** soft key. The following menu appears.



Function select keys and the ELEMENT key

Follow steps 1 and 2 on the previous page to display the Numeric (4), Numeric (8), or Numeric (16) menu.


3. Press **ESC** to clear the menu.

Example of the 8 Items display

Displayed in the upper left of the numeric data display screen



4. Press the cursor keys, the **PAGE** \blacktriangle \blacktriangledown keys, or the **SHIFT+PAGE** \blacktriangle \blacktriangledown (\blacktriangle and \blacktriangledown) keys to select the item that you want to change.
5. Press the function select key that corresponds to the measurement function that you want to display.
Function select keys: **U/I/P**, **S/Q/X/Φ**, **WP/q/TIME**, **FU/FI/η**, **U/I MODE**
6. Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.
 - Press **SHIFT** and the **ELEMENT** (ALL) key for displaying numeric data to turn on the indicator below the ELEMENT key and change all elements of the measurement functions on the displayed page to the same element and wiring unit at once.
 - Press **SHIFT** and the **ELEMENT** (ALL) key for displaying numeric data again to turn the indicator off and stop setting all elements at once.



7.4 Changing the Displayed Items on the Matrix Display

This section explains the following settings for the displayed items on the Matrix display:

- Item number
- Measurement function
- Element and wiring unit
- Harmonic order
- Resetting the displayed items
- Display column
- Turning the display frame on and off

To change the displayed items, you can:

- Set the items on the Matrix Items menu.
- Set items directly by pressing the function select keys and ELEMENT.

► [“Matrix display \(Matrix\)” in the features guide](#)


1. Follow the procedure in section 7.1 to set the numeric data display format to the Matrix display.

Matrix Items menu

2. Press **ITEM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the Matrix Items menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**.




Switching the page

To set items that are not on the current page, switch the page. For how to switch the page, see section 7.2.


Reset Items menu

Press the **Reset Items** soft key. The following menu appears.



Column Settings menu

Press the **Column Settings** soft key. The following menu appears.




Function select keys and the ELEMENT key

Follow steps 1 and 2 on page 7-6 to display the Matrix Items menu.

3. Press **ESC** to clear the menu.

Displayed in the upper left of the numeric data display screen




Changing the Measurement Function (Vertical direction)

4. Press the cursor keys (**▲▼**), the **PAGE▲▼** keys, or the **SHIFT+PAGE▲▼** (**⏮** and **⏭**) keys to select the row that you want to change.
5. Press the function select key that corresponds to the measurement function that you want to display.

Function select keys: **U/I/P**, **S/Q/λ/φ**, **WP/q/TIME**, **FU/FI/η**, **U/I MODE**

Changing the element and wiring unit (horizontal direction)

4. Use the cursor keys (**◀▶**) to select the column that you want to change.
5. Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.



7.5 Changing the All Items Display

This section explains the following All Items display settings:

- Harmonic order
- Turning the display of all element and all wiring unit data on and off
- Turning the display frame on and off

► “All Items Display (All Items)” in the features guide


1. Follow the procedure in section 7.1 to set the numeric data display format to the All Items display.

Numeric (All) menu

2. Press **ITEM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the Numeric (All) menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**.



— **Set the harmonic order (Total, 0 to 500) (/G5 or /G6 option).**

You can set this setting only when you have selected the page of a measurement function that includes a harmonic order.
For details on how to switch pages, see section 7.2.

— **Numeric data display on/off states of all elements or all wiring units**

If the total number of elements or wiring units is 7 or more, set this to ON when you want to display the numeric data of all elements or all wiring units.

— **Turns the display frame on**

Note

On the All Items display, you cannot select individual displayed items and change their measurement function, element, or wiring unit. If you switch to the Matrix display, you can change the measurement functions, elements, and wiring units using the displayed table (see section 7.4).

7.6 Changing the harmonics list display (option)

This section explains the following settings for the harmonics list display (Hrm List): This feature is available on models with the /G5 or /G6 option.

- List number
- Measurement function
- Element and wiring unit
- Turning the display frame on and off

To change the displayed items, you can:

- Set the items on the List Items menu.
- Set items directly by pressing the function select keys and ELEMENT.
 - ▶ [“Single harmonics and dual harmonics lists \(Hrm Single List/Hrm Dual List, option\)” in the features guide](#)


1. Follow the procedure in section 7.1 to set the numeric data display format to the harmonics list display (Hrm List).

List Items menu

2. Press **ITEM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the List Items menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**. There is a List Items menu for the single harmonics list and the dual harmonics list. When you repeatedly press **NUMERIC**, the menu for the single harmonics list is displayed after the All Items display, and the menu for the dual harmonics list is displayed next.



Note

On the harmonics list displays, you can change the measurement function, element, and wiring unit for the selected list, but you cannot change these settings for each individual displayed item.

Function select keys and the ELEMENT key

Follow steps 1 and 2 on page 7-10 to display the List Items menu.


3. Press **ESC** to clear the menu.
4. Use the cursor keys (**◀▶**) to select the harmonic order data side (the right side of the screen).
If you are displaying the dual harmonics list, you can set the left or right column of the harmonic order data, whichever you have selected.

Example of the single harmonics list

Displayed in the upper left of the numeric data display screen



5. Press the function select key that corresponds to the measurement function that you want to display.
Function select keys: **U/I/P** key and **S/Q/λ/Φ** key
(The **WP/q/TIME** key, **FU/FI/η** key, and **U/I MODE** key are disabled.)
6. Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.
 - If you are displaying the dual harmonics list, press **SHIFT** and the **ELEMENT** (ALL) key for displaying numeric data to turn on the indicator below the ELEMENT key and change all elements of the left and right columns of the harmonic order data to the same element and wiring unit at once.
 - Press **SHIFT** and the **ELEMENT** (ALL) key for displaying numeric data again to turn the indicator off and stop setting all elements at once.



7.7 Setting the Custom Display

This section explains the following Custom display settings:

- Loading display configuration files
- Loading background files
- Display configuration

Total items, items per page, custom items (item number, measurement function, element and wiring unit, harmonic order, display position, font size, font color), saving custom display configuration files

- Turning the display frame on and off


► [“Custom display \(Custom\)” in the features guide](#)

1. Follow the procedure in section 7.1 to set the numeric data display format to Custom.

Custom Items menu


2. Press **ITEM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Items menu may be displayed. If this happens, press **ITEM** again.




Setting the display configuration (Edit Items)

Press the **Edit Items** soft key. The following menu appears.



Customizing display items (Custom Items)

Press the **Custom Items** soft key. The following screen appears.



The settings that you can select for each item are as follows:

Selecting the item number that you want to set

1 to the Total Items

Setting the measurement function

None, measurement functions—for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide.

Setting the element and wiring unit

Element 1 to Element 6, ΣA to ΣC

7.7 Setting the Custom Display

Setting the string and order (harmonic)

- When Function is set to None:
Set the character string (up to 15 characters).
- When the measurement function includes a harmonic order:
Set the harmonic order (Total, 0 to 500) (/G5 or /G6 option).

Setting the display position

- X Pos: 0 (left edge of the screen) to 800 (right edge of the screen)
- Y Pos: 0 (top of the screen) to 671 (bottom of the screen)

Setting the font size


14, 16, 20, 24, 32, 48, 64, 96, 128

Setting the font color

Yellow, Green, Magenta, Cyan, Red, Orange, Light Blue, Purple, Blue, Pink, Light Green, Dark Blue, Blue Green, Salmon Pink, Mid Green, Gray, White, Dark Gray, Blue Gray, Black


Saving display configuration files (Save Custom Items)

Press the **Save Custom Items** soft key. The following menu appears.



Loading display configuration and background files at the same time (Load Items & Bmp)

On the Custom Items menu shown on page 7-12, press the **Load Items & Bmp** soft key. The following screen appears.



Select the file to load.

Select a custom display file.

Display configuration files: TXT format


Background file: BMP format

To load both a display configuration file and background file at the same time, load the display configuration file.

However, an error will occur if a background file that has the same name as the display configuration file is not present in the save destination folder of the display configuration file.

For the operating procedure, see section 18.6.

Example of loading a file for the custom display



Note

After you properly load a display configuration file and a background file, if you restart the instrument and the same background file is not in the same location, the background will return to its default.

8.1 Setting User-Defined Functions


This section explains the following settings for user-defined functions:

- Turning computation on and off
- Computation name
- Unit
- Expression
- Turning max hold on and off

► “User-defined functions (User Defined Functions)” in the features guide

Setting user-defined functions (User Defined Function)

Press **MEASURE** and then the User Defined Function soft key. The following screen appears.



8.2 Setting User-Defined Events

This section explains the following settings for user-defined events:

- Event number
- Turning the event on and off
- Event name
- Character string displayed when events occur or do not occur
- Judgment condition setup method
- Using numeric data to perform judgment

Measurement function, element and wiring unit, harmonic order, comparison condition, comparison reference

- Using logical AND and OR of events to perform judgment
- Inverting judgment conditions

► “User-defined events (User Defined Event)” in the features guide

Setting user-defined events (User Defined Event)

Press **MEASURE** and then the **User Defined Event** soft key. The following screen appears.

Set the event number (1 to 8).

Turns the event on and off

Set the event name (up to 8 characters).

Set the character string that is displayed when events occur or do not occur (up to 6 characters).

Select the judgment condition setup method (Range, Condition).

Using numeric data to perform judgment (Range)

- Set the measurement function (for details on the various measurement functions, see "Items That This Instrument Can Measure" in the features guide).
- Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC).
- Set the harmonic order (Total, 0 to 500) (/G5 or /G6 option).

When you turn an event on, the corresponding check box is selected.

Using logical AND and OR of events to perform judgment (Condition)

- Set the judgment condition inversion.
- Set AND, OR, or END.
- Set the events.

You can select events whose event numbers are smaller than the number specified by Event No. for the current event.

The settings are displayed.

The screenshot shows the 'User Defined Event' screen. At the top, 'Event No.' is set to 5, with 'OFF' and 'ON' buttons. 'Event Name' is 'Ev5', and there are 'TRUE' and 'FALSE' buttons. Below, 'Expression' is set to 'Range', with 'Function' (Urms), 'Element/Σ' (Element 1), and 'Order' (Total) buttons. 'Range' has two input fields, both set to 0.0000. 'Condition' has an 'Inverse' checkbox checked and buttons for 'Ev1', 'AND', 'Ev1', 'OR', 'Ev3', and 'END'. At the bottom, a list of events (Ev1 to Ev8) is shown with checkboxes. Ev1 and Ev5 are checked. Ev1's expression is 'URMS(E1)<100.00E+00 AND URMS(E1)>80.000E+00'. Ev5's expression is 'NOT(EV1()) AND EV1() OR EV3()'. A text box 'The settings are displayed.' points to the event list.

8.3 Setting Apparent Power, Reactive Power, and Corrected Power Formulas

This section explains the following settings for the apparent power, reactive power, and corrected power formulas:


- Apparent power formula
- Apparent power and reactive power calculation types
- Corrected power formula

Applicable standard and coefficients

► “Apparent power, reactive power, and corrected power formulas (Formula)”
in the features guide


Formula menu

Press **MEASURE** and then the **Formula** soft key. The following menu appears.



Setting the corrected power formula (Pc Formula)

Press the **Pc Formula** soft key. The following screen appears.




8.4 Setting the Sampling Frequency

This section explains how to set the sampling frequency.

► [“sampling frequency \(Sampling Frequency\)” in the features guide](#)

Measure menu

Press **MEASURE**. The following menu appears.



— Set the sampling frequency (Auto, Clock A, Clock B, Clock C).


8.5 Setting the Phase Difference Display Format

This section explains how to set the phase difference display format.

► [“Phase difference display format \(Phase\)” in the features guide](#)

Measure menu

Press **MEASURE**. The following menu appears.



— Set the phase difference display format (180 degrees, 360 degrees).


8.6 Setting Master and Slave Synchronous Measurement

This section explains the following setting for master and slave synchronous measurement:

- Master and slave
 - ▶ [“Master/slave synchronous measurement \(Sync Measure\)” in the features guide](#)

Measure menu

Press **MEASURE**. The following menu appears.



— Select whether this is the master unit or a slave unit (Master, Slave).

8.7 Setting the Voltages or Currents Whose Frequencies Will Be Measured

This instrument can measure the frequencies of the voltages or currents of all elements.

9.1 Setting Independent Integration


This section explains the following settings for independent integration: If you turn independent integration on, you can start, stop, and reset integration for each input element separately.

- Turning independent integration on and off
- Element that independent integration will be performed on

► **“Enabling or disabling independent integration (Independent Control)”**
in the features guide


Integ menu

Press **INTEG**. The following menu appears.



Selecting the element that independent integration will be performed on (Element Object)

Press the **Element Object** soft key. The following screen appears.



9.2 Setting Integration Conditions


This section explains the following settings for integration conditions:

- Integration mode
- Integration timer
- Scheduled times for real-time integration
- Turning integration auto calibration on and off
- watt-hour integration method for each polarity
- Current mode for current integration
- Rated time of integrated D/A output (/DA option)

► [“Integration conditions \(Integ Set\)” in the features guide](#)

Integ menu

Press **INTEG** and then the **Integ Set** soft key. The following menu appears.



* You can set this when the data update interval is not Auto.

Setting the integration timer (Integ Timer)

Press the **Integ Timer** soft key. The following screen appears.

When Independent Integration Is Off

Set the integration timer (00000 hours : 00 minutes : 00 seconds to 10000 hours : 00 minutes : 00 seconds).*

When Independent Integration Is On

Select the integration timer's setup method (Each, All). When you select Each, you can set the integration timer for each input element.

* When Mode is set to Normal and the integration timer is 00000 : 00 : 00, the instrument is in manual integration mode.

Setting scheduled times for real-time integration (Real-time Control)

Press the **Real-time Control** soft key. The following screen appears.

The Real-time Control soft key is displayed when Mode is set to R-Normal or R-Continuous.

When independent integration is off

Scheduled integration stop time

Scheduled integration start time

Sets the scheduled integration start time to the current time

Copies the scheduled integration start time to the scheduled integration stop time

Set the scheduled start and stop times (Year/month/day, 00 hours : 00 minutes : 00 seconds-23 hours : 59 minutes : 59 seconds).


When independent integration is on

Select the schedule setup method (Each, All).

When you select Each, you can set the schedule for each input element.

Setting the watt-hour integration method for each polarity (WP± Type)

Press the **WP± Type** soft key. The following screen appears.




The screenshot shows the 'WP± Type' screen. At the top, there are two buttons: 'Each' (highlighted in blue) and 'All'. Below this, there are six rows labeled 'Element 1' through 'Element 6'. Each row has two buttons: 'Charge/Discharge' (highlighted in blue) and 'Sold/Bought'. To the right of the screen, there are two text annotations with arrows pointing to the 'Each' button and the 'Charge/Discharge' buttons respectively.

Select the integration method setup method (Each, All).
When you select Each, you can set the integration method for each input element.

Set the integration method (Charge/Discharge, Sold/Bought).

Setting the current mode for current integration (q Mode)

Press the **q Mode** soft key. The following screen appears.




The screenshot shows the 'q Mode' screen. At the top, there are two buttons: 'Each' (highlighted in blue) and 'All'. Below this, there are six rows labeled 'Element 1' through 'Element 6'. Each row has five buttons: 'rms', 'mean', 'dc' (highlighted in blue), 'r-mean', and 'ac'. To the right of the screen, there are two text annotations with arrows pointing to the 'Each' button and the 'dc' buttons respectively.

Select the current mode setup method (Each, All).
When you select Each, you can set the current mode for each input element.

Set the current mode (rms, mean, dc, r-mean, ac).

Setting the rated time of integrated D/A output (D/A Output Rated Time, /DA option)

Press the **D/A Output Rated Time** soft key. The following screen appears.



The screenshot shows the 'D/A Output Rated Time' screen. It has a label 'Rated Time' followed by three input fields: '00001', '00', and '00'. To the right of the screen, there is a text annotation with an arrow pointing to the input fields.

Set the rated time of integrated D/A output (00000 hours : 00 minutes : 00 seconds to 10000 hours : 00 minutes : 00 seconds).


9.3 Starting, Stopping, and Resetting Integration

This section explains how to start, stop, and reset integration.

► “Starting, stopping, and resetting integration (Start/Stop/Reset)” in the features guide

Integ menu

Press **INTEG**. The following menu appears.



Starts integration

The instrument starts integration using the integration mode that you have specified (see section 8.2).

- **The START indicator to the right of the INTEG key lights.**
Integration running: “Integ: Start” is indicated.*
- **The START indicator to the right of the INTEG key blinks.**
Integration ready: “Integ: Ready” is indicated.*

Stops integration

The instrument automatically stops integration according to the integration mode that you have specified. To manually stop integration, press this soft key. The integration time and integrated value are held.

- **The STOP indicator to the right of the INTEG key blinks.**
Integration stopped: “Integ: Stop” is indicated.*
If you press the Start soft key when “Stop” is indicated in yellow, you can resume integration from the point where you stopped integration.
- **The STOP indicator to the right of the INTEG key lights.**
Auto stop due to integration timer expiration: “Integ: TimeUp” is indicated.*
Auto stop due to real-time control: “Integ: Stop” is indicated.* Stop is indicated in orange.

Resets the integration time and integrated value.

All integration data is deleted, and the no-data display, “-----,” appears. The STOP indicator to the right of the INTEG key lights.

* Indicators are displayed in the upper right of the screen.

Note

You cannot restart integration unless you reset it first.

9.4 Setting the Integration Resume Action at Power Failure Recovery

This section explains the following settings for integration resume action at power failure recovery:

- ▶ “Integration resume action at power failure recovery (Integration Resume Action)”
in the features guide

Integration Resume Action menu

Press **UTILITY**, the **System Config** soft key, and then the **Preference** soft key. The following menu appears.

Preference	
Resolution	
	5digits
Freq Display at Frequency Low	
0	Error
Motor Display at Pulse Freq Low	
0	Error
Decimal Point for CSV File	
Period	Comma
Integration Resume Action	
Start	Stop Error
Menu Font Size	
Small	Large
Rounding to Zero	
OFF	ON

— Set the integration resume action at power failure recovery (Start, Stop, Error).

10.1 Setting the Display Format

This section explains the following settings for the waveform display format:


- Number of waveform display windows
- Time axis
- Trigger
- Advanced settings of the waveform display
- Waveform mapping

► “Display format (FORM)” for waveforms in the features guide

Wave Form menu

Press **WAVE** and then **FORM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **FORM** again.



The screenshot shows the Wave Form menu with the following options and annotations:


- Format** — Set the number of divisions of the waveform screen (Single, Dual, Triad, Quad, Hexa).¹
- Time/div** — Set the time axis ($0.5 \text{ ms to } \frac{\text{the specified data update interval}^2}{10}$). The value 50ms is displayed.
- Trigger Settings** — Configure trigger settings.³
- Display Settings** — Configure the advanced waveform display settings.
- Wave Mapping** — Set waveform mapping.

Footnotes:

- 1 In addition to using this Format soft key, you can repeatedly press WAVE to change the order and the number of divisions.
- 2 For how to set the data update interval, see section 2.15.
- 3 You can set this when the data update interval is not Auto.


Configuring trigger settings (Trigger Settings)

Press the **Trigger Settings** soft key. The following menu appears.



Configuring advanced waveform display settings (Display Settings)


Press the **Display Settings** soft key. The following menu appears.



Note Changes that you make to the waveform display settings on the Display Settings menu are also reflected in the detailed settings of the trend display (see section 11.1).

Setting waveform mapping (Wave Mapping)

Press the **Wave Mapping** soft key. The following screen appears.



Select the waveform mapping mode (Auto, Fixed, User).

Set the mapping destination (the divided screen number: 0 to 5).
Map each waveform (U1, I1, etc.) to the part of the divided screen that you want it to appear on.

- These settings are displayed when Mode is set to User.
- Spd/Aux1 and Trq/Aux2 can be set on models with the /MTR or /AUX options.

10.2 Turning the Display of Waveforms On and Off and Setting the Vertical Zoom Factors and Vertical Positions

This section explains the following waveform display settings:

- Turning the display of waveforms on and off
- Vertical zoom factor
- Vertical position

► “Display Items (ITEM)” for waveforms in the features guide

Configuring the waveform display

Press **WAVE** and then **ITEM**. The following screen appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **ITEM** again.

Select the waveforms that you want to display.

Set the vertical zoom factor

(x 0.1, x 0.2, x 0.25, x 0.4, x 0.5, x 0.75, x 0.8, x 1, x 1.14, x 1.25, x 1.33, x 1.41, x 1.5, x 1.6, x 1.77, x 2, x 2.28, x 2.66, x 2.83, x 3.2, x 3.54, x 4, x 5, x 8, x 10, x 12.5, x 16, x 20, x 25, x 40, x 50, x 100)

Set the vertical position (0.000 % to ±130.000 %).

Display ON/OFF	Wave Items	Vertical Zoom	Vertical Position
<input checked="" type="checkbox"/> U1		x 1	0.000%
<input checked="" type="checkbox"/> I1		x 1	0.000%
<input checked="" type="checkbox"/> U2		x 1	0.000%
<input checked="" type="checkbox"/> I2		x 1	0.000%
<input checked="" type="checkbox"/> U3		x 1	0.000%
<input checked="" type="checkbox"/> I3		x 1	0.000%
<input checked="" type="checkbox"/> U4		x 1	0.000%
<input checked="" type="checkbox"/> I4		x 1	0.000%
<input checked="" type="checkbox"/> U5		x 1	0.000%
<input checked="" type="checkbox"/> I5		x 1	0.000%
<input checked="" type="checkbox"/> U6		x 1	0.000%
<input checked="" type="checkbox"/> I6		x 1	0.000%
<input checked="" type="checkbox"/> Speed	Speed and Torque are displayed on models with the /MTR option.		
<input checked="" type="checkbox"/> Torque			

<input checked="" type="checkbox"/> Aux1	Aux1 and Aux2 are displayed on models with the /AUX option.
<input checked="" type="checkbox"/> Aux2	

Turns the display of all waveforms on

Turns the display of all waveforms off

11.1 Setting the Display Format


This section explains the following settings for the trend display format:

- Number of trend display windows
- Time axis
- Restarting trends
- Advanced trend display settings

► “Display format (FORM)” for trends in the features guide

Others menu


Press **OTHERS**. The following menu appears.



Trend Form Menu


Press **FORM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **FORM** again.



Configuring advanced trend display settings (Display Settings)

Press the **Display Settings** soft key. The following menu appears.



Note

Changes that you make to the trend display settings on the Display Settings menu are also reflected in the detailed settings of the waveform display (see section 10.1).

11.2 Turning the Trend Display On and Off and Setting the Measurement Functions to Display and the Vertical Scales

This section explains the following trend display settings:

- Turning the trend display on and off
- Measurement function
- Element and wiring unit
- Harmonic order
- Vertical scale

Vertical scale mode and upper and lower limits of vertical scales

► “Display Items (ITEM)” for trends in the features guide

1. Follow the procedure in section 11.1 to select Trend on the Others menu.

Configuring the trend display

2. Press **ITEM**. The following screen appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **ITEM** again.

Select the trends that you want to display.

If you move the cursor to Display, and then press SET, you can select all the trends and clear all the selections.

Set the measurement function (for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).

Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC).

Set the harmonic order (Total, 0 to 500) (/G5 or /G6 option).

You can set this setting when the measurement function includes a harmonic order.

Trend Items						
Display	Function	Element/ Σ	Order	Scaling	Upper Scale	Lower Scale
<input checked="" type="checkbox"/> T1	Urms	Element 1	-	Manual	100.0	-100.0
<input checked="" type="checkbox"/> T2	Irms	Element 1	-	Auto	-	-
<input checked="" type="checkbox"/> T3	P	Element 1	-	Auto	-	-
<input checked="" type="checkbox"/> T4	S	Element 1	-	Auto	-	-
<input checked="" type="checkbox"/> T5	Q	Element 1	-	Auto	-	-
<input checked="" type="checkbox"/> T6	λ	Element 1	-	Auto	-	-
<input checked="" type="checkbox"/> T7	ϕ	Element 1	-	Auto	-	-
<input checked="" type="checkbox"/> T8	FreqU	Element 1	-	Auto	-	-
<input type="checkbox"/> T9	Urms	Element 1	-	Auto	-	-
<input type="checkbox"/> T10	Urms	Element 1	-	Auto	-	-
<input type="checkbox"/> T11	Urms	Element 1	-	Auto	-	-
<input type="checkbox"/> T12	Urms	Element 1	-	Auto	-	-
<input type="checkbox"/> T13	Urms	Element 1	-	Auto	-	-
<input type="checkbox"/> T14	Urms	Element 1	-	Auto	-	-
<input type="checkbox"/> T15	Urms	Element 1	-	Auto	-	-
<input type="checkbox"/> T16	Urms	Element 1	-	Auto	-	-

Select the vertical scale's setup method (Auto, Manual).

Set the upper and lower limits (-9.999 T to 9.999 T).

These settings can be set when Scaling is set to Manual.

12.1 Setting the Display Format


This section explains the following settings for the bar graph display format: This feature is available on models with the /G5 or /G6 option.

- Number of bar graph display windows
- Bar graph display range (displayed harmonics)

► “Display format (FORM)” for bar graphs in the features guide

Others menu


Press **OTHERS**. The following menu appears.



Bar Form Menu

Press **FORM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **FORM** again.



12.2 Setting the Measurement Function to Display and the Vertical Scale

This section explains the following bar graph display settings: This feature is available on models with the /G5 or /G6 option.

- Bar graph number
- Measurement function
- Element
- Vertical scale

Vertical scale mode, vertical scale type, vertical scale upper limit, and X-axis position

► **“Display Items (ITEM)” for bar graphs in the features guide**

1. Follow the procedure in section 12.1 to select Bar on the Others menu.

Bar Items menu

2. Press **ITEM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **ITEM** again.

Bar Items	
Item No.	1
Function	U
Element	Element 1
Scale Mode	Fixed Manual
Vertical Scale	Linear Log
Upper Scale	100.0
X Axis Position	Bottom Center

— Select the bar graph number that you want to set (1, 2, 3).

— Set the measurement function (U, I, P, S, Q, λ , Φ , ΦU , ΦI , Z, Rs, Xs, Rp, Xp).

— Set the element (Element 1 to Element 6).

— Select the vertical scale's setup method (Fixed, Manual).

— Set the vertical scale type (Linear, Log).
This soft key is displayed when you set Scale Mode to Manual.

— Set the upper limit (0 to 9.999T).
This soft key is displayed when you set Scale Mode to Manual.

— Set the X-axis position (Bottom, Center).
This soft key is displayed when you set Scale Mode to Manual and Vertical Scale to Linear.

13.1 Setting the Display Format


This section explains the following settings for the vector display format: This feature is available on models with the /G5 or /G6 option.

- Number of vector display windows
- Turning the numeric data display on and off

► “Display format (FORM)” for vectors in the features guide

Others menu


Press **OTHERS**. The following menu appears.



Vector Form Menu

Press **FORM**. The following menu appears.

If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **FORM** again.



13.2 Setting the Element and Wiring Unit to Display and the Zoom Factor

This section explains the following vector display settings: This feature is available on models with the /G5 or /G6 option.


- Vector number
- Element and wiring unit
- Zoom factor

► “Display Items (ITEM)” for vectors in the features guide

1. Follow the procedure in section 13.1 to select Vector on the Others menu.

Vector Items menu

2. Press **ITEM**. The following menu appears.
 - If the setup parameter list is being displayed (the INPUT INFO key is lit), the Info Form menu may be displayed. If this happens, press **ITEM** again.
 - If setup parameter list is being displayed, the vector that you have set to vector number 1 is displayed in the bottom half of the screen.



— Select the vector number that you want to set (1, 2).

— Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC).

— Set the zoom factor (0.100 to 100.000).

- Set the zoom factor of fundamental wave U(1) or I(1). The value that indicates the size of the vector display's peripheral circle changes according to the zoom factor, and the size of the vectors that indicate U (1) and I (1) change accordingly as well.
- If you press this soft key to select both U Mag and I Mag, you can change both magnifications while maintaining the relationship between the two.

14.1 Configuring the Split Display

This section explains the following split display settings:

- The two screens to display
- Switching between Form menus
- Switching between Items menus

► “Split Display” in the features guide

Others menu

Press **OTHERS**. The following menu appears.

Others

Trend

Bar

Vector

Numeric
+
Wave

Wave
+

Trend
+

High Speed
Data Capturing

Of the following three configurations, the split screen that you configure last is displayed.

- The top half of the screen shows the Numeric display. Set the display to show in the bottom half (Wave, Trend, Bar,* Vector*).
- The top half of the screen shows the Wave display. Set the display to show in the bottom half (Numeric, Trend, Bar,* Vector*).
- The top half of the screen shows the Trend display. Set the display to show in the bottom half (Numeric, Wave, Bar,* Vector*).

* This feature is available on models with the /G5 or /G6 option.

Form menu

Press **FORM**. The Form menu for each of the two screens set in the Others menu is displayed alternately. Configure the settings on each menu.

Display	For details, see:
Numeric	Sections 7.1 and 7.2
Wave	Section 10.1
Trend	Section 11.1
Bar	Section 12.1
Vector	Section 13.1

When the setup parameter list is displayed (the INPUT INFO key is lit), it appears in the top half of the screen, and the display that you assigned in the Others menu to the top window in the split display is displayed in the bottom half of the screen. Additionally, if you repeatedly press **FORM**, you can switch between the Info Form menu and the menu of the screen that is displayed in the bottom half of the screen.

Items menu

Press **ITEM**. The Items menu for each of the two screens set in the Others menu is displayed alternately. Configure the settings on each menu.

Display	For instructions, see
Numeric	Section 7.3 to section 7.7
Wave	Section 10.2
Trend	Section 11.2
Bar	Section 12.2
Vector	Section 13.2

When the setup parameter list is displayed (the INPUT INFO key is lit), it appears in the top half of the screen, and the display that you assigned in the Others menu to the top window in the split display is displayed in the bottom half of the screen. Additionally, if you repeatedly press **ITEM**, you can switch between the Info Form menu and the menu of the screen that is displayed in the bottom half of the screen.

15.1 Performing Cursor Measurements on Waveforms

This section explains the following settings for performing cursor measurements on waveforms:

- Turning the cursor display on and off
- The waveforms to perform cursor measurements on
- Cursor movement path
- Cursor position
- Turning linked cursor movement on and off

► [“Cursor Measurement” in the features guide](#)

1. Follow the procedures in chapter 10 to display waveforms.

Wave Cursor menu

2. Press **SHIFT+FORM** (CURSOR). The following menu appears.

Wave Cursor	
Cursor	— Turns the cursor display on and off
OFF ON	
C1+ Trace	— Set the waveform to measure with cursor 1 (+) (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Speed, ¹ Torque, ¹ Aux1, ² Aux2 ²).
U1	
C2× Trace	— Set the waveform to measure with cursor 2 (×) (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Speed, ¹ Torque, ¹ Aux1, ² Aux2 ²).
I1	
Cursor Path	— Set the cursor movement path (Max, Min, Mid).
Max	
↔ C1+ Position	— Set the positions of cursor 1 (+) and cursor 2 (×) (0, which is the left edge of the screen to 800, which is the right edge of the screen)
160	
↔ C2× Position	
640	
Linkage	— Turns linked cursor movement on and off
OFF ON	

1 This feature is available on models with the /MTR option.
2 This feature is available on models with the /AUX option.

15.2 Performing Cursor Measurements on Trends

This section explains the following settings for performing cursor measurements on trends:


- Turning the cursor display on and off
- The trends to perform cursor measurements on
- Cursor position
- Turning linked cursor movement on and off

► [“Cursor measurement” in the features guide](#)

1. Follow the procedures in chapter 11 to display trends.

Trend Cursor menu

2. Press **SHIFT+FORM** (CURSOR). The following menu appears.



15.3 Performing Cursor Measurements on Bar Graphs

This section explains the following settings for performing cursor measurements on bar graphs:


- Turning the cursor display on and off
- Cursor position
- Turning linked cursor movement on and off

► [“Cursor measurement” in the features guide](#)

1. Follow the procedures in chapter 12 to display bar graphs.

Bar Cursor menu

2. Press **SHIFT+FORM** (CURSOR). The following menu appears.



16.1 Setting the Number of Data Captures and Configuring the Capture Control Settings

This section explains the following settings concerning the number of data captures for high speed data capturing and the capture control settings.

- Number of data captures
- Confirming and optimizing the maximum capturing count
- Capture control settings


Voltage and current measurement modes, turning the HS filter on and off, setting the HS filter cutoff frequency, triggering, performing synchronous measurement using an external signal

- Turning file recording on and off

► **“Capture count (Capture Count)” and “Capture control settings (Control Settings)” in the features guide**


Others menu

Press **OTHERS**. The following menu appears.



HS Settings menu

Press **FORM**. The following menu appears.




HS Settings

- Capt. Count** (Infinite) — Set the number of data captures (Infinite, 1 to 10000000).
- Optimize Count** — Confirm and optimize the maximum capturing count.*
- Control Settings** — Configure capture control.
 - Record to File** (OFF/ON) — Turns file recording on and off*
 - OFF:** When high speed data capturing is performed, you can use communication commands to output the captured data.
 - ON:** “File State: Ready” appears in the upper left of the screen. When high speed data capturing is performed, the captured data is recorded (saved) according to the save conditions set in section 15.2.
- File Settings** — Set the save conditions. ► sec. 15.2
- Start** — Starts high speed data capturing ► sec. 15.4
- Stop** — Stops high speed data capturing ► sec. 15.4

* You cannot configure the settings in “Confirming and optimizing the maximum capturing count” when Record to File is set to OFF.

Viewing and optimizing the maximum capturing count (Optimize Count)

Press the **Optimize Count** soft key. The following screen appears.



Optimize Count

Maximum Capturing Count: 506811 **Set**


Set the number of data captures.
The capturing count is set to the maximum capturing count displayed to the left.

Maximum capturing count (0 to the maximum number of captures*)

- * The maximum number of times that data can be captured depends on the number of numeric data items that you have set to be saved and the free space at the save destination.
For how to set the save destination and the numeric data items to be saved, see section 15.2.
- If the save destination is set to a USB memory device (drive) and you unplug it, the save destination automatically changes to internal memory. If you close this screen and then open it again by pressing the Optimize Count soft key, the maximum capturing count changes to the value determined by the internal memory's free space.


Configuring capture control settings (Control Settings)

Press the **Control Settings** soft key. The following menu appears.



Setting the voltage and current measurement modes


Press the **U/I Measuring Mode** soft key. The following menu appears.



Note

If the voltage and current measurement mode settings differ for elements assigned to the same wiring unit, the measurement data (Σ function) for the wiring unit is displayed as "-----" (no data).

Configuring trigger settings



Control Settings

U/I Measuring Mode

HS Filter OFF ON

Cutoff

Trigger Settings

Mode

Auto

Source

U1

Slope

f f f

Level

0.0%

Set the trigger mode (Auto, Normal, OFF).

Set the trigger source (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk).

Set the trigger slope (\downarrow , \uparrow , $f\uparrow$).

Set the trigger level (0.0 % to ± 100.0 %).

16.2 Configuring the Save Conditions of Captured Numeric Data

This section explains the following settings for the save conditions of captured numeric data:


- Save destination
- Selecting whether to perform automatic CSV conversion when capturing stops
- Turning the CSV file save destination setting on and off
- Numeric data items to save
- Auto naming
- File name
- Comment

► [“Save conditions \(File Settings\)” in the features guide](#)

1. Follow the procedure in section 16.1 to select High Speed Data Capturing on the Others menu.

File Settings menu

2. Press **FORM** and then the **File Settings** soft key. The following menu appears.



Setting the save destination and performing manual CSV conversion

Press the **File List** or **File List (WTS/HDS)** soft key. The following screen appears.

Set the save destination.*
When high speed data capturing starts (see section 16.4), captured data is saved to the specified file name at the specified save destination.

* For binary files, you cannot specify a network drive as the save destination

The File List screen shows the following data:

File Name	Size	Date	Attr
0000.WTS	5.86K	2024/03/04 14:18:04	r/w
0001.WTS	23.4K	2024/06/14 09:25:00	r/w
0002.WTS	93.8K	2024/06/14 09:25:44	r/w

The File Settings menu includes the following options:

- Auto CSV Conversion: OFF (ON)
- Auto Naming: Numbering (sec. 18.2)
- File Name: (sec. 18.2)
- Comment: (sec. 18.2)
- CSV Convert

Executes the manual CSV conversion
Select the data file (.WTS file) that was saved, and then press the CSV Convert soft key to create a data file in ASCII format.

Setting the save destination (when the CSV file save setting is on)

Press the **File List (conversion CSV)** soft key. The following screen appears.

Set the save destination.
When high speed data capturing starts (see section 16.4), captured data is saved to the specified file name at the specified save destination.

The File List screen shows the following data:

File Name	Size	Date	Attr
0000.CSV	15.2K	2024/03/04 14:18:06	r/w
0001.CSV	15.2K	2024/03/04 14:18:06	r/w
0002.CSV	15.2K	2024/03/04 14:18:06	r/w

The File Settings menu includes the following options:

- Auto CSV Conversion: OFF (ON)
- Auto Naming: Numbering (sec. 18.2)
- File Name: (sec. 18.2)
- Comment: (sec. 18.2)

Setting the numeric data items to save

Press the **Item Settings** soft key. The following screen appears.

The numeric data items in this screen whose check boxes are selected are saved.

For the individual numeric data items U, I, and P, you can set whether to save the numeric data for all installed input elements and wiring units (All ON) or not (All OFF).

You can set whether to save all the numeric data (All ON) or not (All OFF).

For each input element or wiring unit, you can set whether to save the numeric data for U, I, and P (All ON) or not (All OFF). You cannot configure this setting for slots that do not have input elements installed in them.

The screenshot shows the 'Item Settings' screen with the following table:

	All	Element1	Element2	Element3	Element4	Element5	Element6	Σ A	Σ B	Σ C
U	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
I	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
P	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Motor										
Speed	<input type="checkbox"/>									
Torque	<input type="checkbox"/>									
Pm	<input type="checkbox"/>									

Slot in which an input element is not installed

On models with the /MTR option, you can set whether to save the numeric data for Speed, Torque, and Pm (All ON) or not (All OFF).

	Aux
Aux1	<input type="checkbox"/>
Aux2	<input type="checkbox"/>

On models with the /AUX option, you can set whether to save the numeric data for Aux1 and Aux2 (All ON) or not (All OFF).

Note

Even if you select the check box for wiring unit ΣA, ΣB, or ΣC, the wiring unit's numeric data will not be saved if:

- The wiring system has not been set.
- The wiring system is set to 1P3W or 3P3W.
- The input elements assigned to the same wiring unit have different voltage or current measurement mode settings.

For how to set the wiring system, see section 2.1.

16.3 Changing the Displayed Items for High Speed Data Capturing

This section explains the following settings for high speed data capturing:


- Number of columns
- Column number
- Element and wiring unit
- Resetting the displayed items
- Peak over-range information
- Turning the display frame on and off

► [“Display Items \(ITEM\)” for high speed data capturing in the features guide](#)

1. Follow the procedure in section 16.1 to select High Speed Data Capturing on the Others menu.

HS Items menu

2. Press **ITEM**. The following menu appears.



Switching the page

You can switch between page 1 and 2 (pages 1 to 4 on models with the /MTR or /AUX option). The items are arranged for high speed data capturing, and the displayed measurement functions are fixed for every page. For how to switch the page, see section 7.2.

Example of page 1

		Element 1	Element 2	Element 3	Element 4	PAGE
	Voltage	1000Vrms	1000Vrms	1000Vrms	1000Vrms	1
	Current	5Arms	5Arms	5Arms	50Arms	
U	[V]	0.0000 k	0.0000 k	0.0000 k	0.0000 k	2
I	[A]	0.0000	0.0000	0.0000	0.000	3
P	[W]	-0.0000 k	-0.0000 k	-0.0000 k	-0.000 k	4

Example of page 2

		Element 1 1000Vrms 5Arms	Element 2 1000Vrms 5Arms	Element 3 1000Vrms 5Arms	Element 4 1000Vrms 50Arms	PAGE 1
Voltage						2
Current						3
U	[V]	0.0000 k	0.0000 k	0.0000 k	0.0000 k	4
MaxU		0.0000 k	0.0000 k	0.0000 k	0.0000 k	
MinU		0.0000 k	0.0000 k	0.0000 k	0.0000 k	
I	[A]	0.0000	0.0000	0.0000	0.000	
MaxI		0.0000	0.0000	0.0000	0.000	
MinI		0.0000	0.0000	0.0000	0.000	
P	[W]	-0.0000 k	-0.0000 k	-0.0000 k	-0.000 k	
MaxP		0.0000 k	-0.0000 k	-0.0000 k	0.000 k	
MinP		-0.0000 k	-0.0000 k	-0.0000 k	-0.000 k	

Example of page 3

(Page 3 is available only on models with the /MTR or /AUX Option.)

		Element 1 1000Vrms 5Arms	Element 2 1000Vrms 5Arms	Element 3 1000Vrms 5Arms	Element 4 1000Vrms 50Arms	PAGE 1
Voltage						2
Current						3
U	[V]	0.0000 k	0.0000 k	0.0000 k	0.0000 k	4
I	[A]	0.0000	0.0000	0.0000	0.000	
P	[W]	-0.0000 k	-0.0000 k	-0.0000 k	-0.000 k	
Speed	[rpm]	-0.001				
Torque	[Nm]	-0.005				
Pm	[W]	0.000				
Aux1	[kW/m2]	0.000				
Aux2	[kW/m2]	-0.000				

Speed, Torque, and Pm are displayed on models with the /MTR option.

Aux1 and Aux2 are displayed on models with the /AUX option.

Example of page 4

(Page 4 is available only on models with the /MTR or /AUX Option.)

		Element 1 1000Vrms 5Arms	Element 2 1000Vrms 5Arms	Element 3 1000Vrms 5Arms	Element 4 1000Vrms 50Arms	PAGE 1
Voltage						2
Current						3
U	[V]	0.0000 k	0.0000 k	0.0000 k	0.0000 k	4
MaxU		0.0000 k	0.0000 k	0.0000 k	0.0000 k	
MinU		0.0000 k	0.0000 k	0.0000 k	0.0000 k	
I	[A]	0.0000	0.0000	0.0000	0.000	
MaxI		0.0000	0.0000	0.0000	0.000	
MinI		0.0000	0.0000	0.0000	0.000	
P	[W]	-0.0000 k	-0.0000 k	-0.0000 k	-0.000 k	
MaxP		0.0000 k	-0.0000 k	-0.0000 k	0.000 k	
MinP		-0.0000 k	-0.0000 k	-0.0000 k	-0.000 k	
Speed	[rpm]	-0.001				
MaxSpd		0.000				
MinSpd		-0.001				
Torque	[Nm]	-0.005				
MaxTrq		-0.000				
MinTrq		-0.005				
Pm	[W]	0.000				
MaxPm		0.000				
MinPm		-0.000				
Aux1	[kW/m2]	-0.000				
MaxAux1		0.000				
MinAux1		-0.000				
Aux2	[kW/m2]	0.000				
MaxAux2		0.001				
MinAux2		-0.000				

Speed, Torque, and Pm are displayed on models with the /MTR option.

Aux1 and Aux2 are displayed on models with the /AUX option.

ELEMENT key

- Press **ESC** to clear the menu.


Displayed in the upper left of the numeric data display screen



Changing the element and wiring unit (horizontal direction)

- Use the cursor keys (◀▶) to select the column that you want to change.
- Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.

In high speed data capturing, the elements and wiring unit configurations are the same on all four pages. If you change the element and wiring unit configuration on one page, the configuration changes on the other pages as well.




16.4 Starting and Stopping High Speed Data Capturing

This section explains how to start and stop high speed data capturing.

► [“Starting and stopping high speed data capturing \(Start/Stop\)”in the features guide](#)

CAUTION


During high speed data capturing and when captured data is being saved, the storage device is constantly being accessed, even though the icon that indicates this () is not displayed. Do not unplug the USB memory device or turn the power off. Doing so may damage the storage device or corrupt the data.

While high speed data capturing is in progress, “HS State: Start” is displayed in the upper right of the screen.

While the captured data is being saved, “File State: Rec” is displayed in the upper left of the screen.

French

ATTENTION

Pendant la capture de données à grande vitesse et lorsque les données capturées sont enregistrées, le périphérique de stockage est constamment accessible, même si l’icône qui indique ceci () ne s’affiche pas.

Ne débranchez pas le dispositif de mémoire USB et ne coupez pas l’alimentation.

Cela pourrait endommager le dispositif de stockage ou corrompre les données.


Pendant que la capture de données à grande vitesse est en cours, « HS State : Start » s’affiche en haut à droite de l’écran.

Pendant l’enregistrement des données capturées, « File State: Rec » s’affiche en haut à gauche de l’écran.

-
1. Follow the procedure in section 16.1 to select High Speed Data Capturing on the Others menu.

HS Settings menu

2. Press **FORM**. The following menu appears.



Starts high speed data capturing

High speed data capturing starts according to the specified number of data captures (see section 15.1), the capture control settings (see section 15.1), and the save conditions (see section 15.2).

- **When high speed data starts, “HS State: Start” appears in the upper right of the screen.**
- **While the captured data is being saved, “File State: Rec” is displayed in the upper left of the screen.**

Stops high speed data capturing

After the specified number of data captures have been made, high speed data capturing automatically stops. To manually stop high speed data capturing, press this soft key.

- **When high speed data stops, “HS State: Ready” appears in the upper right of the screen.**

Note

- You cannot restart high speed data capturing unless you stop it first.
- If you change the settings or restart high speed data capturing after it stops, the data captured up to that point is deleted.

17.1 Configuring Storage Control

This section explains the following settings for storage control:


- Storage mode
- Storage count
- Confirming and optimizing the maximum storage count
- Storage interval
- Scheduled times for real-time storage mode
- Trigger event (synchronization to a user-defined event)
- Storage of numeric data when storage starts

► [“Storage control \(Control Settings\)” in the features guide](#)

Control Settings menu


Press **SHIFT+STORE START** (STORE SET) and then the **Control Settings** soft key. The menu that appears varies depending on the specified storage mode.

Manual storage mode



Confirming and optimizing the maximum storage count

Press the **Optimize Count** soft key. The following screen appears.




Maximum storage count (0-the maximum number of times that data can be stored to the save destination)*

* The maximum number of times that storage can be performed depends on the number of stored items that you have set and the free space at the save destination. For details on how to set the stored items, see section 17.2. For details on how to set the save destination, see section 17.3.


If the save destination is set to a USB memory device (drive) and you unplug it, the save destination automatically changes to internal memory. If you close this screen and then open it again by pressing the Optimize Count soft key, the maximum capturing count changes to the value determined by the internal memory's free space.

Setting the storage interval

Press the **Interval** soft key. The following screen appears.



Real-time storage mode




Control Settings

- Store Mode** — Set Store Mode to Real Time.
Real Time
- Store Count** — Set the storage count (Infinite, 1 to 9999999).
100
- Optimize Count** — Confirms and optimizes the maximum storage count ► previous page
- Interval** — Set the storage interval. ► previous page
- Real-time Control** — Set the scheduled times for real-time storage mode.
- Store at Start** — Select whether to store numeric data when storage starts.
OFF ON
This soft key is displayed when the storage interval is set to a value other than 00 : 00 : 00.

Setting the scheduled times for real-time storage mode


Press the **Real-Time Control** soft key. The following screen appears.



Real-time Control

- Start** — Set the scheduled start and stop times (Year/month/day, 00 hours : 00 minutes : 00 seconds to 23 hours : 59 minutes : 59 seconds).
2024 / 01 / 01 00 : 00 : 00
- End** — Set the scheduled storage stop time.
2024 / 01 / 01 01 : 00 : 00
- Now** — Copies the scheduled storage start time to the scheduled storage stop time.
- Copy** — Sets the scheduled storage start time to the current time.

Integration-synchronized storage mode



Control Settings

- Store Mode** — Set Store Mode to Integ Sync.
Integ Sync
- Store Count** — Set the storage count (Infinite, 1 to 9999999).
100
- Optimize Count** — Confirms and optimizes the maximum storage count ► previous page
- Interval** — Set the storage interval. ► previous page
- Store at Start** — Select whether to store numeric data when storage starts.
OFF ON

Event-synchronized storage mode

Control Settings

Store Mode

Event

Store Count

100

Optimize Count

Trigger Event

Event1

Set Store Mode to Event.

Set the storage count (Infinite, 1 to 9999999).

Confirms and optimizes the maximum storage count ▶ page 17-1

Select the trigger event (Event 1 to Event 8).
When measured data is updated, storage is started if the conditions of the specified user-defined event are met.

Single-shot storage mode

Control Settings

Store Mode

Single Shot

Store Count

100

Optimize Count

Set Store Mode to Single Shot.

Set the storage count (Infinite, 1 to 9999999).

Confirms and optimizes the maximum storage count ▶ page 17-1

17.2 Setting the Numeric Data Items to Store

This section explains how to set the numeric data items to store.

- Numeric data items to store
- Numeric data items that are displayed on the screen
- Numeric data items specified on the stored item setup screen

► [“Stored items \(Item Settings\)” in the features guide](#)

Item Settings menu

Press **SHIFT+STORE START** (STORE SET) and then the **Item Settings** soft key. The following menu appears.

Item Settings	
Displayed Numeric Items	Stores the numeric data that is displayed on the screen Press this soft key to store the numeric data items that are displayed on the screen.
Selected Items	Stores the numeric data that you have specified on the Store Items setup screen Press this soft key to store the numeric data items that you have specified on the Store Items setup screen that is displayed when you press the Items soft key.
Items	Set the stored items. This soft key is displayed when you select Selected Items.

Setting Stored Items (Items)

Press the **Items** soft key. The following screen appears.

When you press the Selected Items soft key on the Item Settings menu, the numeric data items that you have specified on the following screen are stored.

Selects all the numeric data items

Clears the selection of all the numeric data items

Selects the preset numeric data items

Preset	All ON	All OFF	Preset1	Preset2			
Element	<input checked="" type="checkbox"/> Element1	<input type="checkbox"/> Element2	<input type="checkbox"/> Element3	<input type="checkbox"/> Element4	<input type="checkbox"/> Element5		
Function	<input checked="" type="checkbox"/> ΣA	<input type="checkbox"/> ΣB	<input type="checkbox"/> Udc	<input type="checkbox"/> Umn	<input type="checkbox"/> Uac	<input checked="" type="checkbox"/> FreqU	<input type="checkbox"/> GfU
	<input checked="" type="checkbox"/> Irms	<input type="checkbox"/> Imn	<input type="checkbox"/> Idc	<input type="checkbox"/> Imn	<input type="checkbox"/> Iac	<input checked="" type="checkbox"/> FreqI	<input type="checkbox"/> Cfl
	<input checked="" type="checkbox"/> P	<input checked="" type="checkbox"/> S	<input checked="" type="checkbox"/> Q	<input checked="" type="checkbox"/> λ	<input checked="" type="checkbox"/> ϕ	<input type="checkbox"/> Pc	
	<input type="checkbox"/> U+peak	<input type="checkbox"/> U-peak	<input type="checkbox"/> I+peak	<input type="checkbox"/> I-peak	<input type="checkbox"/> P+peak	<input type="checkbox"/> P-peak	
	<input type="checkbox"/> WP	<input type="checkbox"/> WP+	<input type="checkbox"/> WP-	<input type="checkbox"/> q	<input type="checkbox"/> q+	<input type="checkbox"/> q-	
	<input type="checkbox"/> Time	<input type="checkbox"/> WS	<input type="checkbox"/> WQ				
	<input type="checkbox"/> 71	<input type="checkbox"/> 72	<input type="checkbox"/> 73	<input type="checkbox"/> 74			
	<input type="checkbox"/> F1	<input type="checkbox"/> F2	<input type="checkbox"/> F3	<input type="checkbox"/> F4	<input type="checkbox"/> F5	<input type="checkbox"/> F6	<input type="checkbox"/> F7
	<input type="checkbox"/> F8	<input type="checkbox"/> F9	<input type="checkbox"/> F10	<input type="checkbox"/> F11	<input type="checkbox"/> F12	<input type="checkbox"/> F13	<input type="checkbox"/> F14
	<input type="checkbox"/> F15	<input type="checkbox"/> F16	<input type="checkbox"/> F17	<input type="checkbox"/> F18	<input type="checkbox"/> F19	<input type="checkbox"/> F20	
	<input type="checkbox"/> Event1	<input type="checkbox"/> Event2	<input type="checkbox"/> Event3	<input type="checkbox"/> Event4			
	<input type="checkbox"/> Event5	<input type="checkbox"/> Event6	<input type="checkbox"/> Event7	<input type="checkbox"/> Event8			
	<input type="checkbox"/> FreqPLL1	<input type="checkbox"/> FreqPLL2					
	<input type="checkbox"/> U(k)	<input type="checkbox"/> I(k)	<input type="checkbox"/> P(k)	<input type="checkbox"/> S(k)	<input type="checkbox"/> Q(k)	<input type="checkbox"/> $\lambda(k)$	<input type="checkbox"/> $\phi(k)$
	<input type="checkbox"/> $\Phi U(k)$	<input type="checkbox"/> $\Phi I(k)$	<input type="checkbox"/> Z(k)	<input type="checkbox"/> Rs(k)	<input type="checkbox"/> Xs(k)	<input type="checkbox"/> Rp(k)	<input type="checkbox"/> Xp(k)
	<input type="checkbox"/> Uthd	<input type="checkbox"/> Ithd	<input type="checkbox"/> Pthd	<input type="checkbox"/> Uhdff(k)	<input type="checkbox"/> Ihdff(k)	<input type="checkbox"/> Phdff(k)	
	<input type="checkbox"/> Uthf	<input type="checkbox"/> Ithf	<input type="checkbox"/> Uthf	<input type="checkbox"/> Ithf	<input type="checkbox"/> hvf	<input type="checkbox"/> hcf	<input type="checkbox"/> K-factor
	<input type="checkbox"/> $\Phi Uj-Uj$	<input type="checkbox"/> $\Phi Uj-Uk$	<input type="checkbox"/> $\Phi Uj-Ij$	<input type="checkbox"/> $\Phi Uj-Ik$			
	<input type="checkbox"/> $\Delta U1$	<input type="checkbox"/> $\Delta U2$	<input type="checkbox"/> $\Delta U3$	<input type="checkbox"/> $\Delta U\Sigma$	<input type="checkbox"/> ΔI		
	<input type="checkbox"/> $\Delta P1$	<input type="checkbox"/> $\Delta P2$	<input type="checkbox"/> $\Delta P3$	<input type="checkbox"/> $\Delta P\Sigma$			
	<input type="checkbox"/> Speed	<input type="checkbox"/> Torque	<input type="checkbox"/> SyncSp	<input type="checkbox"/> Slip	<input type="checkbox"/> Pm	<input type="checkbox"/> EaU	<input type="checkbox"/> EaI

Select the numeric items that you want to store.

17.3 Configuring the Save Conditions of Stored Numeric Data


This section explains the following settings for the save conditions of stored numeric data:

- Save destination
- Selecting whether to perform automatic CSV conversion when storage stops
- Turning the CSV file save destination setting on and off
- Auto naming
- File name
- Comment

► “Save conditions (File Settings)” in the features guide

File Settings menu

Press **SHIFT+STORE START** (STORE SET) and then the **File Settings** soft key. The following menu appears.




Setting the save destination and performing manual CSV conversion

Press the **File List** or **File List (WTS/HDS)** soft key. The following screen appears.

Set the save destination.*

When storage starts (see section 17.4), storage data is saved to the specified file name at the specified save destination.

* For binary files, you cannot specify a network drive as the save destination.



Executes the manual CSV conversion


Select the storage data file (.WTS file) that was saved, and then press the CSV Convert soft key to create a storage data file in ASCII format.

Setting the save destination (when the CSV file save setting is on)

Press the **File List (conversion CSV)** soft key. The following screen appears.

Set the save destination.

When storage starts (see section 17.4), storage data is saved to the specified file name at the specified save destination.



17.4 Starting, Stopping, and Resetting Storage

This section explains how to start, stop, and reset storage.

► "Starting, stopping, and resetting storage (STORE START, STORE STOP, and STORE RESET)" in the features guide

CAUTION

During storage, the storage device is constantly being accessed, even though the icon that indicates this (📁) is not displayed. Do not unplug the USB memory device or turn the power off. Doing so may damage the storage device or corrupt the data.

Storage is in progress when the STORE START key is lit or blinking or when the STORE STOP key is blinking.

French

ATTENTION

Pendant le stockage, le dispositif de stockage est constamment accessible, même si l'icône qui indique ceci (📁) ne s'affiche pas. Ne débranchez pas le dispositif de mémoire USB et ne coupez pas l'alimentation.

Cela pourrait endommager le dispositif de stockage ou corrompre les données.

La mémorisation est en cours lorsque la touche STORE START est allumée ou clignote ou lorsque la touche STORE STOP clignote.

Starting the storage operation

Press **STORE START**. The instrument starts storage using the storage mode that you have specified (see section 17.1).

- The STORE START key is lit.
Storage is running; "Store: Start" is indicated.*
 - The STORE START key is blinking.
The storage operation is ready; "Store: Ready" is indicated.*
- * Indicators are displayed in the upper left of the screen.

Stopping the storage operation

The instrument automatically stops storage according to the storage mode that you have specified. To pause storage, press **STORE STOP**.

- The STORE STOP key is blinking.
Storage is paused; "Store: Stop" is indicated.*
If you press STORE START when "Stop" is indicated in yellow, you can resume the storage operation from the point where you stopped the storage operation.
 - The STORE STOP key is lit.
Auto stop; "Store: Close" and then "Store:Cmpl" are indicated.*
- * Indicators are displayed in the upper left of the screen.

Resetting the storage operation

Press **SHIFT+STORE STOP** (STORE RESET). The STORE STOP key turns off.

- If the storage operation is paused
The instrument finishes writing stored data to a file and closes the file.
- If the storage operation has automatically stopped
When the storage operation stops automatically, the instrument finishes writing stored data to a file and closes the file. Therefore, the reset operation performs no file operations.

Note

You cannot restart storage unless you reset it first.


18.1 Connecting USB Memory Devices

This section explains how to connect USB memory devices to save and load data.

If you want to use a storage device on your network (a network drive), you have to use an Ethernet cable to connect the instrument to the network. For details, see Chapter 20.


► [“Storage device” in the features guide](#)

CAUTION

- Do not unplug the USB memory device or turn off the power when the device is being accessed. Doing so may damage the storage device or corrupt the data.
- When the USB memory device is being accessed, an access indicator  is displayed in the top center the screen and the USB memory device indicator blinks.

French

ATTENTION


- Ne débranchez pas le dispositif de mémoire USB et ne coupez pas l'alimentation lorsque vous accédez au dispositif. Cela pourrait endommager le dispositif de stockage ou corrompre les données.
- Lors de l'accès au dispositif de mémoire USB,  un indicateur d'accès s'affiche en haut au centre de l'écran et l'indicateur du dispositif de mémoire USB clignote.

USB memory devices that can be used and how to connect USB memory devices

Use portable USB memory devices that are compatible with USB Mass Storage Class version 1.1. Connect USB storage devices directly to the USB ports (type A) for connecting peripheral devices on the instrument front panel.

Hot-plugging is supported: you can connect or disconnect the USB device at any time, regardless of whether the instrument is on or off. When the power is on, the instrument automatically detects the USB memory device after it is connected.

The instrument has two USB ports: USB-0 and USB-1. The port numbers are not fixed. The port at which the first USB memory device is detected becomes USB-0. The port at which the second USB memory device is detected becomes USB-1.



Note

- Connect USB memory devices directly to the USB ports (type A) for connecting peripheral devices. Do not connect them through a hub.
 - Use portable USB memory devices that are compatible with USB Mass Storage Class version 1.1. Do not connect incompatible USB memory devices.
 - You cannot use protected USB memory devices (such as those that contain encrypted content).
 - Do not connect and disconnect the two USB devices repetitively. Provide at least a 10-second interval between removal and connection.
-

General USB memory device handling precautions

Follow the general handling precautions that are provided with your USB memory device.

18.2 Saving Setup Data


This section explains the following settings for saving setup data:

- Save destination
- Auto naming
- File name
- Comment

► “Saving setup data (Save Setup)” in the features guide


Save Setup menu

Press **FILE** and then the **Save Setup** soft key. The following menu appears.



Setting the save destination (File List)

Press the **File List** soft key. The following screen appears.



Note

For how to move between the operation menu and the file list and how to operate the operation menu, see section 18.6.

Setting auto naming (Auto Naming)

- OFF:** The auto naming feature is disabled. The name that you specified for the File Name setting is used. If there is a file with the same name in the save destination folder, you cannot save the data.
- Numbering:** The instrument automatically adds a four-digit number from 0000 to 0999 after the common name that you specified for the File Name setting and saves the file.
- Date:** The file name is the date and time (down to seconds) when the file is saved. The file name that you specified for the File Name setting is ignored.

20240930_121530_0 (2024/09/30 12:15:30)

Y M D H S
Min

A sequence number (0-9, A-Z) that is appended if a file name with the exact same date and time (down to seconds) exists.

The sequence number that comes after the date and time is appended if a file name with the exact same date and time (down to seconds) exists. The sequence number is incremented by one (0 to 9 and then A to Z) each time a file is added.

Assigning file names (File Name)

You can set the file name that is used when Auto Naming is set to OFF. This is also used as the common file name when Auto Naming is set to Numbering. The maximum number of characters that you can use for file names and folder names is 32 characters. However, there are limitations on the type of characters and the character strings that you can use.

Setting a comment (Comment)

You can add a comment that consists of up to 30 characters when you save a file. You do not have to enter a comment. All characters, including spaces, can be used in comments.

18.3 Saving Waveform Display Data

This section explains the following settings for saving waveform display data:

- Save destination
- Auto naming
- File name
- Comment

► “Saving waveform display data (Save Wave)” in the features guide

Save Wave menu

Press **FILE** and then the **Save Wave** soft key. The following menu appears.



18.4 Saving Numeric Data


This section explains the following settings for saving numeric data:

- Save destination
- Numeric data items to save
- Auto naming
- File name
- Comment

► “Saving numeric data (Save Numeric)” in the features guide

Save Numeric menu

Press **FILE** and then the **Save Numeric** soft key. The following menu appears.



Setting the numeric data items to save (Item Settings)

Press the **Item Settings** soft key. The following menu appears.

Item Settings

Displayed Numeric Items

Selected Items

Items

Saves the numeric data that is displayed on the screen

Press this soft key to save the numeric data items that are displayed on the screen.

Saves the numeric data that you have specified on the File Items setup screen

Press this soft key to save the numeric data items that you have specified on the File Items setup screen that is displayed when you press the Items soft key.

Set the item that you want to save.

This soft key is displayed when you select Selected Items.

Setting Items to Save (Items)

Press the **Items** soft key. The following screen appears.

When you press the Selected Items soft key on the above menu, the numeric data items that you have specified on the following screen are saved.

Selects all the numeric data items

Clears the selection of all the numeric data items

Selects the preset numeric data items

Item Settings

Preset	All ON	All OFF	Preset1	Preset2			
Element	<input checked="" type="checkbox"/> Element1	<input type="checkbox"/> Element2	<input type="checkbox"/> Element3	<input type="checkbox"/> Element4	<input type="checkbox"/> Element5		
Function	<input checked="" type="checkbox"/> ΣA	<input type="checkbox"/> ΣB	<input type="checkbox"/> Udc	<input type="checkbox"/> Umn	<input type="checkbox"/> Uac	<input checked="" type="checkbox"/> FreqU	<input type="checkbox"/> CfU
	<input checked="" type="checkbox"/> Irm	<input type="checkbox"/> Imn	<input type="checkbox"/> ldc	<input type="checkbox"/> lmn	<input type="checkbox"/> lac	<input checked="" type="checkbox"/> FreqI	<input type="checkbox"/> CfI
	<input checked="" type="checkbox"/> P	<input checked="" type="checkbox"/> S	<input checked="" type="checkbox"/> Q	<input checked="" type="checkbox"/> λ	<input checked="" type="checkbox"/> ϕ	<input type="checkbox"/> Pc	<input type="checkbox"/> P-peak
	<input type="checkbox"/> U+peak	<input type="checkbox"/> U-peak	<input type="checkbox"/> I+peak	<input type="checkbox"/> I-peak	<input type="checkbox"/> P+peak	<input type="checkbox"/> P-peak	
	<input type="checkbox"/> WP	<input type="checkbox"/> WP+	<input type="checkbox"/> WP-	<input type="checkbox"/> q	<input type="checkbox"/> q+	<input type="checkbox"/> q-	
	<input type="checkbox"/> Time	<input type="checkbox"/> WS	<input type="checkbox"/> WQ				
	<input type="checkbox"/> 71	<input type="checkbox"/> 72	<input type="checkbox"/> 73	<input type="checkbox"/> 74			
	<input type="checkbox"/> F1	<input type="checkbox"/> F2	<input type="checkbox"/> F3	<input type="checkbox"/> F4	<input type="checkbox"/> F5	<input type="checkbox"/> F6	<input type="checkbox"/> F7
	<input type="checkbox"/> F8	<input type="checkbox"/> F9	<input type="checkbox"/> F10	<input type="checkbox"/> F11	<input type="checkbox"/> F12	<input type="checkbox"/> F13	<input type="checkbox"/> F14
	<input type="checkbox"/> F15	<input type="checkbox"/> F16	<input type="checkbox"/> F17	<input type="checkbox"/> F18	<input type="checkbox"/> F19	<input type="checkbox"/> F20	
	<input type="checkbox"/> Event1	<input type="checkbox"/> Event2	<input type="checkbox"/> Event3	<input type="checkbox"/> Event4			
	<input type="checkbox"/> Event5	<input type="checkbox"/> Event6	<input type="checkbox"/> Event7	<input type="checkbox"/> Event8			
	<input type="checkbox"/> FreqPLL1	<input type="checkbox"/> FreqPLL2					
	<input type="checkbox"/> U(k)	<input type="checkbox"/> I(k)	<input type="checkbox"/> P(k)	<input type="checkbox"/> S(k)	<input type="checkbox"/> Q(k)	<input type="checkbox"/> $\lambda(k)$	<input type="checkbox"/> $\phi(k)$
	<input type="checkbox"/> $\Phi U(k)$	<input type="checkbox"/> $\Phi I(k)$	<input type="checkbox"/> Z(k)	<input type="checkbox"/> Rs(k)	<input type="checkbox"/> Xs(k)	<input type="checkbox"/> Rp(k)	<input type="checkbox"/> Xp(k)
	<input type="checkbox"/> Uthd	<input type="checkbox"/> Ithd	<input type="checkbox"/> Pthd	<input type="checkbox"/> Uhd(k)	<input type="checkbox"/> Ihd(k)	<input type="checkbox"/> Phdf(k)	
	<input type="checkbox"/> Uthf	<input type="checkbox"/> Ithf	<input type="checkbox"/> Uthf	<input type="checkbox"/> Rthf	<input type="checkbox"/> hvf	<input type="checkbox"/> hcf	<input type="checkbox"/> K-factor
	<input type="checkbox"/> $\Phi Uj-Uj$	<input type="checkbox"/> $\Phi Uj-Uk$	<input type="checkbox"/> $\Phi Uj-Ij$	<input type="checkbox"/> $\Phi Uj-Ij$	<input type="checkbox"/> $\Phi Uj-Ik$		
	<input type="checkbox"/> $\Delta U1$	<input type="checkbox"/> $\Delta U2$	<input type="checkbox"/> $\Delta U3$	<input type="checkbox"/> $\Delta U\Sigma$	<input type="checkbox"/> ΔI		
	<input type="checkbox"/> $\Delta P1$	<input type="checkbox"/> $\Delta P2$	<input type="checkbox"/> $\Delta P3$	<input type="checkbox"/> $\Delta P\Sigma$			
	<input type="checkbox"/> Speed	<input type="checkbox"/> Torque	<input type="checkbox"/> SyncSp	<input type="checkbox"/> Slip	<input type="checkbox"/> Pm	<input type="checkbox"/> EaU	<input type="checkbox"/> EaI

Select the numeric items that you want to save.


18.5 Loading Setup Data

This section explains how to load setup data.

► “Loading setup data (Load Setup)” in the features guide

Load Setup menu

Press **FILE** and then the **Load Setup** soft key. The following screen appears.



Note

- Setup data saved on products with incompatible firmware versions cannot be loaded.
(This instrument is not compatible with the setup data files of WT1800 or WT1800E.)
- Setup data saved on products that have different product element configurations, options, and the like cannot be loaded.


18.6 File Operations

This section explains the file list's operation menu and the FILE Utility menu.

- Sorting the file list
- Display format
- Type of file to list
- Changing the storage device (drive)
- Deleting files and folders
- Renaming files and folders
- Making folders (directories).
- Copying files and folders
- Moving files and folders
- Selecting files and folders (All Set, All Reset, and Set/Reset)

► “File operations (Utility)” in the Features Guide

File List (File List)



Selection mark



If you want to perform an operation on a group of files at the same time, move the cursor to a file that you want to select, and then press **SET** to display this mark next to the file. To select multiple folders, press the **Set/Reset** soft key on the FILE Utility menu to display this mark next to the selected folder.




If you want to perform an operation on a single file, move the cursor to the file you want to select to display this mark next to the file.

0000.CSV	258K	2024/02/06	15:46:42	r/w
0000.PNG	70.8K	2024/06/13	16:55:26	r/w
0000.SET	5.86K	2024/06/13	18:19:59	r/w
0001.CSV	15.2K	2024/03/04	14:18:06	r/w
0001.PNG	57.7K	2024/06/13	17:34:20	r/w
0001.SET	5.86K	2024/06/13	18:19:59	r/w

Sorting the file list (Sort To)


Select **Sort To** on the operation menu. The following screen appears.




Setting the display format (≡, 田)

Select ≡, or 田 on the operation menu. The following screen appears.

List display (≡)




Thumbnail display (田)



Setting the type of files to list (Filter)

Select **Filter** on the operation menu. The following screen appears.




File type

.	All files
*.SET	Setup data file
*.CSV	Numeric data files (ASCII format), storage data files (ASCII format), and waveform display data files (ASCII format)
*.WTS	Storage data files (binary format)
*.HDS	Storage header files (binary format)
*.BMP	Screen image data files (BMP format) and custom display background files
*.PNG	Screen image data files (PNG format)
*.JPG	Screen image data files (JPEG format)
*.TXT	Custom display configuration files, user-defined computation setup files

Changing the storage device (Change Drive)

Select **Change Drive** on the operation menu. The following screen appears.



Storage device (drive) type


RAM-0	This instrument's internal RAM disk
User	This instrument's internal memory
USB-0	USB memory device detected first
USB-1	USB memory device detected second
Network	Network drive

Note

You can also change the storage device by highlighting the storage device (drive) you want to change to in the file list and pressing **SET**.

Deleting files and folders (Delete)

1. Select the file or folder that you want to delete from the file list.
2. Select **Delete** on the operation menu. The following screen appears.



Note

- To delete multiple files or folders that are in the file list at the same time, move the cursor to the file or folder that you want to delete, and then carry out the following operations.


Files: Press **SET** or the **Set/Reset** soft key on the Utility menu.

Folders: Press the **Set/Reset** soft key on the FILE Utility menu.

If you press **SET**, all the files and folders that you have selected up to that point will be cleared.


Renaming files and folders (Rename)

1. Select the file or folder that you want to rename from the file list.
2. Select **Rename** on the operation menu. The following screen appears.




Making folders (Make Dir)

1. Select the drive or folder in the file list that you want to make a new folder in.
2. Select **Make Dir** on the operation menu. The following screen appears.




Copying files and folders (Copy)

1. Select the files or folders in the file list that you want to copy.
2. Select **Copy** on the operation menu. The following screen appears.



3. Select the drive or folder in the file list that you want to copy to.
4. Select **Copy Exec** on the operation menu. The following screen appears.




Note

- The procedure for selecting multiple files or folders at the same time to copy them is the same as the procedure for selecting multiple files or folders at the same time to delete them. See Note on page 18-12.
- You can perform file operations on the file list that you are copying to as well.

Moving files and folders (Move)

- 1. Select the files or folders in the file list that you want to move.
- 2. Select **Move** on the operation menu. The following screen appears.



- 3. Select the drive or folder in the file list that you want to move to.
- 4. Select **Move Exec** on the operation menu. The following screen appears.




Note

- The procedure for selecting multiple files or folders at the same time to move them is the same as the procedure for selecting multiple files or folders at the same time to delete them. See Note on page 18-12.
- You can perform file operations on the file list that you are moving data to as well.

FILE Utility menu

Press **FILE** and then the **Utility** soft key. The following menu appears.



Setting the file operation (Operation, More)

You can perform the same file operations as those that you can perform from the operation menu described on pages 18-9 to page 18-14.

Selecting and Clearing (Set/Reset)

This soft key selects the file or folder in the file list that is highlighted or clears the selection. Selection marks (see page 18-9) are displayed to the left of the selected files.

Selecting all and clearing all (All Set/All Reset)

All Set: When the cursor is on a drive or folder in the file list, select ALL Set to select all the files and folders in the device or folder that the cursor is on. Selection marks (see page 18-9) are displayed to the left of the selected files and folders.

All Reset: All the selected files and folders are deselected.

Jump to the specified file or folder (Jump To)

You can make the cursor jump to a file or folder at a specified numeric position in the file list. The first item in the file list is number zero.

Selectable range: 0-999. However, if you specify a position whose number is larger than the total number of files and folders in the file list, the cursor will move to the bottom-most file or folder in the file list.

19.1 Saving Screen Images


This section explains the following settings for saving screen images:

- Save destination
- Data format
- Color
- Auto naming
- File name
- Comment

► [“Saving screen images” in the features guide](#)

Image Save menu

Press **SHIFT+IMAGE SAVE(MENU)** key. The following menu appears.



Saving a screen image

Press **IMAGE SAVE**. A screen image is saved according to the conditions specified on the Image Save menu.


20.1 Connecting the Instrument to a Network

This section explains how to connect the instrument to a network.

Ethernet interface specifications

There is a 1000BASE-T port located on the rear panel of the instrument.

Item	Specifications
Ports	1
Electrical and mechanical specifications	IEEE802.3 compliant
Transmission system	Ethernet(1000BASE-T/100BASE-TX/10BASE-T)
Communication protocol	TCP/IP
Supported services	FTP server, DHCP, DNS, remote control (VXI-11), SNMP, FTP client, Modbus/TCP server, and Web server
Connector type	RJ-45 connector



Items required to connect the instrument to a network


Cable

Use an STP (Shielded Twisted-Pair) cable that is compatible with your network environment (transmission speed).

Connection procedure


To connect to a PC over a network

1. Turn off the instrument.
2. Connect one end of an STP cable to the ETHERNET 1000BASE-T port on the rear panel.
3. Connect the other end of the STP cable to a hub or router.
4. Turn on the instrument.



To connect to a PC through a hub or router

1. Turn off the instrument and the PC.
2. Connect one end of an STP cable to the ETHERNET 1000BASE-T port on the rear panel.
3. Connect the other end of the STP cable to a hub or router.
4. Connect the PC to the hub or router in the same way.
5. Turn on the instrument.



Note

- Use a hub or router that is compatible with the data rate of your network.
- To connect a PC to the instrument through a hub or router, the PC must be equipped with an auto switching 1000BASE-T/100BASE-TX/10BASE-T network card.
- Do not connect the instrument to a PC directly. Direct communication without a hub or router is not guaranteed to work.

20.2 Configuring the TCP/IP Settings


This section explains the following TCP/IP settings for connecting the instrument to a network:

- DHCP
 - IP address, subnet mask, and default gateway
- DNS
 - Domain name, DNS server IP address, and domain suffix

► “TCP/IP (TCP/IP)” in the features guide

Configuring the TCP/IP settings (TCP/IP)

Press **UTILITY**, the **Network** soft key, and then the **TCP/IP** soft key. The following screen appears.



Set the DNS (OFF, ON, or Auto)

- OFF: Disable the DNS.
- ON: Enable the DNS. Set the domain name, and the DNS server's primary and secondary IP addresses and domain suffixes.
- Auto: Enable the DNS. Set the domain suffix. The domain name and the DNS server IP addresses are set automatically. The Auto option is only displayed when DHCP is set to ON.

20.3 Accessing the Instrument from a PC (FTP Server)

This section explains the following settings for accessing the instrument from a PC on a network:

- User name
- Password
- Timeout
- FTP client software

► [“FTP server \(FTP/Web Server\)” in Features Guide](#)

Configuring the FTP server (FTP/Web Server)

Press **UTILITY**, the **Network** soft key, and then the **FTP/Web Server** soft key. The following screen appears.

Network

User Name: anonymous — Set the user name (up to 32 characters).

Password: — Set the password (up to 32 characters).

Time Out(s): 900 — Set the timeout value (30 to 3600 s).

Entry — Applies the settings

TCP/IP FTP/Web Server Net Drive SNMP

FTP client software

Start an FTP client on a PC.

Enter the user name and password that you entered on the screen shown above to connect to the instrument.

Note

If you set the user name to “anonymous,” you can connect to the instrument without entering a password.

20.4 Monitoring the Instrument's Display from a PC (Web Server)

This section explains the following settings for accessing this instrument from a PC over a network to show the instrument's display on the PC and remotely controlling the instrument from the PC:

- User name
- Password
- Connecting to the instrument from a PC

► [“Web server \(Web Server\)” in the features guide](#)

Configuring the Web server (FTP/Web Server)

Press **UTILITY**, the **Network** soft key, and then the **FTP/Web Server** soft key. The following screen appears.

The screenshot shows a dark-themed screen titled "Network". It contains three input fields: "User Name" with the text "anonymous", "Password", and "Time Out(s)" with the value "900". Below these fields is an "Entry" button. To the right of the screen, three callout lines point to the fields with the following text: "Set the user name (up to 32 characters).", "Set the password (up to 32 characters).", and "Applies the settings". At the bottom of the screen, there is a row of four soft keys: "TCP/IP", "FTP/Web Server" (which is highlighted in blue), "Net Drive", and "SNTP".

Note

Time Out is a setting used by the FTP server feature. It is not necessary for the Web server feature.

Connecting to the instrument from a PC

1. Open a Web browser on a PC that is connected to the network.
2. Specify the following address.
http://xxx.xxx.xxx.xxx/
(Type this instrument's IP address for xxx.xxx.xxx.xxx.)
3. Enter the user name and password that you set on the network setup screen, which is shown on the previous page, and connect to the instrument.
The following screen appears.

Note

If you set the user name to "anonymous," you can connect to the instrument without entering a password.

Home screen

Information about the instrument is displayed.

YOKOGAWA | **Precision Power Analyzer WT1806R**

[Home](#)

[LAN Configuration](#)

[Remote View](#)

[Remote Control](#)

[File download](#)

[Link](#)

Instrument Home

Device Model	WT1806R
Manufacturer	Yokogawa Test & Measurement Corporation
Serial Number	711806000
Description	Precision Power Analyzer WT1806R
Hostname	WT1806R-000
MAC Address	98-9D-8C-8D-8D-8D
IP Address	192.168.1.100
Firmware Revision	V1.00
VISA Resource String	TCPIP::192.168.1.100::INSTR::WT1806R



Yokogawa Test & Measurement Corporation

Note

- Disable the pop-up blocker feature on your Web browser when you want to capture the screen image.
- While using the Web server feature, there may be a delay in response or no response depending on the network system.

20.5 Connecting to a Network Drive

This section explains the following settings for saving and loading various data of this instrument from a network drive (FTP server):

- FTP server (file server)
- Login name
- Password
- Turns FTP passive mode on and off
- Timeout
- Connecting to and disconnecting from a network drive

► [“Network drive \(Net Drive\)” in the features guide](#)

Configuring network drive (Net Drive) settings and connecting to it

Press **UTILITY**, the **Network** soft key, and then the **Net Drive** soft key. The following screen appears.

The screenshot shows the 'Network' configuration screen with the following fields and controls:

- FTP Server**: A text input field. Annotation: Set the FTP server's host name.
- Login Name**: A text input field containing 'anonymous'. Annotation: Set the login name (up to 32 characters).
- Password**: A text input field. Annotation: Set the password (up to 32 characters).
- FTP Passive**: A toggle switch currently set to 'OFF'. Annotation: Turns FTP passive mode on and off.
- Time Out(s)**: A text input field containing '15'. Annotation: Set the timeout value (1 to 3600 s).
- Connect** and **Disconnect** buttons. Annotations: Disconnects this instrument from the network drive (FTP server) and Connects this instrument to the network drive (FTP server).

At the bottom, there is a navigation bar with four tabs: **TCP/IP**, **FTP/Web Server**, **Net Drive** (which is highlighted in blue), and **SNTP**.

20.6 Using SNTP to Set the Date and Time


This section explains how to use SNTP to set the Instrument's date and time.

- SNTP server
- Timeout
- Turning automatic adjustment on and off
- Time difference from Greenwich Mean Time (setting shared with the date and time on the System Config menu)
- Time adjustment

► “SNTP (SNTP)” in the Features Guide

Configuring the SNTP settings (SNTP)

Press **UTILITY**, the **Network** soft key, and then the **SNTP** soft key. The following screen appears.




21.1 Viewing System Information (Overview)

This section explains how to view this instrument's system information.

► [“Overview \(System Overview\)” in the features guide](#)

System information list (System Overview)

Press **UTILITY** and then the **System Overview** soft key. The following screen appears.



Displayed information

Model	Model number
Suffix	Suffix code
No.	Instrument number and MAC address
Version	Firmware version
Element Configuration	Input element types
Options	Options
Link Date	Date and time the firmware was created
Product ID	A unique number assigned to each instrument (necessary for the purchase of additional options)


21.2 Setting the Screen Brightness and Configuring the Display Color Settings

This section explains how to set the screen brightness and configure the display color settings.

► [“Adjusting the LCD \(LCD\)” in the features guide](#)


LCD menu

Press **UTILITY**, the **System Config** soft key, and then the **LCD** soft key. The following menu appears.



Setting the Display Colors

Press the **Color Settings** soft key. The following screen appears.



21.3 Configuring the Environment Settings

This section explains the following environment settings:

- Number of digits of numeric data to display
- Frequency display when the measured frequency is less than the lower limit
- Motor display (/MTR option) when the measured pulse frequency is less than the lower limit
- Decimal point and separator to use when data is saved in ASCII format (.CSV)
- Integration resume operation at power failure recovery
- Menu font size
- Rounding to zero

► “Environment settings (Preference)” in the features guide

Preference menu

Press **UTILITY**, the **System Config** soft key, and then the **Preference** soft key. The following menu appears.

Preference	
Resolution 5digits	Set the number of digits of numeric data to display (4digits, 5digits).
Freq Display at Frequency Low 0 Error	Set the frequency display value when the measured frequency is less than the lower limit (0, Error).
Motor Display at Pulse Freq Low 0 Error	On models with the /MTR option, set the motor display value when the measured pulse frequency is less than the lower limit (0, Error).
Decimal Point for CSV File Period Comma	Set the decimal point and separator to use when data is saved in ASCII format as a .CSV file (Period, Comma).
Integration Resume Action Start Stop Error	Set the integration resume action at power failure recovery (Start, Stop, Error).
Menu Font Size Small Large	Sets the menu font size (Small, Large)
Rounding to Zero OFF ON	Turns rounding to zero on and off

21.4 Configuring D/A Output Items (Option)

This section explains the following settings for D/A output: This feature is available on models with the /DA option.

- Measurement function
- Element and wiring unit
- Harmonic order
- D/A output range
 - Range mode, range maximum, and range minimum

► “D/A output (D/A Output Items, option)” in the features guide

Configuring D/A Output Items

Press **UTILITY** and then the **System D/A Output Items** soft key. The following screen appears.

D/A output signal name

For the connector pinout and the D/A output signal assignment, see section 3.6 in the getting started guide, IM WT1801R-03EN.

Output item

This display changes according to the Function, Element/ Σ , and Order settings.

Set the measurement function (None, other functions—for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).

Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC).

Set the harmonic order (Total, 0 to 500) (/G5 or /G6 option).

You can set this setting when the measurement function includes a harmonic order.

D/A Output Items							
Ch	Item	Function	Element/ Σ	Order	Range Mode	Max	Min
1	Urms1	Urms	Element 1	–	Manual	100.0	-100.0
2	Irms1	Irms	Element 1	–	Fixed	–	–
3	P1	P	Element 1	–	Fixed	–	–
4	S1	S	Element 1	–	Fixed	–	–
5	Q1	Q	Element 1	–	Fixed	–	–
6	$\lambda 1$	λ	Element 1	–	Fixed	–	–
7	$\phi 1$	ϕ	Element 1	–	Fixed	–	–
8	fU1	FreqU	Element 1	–	Fixed	–	–
9	fI1	FreqI	Element 1	–	Fixed	–	–
10	Urms1	Urms	Element 1	–	Fixed	–	–
11	Urms1	Urms	Element 1	–	Fixed	–	–
12	Urms1	Urms	Element 1	–	Fixed	–	–
13	Urms1	Urms	Element 1	–	Fixed	–	–
14	Urms1	Urms	Element 1	–	Fixed	–	–
15	Urms1	Urms	Element 1	–	Fixed	–	–
16	Urms1	Urms	Element 1	–	Fixed	–	–
17	Urms1	Urms	Element 1	–	Fixed	–	–
18	Urms1	Urms	Element 1	–	Fixed	–	–
19	Urms1	Urms	Element 1	–	Fixed	–	–
20	Urms1	Urms	Element 1	–	Fixed	–	–

Select the D/A output range mode (Fix, Manual).

Set the maximum and minimum values of the range (–9.999T to 9.999T).

These can be set when range mode is set to Manual.

21.5 Carrying Out Self-Tests

This section explains the following settings for testing whether the instrument’s memory and keys are functioning properly:


- Test item
- Memory test
- Key test (operation keys, indicators, and keyboard)

► “Self-Test (Selftest)” in the Features Guide


Selftest menu

Press **UTILITY** and then the **Selftest** soft key. The following menu appears.

Memory test



Key test



21.6 Performing Zero-Level Compensation

This section explains how to perform zero-level compensation.

► [“Zero-level compensation \(CAL\)” in the features guide](#)

Press **SHIFT+SINGLE (CAL)**. Zero-level compensation is executed.

Note

- The instrument automatically performs zero-level compensation after you change the measurement range or input filter.
 - To make accurate measurements, we recommend that you execute zero-level compensation after warming up the instrument for at least 30 minutes.
 - If the measurement range and input filter remain the same for a long period of time, the zero level may change due to the changes in the instrument's environment. If this happens, we recommend that you execute zero-level compensation.
 - The integration feature includes an auto calibration feature that automatically performs zero-level compensation.
-

21.7 Using the NULL Feature

This section explains the following settings for the NULL feature:

- NULL feature setup method
All the signals of a given signal type or the selected signals
- Enabling and disabling the null function

► “NULL feature (NULL SET)” in the features guide

Configuring NULL Feature Settings

Press **SHIFT+NULL**(NULL SET). The following screen appears.

Select the setup method of the NULL feature (All, Select).
If you select All, the NULL feature is turned on for all the input signals that you can use this screen to set.

Set the state of the NULL feature for all the signals of a given signal type (ON, Hold, OFF).

- For the voltage signals of the installed input elements
- For the current signals of the installed input elements
- For motor evaluation input signals
- For auxiliary signals

The screenshot shows the 'NULL Settings' screen. At the top, 'Target Element' has 'All' and 'Select' buttons. Below are four sections: 'U' (voltage), 'I' (current), 'Motor' (motor evaluation), and 'Aux' (auxiliary). Each section has 'All', 'ON', 'Hold', and 'OFF' buttons. Under each section, there is a 'Status' label and a list of signals with their own 'ON', 'Hold', and 'OFF' buttons. For 'U', signals U1-U5 are listed. For 'I', signals I1-I5 are listed. For 'Motor', 'Speed' and 'Torque' are listed. For 'Aux', 'Aux1' and 'Aux2' are listed. A callout box points to the 'All' button in the 'U' section, explaining the selection method. Another callout box points to the 'ON', 'Hold', and 'OFF' buttons in the 'U' section, explaining the state setting. A third callout box points to the 'Aux' section, explaining the auxiliary signal setup screen. A fourth callout box points to the 'ON', 'Hold', and 'OFF' buttons in the 'Aux' section, explaining the state setting.

Set the state of the NULL feature for each signal (ON, Hold, OFF)

The motor evaluation input signal setup screen is displayed on models with the /MTR option.

The auxiliary signal setup screen is displayed on models with the /AUX option.

Enabling and disabling the NULL feature

Press **NULL**. The NULL key lights, and the feature is enabled.

- The null value of each input signal is used for those signals whose NULL feature is turned on.
- Press **NULL** again to turn the NULL key off and disable the NULL feature.

21.8 Locking the Keys

This section explains how to lock the panel keys, which prevents you from unintentionally changing the current state of the instrument

► [“Key lock \(KEY LOCK\)” in the features guide](#)

Key lock (KEY LOCK)

Press **SHIFT+LOCAL** (KEY LOCK). LOCK is displayed in the upper right of the screen, and the operation keys are locked.

- The key lock disables all the instrument's keys except for the power switch, SHIFT key, and LOCAL key.
- Press **SHIFT+LOCAL** (KEY LOCK) again to release the key lock.

Note

When the keys are locked, you cannot use a USB mouse or keyboard to operate the instrument either.

Appendix 1 Messages and Corrective Actions

Messages

Messages may appear on the screen while you are using this instrument. This section describes the error messages and how to respond to them. You can display the messages in the language that you specify through the operations explained in section 1.4. If servicing is necessary to solve the problem indicated by a message, contact your nearest YOKOGAWA dealer.

In addition to the following error messages, there are also communications error messages. These messages are explained in the communication interface user's manual, IM WT1801-17EN.

Warning Messages (1 to 99)

Code	Message	Chapter or Section
3	Turned on pressing the RESET key. The system has been initialized.	1.6
11	Cannot measure PLL frequency. Check input level.	3.1
12	File access slow. Too many files in directory or medium read/write speed slow.	18.6
64	File access is aborted.	—
80	System Configuration was changed. The system has been initialized.	—
84	Key lock is enabled. To release the lock, press the KEY LOCK (SHIFT+LOCAL) key.	21.8
85	In remote control mode, all keys are locked except LOCAL key. Please hit LOCAL key to exit the remote control mode.	Chapters 1 to 3 ¹
86	In Local Lockout mode, all keys are locked. Please cancel the local lockout.	Chapters 1 to 3 ¹
87	Firmware was changed. The system has been initialized.	—
88	Integration has started and measurement ranges of the MOTOR/AUX are switched to fixed ranges. Even if the Data Update Interval setting is Auto, Voltage/Current measurement range are also switched to fixed ranges.	2.2, 2.15
89	Processing system settings change. Please wait for a moment.	—
90	This model has no external current sensor. Check the specifications to see whether or not the optional external current sensor is provided.	21.1
92	This model has no harmonics measurement. Check the specifications to see whether or not the optional harmonics measurement is provided.	21.1
93	This model has neither motor evaluation function or auxiliary input. Check the specifications to see whether or not the optional motor evaluation function and the optional auxiliary input are provided.	21.1
95	Be careful not to exceed a current supply limit value to use the power supply for a current sensor.	2.11 ¹

¹ Communication Interface User's Manual, IM WT1801-17EN

Appendix 1 Messages and Corrective Actions

Code	Message	Chapter or Section
96	If the S or Q computation is set to type 1 or 2, the following is applied to elements with the rectifier set to on. <ul style="list-style-type: none">• Φ is fixed to lag (G). Displayed in the range of 0 to 180° (360 degrees format).• The sign of Q is fixed to positive. For QΣ that includes elements with the rectifier set to on, type 2 is used.	Chapter 8
97	There are measure conditions which make sigma functions unmeasurable. All or part of sigma functions will not be measured.	2.1, 16.1
98	External Sync interval has gone out of range. Check External Sync (MEAS START) input.	3.4 ¹

1 Getting Started Guide, IM WT1801R-03EN

Setup Error Messages (500 to 899)

Code	Message	Chapter or Section
600	File access failure.	—
601	Invalid file name. Check the file name.	18.2
602, 603	No USB device or no storage media inserted. Check the USB device connection, and the existence of a storage medium in the drive.	18.1
604	Media failure. Check the storage medium.	18.1
605	File not found. Check the filename and the storage medium.	—
606	Media is protected. Set the disk's (medium's) write protect switch to OFF.	—
607	Media was removed while accessing. Check the storage medium.	18.1
608, 609	File already exists.	—
610	Contains invalid characters.	18.2
611, 612	Media full. Delete unnecessary file(s) or use another disk.	18.6
613	Cannot delete a directory if there are files in the directory.	18.6
614	File is protected.	—
615	Physical format error. Reformat the medium. If the same error occurs, the instrument is probably unable to execute a format on this medium.	—
616 to 620, 622 to 641	File system failure. Check using another disk. If the same message still appears, maintenance service is required.	—
621	File is damaged. Check the file.	—
643 to 653	Media failure. Check the medium.	—
657	File operation is interrupted.	—
658	File unknown format. Check the file format.	18.5, 18.6
662	Cannot load this bitmap file. Use file of 16bit Color or 24bit Color Mode with less or equal size 800x672.	7.7
663	Cannot load this text file. Confirm the contents of file.	7.7
665	Cannot load this file format. File was stored on other models or other versions.	—

Appendix 1 Messages and Corrective Actions

Code	Message	Chapter or Section
666	File is now being accessed. Execute after access is made.	—
675	Cannot load this file. Model/options do not conform.	—
676	Writing prohibited in this file.	—
677	An error occurred while network access. Confirm network conditions.	Chapter 20
690	Cannot execute for the directory depth is 10 or more.	—
691	Cannot execute because of source and destination are overlapped.	—
692	Cannot execute for the media itself.	—
693	Cannot store at Network Drive.	17.3
694	Trigger Event is Off.	8.2
695	File version is new. Update firmware.	—
696	The file may be damaged or an unsuccessful file close could have occurred.	—
697	Abnormal data file. Unsuccessful finish of file save is detected.	—
705	Can not operate while accessing medium. Wait until access has completed.	—
706	Can not operate during hard copy. Wait until output has completed.	—
713	Cannot execute for All or Custom display mode.	—
720	Over Run had occurred.	—
721	Can not set or execute because store is processing. Try Again.	—
722	No target Element for integration execution.	9.1
723	Can not set or execute when Integ Independent Control is on.	9.1
724	Can not set or execute because recording is processing. Try again.	—
725	File creation stopped. File size exceeded 2G bytes.	—
750, 751	Unable to connect to the server. Check the network settings and configuration.	Chapter 20
752	This ftp function in not supported.	—
753	FTP Error: Client Handle Confirm the network settings and connection.	Chapter 20
758	Failed to acquire time from SNTP server. Confirm the network settings and connection.	20.5
759	Failed to initialize network. Confirm the network settings.	Chapter 20
800	Illegal date-time. Set the correct date and time.	1.5
801	Illegal file name. The file name contains characters which are not allowed or the file name is not a valid MS-DOS file name. Enter another file name.	18.2
802	Cannot be set or executed in the Normal measurement mode. Usable measurement mode are as follows.	—
811	Cannot be set to this display mode. Harmonics option is necessary.	—
812	Cannot be set or executed while storing data.	—
813	Cannot be set while integration is running. Reset Integration.	9.3
814	Cannot be set or executed when NULL is on. Please turn NULL off.	21.7
815	Cannot be set or executed when the Data Update Interval is Auto.	2.15
823	Cannot change during CAL. Wait until CAL is completed.	21.6
827	Illegal math expression. Input a correct computing equation.	9.1
831	Processing now. Retry setting or execution again.	—
841	Attempted to start integration after integration time has reached its preset value.	9.3

Appendix 1 Messages and Corrective Actions

Code	Message	Chapter or Section
842	Attempted to start integration while integration is in progress.	9.3
843	Measurement stopped due to overflow during integration or due to a power failure.	9.3
844	Attempted to stop integration even though integration was not in progress.	9.3
845	Attempted to reset integration even though integration was in progress or integration mode was not selected.	9.3
846	Attempted to start integration while measurement of peak overflow was in progress.	—
847	Attempted to start integration in continuous integration mode when integration preset time was set to "0".	9.2
848	Attempted made to start integration in real time counting integration mode when the end time had already passed.	9.2
849	Attempted made to start storing in real time counting storing mode when the end time had already passed.	17.1
850	Cannot be set or executed at current store state. To set or execute, reset store.	17.4
852	Stored file is illegal. Initialize memory before storing.	17.4
854	Waveform display data not found.	—
855	Data destination memory is full. Saving has been stopped.	—
856	An error has occurred while storing. Storing has been stopped.	—
857	Cannot be set while Master/Slave Synchronized Measurement is set to Slave.	8.6
858	Store process is in progress now. Execute or set setting again.	—
859	Cannot convert selected file. Select a file with an extension of WTS or HDS.	17.3
862	Numeric data not found.	—
863	Cannot be set or executed when different types of elements are installed.	—
864	This wiring cannot be set as the first selected element.	2.1
865	Cannot be set while integration is running. Stop or reset Integration.	9.3
874	Sync source, PLL source or trigger source cannot be set to Ext Clk, while Master/Slave Synchronization Measurement is set to Slave.	8.6
875	Master/Slave Synchronization Measurement cannot be set to Slave, while sync source, PLL source or trigger source is set to Ext Clk.	8.6
876	Can not calculate from present point value.	4.1, 5.1
877	Can not set 0 to count.	16.1, 17.1
879	Can not set or execute while recording high speed data. Stop measurement and wait for file status "Ready".	16.4
880	Cannot be set or executed while initialization. Wait until status changes to "Ready".	16.4
881	Cannot be set or executed while measurement is in progress. To set or execute, "Stop" measurement.	16.4
882	Stopped measurement. Detection error of measuring interval signal. Check External Sync (MEAS START) input.	4.4 ¹
883	Cannot be set or executed in High Speed Data Capturing Mode.	—
884	Can not set wiring to 1P3W/3P3W in High Speed Data Capturing Mode. Select a different wiring.	2.1
885	Cannot be set or executed in High Speed Data Capturing Mode. Set or execute in Normal Measurement Mode.	Appendix 9 ²
886	Cannot be set or executed to same current ranges, due to different types of elements are installed or external current sensor settings are not same.	2.3

1 Getting Started Guide, IM WT1801R-03EN

2 Features Guide, IM WT1801R-01EN

Code	Message	Chapter or Section
887	Cannot start integration. Turn off Independent Element setting by the [WIRING] menu, or switch the measurement ranges to fixed ranges.	2.1
888	Cannot start the integration. Turn off Independent control by the [INTEG] menu or turn off Auto of the Data Update Interval by the [UPDATE RATE] menu.	9.1, 2.15
889	Setting and execution is not available when auto-ranging is set to ON.	2.2
890	Cannot start the store. Change store mode from synchronize with integration or set store interval to zero by the [STORE SET] menu. Otherwise, turn off Auto of the Data Update Interval by the [UPDATE RATE] menu.	17.1, 2.15
892	Cannot start the integration. Set S and Q Formula to another expecting for Type 3 by the [MEASURE] menu, or fix measurement ranges.	8.3, 2.2, 2.3

System Error Messages (900 to 999)

Code	Message	Chapter or Section
901	Failed to backup setup data. The system has been initialized. Maintenance service is required.	—
902	System RAM failure. Maintenance service is required.	—
903	System ROM failure. Maintenance service is required.	—
905	System failure. Install the input modules and the options correctly.	—
906	Fan stopped. Power off immediately. Maintenance service is required.	—
907	Backup battery is flat. Maintenance service is required to replace the back-up battery.	—
909	Illegal SUM value. Maintenance service is required.	—
910	This operation is prohibited for EEPROM protection.	—
915	EEPROM SUM error. EEPROM may be damaged. Maintenance service is required.	—
919	Module installation condition and setup parameters do not match. The system has been initialized. Maintenance service is required.	—
920	SUM error of NULL value. The Null value is reset to 0.	—
921	System Failed to Draw Display. Maintenance service is required.	—
922	Failed to communicate with measure component. Reboot the instrument and try again. If this error persists after rebooting, please consult with service.	—
923	Transmit data abnormality from devices. Maintenance service is required.	—
926	The USB device's power consumption exceeded the capacity of the USB hub.	—
927	Disconnected USB device port 1, because overcurrent was detected.	—
928	Disconnected USB device port 2, because overcurrent was detected.	—

Appendix 1 Messages and Corrective Actions

Code	Message	Chapter or Section
929	A USB mass storage device that is greater than 137 GB in capacity has been connected. Be careful in using this device. If an area exceeding 137 GB is accessed, the storage device may break.	—
931	Hardware configuration error occurred. Restart this machine. If it occurred again, maintenance service is required.	—
932	Error occurred while ImageFile process.	—

Index

Numerics

	Page
4, 8, and 16 Items displays	7-4
1000BASE-T port	20-1

A

	Page
A and B calculation (auxiliary input)	5-1
A and B calculation (motor evaluation)	4-2
All Items display	7-9
analog input, motor evaluation	4-1
AND	8-2
apparent power formula	8-3
applicable standards (corrected power)	8-3
ASCII	18-11
auto calibration	9-2
AUTO key (current range)	2-3
AUTO key (voltage range)	2-2
automatic CSV conversion (high speed data capturing)	16-5
automatic CSV conversion (storage)	17-6
auto naming	18-4
auto off	21-2
auxiliary input	5-1
averaging	2-23
AVG key	2-23

B

	Page
background	7-12
background color (display)	21-2
backlight	21-2
bar graph display	12-1
bar graph divisions	12-1
binary	18-11

C

	Page
cable (network)	20-1
capture control	16-1
captured data, save conditions of (high speed data capturing)	16-5
captures, number of	16-1
character strings, entering	1-4
color (display)	21-2
color (screen image data)	19-1
column (high speed data capturing)	16-8
column (Matrix display)	7-6
comment	18-4
common name (files)	18-4
compensation (zero level)	21-6
CONFIG (DIRECT/MEASURE) key	2-7
CONFIG key (current range)	2-12
CONFIG key (voltage range)	2-11
connection procedure (network)	20-2
conventions used in this manual	iii
Corrected Power	8-3
crest factor	2-18
CSV file save destination setting	16-5, 17-6
CT ratio	2-9
current integration	9-4
current mode (current integration)	9-4
current range	2-3
cursor keys operations	1-2
cursor measurement (bar graph)	15-3
cursor measurement (trend)	15-2

cursor measurement (waveform)	15-1
Custom display	7-12
customizing	7-12
cutoff frequency (high speed data capturing)	16-1
cutoff frequency (normal measurement)	2-20

D

	Page
D/A output	21-4
D/A output, rated time of	9-4
data format (screen image data)	19-1
data, storing	17-1
data update interval	2-22
decimal point	21-3
delete (files)	18-12
delta calculation	2-17
DHCP	20-3
digits, number of displayed	21-3
display brightness	21-2
display, changing (4, 8, and 16 Items displays)	7-4
display, changing (All Item display)	7-9
display, changing (high speed data capturing)	16-8
display, changing (Matrix display)	7-6
display color (display)	21-2
display configuration	7-12
displayed harmonic orders	12-1
displayed page, switching	7-2
display format (bar graph)	12-1
display format (files)	18-10
display format (numeric data)	7-1
display format (phase difference)	8-5
display format (trend)	11-1
display format (vector)	13-1
display format (waveform)	10-1
display frame	7-4, 7-6, 7-9, 7-10, 16-8
display (harmonics list)	7-10
display interpolation	10-2, 11-2
display position	7-12
distortion factor formula	3-1
DNS	20-3

E

	Page
efficiency formula	2-15
electrical angle	4-1
electrical angle correction	4-2
ELEMENT (ALL) key (numeric data)	7-5, 7-11
ELEMENT (ALL) key (range)	2-2, 2-3, 2-4, 2-7
ELEMENT key (numeric data)	7-5, 7-8, 7-11, 16-10
ELEMENT key (range)	2-2, 2-3, 2-4, 2-7
environment settings	21-3
error messages	App-2
ESC key operation	1-2
Ethernet communication	20-1
event	8-2
event-synchronized storage	17-4
expressions	8-1, 8-3
extension	18-11
external current sensor conversion ratio	2-6
external current sensor range	2-4
external current sensor range, display format	2-7
external VT/CT	2-8
EXT SENSOR key	2-4, 2-7
EXT SENSOR (SENSOR RATIO) key	2-6

Index

F	Page
factory default settings, resetting to.....	1-16
FILE key	18-3, 18-5, 18-6, 18-8, 18-15
file list.....	18-9
file name	18-4
file name, changing	18-12
file operation	18-9, 18-15
files, copying.....	18-13
files, deleting.....	18-12
files, moving.....	18-14
file type	18-11
firmware version	21-1
folders, making	18-13
font color.....	7-12
font size	7-12
font size (menu).....	21-3
FORM (CURSOR) key	15-1, 15-2, 15-3
FORM key	2-25, 7-1, 10-1, 11-2, 12-1, 13-1, 14-1, 16-2, 16-5, 16-12
frequency display (less than the lower limit).....	21-3
frequency filter.....	2-21
FTP server (network).....	20-7
FTP server (this instrument's feature)	20-4
FU/FI/I _η key.....	7-5, 7-8
function select keys	7-5, 7-8, 7-11

G	Page
graph color.....	21-2
grid.....	10-2, 11-2
grid intensity	21-2

H	Page
harmonic measurement.....	3-1
harmonics list.....	7-10
help.....	1-17
HOLD key	6-1
hold (measured value).....	6-1
HRM SET key	3-1
HS filter.....	16-1

I	Page
IMAGE SAVE key	19-1
IMAGE SAVE (MENU) key	19-1
independent input element configuration.....	2-16
independent integration.....	9-1
initialization	1-16
INPUT INFO key.....	2-25
INPUT SET key	2-24
instrument, accessing from a PC.....	20-4, 20-5
INTEG key	9-1, 9-2, 9-5
integration auto calibration	9-2
integration condition	9-2
Integration mode.....	9-2
integration, scheduled times for.....	9-3
integration, starting, stopping, and resetting.....	9-5
integration-synchronized storage	17-3
integration timer.....	9-3
internal memory	18-11
ITEM key	2-26, 7-4, 7-6, 7-9, 7-10, 7-12, 10-4, 11-3, 12-2, 13-2, 14-2, 16-8

J	Page
judgment condition	8-2

K	Page
k and K	iii
keyboard, operating.....	1-4
key lock.....	21-8
key operations	1-1
key test	21-5

L	Page
language.....	1-12
linear scale (auxiliary input).....	5-1
linear scale, motor evaluation.....	4-1
line filter	2-20
line filter (auxiliary input).....	5-1
LINE FILTER (FREQ FILTER) key	2-21
LINE FILTER key	2-20
line filter, motor evaluation.....	4-1
list number.....	7-10
LOCAL (KEY LOCK) key	21-8
lock	21-8

M	Page
MAC address.....	21-1
manuals	ii
master and slave synchronization	8-6
Matrix display.....	7-6
max hold.....	8-1
measured harmonic.....	3-1
MEASURE key	8-1, 8-2, 8-3, 8-4, 8-5, 8-6
measurement mode (high speed data capturing).....	16-1
measurement period.....	2-19
memory access icon.....	18-1
memory test.....	21-5
menu language.....	1-12
message language	1-12
messages	App-1
motor display (less than the lower limit)	21-3
motor efficiency	4-2
motor evaluation	4-1
movement path.....	15-1

N	Page
network connection.....	20-1
network drive	20-7
NULL feature	21-7
NULL key	21-7
NULL (NULL SET) key	21-7
numeric data (display, high speed data capturing).....	16-8
numeric data (display, normal measurement)	7-1
numeric data (saving).....	18-6
numeric data (saving, high speed data capturing).....	16-5
numeric data (storage)	17-5
numeric data to store.....	17-5
NUMERIC key	7-1

O	Page
optimization (high speed data capturing).....	16-1
optimization (storage).....	17-2
OR	8-2
OTHERS key	11-1, 12-1, 13-1, 14-1, 16-1
output items (D/A output).....	21-4
overview	21-1

P	Page
PAGE ▲ key.....	7-2, 7-3
PAGE ▼ key.....	7-2, 7-3
page, switching.....	7-2
phase difference.....	8-5
PLL source.....	3-1
poles, number of.....	4-1
position.....	10-4
power coefficient.....	2-10
power measurement.....	7-1
pulse input, motor evaluation.....	4-1

R	Page
RAM disk.....	18-11
range (auxiliary input).....	5-1
range (D/A output).....	21-4
rated time.....	9-4
rated time of integrated D/A output.....	9-4
reactive power formula type.....	8-3
real-time storage.....	17-3
renaming (files).....	18-12
reset (4, 8, and 16 Items displays).....	7-4
reset (high speed data capturing).....	16-8
RESET key operation.....	1-2
reset (Matrix display).....	7-6
resume (storage).....	17-8
revisions.....	i
revolution signal.....	4-1
rounding to zero.....	21-3

S	Page
safety markings.....	iii
sampling frequency.....	8-4
save conditions (high speed data capturing).....	16-5
save conditions of storage data.....	17-6
save conditions (storage).....	17-6
save destination.....	18-4
scale values.....	10-2, 11-2
scaling coefficient (auxiliary input).....	5-1
scaling factor, motor evaluation.....	4-1
scaling feature.....	2-8
SCALING key.....	2-8
SCALING (MOTOR/AUX SET) key.....	4-1, 5-1
scheduled time (integration).....	9-3
scheduled time (storage).....	17-3
screen image, saving.....	19-1
self-test.....	21-5
separator.....	21-3
serial number (files).....	18-4
SET key operation.....	1-2
setup data, loading.....	18-8
setup data, saving.....	18-3
setup dialog box, operating.....	1-3
setup menus, operating.....	1-1
setup parameters, viewing.....	2-25
SINGLE (CAL) key.....	21-6
SINGLE key.....	6-1
single measurement.....	6-1
single-shot storage.....	17-4
SNTP.....	20-8
sort (files).....	18-10
split display.....	14-1
S/Q/Λ/Φ key.....	7-5, 7-8, 7-11
standard (corrected power).....	8-3
storage count.....	17-2
storage device (drive) (files).....	18-11
storage interval.....	17-2

storage mode.....	17-1
storage; starting, stopping, resetting.....	17-8
STORE START key.....	17-8
STORE START (STORE SET) key.....	17-1, 17-5, 17-6
STORE STOP key.....	17-8
STORE STOP (STORE RESET) key.....	17-9
synchronization source, motor evaluation.....	4-1
synchronous measurement (high speed data capturing).....	16-1
synchronous measurement (master/slave).....	8-6
synchronous speed.....	4-1
SYNC SOURCE key.....	2-19
system information.....	21-1

T	Page
TCP/IP.....	20-3
test.....	21-5
time axis (trend).....	11-1
time axis (waveform).....	10-1
time difference.....	20-8
time difference from Greenwich Mean Time.....	20-8
torque signal.....	4-1
total efficiency.....	4-2
trademarks.....	i
trend display.....	11-1
trend display windows.....	11-1
trend label.....	11-2
trigger.....	10-1, 16-1
type A.....	18-1

U	Page
U/I MODE key.....	7-5, 7-8
U/I/P key.....	7-5, 7-8, 7-11
UPDATE RATE key.....	2-22
USB keyboard language.....	1-6
USB memory device, connecting.....	18-1
USB port.....	18-1
user-defined events.....	8-2
user-defined functions.....	8-1
UTILITY key.....	1-7, 1-12, 1-14, 1-16, 2-18, 9-6, 20-3, 20-4, 20-5, 20-7, 20-8, 21-1, 21-2, 21-3, 21-4, 21-5

V	Page
valid measurement range.....	2-11
values, entering.....	1-4
vector display.....	13-1
vector display windows.....	13-1
vertical position.....	10-4
vertical scale (bar graph).....	12-2
vertical scale (trend).....	11-3
vertical zoom factor.....	10-4
voltage and current measurement modes (high speed data capturing).....	16-1
voltage range.....	2-2
VT ratio.....	2-9

W	Page
watt-hours.....	9-1
watt hours for each polarity.....	9-4
waveform display.....	10-1
waveform display data, saving.....	18-5
waveform label.....	10-2
waveform mapping.....	10-3
waveform screen divisions.....	10-1
WAVE key.....	10-1, 10-4
Web server.....	20-5
WIRING key.....	2-1, 2-15, 2-16, 2-17
wiring pattern.....	2-1

Index

wiring system..... 2-1
wiring unit 2-1
WP/q/TIME key..... 7-5, 7-8

Z **Page**

zero-level compensation..... 21-6
zoom factor (vector)..... 13-2
zoom factor (waveform)..... 10-4