

# **WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer**

## **U S E R ' S M A N U A L**

---

### **Features Guide**

Thank you for purchasing the WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, or WT1806E Precision Power Analyzer. This manual contains useful information about the features of this instrument. To ensure correct use, please read this manual thoroughly before beginning operation. After reading the manual, keep it in a convenient location for quick reference whenever a question arises during operation.

## List of Manuals

The following manuals, including this one, are provided as manuals for this instrument. Please read all the manuals.

Manual Title	Manual No.	Description
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer Features Guide	IM WT1801E-01EN	This manual. The supplied CD contains the PDF file of this manual. This manual explains all the features of this instrument other than the communication interface features.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer User's Manual	IM WT1801E-02EN	The supplied CD contains the PDF file of this manual. The manual explains how to operate this instrument.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer Getting Started Guide	IM WT1801E-03EN	The manual explains the handling precautions and basic operations of this instrument.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer Communication Interface User's Manual	IM WT1801E-17EN	The supplied CD contains the PDF file of this manual. The manual explains the communication interface features of this instrument and how to use them.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer	IM WT1801E-92Z1	Document for China

The "EN" and "Z1" in the manual numbers are the language codes.

Contact information of Yokogawa offices worldwide is provided on the following sheet.

Document No.	Description
PIM 113-01Z2	List of worldwide contacts

## Notes

- The contents of this manual are subject to change without prior notice as a result of continuing improvements to the instrument's performance and functionality. The figures given in this manual may differ from those that actually appear on your screen.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without the permission of YOKOGAWA is strictly prohibited.
- The TCP/IP software of this product and the documents concerning it have been developed/ created by YOKOGAWA based on the BSD Networking Software, Release 1 that has been licensed from the Regents of the University of California.

---

## Trademarks

- Microsoft, Internet Explorer, MS-DOS, Windows, Windows Vista, Windows 7, Windows 8, Windows 8, and Windows 10 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are either registered trademarks or trademarks of Adobe Systems Incorporated.
- Modbus is a registered trademark of AEG Schneider.
- In this manual, the ® and TM symbols do not accompany their respective registered trademark or trademark names.
- Other company and product names are trademarks or registered trademarks of their respective holders.

## Revisions

- 1st Edition: September 2016
- 2nd Edition: June 2017
- 3rd Edition: October 2017

# Contents

<b>1</b>	<b>Items That This Instrument Can Measure</b>	
	Measurement Functions Used in Normal Measurement.....	1-1
	Harmonic Measurement Functions (Option) .....	1-3
	Delta Computation Functions.....	1-5
	Motor Evaluation Functions (Option) .....	1-5
	Auxiliary Input Measurement Functions (Option).....	1-5
	High Speed Data Capturing Measurement Functions .....	1-5
	What Is a Measurement Function? .....	1-6
	Measurement Period.....	1-6
<b>2</b>	<b>Fundamental Measurement Conditions</b>	
	Wiring System Settings (WIRING).....	2-1
	Wiring System (Wiring) .....	2-1
	Efficiency Equation ( $\eta$ Formula).....	2-3
	Independent Input Element Configuration (Element Independent).....	2-4
	Delta Computation ( $\Delta$ Measure).....	2-5
	Settings of All Elements (All Elements Setup) .....	2-8
	Selecting an Element Whose Measurement Range You Want to Specify (ELEMENT).....	2-8
	Selecting All Input Elements (ALL).....	2-8
	Voltage Range (RANGE UP/DOWN (V)).....	2-9
	Auto Voltage Range (AUTO (V)).....	2-10
	Current Range (RANGE UP/DOWN (A)).....	2-11
	Auto Current Range (AUTO (A)).....	2-11
	Power Range .....	2-12
	External Current Sensor Range (EXT SENSOR; option) .....	2-12
	External Current Sensor Conversion Ratio (SENSOR RATIO; option).....	2-13
	External Current Sensor Range Display Format (DIRECT/MEASURE; option) .....	2-14
	Scaling (SCALING).....	2-14
	Valid Measurement Range (CONFIG(V)/CONFIG(A)).....	2-16
	Crest Factor (Crest Factor) .....	2-17
	Measurement Period (SYNC SOURCE).....	2-18
	Line Filter (LINE FILTER).....	2-20
	Frequency Filter (FREQ FILTER) .....	2-20
	Data Update Interval (UPDATE RATE).....	2-21
	Averaging (AVG) .....	2-22
	Displaying the Setup Parameter List (INPUT INFO).....	2-24
<b>3</b>	<b>Harmonic Measurement Conditions (Option)</b>	
	Harmonic Measurement Conditions (HRM SET).....	3-1
	PLL Source (PLL Source) .....	3-1
	Measured Harmonic Orders (Min Order/Max Order) .....	3-2
	Distortion Factor Equation (Thd Formula).....	3-3
	Number of FFT points (FFT Points) .....	3-3
	Input Element Group (Element Settings) .....	3-3
	Anti-Aliasing Filter .....	3-4



<b>4</b>	<b>Motor Evaluation Conditions (Option)</b>	
	Motor Evaluation Conditions and Auxiliary Input Conditions (MOTOR/AUX SET) .....	4-1
	Scaling Factor (Scaling).....	4-1
	Unit (Unit).....	4-2
	Input Signal Type (Sense Type).....	4-2
	Analog Input Range .....	4-3
	Linear Scaling of Analog Input .....	4-3
	Line Filter (Line Filter) .....	4-4
	Synchronization Source (Sync Source) .....	4-5
	Pulse Input Range .....	4-5
	Torque Signal Pulse Rating.....	4-5
	Revolution signal pulses per revolution (Pulse N) .....	4-7
	Synchronous Speed (Sync Speed).....	4-7
	Electrical Angle Measurement (Electrical Angle Measurement) .....	4-8
	Motor Efficiency and Total Efficiency Computation .....	4-9
<b>5</b>	<b>Auxiliary Input Conditions (Option)</b>	
	Auxiliary Input Conditions (MOTOR/AUX SET) .....	5-1
	Input Signal Name (Aux Name) .....	5-1
	Scaling Factor (Scaling).....	5-1
	Unit (Unit).....	5-1
	Analog Input Range .....	5-1
	Linear Scaling of Analog Input .....	5-2
	Line Filter (Line Filter) .....	5-3
<b>6</b>	<b>Holding Measured Values and Performing Single Measurements</b>	
	Holding Measured Values (HOLD).....	6-1
	Single Measurement (SINGLE) .....	6-1
<b>7</b>	<b>Numeric Data Display</b>	
	Numeric Data Display (NUMERIC).....	7-1
	Display Format (FORM).....	7-1
	Numeric Data Display Format.....	7-1
	Switching the Displayed Page (PAGE UP/PAGE DOWN) .....	7-3
	Jumping to the First or Last Page (PAGE TOP/PAGE END) .....	7-3
	Number of Displayed Digits (Display Resolution) .....	7-4
	Display Item (ITEM) .....	7-4
	4-, 8-, and 16-Value Displays (4 Items/8 Items/16Items) .....	7-5
	Matrix display (Matrix).....	7-7
	All Items Display (All Items) .....	7-8
	Single Harmonics and Dual Harmonics Lists (Hrm List Single/Dual; option).....	7-9
	Custom Display (Custom).....	7-10

<b>8</b>	<b>Computation</b>	
	Computation (MEASURE) .....	8-1
	User-Defined Functions (User Defined Function) .....	8-1
	Measuring the Average Active Power .....	8-5
	MAX Hold (Max Hold) .....	8-5
	User-Defined Events (User Defined Event) .....	8-6
	Apparent Power, Reactive Power, and Corrected Power Equations (Formula) .....	8-8
	Sampling Frequency (Sampling Frequency) .....	8-9
	Phase Difference Display Format (Phase) .....	8-10
	Master/Slave Synchronization Measurement (Sync Measure) .....	8-10
	Voltages or Currents Whose Frequencies Will Be Measured (FREQ MEASURE) .....	8-11
<b>9</b>	<b>Integrated Power (Watt hours)</b>	
	Integration-Related Display Indications .....	9-1
	Number of Displayed Digits (Display Resolution) .....	9-2
	Enabling or Disabling Independent Integration (Independent Control) .....	9-4
	Independently Integrated Elements (Element Object) .....	9-4
	Starting, Stopping, and Resetting Integration (Start/Stop/Reset) .....	9-5
	Integration Conditions (Integ Set) .....	9-7
	Integration Mode (Mode) .....	9-7
	Integration Timer (Integ Timer) .....	9-10
	Scheduled Times for Real-Time Integration (Real-time Control) .....	9-10
	Integration Auto Calibration On/Off (Auto Cal) .....	9-11
	Watt Hour Integration Method for Each Polarity (WP $\pm$ Type) .....	9-11
	Current Mode for Current Integration (q Mode) .....	9-11
	Rated Time of Integrated D/A Output (D/A Output Rated Time; Option) .....	9-12
	Integration Resume Action at Power Failure Recovery (Integration Resume Action) .....	9-12
<b>10</b>	<b>Waveform Display</b>	
	Waveform Display (WAVE) .....	10-1
	Display Format (FORM) .....	10-2
	Number of Windows (Format) .....	10-2
	Time Axis (Time/div) .....	10-2
	Vertical Axis (Amplitude) .....	10-4
	Trigger (Trigger Settings) .....	10-5
	Advanced Waveform Display Settings (Display Settings) .....	10-7
	Waveform Mapping (Wave Mapping) .....	10-8
	Display Item (ITEM) .....	10-8
<b>11</b>	<b>Trend Display</b>	
	Other Displays (OTHERS) .....	11-1
	Trend Display (Trend) .....	11-1
	Display Format (FORM) .....	11-2
	Display Item (ITEM) .....	11-3
<b>12</b>	<b>Bar Graph Display (Option)</b>	
	Bar Graph Display (OTHERS (Bar)) .....	12-1
	Display Format (FORM) .....	12-1
	Display Item (ITEM) .....	12-2

<b>13</b>	<b>Vector Display (Option)</b>	
	Vector Display (OTHERS (Vector)).....	13-1
	Display Format (FORM).....	13-2
	Display Item (ITEM) .....	13-2
<b>14</b>	<b>Split Display</b>	
	Split Display (OTHERS).....	14-1
	Split Displays with the Numeric Display (Numeric+***).....	14-1
	Split Displays with the Waveform Display (Wave+***) .....	14-1
	Split Displays with the Trend Display (Trend+***).....	14-1
	Split Display Settings .....	14-1
<b>15</b>	<b>Cursor Measurement</b>	
	Cursor Measurement (CURSOR) .....	15-1
	Turning Cursor Measurement On and Off (Cursor) .....	15-1
	Waveform Measured by Cursor 1 (+; C1+ Trace).....	15-1
	Waveform Measured by Cursor 2 (x; C2x Trace) .....	15-1
	Cursor Path (Cursor Path) .....	15-2
	Position of Cursor 1 (+; C1+ Position) .....	15-2
	Position of Cursor 2 (x; C2x Position).....	15-2
	Linking Cursor Movement (Linkage).....	15-2
	Measured Items .....	15-2
	Cursor Movement .....	15-4
<b>16</b>	<b>High Speed Data Capturing</b>	
	High Speed Data Capturing (OTHERS(High Speed Data Capturing)) .....	16-1
	High Speed Data Capturing (HS) Settings (FORM).....	16-4
	Number of Data Captures (Capture Count) .....	16-4
	Viewing and Optimizing the Maximum Capturing Count (Optimize Count) .....	16-4
	Capture Control Settings (Control Settings).....	16-5
	Recording to a File (Record to File).....	16-7
	Save Conditions (File Settings).....	16-8
	Starting and Stopping High Speed Data Capturing (Start/Stop).....	16-9
	Display Items (ITEM) .....	16-11
<b>17</b>	<b>Data Storage</b>	
	Storage-Related Display Indications.....	17-1
	Storage Conditions (STORE SET).....	17-1
	Storage Control (Control Settings).....	17-2
	Stored Items (Item Settings) .....	17-4
	Save Conditions (File Settings).....	17-5
	Starting, Stopping, and Resetting Storage (STORE START, STORE STOP, and STORE RESET)...	17-6
	Storage Operations in Each Storage Mode .....	17-8

<b>18</b>	<b>Saving and Loading Data</b>	
	Storage Media.....	18-1
	Saving Setup Data (Save Setup).....	18-2
	Saving Waveform Display Data (Save Wave).....	18-2
	Saving Numeric Data (Save Numeric).....	18-2
	File Save Conditions.....	18-3
	Loading Setup Data (Load Setup).....	18-5
	File Operations (Utility).....	18-6
<b>19</b>	<b>Saving Screen Images</b>	
	Conditions for Saving Screen Image Data (IMAGE SAVE MENU).....	19-1
	Saving a Screen Image (IMAGE SAVE).....	19-1
<b>20</b>	<b>Printing Screen Images and Numeric Data (Option)</b>	
	Printing Conditions (PRINT MENU).....	20-1
	Output Format (Format).....	20-1
	Automatic Printing Execution (Auto Print ON).....	20-2
	Automatic Printing (Auto Print Settings).....	20-2
	Comment (Comment).....	20-3
	Paper Feed (Paper Feed).....	20-3
	Print Timing for Different Print Modes.....	20-4
	Printing (PRINT).....	20-6
<b>21</b>	<b>Ethernet Communication (Network)</b>	
	TCP/IP (TCP/IP).....	21-2
	FTP Server (FTP/Web Server).....	21-3
	Web Server (FTP/Web Server).....	21-4
	Network Drive (Net Drive).....	21-6
	SNTP (SNTP).....	21-7
<b>22</b>	<b>Utility</b>	
	Utility (UTILITY).....	22-1
	Overview (System Overview).....	22-2
	Initializing the Settings (Initialize Settings).....	22-2
	Remote Control (Remote Control).....	22-3
	System Configuration (System Config).....	22-5
	D/A Output (D/A Output Items; option).....	22-9
	Self-Test (Selftest).....	22-12
<b>23</b>	<b>Other Features</b>	
	Zero-Level Compensation (CAL).....	23-1
	NULL Feature (NULL SET).....	23-1
	Enabling and Disabling the NULL Feature (NULL).....	23-3
	Clearing Remote Mode (LOCAL).....	23-3
	Key Lock (KEY LOCK).....	23-3

## Index

# 1 Items That This Instrument Can Measure

The items that you can measure with this instrument are listed below. For details about how the values of the measurement functions are determined, see appendix 1 in the getting started guide, IM WT1801E-03EN. For explanations of the terms measurement function, input element, and wiring unit, see “What Is a Measurement Function?”

► [Click here.](#)

The input elements and wiring units referred to in each measurement function table are listed below. However, the input elements and wiring units that you can measure vary depending on how many input elements are installed in this instrument.

- Input elements: Element1, Element2, Element3, Element4, Element5, Element6
- Wiring units:  $\Sigma A$ ,  $\Sigma B$ ,  $\Sigma C$

## Measurement Functions Used in Normal Measurement

### Voltage

Function	Description	Input Element	Wiring Unit
Urms	True rms voltage	Yes	Yes
Umn	Rectified mean voltage calibrated to the rms value	Yes	Yes
Udc	Simple voltage average	Yes	Yes
Urmn	Rectified mean voltage	Yes	Yes
Uac	AC voltage component	Yes	Yes
U+pk	Maximum voltage	Yes	No
U-pk	Minimum voltage	Yes	No
CfU	Voltage crest factor	Yes	No

### Current

Function	Description	Input Element	Wiring Unit
Irms	True rms current	Yes	Yes
Imn	Rectified mean current calibrated to the rms value	Yes	Yes
Idc	Simple current average	Yes	Yes
Irmn	Rectified mean current	Yes	Yes
Iac	AC current component	Yes	Yes
I+pk	Maximum current	Yes	No
I-pk	Minimum current	Yes	No
CfI	Current crest factor	Yes	No

### Power

Function	Description	Input Element	Wiring Unit
P	Active power	Yes	Yes
S	Apparent power	Yes	Yes
Q	Reactive power	Yes	Yes
$\lambda$	Power factor	Yes	Yes
$\Phi$	Phase difference	Yes	Yes
Pc	Corrected Power	Yes	Yes
P+pk	Maximum power	Yes	No
P-pk	Minimum power	Yes	No

### Frequency

Function	Description	Input Element	Wiring Unit
fU	Voltage frequency	Yes	No
fI	Current frequency	Yes	No
fPLL1	Frequency of PLL1 <sup>1</sup>	No	No
fPLL2	Frequency of PLL2 <sup>2</sup>	No	No

1 On models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

2 Only on models with the simultaneous dual harmonic measurement option.

**Integrated Power (Watt hours)**

Function	Description	Input Element	Wiring Unit
Time	Integration time	Yes	No
WP	Sum of positive and negative watt hours	Yes	Yes
WP+	Sum of positive P values	Yes	Yes
WP-	Sum of negative P values	Yes	Yes
q	Sum of positive and negative ampere hours	Yes	Yes
q+	Sum of positive I values	Yes	Yes
q-	Sum of negative I values	Yes	Yes
WS	Volt-ampere hours	Yes	Yes
WQ	Var hours	Yes	Yes

**Efficiency**

Function	Description
$\eta 1$ to $\eta 4$	Efficiency

**User-Defined Functions**

Function	Description
F1 to F20	User-defined functions

**User-defined events**

Function	Description
Ev1 to Ev8	User-defined events

## Harmonic Measurement Functions (Option)

Function	Description	Input Element	Wiring Unit
U(k)	Rms voltage of harmonic order k	Yes	Yes
I(k)	Rms current of harmonic order k	Yes	Yes
P(k)	Active power of harmonic order k	Yes	Yes
S(k)	Apparent power of harmonic order k	Yes	Yes
Q(k)	Reactive power of harmonic order k	Yes	Yes
$\lambda(k)$	Power factor of harmonic order k	Yes	Yes
$\Phi(k)$	Phase difference between the voltage and current of harmonic order k.	Yes	No
$\Phi U(k)$	Phase difference between the fundamental signal, U(1), and harmonic voltage U(k)	Yes	No
$\Phi I(k)$	Phase difference between the fundamental signal, I(1), and harmonic current I(k)	Yes	No
Z(k)	Impedance of the load circuit	Yes	No
Rs(k)	Series resistance of the load circuit	Yes	No
Xs(k)	Series reactance of the load circuit	Yes	No
Rp(k)	Parallel resistance of the load circuit	Yes	No
Xp(k)	Parallel reactance of the load circuit	Yes	No
Uhdf(k)	Harmonic voltage distortion factor	Yes	No
Ihdf(k)	Harmonic current distortion factor	Yes	No
Phdf(k)	Harmonic active power distortion factor	Yes	No
Uthd	Total harmonic voltage distortion	Yes	No
Ithd	Total harmonic current distortion	Yes	No
Pthd	Total harmonic active power distortion	Yes	No
Uthf	Telephone harmonic factor of the voltage	Yes	No
Ithf	Telephone harmonic factor of the current	Yes	No
Utif	Telephone influence factor of the voltage	Yes	No
Itif	Telephone influence factor of the current	Yes	No
hvf	Harmonic voltage factor	Yes	No
hcf	Harmonic current factor	Yes	No
K-factor	K factor	Yes	No
$\Phi U_i - U_j^1$	Phase difference between the fundamental voltage of element i, $U_i(1)$ , and the fundamental voltage of element j, $U_j(1)$ .	No	Yes
$\Phi U_i - U_k^1$	Phase difference between $U_i(1)$ and the fundamental voltage of element k, $U_k(1)$	No	Yes
$\Phi U_i - I_i^1$	Phase difference between $U_i(1)$ and the fundamental current of element i, $I_i(1)$	Yes <sup>2</sup>	Yes
$\Phi U_j - I_j^1$	Phase difference between $U_j(1)$ and the fundamental current of element j, $I_j(1)$	No	Yes
$\Phi U_k - I_k^1$	Phase difference between $U_k(1)$ and the fundamental current of element k, $I_k(1)$	No	Yes

1 i, j, and k are input element numbers. For example, when the number of input elements in wiring unit  $\Sigma A$  is six and the wiring system of elements 1, 2, and 3 is three phase, four wire, i is 1, j is 2, and k is 3.  $\Phi U_i - U_j$  represents  $\Phi U_1 - U_2$ , the difference between the fundamental voltage signal of element 1,  $U_1(1)$ , and the fundamental voltage signal of element 2,  $U_2(1)$ . In the same way  $\Phi U_i - U_k$ ,  $\Phi U_i - I_i$ ,  $\Phi U_j - I_j$ , and  $\Phi U_k - I_k$  represent to  $\Phi U_1 - U_3$ ,  $\Phi U_1 - I_1$ ,  $\Phi U_2 - I_2$ , and  $\Phi U_3 - I_3$ , respectively.

2 Setting i to an input element, is the same as setting k to 1 in  $\Phi(k)$ .

## Harmonic Measurement Function Orders

The harmonic orders that you can specify are indicated below.

### Input Element Harmonic Measurement Functions

Measurement Function	Characters or Numbers in Parentheses			
	Total	0 (DC)	1	k
U( )	Yes	Yes	Yes	2 to 500
I( )	Yes	Yes	Yes	2 to 500
P( )	Yes	Yes	Yes	2 to 500
S( )	Yes	Yes	Yes	2 to 500
Q( )	Yes	Fixed at 0	Yes	2 to 500
$\lambda$ ( )	Yes	Yes	Yes	2 to 500
$\Phi$ ( )	Yes	No	Yes	2 to 500
$\Phi U$ ( )	No	No	No	2 to 500
$\Phi I$ ( )	No	No	No	2 to 500
Z( )	No	Yes	Yes	2 to 100
Rs( )	No	Yes	Yes	2 to 100
Xs( )	No	Yes	Yes	2 to 100
Rp( )	No	Yes	Yes	2 to 100
Xp( )	No	Yes	Yes	2 to 100
Uhdf( )	No	Yes	Yes	2 to 500
Ihdf( )	No	Yes	Yes	2 to 500
Phdf( )	No	Yes	Yes	2 to 500
Uthd	Yes	No	No	No
Ithd	Yes	No	No	No
Pthd	Yes	No	No	No
Uthf	Yes	No	No	No
Ithf	Yes	No	No	No
Utif	Yes	No	No	No
Itif	Yes	No	No	No
hvf	Yes	No	No	No
hcf	Yes	No	No	No
K-factor	Yes	No	No	No

Functions with parentheses will produce different values depending on which of the following is contained in their parentheses.

- Total: Total value (The total value of all harmonic components from the minimum order to N.\* For information about how the value is determined, see appendix 1 in the getting started guide, IM WT1801E-03EN.)
- 0(DC): DC value
- 1: Fundamental harmonic value
- k: The value of any order from 2 to N.\*

\* N is the maximum measurable order. The maximum measurable harmonic order is the smallest of the three orders listed below.

- The specified maximum measurable harmonic order
- The value determined automatically according to the PLL source frequency (see section 6.4 in the getting started guide, IM WT1801E-03EN)
- When the data update interval is 50 ms or Auto, the maximum measurable harmonic order is 100.



**Wiring Unit Harmonic Measurement Functions ( $\Sigma$  functions)**

Measurement Function	Characters or Numbers in Parentheses	
	Total	1
U $\Sigma$ ( )	Yes	Yes
I $\Sigma$ ( )	Yes	Yes
P $\Sigma$ ( )	Yes	Yes
S $\Sigma$ ( )	Yes	Yes
Q $\Sigma$ ( )	Yes	Yes
$\lambda\Sigma$ ( )	Yes	Yes

Functions with parentheses will produce different values depending on which of the following is contained in their parentheses.

- Total: Total value
- 1: Fundamental harmonic value

**Delta Computation Functions**

Function	Description
$\Delta U1$	The values returned by the delta computation functions vary depending on the specified delta computation type.
$\Delta U2$	
$\Delta U3$	
$\Delta U\Sigma$	
$\Delta I$	
$\Delta P1$	
$\Delta P2$	
$\Delta P3$	
$\Delta P\Sigma$	

For details about delta computation functions, see “Delta Computation ( $\Delta$  Measure).”

► [Click here.](#)

**Motor Evaluation Functions (Option)**

Function	Description
Speed	Motor rotating speed
Torque	Motor torque
SyncSp	Synchronous speed
Slip	Slip (%)
Pm	Mechanical output of the motor (mechanical power)
EaU1 to 6*	Electrical angle: Phase angles of U1 to I6 with the falling edge of the signal received through the Z terminal of the motor evaluation function as the reference.
EaI1 to 6*	

- \* On models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

**Auxiliary Input Measurement Functions (Option)**

Function	Description
Aux1	Auxiliary input 1
Aux2	Auxiliary input 2

**High Speed Data Capturing Measurement Functions**

- For the U and I of each input element and wiring unit: Select rms, mean, dc, or r-mean.
- The P of each input element and wiring unit
- Motor evaluation function (option) speed, torque, and Pm
- Auxiliary inputs (option) Aux1 and Aux2
- The maximum and minimum values of the above measurement functions

# What Is a Measurement Function?

## Measurement Function

The physical values (such as rms voltage, average current, power, and phase difference) that this instrument measures and displays are called measurement functions. Each measurement function is displayed using symbols that correspond to its physical value. For example, “Urms” corresponds to the true rms voltage.

## Element

Element refers to a set of input terminals that can receive a single phase of voltage and current to be measured. This instrument can contain up to six elements, numbered from 1 to 6. An element number is appended to the measurement function symbol for the measured data that this instrument displays, so that you can tell which data belongs to which element. For example, “Urms1” corresponds to the true rms voltage of element 1.

## Wiring System

You can specify five wiring systems on this instrument to measure the power of various single-phase and three-phase power transmission systems: single-phase, two-wire; single-phase, three-wire; three-phase, three-wire; three-phase, four-wire; and three-phase, three-wire with three-voltage, three-current method.

## Wiring Unit


The wiring unit is a set of two or three input elements of the same wiring system that are grouped to measure three-phase power. There can be up to three wiring units:  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$ .

► [Click here.](#)

## $\Sigma$ Functions

The measurement function of a wiring unit is called a  $\Sigma$  function. For example, “Urms $\Sigma A$ ” corresponds to the average of the voltages of the input elements that are assigned to the wiring unit  $\Sigma A$ . The average value represents the true rms value.

► [Click here.](#)



# Measurement Period

For information about the measurement period for computing measurement functions, see “Measurement Period (SYNC SOURCE).”

► [Click here.](#)

---

## 2 Fundamental Measurement Conditions

### Wiring System Settings (WIRING)

The wiring system settings are listed below.

- [Wiring system \(Wiring\)](#)
- [Efficiency equation \( \$\eta\$  Formula\)](#)
- [Independent input element configuration \(Element Independent\)](#)
- [Delta computation \( \$\Delta\$  Measure\)](#)
- [Settings of All Elements \(All Elements Setup\)](#)

### Wiring System (Wiring)

There are five wiring systems available on this instrument. The selectable wiring systems vary depending on the number of installed input elements.

- 1P2W: Single-phase, two-wire system
- 1P3W: Single-phase, three-wire system
- 3P3W: Three-phase, three-wire system
- 3P4W: Three-phase, four-wire system
- 3P3W(3V3A): Three-voltage, three-current method

#### Wiring Unit

Wiring units are sets of two or three input elements of the same wiring system that are grouped together. You can define up to three wiring units:  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$ .

- When there is one wiring unit, that unit is  $\Sigma A$ . You cannot make  $\Sigma B$  or  $\Sigma C$  the first wiring unit.
- When there are two wiring units, those units are  $\Sigma A$  and  $\Sigma B$ . You cannot make  $\Sigma C$  one of the first two wiring units.
- When there are three wiring units, those units are  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$ .
- When there are multiple wiring units, element numbers are assigned to them in ascending order. The element numbers are assigned to  $\Sigma A$ ,  $\Sigma B$ , and then  $\Sigma C$ .
- Wiring units are composed of input elements that are next to each other. Wiring units cannot consist of input elements that are not next to each other.
- A wiring unit must either be composed of only 50 A input elements or only 5 A input elements. Wiring units cannot consist of different types of input elements.

#### $\Sigma$ Functions

The measurement function of a wiring unit is called a  $\Sigma$  function.

For example, "Urms $\Sigma A$ " corresponds to the average of the voltages of the input elements that are assigned to the wiring unit  $\Sigma A$ . The average value represents the true rms value.

#### Wiring System Combinations

You can configure any pattern that meets the conditions for wiring units described above.

For details about the relationship between wiring systems and how the values of the measurement functions are determined, see appendix 1 in the getting started guide, IM WT1801E-03EN.




---

Select the wiring system to match the actual wiring of the circuit under measurement. The method in which the  $\Sigma$  functions (wiring unit measurement functions) are determined varies depending on the wiring system. If the selected wiring system does not match the wiring of the actual circuit, measurements and computation will not be correct.

---

### Wiring System Display

The wiring system configuration is displayed on the right side of the screen. Because it is displayed behind the menu, to view it, you need to press the ESC key to hide the menu. The figure below shows wiring system display examples for a model with six input elements installed.



### Settings of Elements Grouped in a Wiring Unit

If [independent input element configuration](#) is off and a wiring system other than 1P2W is selected when the measurement range, valid measurement range, or valid synchronization source settings of each input element are different, these settings are changed in the manner described below:

- The measurement range is set to the greatest of the measurement ranges of the input elements assigned to the same wiring unit. The external current sensor input range has precedence over the direct input current range.
- The auto range on/off settings are changed to match the setting of the input element whose measurement range is highest. If multiple input elements are set to a common highest measurement range, the setting of the input element with the smallest input element number takes precedence.
- In the valid measurement range settings, all measurement ranges are enabled (selected).
- The synchronization source for a wiring unit is set to the input element whose number is the smallest of the elements in the unit.

At the same time that you press ELEMENT to select the element that you want to set the voltage or current range of, the indicators for the input elements that have been assigned to the same wiring unit illuminate.

### Wiring System during High Speed Data Capturing

► [Click here.](#)

## Efficiency Equation ( $\eta$ Formula)

You can create an efficiency equation by combining measurement function symbols. This instrument can determine the energy conversion efficiency of the device using the numeric values of the measurement functions.

### $\eta 1$ to $\eta 4$

You can create four efficiency equations ( $\eta 1$  to  $\eta 4$ ), using the following measurement functions as operands.

- The active powers of each element (P1 to P6)
- The active powers of the  $\Sigma$  functions (P $\Sigma$ A to P $\Sigma$ C)
- The motor output (Pm; on models with the motor evaluation option)
- Udef1 and Udef2

### Udef1 and Udef2

To add active powers and motor output and use them in  $\eta 1$  to  $\eta 4$ , use Udef1 and Udef2. You can add up to four operands consisting of the measurement functions listed above.

### Equation Examples

- **Efficiency of a Single-Phase, Two-Wire Input/Single-Phase, Two-Wire Output Device**

Input: Power of element 1 (P1)

Output: Power of element 2 (P2)

Efficiency equation:  $P2/P1 \times 100$  (%)



- **Efficiency of a Single-Phase, Two-Wire Input/Three-Phase, Three-Wire Output Device**

Input: Power of element 1 (P1)

Output:  $\Sigma$  power of elements 2 and 3 (P $\Sigma$ A)

Efficiency equation:  $P\Sigma A/P1 \times 100$  (%)

- **Efficiency of a Three-Phase, Three-Wire Input/Three-Phase, Three-Wire Output Device**

Input:  $\Sigma$  power of elements 1 and 2 (P $\Sigma$ A)

Output:  $\Sigma$  power of elements 3 and 4 (P $\Sigma$ B)

Efficiency equation:  $P\Sigma B/P\Sigma A \times 100$  (%)

- **Efficiency of a Motor with a Single-Phase, Two-Wire Input**

Input: Power of element 1 (P1)

Output: Motor output (Pm)

Efficiency equation:  $Pm/P1 \times 100$  (%)

- **Efficiency of a Motor with a Three-Phase, Three-Wire Input**

Input:  $\Sigma$  power of elements 1 and 2 (P $\Sigma$ A)

Output: Motor output (Pm)

Efficiency equation:  $Pm/P\Sigma A \times 100$  (%)



To correctly compute the efficiency, set the power coefficients of all elements so that all power units used in the computation are the same. For example, the efficiency cannot be computed correctly if elements or wiring units used in the computation have different power units, such as W (watt) and J (joule).

## Independent Input Element Configuration (Element Independent)

In the wiring system settings, you can select whether to set the measurement range or sync source of input elements in the same wiring unit collectively or independently.

### Turning Independent Input Element Configuration On or Off

For example, assume that the wiring system on a model with three input elements is set as follows:

Input elements 1 to 3: Three-phase, four-wire system (3P4W). Input elements 1 to 3 are assigned to a single wiring unit  $\Sigma A$ .

- ON  
The measurement range and sync source can be set independently for each input element included in a wiring unit.
- OFF  
The measurement range and sync source of input elements 1 to 3 are set to the same setting. This is convenient because when you are measuring a three-phase device, you can set the range and sync source settings of all input elements included in a wiring unit simultaneously.

### Settings That Are Shared between Input Elements When Independent Input Element Configuration Is Turned Off

- Measurement range (including auto range on or off)
- Direct current input or external current sensor input
- Valid measurement range
- Synchronization source
- Input element group for harmonic measurement (applies to models with the simultaneous dual harmonic measurement option).

### Settings That Can Be Configured Independently Even When Independent Input Element Configuration Is Turned Off

- External current sensor conversion ratio (option)
- Scaling values (VT ratio, CT ratio, and power coefficient)
- Input filters (line filter and frequency filter)

These settings can be configured independently for each input element regardless of whether independent input element configuration is turned on or off.

### How Settings Are Aligned When You Turn Independent Input Element Configuration from On to Off

When independent input element configuration is switched from on to off, the measurement range, valid measurement range, and sync source settings of each input element in a wiring unit ( $\Sigma A$ ,  $\Sigma B$ , or  $\Sigma C$ ) are changed as follows:

- The measurement range is set to the greatest of the measurement ranges of the input elements assigned to the same wiring unit. The external current sensor input range has precedence over the direct input current range.
- The auto range on/off settings are changed to match the setting of the input element whose measurement range is highest. If multiple input elements are set to a common highest measurement range, the setting of the input element with the smallest input element number takes precedence.
- In the valid measurement range settings, all measurement ranges are enabled (selected).
- The synchronization source for a wiring unit is set to the input element whose number is the smallest of the elements in the unit.

## Delta Computation ( $\Delta$ Measure)

The sum or difference of the instantaneous voltage or current values (sampled data) between the elements in a wiring unit can be used to determine various types of data such as the differential voltage and phase voltage. This operation is called delta computation.

### Types of Delta Computation ( $\Delta$ Measure Type)

The following types of delta computation are available:

- Differential voltage and differential current (Difference)
- Line voltage and phase current (3P3W > 3V3A)
- Star-delta transformation (Star>Delta)
- Delta-star transformation (Delta>Star)

The delta computation types that you can select vary as indicated below according to the wiring system.

Wiring System	Delta Computation Type
1P3W	Difference, 3P3W>3V3A
3P3W	Difference, 3P3W>3V3A
3P4W	Star>Delta
3P3W(3V3A)	Delta>Star

#### • Differential Voltage and Differential Current (Difference)

The differential voltage and differential current between two elements can be computed on a single-phase, three-wire system or on a three-phase, three-wire system.

When you perform delta computation on wiring unit  $\Sigma A$ , the available measurement functions are as follows.

$\Delta U1rms[UdiffA]$ ,  $\Delta U1mn[UdiffA]$ ,  $\Delta U1dc[UdiffA]$ ,  $\Delta U1rmn[UdiffA]$ ,  $\Delta U1ac[UdiffA]$


$\Delta Irms[IdiffA]$ ,  $\Delta Imn[IdiffA]$ ,  $\Delta Idc[IdiffA]$ ,  $\Delta Irmn[IdiffA]$ ,  $\Delta Iac[IdiffA]$

\* In the measurement functions, *rms*, *mn(mean)*, *dc*, *rmn(r-mean)*, and *ac* are the delta computation modes. *A* indicates the wiring unit.

► [Click here.](#)

#### • Line Voltage and Phase Current (3P3W > 3V3A)


You can compute unmeasured line voltages and phase currents by converting the data of a three-phase, three-wire system to the data of the three-voltage, three-current method (3V3A).



When you perform delta computation on wiring unit  $\Sigma A$ , the available measurement functions are as follows.

$\Delta U1rms[UrsA]$ ,  $\Delta U1mn[UrsA]$ ,  $\Delta U1dc[UrsA]$ ,  $\Delta U1rmn[UrsA]$ ,  $\Delta U1ac[UrsA]$

$\Delta Irms[ItA]$ ,  $\Delta Imn[ItA]$ ,  $\Delta Idc[ItA]$ ,  $\Delta Irmn[ItA]$ ,  $\Delta Iac[ItA]$




\* In the measurement functions, *rms*, *mn(mean)*, *dc*, *rmn(r-mean)*, and *ac* are the delta computation modes. *A* indicates the wiring unit.

► [Click here.](#)


### • Star-delta transformation (Star>Delta)

You can use the data from a three-phase, four-wire system to compute the data of a delta connection from the data of a star connection.



When you perform delta computation on wiring unit  $\Sigma A$ , the available measurement functions are as follows.

$\Delta U1_{rms}[UrsA]$ ,  $\Delta U1_{mn}[UrsA]$ ,  $\Delta U1_{dc}[UrsA]$ ,  $\Delta U1_{rmn}[UrsA]$ ,  $\Delta U1_{ac}[UrsA]$   
 $\Delta U2_{rms}[UstA]$ ,  $\Delta U2_{mn}[UstA]$ ,  $\Delta U2_{dc}[UstA]$ ,  $\Delta U2_{rmn}[UstA]$ ,  $\Delta U2_{ac}[UstA]$   
 $\Delta U3_{rms}[UtrA]$ ,  $\Delta U3_{mn}[UtrA]$ ,  $\Delta U3_{dc}[UtrA]$ ,  $\Delta U3_{rmn}[UtrA]$ ,  $\Delta U3_{ac}[UtrA]$   
 $\Delta U\Sigma_{rms}[U\Sigma A]$ ,  $\Delta U\Sigma_{mn}[U\Sigma A]$ ,  $\Delta U\Sigma_{dc}[U\Sigma A]$ ,  $\Delta U\Sigma_{rmn}[U\Sigma A]$ ,  $\Delta U\Sigma_{ac}[U\Sigma A]$   
 $\Delta I_{rms}[InA]$ ,  $\Delta I_{mn}[InA]$ ,  $\Delta I_{dc}[InA]$ ,  $\Delta I_{rmn}[InA]$ ,  $\Delta I_{ac}[InA]$



\* In the measurement functions, *rms*, *mn(mean)*, *dc*, *rmn(r-mean)*, and *ac* are the delta computation modes. A indicates the wiring unit.

► [Click here.](#)

### • Delta-star transformation (Delta>Star)


Using the data from a three-phase, three-wire system that uses a three-voltage, three-current method, you can compute the data of a star connection from the data of a delta connection. This function is useful when you wish to observe the phase voltage of an object that has no neutral line, such as a motor. The center N of the star connection is computed as the center of the delta connection. If the actual center of the star connection does not match the center of the delta connection, an error results.



When you perform delta computation on wiring unit  $\Sigma A$ , the available measurement functions are as follows.

$\Delta U1_{rms}[UrA]$ ,  $\Delta U1_{mn}[UrA]$ ,  $\Delta U1_{dc}[UrA]$ ,  $\Delta U1_{rmn}[UrA]$ ,  $\Delta U1_{ac}[UrA]$   
 $\Delta U2_{rms}[UsA]$ ,  $\Delta U2_{mn}[UsA]$ ,  $\Delta U2_{dc}[UsA]$ ,  $\Delta U2_{rmn}[UsA]$ ,  $\Delta U2_{ac}[UsA]$   
 $\Delta U3_{rms}[UtA]$ ,  $\Delta U3_{mn}[UtA]$ ,  $\Delta U3_{dc}[UtA]$ ,  $\Delta U3_{rmn}[UtA]$ ,  $\Delta U3_{ac}[UtA]$   
 $\Delta U\Sigma_{rms}[U\Sigma A]$ ,  $\Delta U\Sigma_{mn}[U\Sigma A]$ ,  $\Delta U\Sigma_{dc}[U\Sigma A]$ ,  $\Delta U\Sigma_{rmn}[U\Sigma A]$ ,  $\Delta U\Sigma_{ac}[U\Sigma A]$   
 $\Delta I_{rms}[InA]$ ,  $\Delta I_{mn}[InA]$ ,  $\Delta I_{dc}[InA]$ ,  $\Delta I_{rmn}[InA]$ ,  $\Delta I_{ac}[InA]$   
 $\Delta P1[PrA]$   
 $\Delta P2[PsA]$   
 $\Delta P3[PtA]$   
 $\Delta P\Sigma[P\Sigma A]$





\* In the measurement functions, *rms*, *mn(mean)*, *dc*, *rmn(r-mean)*, and *ac* are the delta computation modes. *A* indicates the wiring unit.

► [Click here.](#)

For information about equations, see appendix 1 in the getting started guide, IM WT1801E-03EN.

For information about the measurement period, see “Measurement Period.”

► [Click here.](#)

### Delta Computation Modes ( $\Delta$ Measure Mode)

You can select the voltage or current mode to be displayed as delta computation values from the following:  
rms, mean, dc, r-mean, ac



- We recommend that you set the measurement range and scaling (VT/CT ratio and coefficients) of the elements that are undergoing delta computation as closely as possible. Using different measurement ranges or scaling causes the measurement resolutions of the sampled data to be different. This results in errors.
- The numbers (1, 2, and 3) that are attached to delta computation measurement function symbols have no relation to the element numbers. The computation of all delta measurement functions, from  $\Delta U1$  to  $\Delta P\Sigma$ , varies depending on the wiring system and the delta computation type. For details, see appendix 1 in the getting started guide, IM WT1801E-03EN.
- When only one element is installed in this instrument, this feature cannot be used, and its settings do not appear.
- Delta computation cannot be performed on a single-phase, two-wire (1P2W) wiring system.

## Settings of All Elements (All Elements Setup)

You can configure the settings of all elements while viewing the settings in a list. By selecting the left most cell, you can collectively set all elements.

### Sensor Conversio Ratio Preset (Sensor Preset)

When using the dedicated shunt box, preset the external current sensor conversion ratio. Select the preset name (shunt box) from one of the settings below.

Preset Name	External Current Sensor Conversion Ratio (Sensor Ratio)
Shunt20 (20 $\Omega$ )	20000.0000 mV/A (m $\Omega$ )
Shunt10 (10 $\Omega$ )	10000.0000 mV/A (m $\Omega$ )
Shunt5 (5 $\Omega$ )	5000.0000 mV/A (m $\Omega$ )

If you set this item, the external current sensor input ON/OFF (Ext Sensor) is set to ON. If you change the external current sensor conversion ratio (Sensor Ratio) after setting this item, an asterisk will be added to the preset name. To use other sensors, select Others. If you select Others, the external current sensor input ON/OFF and external current sensor conversion ratio do not change.

### CT Ratio Preset (CT Preset)

When using the dedicated CT, preset the CT ratio. Select the preset name (CT) from one of the settings below.

Preset Name	CT Ratio (CT Scaling)
CT2000A	2000.0000
CT1000	1500.0000
CT200	1000.0000
CT60	600.0000

If you set this item, the scaling ON/OFF (Scaling) is set to ON. If you change the CT ratio (CT Scaling) after setting this item, an asterisk will be added to the preset name. To use other sensors, select Others. If you select Others, the scaling ON/OFF and CT ratio do not change.

## Selecting an Element Whose Measurement Range You Want to Specify (ELEMENT)

Select an element whose measurement range you want to specify. Press ELEMENT to switch in order between the indicators of the installed elements. When independent input element configuration is off, the selected elements will switch by wiring unit, according to the wiring system.

## Selecting All Input Elements (ALL)

At the same time, you can select the currently selected element and all elements that meet the following conditions. You can set their voltage and current ranges at the same time.

### Conditions for Simultaneous Element Selection

- Only input elements of the same type (50 A input or 5 A input) can be selected.
- Only input elements whose valid measurement range settings are the same can be selected.

### Initial Values for Simultaneously Selected Elements

The voltage range, current range, and auto range on/off settings of the element that was selected before you selected the other elements are copied to all the other selected elements.

After you have selected all the input elements, changes that you make to the voltage range, current range, and auto range on/off settings affect all the selected input elements.

To disable simultaneous selection and specify independent input element settings, press ELEMENT.

## Voltage Range (RANGE UP/DOWN (V))

The voltage range can be fixed (when auto range is set to off) or determined automatically (when auto range is set to on).

### Fixed Ranges

When the voltage range is fixed, you can select a range from the available options. The selected voltage range does not change even if the amplitude of the input signal changes. Set the range in reference to the rms value of the input signal.

#### When the Crest Factor Is Set to CF3

You can select from 1.5 V, 3 V, 6 V, 10 V, 15 V, 30 V, 60 V, 100 V, 150 V, 300 V, 600 V, and 1000 V.

#### When the Crest Factor Is Set to CF6 or CF6A

You can select from 0.75 V, 1.5 V, 3 V, 5 V, 7.5 V, 15 V, 30 V, 50 V, 75 V, 150 V, 300 V, and 500 V.

### Auto Range

► [Click here.](#)



- Set the range in reference to the rms value of the input signal. For example, if you are applying a 100-Vrms sinusoidal signal, set the range to 100 V.
- When measuring a signal other than a sine wave (such as a distorted wave), you can obtain accurate measurements by selecting the smallest measurement range that does not produce any of the conditions below.
  - The input peak over-range indicator at the top center of the screen illuminates or blinks in red.
  - The measured values of the voltage and current are indicated as being overload values (“-OL-”).
- The peak over-range indicator may not illuminate or blink in the following cases.
  - If the pulse width is narrow, and the peak value of the waveform cannot be acquired at the sampling rate of this instrument (approximately 2 Ms/S).
  - If the high frequency components of the pulse waveform attenuate due to the bandwidth limitations of this instrument measurement circuit, causing the waveform peak value to be less than the peak over-range detection level.
- When a signal with the peak which becomes more than about 10 times of the range is input, it takes about 1 second to change the range.
- When the secondary output of a VT (voltage transformer) is being applied to the voltage input terminal, set the voltage range according to the maximum value of the VT output. Then, use the scaling feature to set the VT ratio.
- To display a list of the range settings of all input elements, see “Displaying the Setup Parameter List.” You can change measurement ranges from the list.

► [Click here.](#)

## Auto Voltage Range (AUTO (V))

When you press AUTO, the AUTO key illuminates, and the range is set automatically. The measurement range is switched automatically depending on the amplitude of the input signal as described below. The different ranges used in the auto range are the same as those available for the fixed range.

### Range Increase

The measurement range is increased when any of the following conditions is met.

- The crest factor is set to CF3 or CF6 and The data of measurement function Urms or Irms exceeds 110% of the measurement range.
- The crest factor is set to CF6A and The data of measurement function Urms or Irms exceeds 220% of the measurement range.
- The crest factor is set to CF3 and the data of Upk\* or Ipk\* exceeds 330% of the current measurement range.
- The crest factor is set to CF6 or CF6A and the data of Upk\* or Ipk\* exceeds 660% of the current measurement range.
- If all the installed input elements are selected (all the element indicators are illuminated), the measurement range is increased on all input elements when any of the elements meets the range-increase conditions described above.
- When a wiring unit is configured, the measurement range is increased on all input elements in the wiring unit when any of the elements in the unit meets the range-increase conditions described above.

### Range Decrease

The measurement range is decreased when all the following conditions are met.

- The data of Urms or Irms is less than or equal to 30% of the measurement range.
- The data of Urms or Irms is less than or equal to 105% of the next lower range.
- The crest factor is set to CF3 and the data of Upk\* or Ipk\* is less than or equal to 300% of the next lower range.
- The crest factor is set to CF6 or CF6A and the data of Upk\* or Ipk\* is less than or equal to 600% of the next lower range.
- \* Even if the NULL feature is on, the values are determined as if it were off.
- If all the installed input elements are selected (all the element indicators are illuminated) and meet the range-decrease conditions described above, all their measurement ranges are decreased.
- When a wiring unit is configured and all the elements in the unit meet the range-increase conditions described above, all their measurement ranges are increased.



- 
- If you disable a measurement range in the [valid measurement range](#) settings, that measurement range is skipped, and the auto range feature operates using only the valid measurement ranges.
  - When non-periodic pulse waveforms are applied, the range may not remain constant. If this happens, use the fixed range setting.
-

## Current Range (RANGE UP/DOWN (A))

The current range can be fixed (when auto range is set to off) or determined automatically (when auto range is set to on).

### Fixed Ranges

When the current range is fixed, you can select a range from the available options. The selected current range does not change even if the amplitude of the input signal changes. Set the range in reference to the rms value of the input signal.

#### For 5 A Input Elements

- **When the Crest Factor Is Set to CF3**

You can select from 10 mA, 20 mA, 50 mA, 100 mA, 200 mA, 500 mA, 1 A, 2 A, and 5 A.

- **When the Crest Factor Is Set to CF6 or CF6A**

You can select from 5 mA, 10 mA, 25 mA, 50 mA, 100 mA, 250 mA, 500 mA, 1 A, and 2.5 A.

#### For 50 A Input Elements

- **When the Crest Factor Is Set to CF3**

You can select from 1 A, 2 A, 5 A, 10 A, 20 A, and 50 A.

- **When the Crest Factor Is Set to CF6 or CF6A**

You can select from 500 mA, 1 A, 2.5 A, 5 A, 10 A, and 25 A.

### Auto Range

This is the same as the auto range feature for voltage.

► [Click here.](#)



- When the secondary output of a CT (current transformer) or a clamp-type current sensor that outputs current is being applied to the current input terminal, set the current range according to the maximum value of the CT or current sensor output. Then, use the scaling feature to set the CT ratio or the conversion ratio of the clamp-type current sensor that outputs current.

## Auto Current Range (AUTO (A))

This is the same as the auto range feature for voltage.

► [Click here.](#)

## Power Range

The measurement ranges (power ranges) of active power (P), apparent power (S), and reactive power (Q) are as follows:

Wiring System	Power Range
1P2W (single-phase, two-wire system)	Current range × voltage range
1P3W (single-phase, three-wire system)	Voltage range × current range × 2
3P3W (three-phase, three-wire system)	(when the voltage and current ranges on the
3P3W (3V3A; three-voltage, three-current method)	elements in the wiring unit are set to the same range)
3P4W (three-phase, four-wire system)	Voltage range × current range × 3
	(when the voltage and current ranges on the
	elements in the wiring unit are set to the same range)

- When the result of the equation voltage range × current range exceeds 1000 W (VA or var), the displayed unit changes to kW (kVA or kvar).
- Number of displayed digits (display resolution)

► [Click here.](#)

For a detailed list of the available voltage and current range combinations and power ranges when all the elements have the same voltage or current range, see appendix 4 in the getting started guide, IM WT1801E-03EN.



In auto range mode, because the voltage and current ranges switch independently according to range increase and decrease conditions, different power ranges may be set for the same power value.

## External Current Sensor Range (EXT SENSOR; option)

The output of current sensors that produce voltage, such as shunts and clamps, can be applied to an element's external current sensor input terminal (EXT) and measured. Press EXT SENSOR so that it illuminates, and then set the external current sensor range.

The external current sensor range can be fixed (when auto range is set to off) or determined automatically (when auto range is set to on).

### Fixed Ranges

When the current range is fixed, you can select a range from the available options. The selected current range does not change even if the amplitude of the input signal changes. Set the range in reference to the rms value of the input signal.

- **When the Crest Factor Is Set to CF3**

You can select from 50 mV, 100 mV, 200 mV, 500 mV, 1 V, 2 V, 5 V, and 10 V.

- **When the Crest Factor Is Set to CF6 or CF6A**

You can select from 25 mV, 50 mV, 100 mV, 250 mV, 500 mV, 1 V, 2.5 V, and 5 V.

### Auto Range

This is the same as the auto range feature for voltage.

► [Click here.](#)

## External Current Sensor Conversion Ratio (SENSOR RATIO; option)

Set the conversion ratio used to measure the signal received by the external current sensor input terminal (EXT) from a current sensor that produces voltage. Set how many millivolts the current sensor transmits when 1 A of current is applied (conversion ratio). Then, the input signal can be made to correspond to the numeric data or waveform display data that is obtained when the current is directly applied to the input terminals. When using a current sensor that produces current, set the conversion ratio as the CT ratio.

► [Click here.](#)

Measurement Function	Conversion Ratio	Data before Transformation	Transformation Result
Current I	E	$I_S$ (current sensor output)	$I_S/E$
Active power P	E	$P_S$	$P_S/E$
Apparent power S	E	$S_S$	$S_S/E$
Reactive power Q	E	$Q_S$	$Q_S/E$
Max./min. current Ipk	E	$I_{pkS}$ (current sensor output)	$I_{pkS}/E$

### Element1 to Element6

Use the soft keys to select an element, and then set the element's external current sensor conversion ratio to a value within the following range.

0.0001 to 99999.9999

### Copying the External Current Sensor Conversion Ratio (Exec Copy $\Sigma$ )

Copy the external current sensor conversion ratio of the selected input element to the other input elements in the same wiring unit.

### External Current Sensor Range and Conversion Ratio Configuration Example

When you measure a current with a maximum value of 100 A using a current sensor that produces 10 mV when 1 A of current is flowing, the maximum voltage that the current sensor produces is  $10 \text{ mV/A} \times 100 \text{ A} = 1 \text{ V}$ . Therefore, configure the settings as indicated below.

- External current sensor range: 1 V
- External current sensor conversion ratio: 10 mV/A



- When using the dedicated shunt box, you can select an external current sensor conversion ratio preset in the settings of all elements (All Elements Setup).  
► [Click here.](#)
- When you want to divide the external current sensor output by the conversion ratio and read the current of the circuit under measurement directly, turn the external VT/CT scaling feature off. If the feature is turned on, the value will be further multiplied by the CT ratio.
- When you are measuring a signal other than a sine wave (such as a distorted wave), you can obtain accurate measurements by selecting the smallest measurement range that does not produce any of the conditions below.
  - The input peak over-range indicator at the top center of the screen illuminates or blinks in red.
  - The measured values of the voltage and current are indicated as being overload values ("OL-").

## External Current Sensor Range Display Format (DIRECT/MEASURE; option)

You can select the external current sensor range display format from the following options.

- **DIRECT** (direct input value display)  
Values are displayed within the external current sensor range (voltage). This setting is useful when you want to set the external current sensor range using the voltage received by this instrument from the external current sensor as a guide.
- **MEASURE** (measurement range display)  
The external current sensor range is divided by the external current sensor conversion ratio, and the resulting (current) range is displayed. This setting is useful when you want to set the external current sensor range using the current measured by the external current sensor as a guide. For example, if you are using a current sensor that produces 10 mV when it receives 1 A (external current sensor conversion ratio: 10 mV/A) and you set the external current sensor range to 1 V, the displayed current range is 100 A.

## Scaling (SCALING)

You can set coefficients for when you apply a voltage or current signal from an external VT (voltage transformer) or CT (current transformer).

### Turning Scaling On and Off (Scaling)

You can select whether to apply the VT ratio, CT ratio, and power coefficient to applicable measurement functions.

When reading measured values directly by using a VT or CT (or current sensor), select ON. When you select ON, the SCALING key and the Scaling indicator at the top of the screen illuminate.

#### Applicable Measurement Functions

Voltage (U), current (I), power (P, S, and Q), maximum and minimum voltages (U+pk and U-pk), and maximum and minimum currents (I+pk and I-pk)

- **ON:** The measurement functions above are multiplied by the VT ratio, CT ratio, or power coefficient.
- **OFF:** The measurement functions above are not multiplied by the VT ratio, CT ratio, or power coefficient. The output values of the VT and CT are displayed directly as numeric data.

### VT Ratio (VT Scaling)

Set the VT ratio when applying the secondary output of a VT to the voltage input terminal. Then, set the voltage range according to the maximum VT output.

#### Element1 to Element6

Use the soft keys to select an element, and then set the element's VT ratio to a value within the following range. 0.0001 to 99999.9999

#### Copying the VT Ratio (Exec Copy $\Sigma$ )

Copy the VT ratio of the selected input element to the other input elements in the same wiring unit.

### CT Ratio (CT Scaling)

Set the CT ratio (or the conversion ratio of the current sensor that produces current) when applying the secondary output of a CT or clamp-type current sensor that produces current to the current input terminal. Then, set the current range according to the maximum CT or current sensor output.

#### Element1 to Element6

Use the soft keys to select an element, and then set the element's CT ratio to a value within the following range. 0.0001 to 99999.9999



**Copying the CT Ratio (Exec Copy  $\Sigma$ )**

Copy the CT ratio of the selected input element to the other input elements in the same wiring unit.



When using the CT, you can select a CT ratio preset in the settings of all elements (All Elements Setup).

► [Click here.](#)

**Power Coefficient (SF Scaling; scaling factor)**

By setting the power coefficient (SF), you can display the measured active power, apparent power, and reactive power after they have been multiplied by a coefficient.

Measurement Function	Data before Transformation	Transformation Result	
Voltage U	$U_2$ (secondary output of the VT)	$U_2 \times V$	V: VT ratio
Current I	$I_2$ (secondary output of the CT)	$I_2 \times C$	C: CT ratio
Active power P	$P_2$	$P_2 \times V \times C \times SF$	SF: Power coefficient
Apparent power S	$S_2$	$S_2 \times V \times C \times SF$	
Reactive power Q	$Q_2$	$Q_2 \times V \times C \times SF$	
Max./min. voltage Upk	Upk <sub>2</sub> (secondary output of the VT)	Upk <sub>2</sub> × V	
Max./min. current Ipk	Ipk <sub>2</sub> (secondary output of the CT)	Ipk <sub>2</sub> × C	

**Element1 to Element6**

Use the soft keys to select an element, and then set the element's power coefficient to a value within the following range.

0.0001 to 99999.9999

**Copying the Power Coefficient (Exec Copy  $\Sigma$ )**

Copy the power coefficient of the selected input element to the other input elements in the same wiring unit.



- If the value of the result of multiplying the measured value by the VT ratio, CT ratio, or power coefficient (scaling factor) exceeds 9999.99 M, “-OF-” will appear in the numeric data display frame.
- You can view the VT and CT ratios and the power coefficients of all input elements by displaying the setup parameter list.  
► [Click here.](#)
- To correctly compute the power and efficiency of  $\Sigma$  functions, set the power coefficients of all elements so that all power units used in the computation are the same. For example, the efficiency cannot be computed correctly if elements or wiring units used in the computation have different power units, such as W (watt) and J (joule). To compute the efficiency correctly, make all the power units the same (either all W or all J).

## Valid Measurement Range (CONFIG(V)/CONFIG(A))

You can enable or disable a measurement range by selecting or clearing its check box. This instrument switches between enabled measurement ranges. Disabled measurement ranges are skipped. For example, when using auto range to measure the current of a device that produces 2 A when operating and 100 mA when in standby, disable the 200 mA, 500 mA, and 1 A ranges. When the device is in standby, the range will be 200 mA. When the device begins operating, this instrument will skip the intermediate 200 mA, 500 mA, and 1 A ranges and switch directly to the 2 A range.

### Element1 to Element6

For each input element or wiring unit, you can enable all measurement ranges at the same time (All ON).

### Measurement Range Box (Left column of the list)

You can enable (All ON) or disable (All OFF) a range for all input elements at the same time.

### Measurement Range in Which a Peak Over-Range Has Occurred (Peak Over Jump)

You can specify which measurement range to switch to when the auto range feature is enabled and a peak over-range occurs. The background of the selected measurement range turns yellow. If a peak over-range occurs when this feature is disabled, this instrument increases the measurement range, switching between valid measurement ranges (measurement ranges whose check boxes have been selected).

You can specify valid current measurement ranges for each input element type.

- **50A Input Element**

Select the valid direct input measurement ranges of 50 A input elements.

- **5A Input Element**

Select the valid direct input measurement ranges of 5 A input elements.

- **Ext Sensor Input Element (Option)**

Select the valid external current sensor input measurement range.




- You cannot set all measurement ranges to OFF. There must be at least one valid range.
  - The settings for the valid range and for the measurement range to switch to when peak over-range occurs are shared by all the input elements in a wiring unit.
  - When independent input element configuration is disabled and you change the wiring system, all measurement ranges are enabled (set to their initial setting).
  - When you switch independent input element configuration from on to off, all measurement ranges are enabled (set to their initial setting).
  - If you set the valid range setting for the current measurement range to OFF, this instrument switches to the next highest measurement range. If there is no measurement range above the current one, this instrument switches to the next lowest measurement range.
-

## Crest Factor (Crest Factor)

The crest factor is defined as the ratio of the peak value of the waveform to the rms value.

$$\text{Crest factor (CF)} = \frac{\text{Peak value}}{\text{Rms value}}$$



On this instrument, the crest factor is the ratio of the maximum applicable peak value to the measurement range.

$$\text{Crest factor (CF)} = \frac{\text{Peak value that can be input}}{\text{Measurement range}}$$

You can set the crest factor to CF3 or CF6.

- CF3: The crest factor is 3.
- CF6: The crest factor is 6.
- CF6A: The input range of the measurement range is expanded as follows as compared to when the crest factor is set to 6. This is used to suppress frequent range changes when measuring a distorted waveform in auto range mode.
  - Condition for increasing the range in auto range mode.  
The voltage or current exceeds 220% of the currently set measurement range.
  - Condition that cause an overload indication (" - O L - ") (for details, see section 1.3 in the Getting Started Guide, IM WT1801E-03EN)  
The measured voltage or current exceeds 280% of the currently set measurement range.

The measurable crest factor is as follows:

$$\text{Crest factor (CF)} = \frac{\{\text{measurement range} \times \text{CF setting (3 or 6)}\}}{\text{Measured value (rms value)}}$$

- \* However, the peak value of the input signal must be less than or equal to the maximum allowable input.

If the crest factor of the measured signal is greater than the specifications of this instrument (the crest factor defined at the rated input), you can measure the signal by setting a greater measurement range. For example, even if CF is set to 3, measurement is possible for signals with a crest factor greater than or equal to 5 when the measured value (rms value) is less than 60% of the measurement range. If the minimum effective input (1% of the measurement range) is being applied when CF is set to 3, measurement for CF = 300 is possible.

The voltage range, current range, effective input range, and measurement accuracy vary depending on the crest factor setting. For details, see chapter 6 in the getting started guide, IM WT1801E-03EN.




- When you change the crest factor, the following settings change for all elements.
  - All elements are automatically set to their maximum voltage and current ranges.
  - In the valid measurement range settings, all measurement ranges are enabled (selected).
- If the crest factor is set to CF6 or CF6A, the measurement conditions of crest factor 5 and higher required by IEC 62018 are met.
- When measuring waveforms whose crest factor is less than or equal to CF3, you can achieve more accurate measurements by setting the crest factor to 3.

## Measurement Period (SYNC SOURCE)


### Measurement Period for Measurement Functions Used in Normal Measurement

The measurement period is determined by the input signal that is used as the reference (synchronization source). The measurement period is set within the data update interval between the first point where the sync source crosses the level-zero point (center of the amplitude) on a rising slope (or falling slope) and the last point where the sync source crosses the level-zero point (center of the amplitude) on a rising slope (or falling slope).

- When the data update interval is not Auto




- When the data update interval is Auto




When the data update interval is not Auto, if there is not more than one rising or falling slope within the data update interval, the entire data update interval is set as the measurement period.


- When the data update interval is not Auto



- When the data update interval is Auto



- When the data update interval is Auto and timeout occurs



When the data update interval is not Auto, the measurement period for determining the numeric data of the peak voltage or peak current is always the entire span of the data update interval. Therefore, the measurement period for the measurement functions that are determined on the basis of the maximum voltage or current value (U+pk, U-pk, I+pk, I-pk, CfU, and CfI) is also the entire span of the data update interval.

For details, see appendix 5 in the getting started guide, IM WT1801E-03EN.

When the data update interval is Auto, the numeric data of the peak voltage or peak current is the data within the measurement period.

### Measurement Period for Measurement Functions Used in Harmonic Measurement

The measurement period extends from the first sample in the data update interval for the number of points indicated below:

- When the data update interval is 50 ms, 100 ms, or 200 ms: 1024 points
- When the data update interval is 500 ms, 1 s, 2 s, 5 s, 10 s, or 20 s: 8192 points
- When the data update interval is Auto: Select 1024 points or 8192 points

This instrument determines the harmonic sampling frequency automatically based on the period of the signal that is set as the PLL source. The sampling data and measurement period that are used to determine the values of harmonic measurement functions may be different from those used to determine the values of normal measurement functions.

### Element1 to Element6

Use the soft keys to select an element, and then select the signal to use as the sync source from the options listed below. The available options vary depending on the installed elements. When independent input element configuration is off, elements in the same wiring unit have the same sync source.

U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk (external clock),\* and None

- \* When you select Ext Clk, the external signal applied to the external clock input connector (EXT CLK) on the rear panel is used as the sync source. For the EXT CLK connector specifications, see section 4.3 in the getting started guide, IM WT1801E-03EN.

### Setting the Synchronization Source for when the Data Update Interval is Auto (Sync Source Setting)

#### Turning On and Off the Synchronization Source Rectifier for when the Data Update Interval is Auto (Voltage/Current/Ext Sensor Rectifier)

When the data update interval is Auto, select whether to rectify the synchronization source that determines the measurement period (ON\*/OFF).

- \* If rectifier is set to ON, reactive power Q, phase difference  $\Phi$ , and  $Q\Sigma$  measurements may change. See appendix 1 in the Getting Started Guide, IM WT1801E03EN.

#### Synchronization Source Level for when the Data Update Interval is Auto (Voltage/Current/Ext Sensor Level)

Set the synchronization source signal level for when the Data Update Interval is Auto.

Set the signal level in the following range.

- When the synchronization source rectifier is off: -100.0% to 100.0%
- When the synchronization source rectifier is on: 0.0% to 100.0% (absolute value)



- If synchronization source is set to None
  - When the data update interval is not Auto, all of the sampled data within the data update interval is used to determine the numeric data.
  - When the data update interval is Auto, all the sampling data up to the timeout time are used to determine numeric data.

When you are measuring DC signals, this method can be used to prevent noise from causing errors in the detection of the measurement period.

- If the sync source is not set correctly, the measured value may fluctuate or be incorrect. When you set the sync source, refer to appendix 5 in the getting started guide, IM WT1801E-03EN.

## Line Filter (LINE FILTER)

There are two types of input filters, line filters and frequency filters.

Because the line filter is inserted into the voltage and current measurement input circuits, it directly affects voltage, current, and power measurements (see the block diagram in appendix 11 in the getting started guide, IM WT1801E-03EN). When the line filter is turned on, measured values do not contain high frequency components. Thus, the voltage, current, and power of inverter waveforms, strain waveforms, etc., can be measured with their high frequency components eliminated.

### Element1 to Element6

Use the soft keys to select an element, and then turn the line filter on or off, and set the cutoff frequency.

You can set the cutoff frequency to

300 kHz, 1 MHz, or a value from 0.1 kHz to 100.0 kHz (in 0.1 kHz steps)

- If the line filter of even one of the elements is not set to OFF, the LINE FILTER key and the Line Filter indicator at the top of the screen illuminate.
- Selecting OFF disables the line filter.

### Copying the Line Filter Setting (Exec Copy $\Sigma$ )

Copy the line filter on/off setting and cutoff frequency of the selected input element to the other input elements in the same wiring unit.

### Line Filter for High Speed Data Capturing

► [Click here.](#)

## Frequency Filter (FREQ FILTER)

The frequency filter is inserted into the frequency measurement input circuit and affects frequency measurements. It also affects the detection of the measurement period for voltage, current, and power measurements (see appendix 5 in the getting started guide, IM WT1801E-03EN). In this case, the filter also acts as a filter for detecting the [zero-crossing](#) of the synchronization source signal more accurately. The frequency filter is not inserted into the voltage and current measurement input circuits. Therefore, the measured values include high frequency components even when the frequency filter is turned on.

- This instrument detects the zero-crossing point with a hysteresis of approximately 5% of the measurement range.
- If even one element is not set to OFF, the Freq Filter indicator at the top of the screen illuminates.
- If the line filter described above is on, it affects the frequency measurement even when the frequency filter is off.
- We recommend that you turn the frequency filter on when the input signal frequency is less than or equal to 1 kHz.

The following two types of frequency filters are available. When you press FREQ FILTER, either one appears depending on the data update interval setting.

- Element1 to Element6 (When the data update interval is not Auto)
- Element1 to Element6 (When the data update interval not Auto)

### Element1 to Element6

#### (When the data update interval is not Auto)

Use the soft keys to select an element, and then select the element's cutoff frequency from the options listed below. OFF, 100 Hz, and 1 kHz

### Freq Filter at Update Rate Auto

Displays the frequency filter setup menu for when the data update interval is Auto.

## Element1 to Element6

### (When the data update interval is Auto)

Select the soft key for the element you want to set. Then, set the frequency filter (for when the data update interval is Auto) to ON or OFF, and set the cutoff frequency.

You can set the cutoff frequency to

100 Hz, 200 Hz, 400 Hz, 800 Hz, 1.6 kHz, 3.2 kHz, 6.4 kHz, 12.8 kHz, and 25.6 kHz

### Freq Filter

Displays the frequency filter setup menu for when the data update interval is not Auto.



- When the data update interval is not Auto (50 ms to 20 s), the frequency filter is used for data update interval extraction and frequency measurement noise filter.
- When the data update interval is Auto, the frequency filter (for when the data update interval is Auto) is used for data update interval extraction and frequency measurement noise filter.

## Data Update Interval (UPDATE RATE)

The data update interval is the interval at which the data that is used in measurement functions is sampled.

- When the data update interval is not Auto
  - You can select the data update interval from the options below.  
50 ms, 100 ms, 200 ms, 500 ms, 1 s, 2 s, 5 s, 10 s, 20 s, and Auto
  - At each data update interval, the numeric data is updated, stored, transmitted through a communication interface, and converted and output as analog signals.
  - If the waveform display is enabled and the trigger mode is set to Auto or Normal, the data update interval depends on the trigger operation.
- When the data update interval is Auto
  - Every time a period\* of the input waveform specified as the synchronization source is detected, measured data is updated, output as analog signals, and transmitted through the communication interface.  
\* 50 ms or more.
  - The trigger mode on the waveform display is set to OFF.

If the waveform display is enabled and the trigger mode is set to Auto or Normal, the data update interval depends on the trigger operation.

To capture relatively fast load fluctuations in the power system, select a fast data update rate. To capture low frequency signals, select a slow data update rate.

If the fluctuation in the input signal period is large, select Auto.

### Turning Auto Data Update Interval On and Off

Select whether to set the data update interval to Auto (ON/OFF).

- When set to ON
  - The Fast/Slow soft key is disabled.
  - The measurement mode indication at the upper left of the screen is Normal Mode (Auto).
  - Set the following items.
    - [Timeout value for when the data update interval is Auto](#)
    - [Element1 to Element6 \(When the data update interval is Auto\)](#)
    - [Turning On and Off the Synchronization Source Rectifier for when the Data Update Interval is Auto](#)
    - [Synchronization source signal level for when the data update interval is Auto](#)
- When set to OFF, use the Fast/Slow soft key to set the data update interval.

### Fast

This instrument switches to the next fastest data update interval (out of the intervals listed above).

### Slow

This instrument switches to the next slowest data update interval (out of the intervals listed above).

### Current Rate

Displays the current data update interval. You can press a soft key to select a data update interval from the options listed above.

### Timeout value for when the data update interval is Auto (Time Out at Update Rate Auto)

Timeout is the time limit for detecting the period of the input waveform.

Select 1s, 5s, 10s, or 20s.

If the input signal frequency is low and the period of the synchronization source cannot be detected within the timeout period, the frequency data will be outside the measurement range and will result in error. The measurement functions of normal measurement determine measured values using the entire period up to the timeout as the measurement period.



- The display update intervals of numeric data and waveform data may be longer than the data update interval.
  - The lowest measurable AC signal frequency varies depending on the data update interval. The measured value may not be stable if an AC signal of a frequency lower than the low frequency measurement limit (see section 6.5 in the getting started guide, IM WT1801E-03EN) is measured.
  - When the data update interval is Auto, fPLL2, WS, and WQ are not measured and displayed as “-----” (no data).
- 

## Averaging (AVG)

You can take exponential or moving averages of the numeric data. The averaging function is effective when reading of the numeric display is difficult due to fluctuations. This occurs when the fluctuation of the power supply or the load is large or when the input signal frequency is low.

### Turning Averaging On and Off (Averaging)

#### Measurement Functions Used in Normal Measurement

You can select whether to average values. When you enable averaging (ON), the AVG key and the AVG indicator at the top of the screen illuminate.

#### Measurement Functions Used in Harmonic Measurement (Option)

- If averaging is turned on, and the averaging type is Exp (exponential averaging), averaging is performed on harmonic measurement functions.
- Even if averaging is turned on, if the averaging type is Lin (moving average), averaging is not performed on harmonic measurement functions.

### Averaging Types (Type)

You can use exponential or moving averages.

#### Exponential Averaging (Exp)

With the specified attenuation constant, the numeric data is exponentially averaged according to the equation below.

$$D_n = D_{n-1} + \frac{(M_n - D_{n-1})}{K}$$

$D_n$ : Displayed value that has been exponentially averaged  $n$  times. (The first displayed value,  $D_1$ , is equal to  $M_1$ .)

$D_{n-1}$ : Displayed value that has been exponentially averaged  $n - 1$  times.

$M_n$ : Measured data at the  $n^{\text{th}}$  time.

$K$ : Attenuation constant (select from 2 to 64)



**Moving Average (Lin)**

The specified average count is used to compute moving averages according to the equation below.

$$D_n = \frac{M_{n-(m-1)} + \dots + M_{n-2} + M_{n-1} + M_n}{m}$$

$D_n$ :  $n-(m-1)^{\text{th}}$  to the  $n^{\text{th}}$  time

$M_{n-(m-1)}$ : Measured data at the  $n-(m-1)^{\text{th}}$  time

.....

$M_{n-2}$ : Measured data at the  $n-2^{\text{th}}$  time.

$M_{n-1}$ : Measured data at the  $n-1^{\text{st}}$  time.

$M_n$ : Measured data at the  $n^{\text{th}}$  time.

$m$ : Average count (select a number from 8 to 64)

**Attenuation Constant or Average Count (Count)**

- If the averaging type is Exp (exponential averaging), set the attenuation constant to a value within the following range.  
2 to 64
- If the averaging type is Lin (moving average), set the average count to a value within the following range.  
8 to 64

**Measurement Functions That Are Averaged**

The measurement functions that are directly averaged are indicated below. Other functions that use these functions in their computation are also affected by averaging. For details about how the values of the measurement functions are determined, see appendix 1 in the getting started guide, IM WT1801E-03EN.

**Measurement Functions Used in Normal Measurement**

- Urms, Umn, Udc, Urmn, Uac, Irms, Imn, Idc, Irmn, Iac, P, S, and Q
- $\Delta U1$  to  $\Delta P\Sigma$  (delta computation)
- Torque, speed, and Pm (on models with the motor evaluation option)
- Aux1 and Aux2 (on models with the auxiliary input option)
- $\lambda$ ,  $\Phi$ , CfU, Cfl, Pc, q, q+, q-, and  $\eta1$  to  $\eta4$  are computed using the averaged values of Urms, Irms, P, S, and Q.
- Slip is computed using the averaged value of Speed (on models with the motor evaluation option).

**Measurement Functions Used in Harmonic Measurement (Option)**

- $U(k)$ ,  $I(k)$ ,  $P(k)$ ,  $S(k)$ , and  $Q(k)$
- $\lambda(k)$ , and  $\Phi(k)$  are computed using the averaged values of  $P(k)$  and  $Q(k)$ .
- Z, Rs, Xs, Rp, Xp, Uhdf, Ihdf, Phdf, Uthd, Ithd, Pthd, Uthf, Ithf, Utif, Itif, hvf, hcf, and K-factor are computed using the averaged values of  $U(k)$ ,  $I(k)$ , and  $P(k)$ .

k: The harmonic order

**Measurement Functions That Do Not Perform Averaging**

The following measurement functions do not perform averaging.

**Measurement Functions Used in Normal Measurement**

fU, fI, U+pk, U-pk, I+pk, I-pk, P+pk, P-pk, Time, WP, WP+, WP-, WP $\Sigma$ , WP+ $\Sigma$ , WP- $\Sigma$ , WS, WQ, and SyncSp (on models with the motor evaluation option)

**Measurement Functions Used in Harmonic Measurement (Option)**

$\Phi U(k)$ ,  $\Phi I(k)$ ,  $\Phi U_i-U_j$ ,  $\Phi U_i-U_k$ ,  $\Phi U_i-I_i$ ,  $\Phi U_j-I_j$ ,  $\Phi U_k-I_k$ , fPLL1, fPLL2, EaU, and EaI

\* k: The harmonic order

### Measurement Functions Used in Normal and Harmonic Measurement (Option)

F1 to F20 and Event 1 to Event 8



- When averaging is turned on, the average value of multiple measurements is determined and displayed. If the input signal changes drastically, it will take longer for the change to be reflected in the measured values when averaging is used.
  - A larger attenuation constant (for exponential averaging) or average count (for moving averages) will result in more stable (and less responsive) measured values.
  - When the data update interval is Auto, averaging is performed every 50 ms.
- 

## Displaying the Setup Parameter List (INPUT INFO)

The setup parameter list appears in the top half of the screen.

### Display Format (FORM)

#### Input Element Settings List (Power Element Settings)

The wiring system, measurement range, scaling factor, synchronization source, line filter, and frequency filter settings for each element are displayed.

#### Measurement Range Settings List (Range Settings)

The measurement range settings for each element are displayed. Measurement ranges that have been disabled in the valid measurement range settings are dimmed.

### Display Items (ITEM)

#### Turning the Display Frame On and Off (Display Frame)

▶ [Click here.](#)



- The setup parameter list shows the settings when measurement took place. If the measurement range or some other setting is changed while the hold feature is on, the changes will not be reflected in the list.
  - When the setup parameter list is displayed, press FORM to switch between the FORM menu for the setup parameter list and the FORM menu for the display in the bottom half of the screen. Likewise, press ITEM to switch between ITEM menus.
-

---

## 3 Harmonic Measurement Conditions (Option)

### Harmonic Measurement Conditions (HRM SET)

Using harmonic measurement, you can measure functions that are based on the voltage, current, and power harmonics and their distortion factors; on the phase angle of each harmonic relative to the fundamental; etc. You can also compute the harmonic distortion factors for voltage and current.

For a list of the measurement functions that can be measured with harmonic measurement and their descriptions, see “Harmonic Measurement Functions” under “Items That This Instrument Can Measure.”

► [Click here.](#)

#### Models with the Harmonic Measurement Option

The following menu items appear.

- [PLL source \(PLL Source\)](#)
- [Measured harmonic orders \(Min Order/Max Order\)](#)
- [Distortion Factor Equation \(Thd Formula\)](#)
- [Number of FFT points \(FFT Points\)](#)

#### Models with the Simultaneous Dual Harmonic Measurement Option

The following menu items appear.

- [Input element group \(Element Settings\)](#)
- [PLL source of group Hrm1 \(Hrm1 PLL Source\)](#)
- [Measured harmonic orders of group Hrm1 \(Min Order/Max Order\)](#)
- [Distortion factor equation of group Hrm1 \(Thd Formula\)](#)
- [Number of FFT points \(FFT Points\)](#)
- [PLL source of group Hrm2 \(Hrm2 PLL Source\)](#)
- [Measured harmonic orders of group Hrm2 \(Min Order/Max Order\)](#)
- [Distortion factor equation of group Hrm2 \(Thd Formula\)](#)

### PLL Source (PLL Source)

For harmonics to be measured, the fundamental period (the period of the fundamental signal) that will be used to analyze the harmonics must be determined. The signal for determining the fundamental period is the PLL (phase locked loop) source.

Select the PLL source from the choices below. The available options vary depending on the installed elements. U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, and Ext Clk\*

- \* If you select Ext Clk, the frequency of the signal applied to the rear panel's external clock input connector (EXT CLK) is used as the fundamental frequency for harmonic measurement. For the EXT CLK connector specifications, see section 4.3 in the getting started guide, IM WT1801E-03EN.



- Select a signal that has the same period as the signal that you want to measure the harmonics of. For stable harmonic measurement, choose an input signal for the PLL source that has as little distortion and fluctuation as possible. If the fundamental frequency of the PLL source fluctuates or if the fundamental frequency cannot be measured due to waveform distortion, correct measurements will not be obtained. When the measured item is a switching power supply and in other cases where the distortion of the voltage signal is smaller than that of the current signal, we recommend that the PLL source be set to the voltage.
  - If all of the input signals are distorted or the amplitude is small compared to the measurement range, the specifications may not be met. To achieve stable, accurate measurements on high harmonics, set the PLL source to an external clock signal and apply a signal with the same period as the input signal to the external clock input connector.
  - If the fundamental frequency is less than or equal to 1 kHz and the signal contains high frequency components, we recommend that you use the frequency filter. This filter is only effective on the frequency measurement circuit.
  - If the amplitude level of the signal applied to the element that is specified as the PLL source is small compared to the range, PLL synchronization may not be achieved. If the [crest factor](#) is set to CF3, set the measurement range so that the amplitude level of the PLL source is at least 50%. If the crest factor is set to CF6 or CF6A, set the measurement range so that the amplitude level of the PLL source is at least 100%.
  - If the frequency of the PLL source changes, correct measured values are displayed four data updates after the change. Correct measured values may not be obtained immediately after the PLL source or its frequency changes, because the PLL circuit inside this instrument redetects the frequency.
- 

## Measured Harmonic Orders (Min Order/Max Order)

The harmonic measurement range can be specified. The harmonic orders specified here are used to determine the numeric data of the distortion factor.

► [Click here.](#)

### Minimum Harmonic Order to Be Measured (Min Order)

Select from the following.

- 0: The 0th order (DC) component is included when numeric harmonic waveform data is determined.
- 1: The 0th order (DC) component is not included when numeric harmonic waveform data is determined. The harmonic measurement data (the harmonic waveform data) is determined from the 1st order (the fundamental wave).

### Maximum Harmonic Order to Be Measured (Max Order)

You can select a value between 1 and 500.

However, the maximum measurable harmonic order is the smallest of the three orders listed below.

- The specified maximum harmonic order to be measured
- The value determined automatically according to the PLL source frequency (see section 6.6 in the getting started guide, IM WT1801E-03EN)
- When the data update interval is 50 ms or Auto, the maximum measurable harmonic order is 100.

The numeric data corresponding to harmonic orders above the maximum measurable harmonic order is displayed as "-----" (no data).



- If the minimum harmonic order to be measured is set to 1, the data of the DC component is not included when the distortion factor is determined.
  - There is no overload value indication ("-OL-") or zero indication (rounding to zero) for the numeric data of harmonic orders 0 (DC) to 500. For information about the overload value indication ("-OL-") and zero indication (rounding to zero) in normal measurement, see section 6.4 in the getting started guide, IM WT1801E-03EN.
-

## Distortion Factor Equation (Thd Formula)

When determining the harmonic measurement functions U<sub>hdf</sub>, I<sub>hdf</sub>, P<sub>hdf</sub>, U<sub>thd</sub>, I<sub>thd</sub>, and P<sub>thd</sub>, you can select to use one of the denominators described below as the denominator for the equation. For information about equations, see appendix 1 in the getting started guide, IM WT1801E-03EN.

### 1/Total

The denominator is the measured data of all orders from the minimum measured order (0 or 1<sup>st</sup>) to the maximum measured order (within the upper limit of harmonic analysis).

### 1/Fundamental

The denominator is the data of the fundamental signal component (1st order).

## Number of FFT points (FFT Points)

When the data update interval is Auto, set the number of FFT points to 1024 or 8192.

## Input Element Group (Element Settings)

This setting appears on models with the simultaneous dual harmonic measurement option. You can divide all the input elements into two groups: Hrm1 and Hrm2, and measure harmonics using two PLL sources with different frequencies. You can measure the input and output harmonics of an AC–AC converter whose input and output frequencies are different.

This setting does not appear on models with the harmonic measurement option.

When the data update interval is Auto, harmonics of the Hrm2 group are not measured.

### Element1 to Element6

Use the soft keys to select an element, and then assign the element to group Hrm1 or group Hrm2. Input elements that are assigned to the same wiring unit are assigned to the same group.

### PLL Source of Group Hrm1 (Hrm1 PLL Source)

### PLL Source of Group Hrm2 (Hrm2 PLL Source)\*

These settings are the same as the PLL source (PLL Source) setting.

▶ [Click here.](#)

### Measured Harmonic Orders of Group Hrm1 (Min Order/Max Order)

### Measured Harmonic Orders of Group Hrm2 (Min Order/Max Order)\*

These settings are the same as the measured harmonic orders (Min Order/Max Order) setting.

▶ [Click here.](#)

### Distortion Factor Equation of Group Hrm1 (Thd Formula)

### Distortion Factor Equation of Group Hrm2 (Thd Formula)\*


These settings are the same as the distortion factor equation (Thd Formula) setting.

▶ [Click here.](#)

\* When the data update interval is Auto, these menus do not appear.

## Anti-Aliasing Filter

When an FFT is taken through the performance of A/D conversion on a repetitive waveform, a phenomenon occurs in which frequency components that exceed half the frequency of the sampling frequency are detected as low frequency components. This is called aliasing.



Aliasing causes problems such as increased errors in measured values and incorrect measurements of the phase angles on each harmonic. An anti-aliasing filter is used to prevent aliasing and eliminate high frequency components that are irrelevant to the harmonic measurement.

For example, when an input signal with a fundamental frequency of 50 Hz is measured up to the 50th order, the frequency of the 50th order is 2.5 kHz. Thus, a 5-kHz anti-aliasing filter is used to eliminate high frequency components that are greater than or equal to approximately 5 kHz, which are irrelevant to harmonic measurement.

This instrument uses the line filter as an anti-aliasing filter for harmonic measurements. For information about how to configure the filter, see “Line Filter (LINE FILTER).”

► [Click here.](#)

The accuracy and the upper limit of the measurement bandwidth change when the anti-aliasing filter (line filter) is turned ON. For details, see appendix 6.6 in the getting started guide, IM WT1801E-03EN.

---

## 4 Motor Evaluation Conditions (Option)

### Motor Evaluation Conditions and Auxiliary Input Conditions (MOTOR/AUX SET)

Press MOTOR/AUX SET to display a setup dialog box for the installed option.

#### Models with the Motor Evaluation Option

The MOTOR Settings dialog box appears.

This instrument can determine the motor rotating speed, torque, and output. It determines them using the revolution sensor signal, which is proportional to the motor rotating speed, and the torque meter signal, which is proportional to the motor torque. You can configure this instrument to receive analog (DC voltage) signals or pulse signals from the revolution sensor and torque meter. Also, you can set the number of motor poles and determine the motor's synchronous speed and slip. Furthermore, you can use the active power, frequency, and motor output measured by this instrument to compute the motor efficiency and total efficiency.

For a list of the measurement functions that can be measured with the motor evaluation feature and their descriptions, see "Motor Evaluation Functions" under "Items That This Instrument Can Measure."

► [Click here.](#)

#### Models with the Auxiliary Input Option

The Aux Settings dialog box appears.

► [Click here.](#)

#### Motor Evaluation Settings

You can configure the following motor evaluation settings.

- [Scaling factor \(Scaling\)](#)
- [Unit \(Unit\)](#)
- [Input signal type \(Sense Type\)](#)
- [Analog input range](#)
- [Linear scaling of analog input](#)
- [Line Filter \(Line Filter\)](#)
- [Synchronization Source \(Sync Source\)](#)
- [Pulse input range](#)
- [Torque signal pulse rating](#)
- [Revolution signal pulses per revolution \(Pulse N\)](#)
- [Motor poles \(Pole\)](#)
- [Frequency measurement source \(Source\)](#)
- [Electrical angle measurement \(Electrical Angle Measurement\)\\*](#)
- [Motor efficiency and total efficiency computation](#)

\* This item is available on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

### Scaling Factor (Scaling)

#### Setting the Scaling Factor for Scaling the Revolution Signal

You can set the factor for scaling the revolution signal. Set the factor to a value from 0.0001 to 99999.9999.

- **When the Revolution Signal Type is Analog**

This setting is used as the scaling factor in the equation for the [linear scaling of analog input](#).

- **When the Revolution Signal Type is Pulse**

This setting is used as the scaling factor in the equation for the number of [revolution signal pulses per revolution](#).

### Setting the Scaling Factor for Scaling the Torque Signal

You can set the factor for scaling the torque signal to motor torque. Set the factor to a value from 0.0001 to 99999.9999.

- **When the Torque Signal Type is Analog**

This setting is used as the scaling factor in the equation for the [linear scaling of analog input](#).

- **When the Torque Signal Type is Pulse**

This setting is used as the scaling factor in the equation for the [torque signal pulse rating](#).

### Setting the Scaling Factor for Computing the Motor Output

You can specify the scaling factor for computing the motor output (mechanical power) from the rotating speed and torque. Set the factor to a value from 0.0001 to 99999.9999.

The equation is indicated below. The scaling factors of the rotating speed and torque are set so that the unit of the rotating speed is  $\text{min}^{-1}$  (or rpm) and the unit of torque is  $\text{N}\cdot\text{m}$ . When the scaling factor of the motor output specified here is 1, the unit of the motor output  $P_m$  is W. Because the [efficiency computation](#) uses W as the unit of  $P_m$ , we recommend that you set the scaling factor of each item so that the unit of  $P_m$  is W.

$$\text{Motor output } P_m = \frac{2\pi}{60} \times \text{Speed} \times \text{Torque} \times S$$

Speed: The rotating speed, determined from the number of pulses per revolution

Torque: The torque, determined from the torque signal pulse rating

S: The scaling factor

## Unit (Unit)

- Number of characters: Up to eight
- Usable characters: Spaces and all characters that are displayed on the keyboard

## Input Signal Type (Sense Type)

You can select which of the following two types of signals you want this instrument to receive from the revolution sensor and torque meter.

- Analog: Select this option when this instrument will receive DC voltage (analog) signals.
- Pulse: Select this option when this instrument will receive pulse signals.

### Settings for Different Signal Types

As indicated below, the settings that you need to configure vary depending on the revolution and torque signal type.

#### Settings Related to the Signal Type

Setting	Signal Type	
	Analog	Pulse
Analog auto range	Yes	No
Analog range	Yes	No
Linear scale A, B	Yes	No
Line filter	Yes	No
Synchronization source	—	—
Pulse range	No	Yes
Number of pulses per revolution	No	Yes

Yes: Must be set.

No: Does not need to be set.

—: Measurement can be performed when the sync source is set to None (the default setting), but you can increase synchronicity with power measurement by specifying a sync source.



**Common Settings Unrelated to the Signal Type**

- Scaling factor
- Unit
- Motor poles
- Sync speed frequency measurement source

## Analog Input Range

Set the analog input range for input signals whose type has been set to analog. For input signals whose type has been set to pulse, there is no need to set the analog input range.

**Turning Auto Range On and Off (Analog Auto Range)**

Select whether to turn auto range on or off. When auto range is on, this instrument automatically switches between the following ranges according to the size of the input signal.

20 V, 10 V, 5 V, 2 V, and 1 V

**Range Increase**

- The measurement range is increased when the rotating speed signal or torque signal exceeds 110% of the measurement range.
- The measurement range is increased when the peak value of the input signal exceeds 150% of the measurement range.

**Range Decrease**

The measurement range is decreased when the rotating speed signal or torque signal falls below 30% of the measurement range and the peak value of the input signal is less than 125% of the lower range.



When non-periodic pulse waveforms are applied during auto range, the range may not remain constant. If this happens, use the fixed range setting.

**Fixed Range (Analog Range)**

You can select one of the following input ranges.

20 V, 10 V, 5 V, 2 V, or 1 V

## Linear Scaling of Analog Input

You can set the slope and the offset value of the input signal using one of the following two methods.

- Set the values manually.
- Specify two points, and use those points to compute the values

**Manually Setting the Input Signal Slope and Offset (Linear Scale A, B)**

You can set the slope (A) and offset (B) of the rotating speed and torque input signals to values within the following ranges.

A: 1.000 m to 1.000 M

B: -1.000 M to 1.000 M

The following equation is used to compute the rotating speed and torque.

Rotating speed, torque =  $S(AX + B) - \text{NULL}$

S: The scaling factor

A: The input signal slope

X: The input voltage from the revolution sensor or torque meter.

B: The offset

NULL: The **NULL value**

**When There Is No Offset in the Input Voltages from the Revolution Sensor and Torque Meter**

If you set A to 1 and B to 0, the linear scaling settings do not affect computation, and the previous equation becomes:

Rotating speed, torque = SX – NULL

You can compute the rotating speed and torque by setting the scaling factors to the number of revolutions and the amount of torque per 1 V.

**When There Is Offset in the Input Voltages from the Revolution Sensor and Torque Meter**

If you set S to 1, the scaling factor does not affect the computation, and the previous equation becomes

Rotating speed, torque = AX + B – NULL

You can compute the rotating speed and torque by setting the offset values (B) and setting the input signal slopes (A) to the number of revolutions and the amount of torque per 1 V.



If you enable the NULL function and then change the input signal slope (A) or offset value (B), NULL correction will be offset. Reset the NULL value.


**Computing the Input Signal Slope and Offset by Specifying Two Points (Calculation)**

On the input characteristic graphs of the rotating speed and torque, you can specify two measured rpm or N·m values (Point1Y and Point2Y) in relation to two input voltage values (Point1X and Point2X).

Measured values (Point1X and Point2X): –1.000 T to 1.000 T

Computed values (Point1Y and Point2Y): –1.000 T to 1.000 T

Select Execute to use these four values to determine and set the input signal slope (A) and offset (B).

**Line Filter (Line Filter)**

You can remove high-frequency noise by inserting a line filter into the circuit used to measure the revolution and torque signals.

You can select the cutoff frequency from the following options.

OFF, 100 Hz, and 1 kHz

Selecting OFF disables the filter.



The line filter setting applies to input signals whose type has been set to analog. For input signals whose type has been set to pulse, there is no need to configure this setting.

## Synchronization Source (Sync Source)

- When you are measuring analog revolution and torque signals, you can select the element to use as the sync source from the following options. The available options vary depending on the installed elements.  
U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk (external clock),\* and None  
\* For the EXT CLK connector specifications, see section 4.3 in the getting started guide, IM WT1801E-03EN.
- The measurement period is determined according to the zero-crossing point of the selected synchronization source. This instrument uses the measurement period to measure the analog revolution and torque signals.
- If synchronization source is set to None
  - When the data update interval is not Auto, all the sampled data within the data update interval is used to determine the rotating speed and torque.
  - When the data update interval is Auto, all the sampling data up to the timeout time are used to determine rotating speed (Speed) and torque (Torque).
- When the revolution or torque signal is a pulse signal, its value is the pulse signal period averaged over the measurement period. The measurement period is determined according to the sync source. If the pulse signal period does not fit within the measurement period, the previous period is used to determine the measured value.
- To achieve stable motor efficiency measurements, we recommend that you set the sync source for motor efficiency measurement to the same [sync source](#) that is set in the fundamental measurement conditions. This ensures that the measurement period is in sync with the measurement functions, such as those for voltage, current, and active power.

## Pulse Input Range

Set an appropriate range for the maximum and minimum input signal values. For example, when you are measuring signals for rotating speeds of 120 rpm to 180 rpm and torques of  $-18 \text{ N}\cdot\text{m}$  to  $+18 \text{ N}\cdot\text{m}$ , set the rotating speed pulse input range to 100 rpm to 200 rpm, and set the torque pulse input range to  $-20 \text{ N}\cdot\text{m}$  to  $+20 \text{ N}\cdot\text{m}$ .

### Upper and Lower Limits ((Pulse Range Upper, Pulse Range Lower)

You can set the pulse range for each input signal within the following limits.

- Revolution signal: 0.0000 to 99999.9999 (rpm)
- Torque signal:  $-10000.0000$  to  $10000.0000$  ( $\text{N}\cdot\text{m}$ )

When the input signal type is pulse, the waveform display lower and upper limits are the values that you set here.

On models with the D/A output option, the rated D/A output values are as follows.

Revolution and Torque Input Signals	D/A output
Setting for Pulse Range Upper	+5 V
Setting for Pulse Range Upper $\times (-1)$	-5 V

## Torque Signal Pulse Rating

When the torque signal type is pulse, refer to the torque meter's specifications to set its rated positive and negative values.

### Positive and Negative Rated Torque Signal Values (Rated Upper, Rated Lower)

Range:  $-10000.0000$  to  $10000.0000$  ( $\text{N}\cdot\text{m}$ )

### Positive and Negative Rated Torque Signal Pulse Frequencies (Rated Freq Upper, Rated Freq Lower)

Range: 1 to 100000000 (Hz)

The following equation is used to compute the torque.

$$\text{Torque} = S(AX + B) - \text{NULL}$$


- S: The scaling factor<sup>1</sup>  
 A: The torque pulse coefficient<sup>2</sup>  
 X: The pulse frequency  
 B: The torque pulse offset<sup>2</sup>  
 NULL: The [NULL value](#)

- 1 If the torque signal is a changed signal, you can set the [scaling factor](#) to determine the torque before the change.
- 2 The torque pulse coefficient and torque pulse offset are determined from the torque signal pulse rating as shown in the next figure.

### Relationship between the Torque Signal Pulse Input Range and Pulse Rating

To measure a torque of  $-20 \text{ N}\cdot\text{m}$  to  $+20 \text{ N}\cdot\text{m}$  using a torque meter with specifications in the figure below, configure the pulse input range and pulse rating settings as indicated below.

- Upper limit of the pulse input range (Pulse Range Upper): 20.0000
- Lower limit of the pulse input range (Pulse Range Lower):  $-20.0000$
- Positive rated torque signal value (Rated Upper): 50.0000
- Negative rated torque signal value (Rated Lower):  $-50.0000$
- Positive rated torque signal pulse frequency (Rated Freq Upper): 15000
- Negative rated torque signal pulse frequency (Rated Freq Lower): 5000





The pulse input range setting applies to input signals whose type has been set to pulse. For input signals whose type has been set to analog, there is no need to configure this setting.

## Revolution signal pulses per revolution (Pulse N)

Set the number of pulses per revolution to a value from 1 to 9999.

The following equation is used to compute the rotating speed.

$$\text{Rotating speed} = S \frac{X}{N} - \text{NULL}$$

S: The scaling factor\*

X: The number of input pulses from the revolution sensor per minute

N: The number of pulses per revolution

NULL: The [NULL value](#)

- \* When the scaling factor is 1, the rotating speed is the number of revolutions per minute ( $\text{min}^{-1}$  or rpm). If the revolution signal is a changed signal, you can set the [scaling factor](#) to determine the rotating speed before the change.



The setting specifying the number of revolution signal pulses per revolution applies to input signals whose type has been set to pulse. For input signals whose type has been set to analog, there is no need to configure this setting.

## Synchronous Speed (Sync Speed)

### Motor Poles (Pole)

Set the number of motor poles to a value from 1 to 99. This number is used to compute the sync speed.

### Frequency Measurement Source (Source)

- Select the frequency measurement source to use to compute the sync speed from the options below. The frequency measurement source is used to compute the sync speed. The available options vary depending on the installed elements.  
U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, and I6
- Normally, you should select the voltage or current that is being applied to the motor. If you select the frequency of a voltage or current that is not being applied to the motor, the sync speed may not be determined properly.

### Sync Speed Equation

The sync speed unit is fixed at  $\text{min}^{-1}$  or rpm.

$$\text{Sync speed (min}^{-1}\text{)} = \frac{120 \times F_s}{\text{Pole}}$$

Fs: The frequency of the frequency measurement source (Hz)

Pole: The number of motor poles

### Slip Equation

The sync speed unit is fixed at  $\text{min}^{-1}$  or rpm. To determine the slip, configure the rotating speed [scaling factor](#) so that the unit of the rotating speed is also  $\text{min}^{-1}$  (or rpm).

$$\text{Slip (\%)} = \frac{\text{SyncSp} - \text{Speed}}{\text{SyncSp}} \times 100$$

SyncSp: The synchronous speed ( $\text{min}^{-1}$ )

Speed: The rotating speed ( $\text{min}^{-1}$ )



---

Set the frequency measurement source to a stable voltage or current signal that is being applied to the motor and that has low distortion and noise.

---

## Electrical Angle Measurement (Electrical Angle Measurement)

This item is appears on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

### Turning Electrical Angle Measurement On and Off

Select whether to measure electrical angles.

### Electrical Angle Correction (Electrical Angle Correction)

Set the electrical angle correction value.

#### Correction Value (Correction Value)

Set the correction value to a number from  $-180.00^\circ$  to  $180.00^\circ$ .

#### Clearing the Correction Value (Clear Correction)

Set the correction value to 0.00.

#### Automatically Computing the Correction Value (Auto Enter Correction)

This instrument automatically sets the correction value to the difference between the phase of the voltage or current whose correction value is being automatically computed and the current electrical angle phase.

#### Voltage or Current to Automatically Compute the Correction Value of (Auto Enter Target)

Select the voltage or current to automatically compute the correction value of from the options below. The available options vary depending on the installed elements.

U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, and I6

## Motor Efficiency and Total Efficiency Computation

This instrument can compute the motor efficiency (the ratio of power consumption to motor output) and total efficiency from the active power and motor output that it measures.\* You can set the efficiency equation using the  $\eta$  Formula setting.


► [Click here.](#)

- \* The total efficiency is the ratio of total power consumption—not just the power consumption of the motor but also the power consumption of the converter that supplies the motor with power—to motor output.

The following is an example of how the values are computed.

### When the Motor Input Is Wired to $\Sigma A$


$$\text{Motor efficiency (\%)} = \frac{\text{Motor output } P_m \text{ (W)}}{P_{\Sigma A} \text{ (W)}} \times 100$$



### When the Converter and Motor Inputs Are Wired to $\Sigma A$ and $\Sigma B$ , Respectively

$$\text{Motor efficiency (\%)} = \frac{\text{Motor output } P_m \text{ (W)}}{P_{\Sigma B} \text{ (W)}} \times 100$$


$$\text{Total efficiency (\%)} = \frac{\text{Motor output } P_m \text{ (W)}}{P_{\Sigma A} \text{ (W)}} \times 100$$



### When the Converter and Motor Inputs Are Wired to $\Sigma B$ and $\Sigma A$ , Respectively

$$\text{Motor efficiency (\%)} = \frac{\text{Motor output } P_m \text{ (W)}}{P_{\Sigma A} \text{ (W)}} \times 100$$

$$\text{Total efficiency (\%)} = \frac{\text{Motor output } P_m \text{ (W)}}{P_{\Sigma B} \text{ (W)}} \times 100$$



If  $\Sigma A$  or  $\Sigma B$  is a three-phase, three-wire (3P3W) system, you can use [delta computation](#) to perform 3P3W>3V3A transformation on  $\Sigma A$  and  $\Sigma B$ . From the 3P3W>3V3A transformation, you can determine one unmeasured line voltage and one unmeasured common mode current.

---

## 5 Auxiliary Input Conditions (Option)

### Auxiliary Input Conditions (MOTOR/AUX SET)

You can apply the signals of sensors, such as luminance, wind-power, or temperature sensors, to the AUX1 and AUX2 connectors, and display the physical values measured by the sensors. You can configure the following auxiliary input settings.

- [Input signal name \(Aux Name\)](#)
- [Scaling factor \(Scaling\)](#)
- [Unit \(Unit\)](#)
- [Analog input range](#)
- [Linear scaling of analog input](#)
- [Line filter \(Line Filter\)](#)

### Input Signal Name (Aux Name)

- Number of characters: Up to eight
- Usable characters: Spaces and all characters that are displayed on the keyboard

### Scaling Factor (Scaling)

You can set the factor for scaling the auxiliary input. Set the factor to a value from 0.0001 to 99999.9999. This setting is used as the scaling factor in the equation for the linear scaling of analog input.

### Unit (Unit)

This setting is the same as the input signal name (Aux Name) setting.

► [Click here.](#)

### Analog Input Range

Set the auxiliary input (analog input) range.

#### Turning Auto Range On and Off (Analog Auto Range)

Select whether to turn auto range on or off. When auto range is on, this instrument automatically switches between the following ranges according to the size of the auxiliary input.

20 V, 10 V, 5 V, 2 V, 1 V, 500 mV, 200 mV, 100 mV, and 50 mV

#### Range Increase

- The measurement range is increased when the auxiliary input exceeds 110% of the measurement range.
- The measurement range is increased when the peak value of the auxiliary input exceeds 150% of the measurement range.

#### Range Decrease

The measurement range is decreased when auxiliary input falls below 30% of the measurement range and the peak value of the auxiliary input is less than 125% of the lower range.



---

When non-periodic pulse waveforms are applied during auto range, the range may not remain constant. If this happens, use the fixed range setting.

---

#### Fixed Range (Analog Range)

You can select one of the following input ranges.

20 V, 10 V, 5 V, 2 V, 1 V, 500 mV, 200 mV, 100 mV, and 50 mV



## Linear Scaling of Analog Input

You can set the slope and the offset value of the auxiliary input using one of the following two methods.

- Set the values manually.
- Specify two points, and use those points to compute the values

### Manually Setting the Auxiliary Input Slope and Offset (Linear Scale A, B)

You can set the slope (A) and offset (B) of the auxiliary input to values within the following ranges.

A: 1.000 m to 1.000 M

B: -1.000 M to 1.000 M

The following equation is used to compute measured values of the auxiliary input.

Auxiliary input measured value =  $S(AX + B) - \text{NULL}$

S: The scaling factor

A: The auxiliary input slope

X: The input voltage of the auxiliary input

B: The offset

NULL: The [NULL value](#)

### When There Is No Offset in the Auxiliary Input Voltage

If you set A to 1 and B to 0, the linear scaling settings do not affect computation, and the previous equation becomes:

Auxiliary input measured value =  $SX - \text{NULL}$

You can scale the auxiliary input by setting the scaling factor to the number of units per 1 V.

### When There Is Offset in the Auxiliary Input Voltage

If you set S to 1, the scaling factor does not affect the computation, and the previous equation becomes:

Auxiliary input measured value =  $AX + B - \text{NULL}$

You can scale the auxiliary input by setting the offset value (B) and setting the auxiliary input slope (A) to the number of units per 1 V.



If you enable the NULL function and then change the auxiliary input slope (A) or offset value (B), NULL correction will be offset. Reset the NULL value.


## Computing the Auxiliary Input Slope and Offset by Specifying Two Points (Calculation)

On the input characteristic graph of the external input signal, you can specify two measured unit values (Point1Y and Point2Y) in relation to two input voltage values (Point1X and Point2X). Select Execute to use these four values to determine and set the auxiliary input slope (A) and offset (B).

Measured values (Point1X and Point2X): -1.000 T to 1.000 T

Computed values (Point1Y and Point2Y): -1.000 T to 1.000 T

Select Execute to use these four values to determine and set the auxiliary input slope (A) and offset (B).



## **Line Filter (Line Filter)**

You can remove high-frequency noise by inserting a line filter into the circuit used to measure the Aux1 and Aux2 auxiliary inputs.

You can select the cutoff frequency from the following options.

OFF, 100 Hz, and 1 kHz

Selecting OFF disables the filter.

---

## 6 Holding Measured Values and Performing Single Measurements

### Holding Measured Values (HOLD)

The hold operation stops data measurement and display operations for each data update interval and holds the display of all measurement function data. The D/A output values, the values in the data lists printed by the built-in printer, and the communication values all reflect the held values.



---

During integration and high speed data capturing, the display is held, but measurement continues without stopping.

For information about how holding works during integration, see the sections on holding and releasing integration.

▶ [Click here.](#)

---

### Single Measurement (SINGLE)

- When the data update interval is not Auto, While the display is held, the signal is measured once at the data update interval, and then the display is re-held. If you press SINGLE when the display is not held, measurement restarts from that point.
- When the data update interval is set to Auto, single measurement is not possible.

### Using an External Signal to Hold Measured Values and Perform Single Measurements (Option)

On models with the 20-channel D/A output option, you can use the remote control feature to hold measured values and perform single measurements. For details about the remote control feature, see appendix 4.6 in the getting started guide, IM WT1801E-03EN.

---

## 7 Numeric Data Display

### Numeric Data Display (NUMERIC)

You can press NUMERIC to make the numeric data display appear.

Each time you press NUMERIC the display format switches in order between 4 Items, 8 Items, 16 Items, Matrix, All Items, Hrm List Single, Hrm List Dual, and Custom.

### Display Format (FORM)

The display format options vary depending on the current display.

- [Numeric data display format](#)
- [Waveform display format](#)
- [Trend display format](#)
- [Bar graph display format](#)
- [Vector display format](#)
- [Setup parameter list display format](#)
- [High speed data capturing settings](#)

### Numeric Data Display Format

You can select the number of numeric data items that are displayed simultaneously from the choices below or choose to display a list of items.

#### 4-Value Display (4 Items)

Four numeric data values are displayed in one column.

#### 8-Value Display (8 Items)

- When the display mode is Numeric, eight numeric data values are displayed in one column.
- When the display is split, eight numeric data values are displayed in two columns.

#### 16-Value Display (16 Items)

Sixteen numeric data values are displayed in two columns.

#### Matrix (Matrix) and All (All Items) Displays

A table of numeric data is displayed with measurement functions listed vertically and symbols indicating elements and wiring units listed horizontally. The number of displayed items varies depending on the number of elements that are installed in this instrument.

**Single Harmonics List Display (Hrm List Single; option)**

- When the display mode is Numeric, up to 42 of the harmonic order data items of a single measurement function are displayed in two columns.
- When the display is split, up to 22 of the harmonic order data items of a single measurement function are displayed in two columns.

**Measurement function display area**  
(Data concerning all harmonics)

**Harmonic order data display area**

**Measurement functions**

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

**Numeric data for each harmonic**

**Distortion factors of each harmonic**  
(When the selected measurement function is U, I, or P, Uhdf, Ihdf, or Phdf is displayed.)

**Dual Harmonics List Display (Hrm List Dual; option)**

- When the display mode is Numeric, the numeric values of two measurement functions are displayed in two separate columns, each containing up to 22 numeric values.
- When the display is split, the numeric values of two measurement function are displayed in two separate columns, each containing up to 12 numeric values.

**Measurement function display area**  
(Data concerning all harmonics)

**Harmonic order data display area**

**Measurement function 1**

**Measurement function 2**


rPLL1:U1 49.985 Hz rPLL2:U1 49.985 Hz  Urms1 1.729 V Irms1 1.729 A P1 4074.00 W S1 1.66 VA Q1 -0.20 var A1 Error φ1 Error  Uthd1 12.028 % Ithd1 0.443 % Pthd1 0.008 % Uthf1 1.283 % Ithf1 0.605 % Uthf1 45.181 Ithf1 28.708 hvf1 6.676 % hcf1 0.090 % Kfact1 1.0730 PAGE 1/11	<table> <tr> <th>Order</th><th>U1 [V]</th><th>hdf[%]</th></tr> <tr><td>Total</td><td>1.729</td><td></td></tr> <tr><td>1</td><td>1.717</td><td>99.274</td></tr> <tr><td>3</td><td>0.191</td><td>11.027</td></tr> <tr><td>5</td><td>0.069</td><td>3.973</td></tr> <tr><td>7</td><td>0.035</td><td>2.038</td></tr> <tr><td>9</td><td>0.021</td><td>1.231</td></tr> <tr><td>11</td><td>0.014</td><td>0.794</td></tr> <tr><td>13</td><td>0.010</td><td>0.536</td></tr> <tr><td>15</td><td>0.008</td><td>0.467</td></tr> <tr><td>17</td><td>0.006</td><td>0.340</td></tr> <tr><td>19</td><td>0.005</td><td>0.266</td></tr> <tr><td>21</td><td>0.004</td><td>0.236</td></tr> <tr><td>23</td><td>0.003</td><td>0.183</td></tr> <tr><td>25</td><td>0.003</td><td>0.166</td></tr> <tr><td>27</td><td>0.002</td><td>0.116</td></tr> <tr><td>29</td><td>0.002</td><td>0.120</td></tr> <tr><td>31</td><td>0.001</td><td>0.078</td></tr> <tr><td>33</td><td>0.002</td><td>0.094</td></tr> <tr><td>35</td><td>0.001</td><td>0.082</td></tr> <tr><td>37</td><td>0.001</td><td>0.072</td></tr> <tr><td>39</td><td>0.001</td><td>0.063</td></tr> </table>	Order	U1 [V]	hdf[%]	Total	1.729		1	1.717	99.274	3	0.191	11.027	5	0.069	3.973	7	0.035	2.038	9	0.021	1.231	11	0.014	0.794	13	0.010	0.536	15	0.008	0.467	17	0.006	0.340	19	0.005	0.266	21	0.004	0.236	23	0.003	0.183	25	0.003	0.166	27	0.002	0.116	29	0.002	0.120	31	0.001	0.078	33	0.002	0.094	35	0.001	0.082	37	0.001	0.072	39	0.001	0.063	<table> <tr> <th>Order</th><th>U1 [V]</th><th>hdf[%]</th></tr> <tr><td>Total</td><td></td><td></td></tr> <tr><td>2</td><td>0.000</td><td>0.008</td></tr> <tr><td>4</td><td>0.000</td><td>0.020</td></tr> <tr><td>6</td><td>0.000</td><td>0.018</td></tr> <tr><td>8</td><td>0.000</td><td>0.016</td></tr> <tr><td>10</td><td>0.000</td><td>0.017</td></tr> <tr><td>12</td><td>0.000</td><td>0.012</td></tr> <tr><td>14</td><td>0.000</td><td>0.004</td></tr> <tr><td>16</td><td>0.000</td><td>0.022</td></tr> <tr><td>18</td><td>0.000</td><td>0.010</td></tr> <tr><td>20</td><td>0.000</td><td>0.023</td></tr> <tr><td>22</td><td>0.000</td><td>0.016</td></tr> <tr><td>24</td><td>0.000</td><td>0.006</td></tr> <tr><td>26</td><td>0.000</td><td>0.022</td></tr> <tr><td>28</td><td>0.000</td><td>0.019</td></tr> <tr><td>30</td><td>0.000</td><td>0.009</td></tr> <tr><td>32</td><td>0.000</td><td>0.016</td></tr> <tr><td>34</td><td>0.000</td><td>0.008</td></tr> <tr><td>36</td><td>0.000</td><td>0.017</td></tr> <tr><td>38</td><td>0.000</td><td>0.002</td></tr> <tr><td>40</td><td>0.000</td><td>0.018</td></tr> </table>	Order	U1 [V]	hdf[%]	Total			2	0.000	0.008	4	0.000	0.020	6	0.000	0.018	8	0.000	0.016	10	0.000	0.017	12	0.000	0.012	14	0.000	0.004	16	0.000	0.022	18	0.000	0.010	20	0.000	0.023	22	0.000	0.016	24	0.000	0.006	26	0.000	0.022	28	0.000	0.019	30	0.000	0.009	32	0.000	0.016	34	0.000	0.008	36	0.000	0.017	38	0.000	0.002	40	0.000	0.018
Order	U1 [V]	hdf[%]																																																																																																																																				
Total	1.729																																																																																																																																					
1	1.717	99.274																																																																																																																																				
3	0.191	11.027																																																																																																																																				
5	0.069	3.973																																																																																																																																				
7	0.035	2.038																																																																																																																																				
9	0.021	1.231																																																																																																																																				
11	0.014	0.794																																																																																																																																				
13	0.010	0.536																																																																																																																																				
15	0.008	0.467																																																																																																																																				
17	0.006	0.340																																																																																																																																				
19	0.005	0.266																																																																																																																																				
21	0.004	0.236																																																																																																																																				
23	0.003	0.183																																																																																																																																				
25	0.003	0.166																																																																																																																																				
27	0.002	0.116																																																																																																																																				
29	0.002	0.120																																																																																																																																				
31	0.001	0.078																																																																																																																																				
33	0.002	0.094																																																																																																																																				
35	0.001	0.082																																																																																																																																				
37	0.001	0.072																																																																																																																																				
39	0.001	0.063																																																																																																																																				
Order	U1 [V]	hdf[%]																																																																																																																																				
Total																																																																																																																																						
2	0.000	0.008																																																																																																																																				
4	0.000	0.020																																																																																																																																				
6	0.000	0.018																																																																																																																																				
8	0.000	0.016																																																																																																																																				
10	0.000	0.017																																																																																																																																				
12	0.000	0.012																																																																																																																																				
14	0.000	0.004																																																																																																																																				
16	0.000	0.022																																																																																																																																				
18	0.000	0.010																																																																																																																																				
20	0.000	0.023																																																																																																																																				
22	0.000	0.016																																																																																																																																				
24	0.000	0.006																																																																																																																																				
26	0.000	0.022																																																																																																																																				
28	0.000	0.019																																																																																																																																				
30	0.000	0.009																																																																																																																																				
32	0.000	0.016																																																																																																																																				
34	0.000	0.008																																																																																																																																				
36	0.000	0.017																																																																																																																																				
38	0.000	0.002																																																																																																																																				
40	0.000	0.018																																																																																																																																				

**Numeric data for each harmonic**

**Distortion factors of each harmonic**  
(When the selected measurement function is U, I, or P, Uhdf, Ihdf, or Phdf is displayed.)

### Custom Display (Custom)

You can use an illustration (.BMP) or picture (.BMP) from a PC or other device as the background of the display. You can arrange numeric data boxes on top of this background to create a custom display. Numeric data appears in this custom display.



## Switching the Displayed Page (PAGE UP/PAGE DOWN)

You can switch the displayed page and display a new set of items.

- **PAGE▼:** The next page is displayed.
- **PAGE▲:** The previous page is displayed.

### In the 4-, 8-, and 16-Value Displays

You can switch between and display pages 1 to 12.

### In the Matrix Display

You can switch between and display pages 1 to 9.

### In the All Items Display

The first page is always displayed in the top half of the screen. You can switch between pages 2 and later pages in the bottom half of the screen. When the display is split and the All Items display is shown, you can switch between all pages, including page 1, in order.

### In the Single Harmonics List and Dual Harmonics List Displays

You can switch separately between the pages of the measurement function display (on the left side of the screen) and the harmonic order data display (on the right side of the screen). Use the left and right cursor keys to select the display whose pages you want to switch between.

### In the Custom Display

When you have configured the custom display to contain multiple pages, you can switch between each of the pages.

## Jumping to the First or Last Page (PAGE TOP/PAGE END)

- **▼:** The last page is displayed.
- **▲:** The first page is displayed.

## Number of Displayed Digits (Display Resolution)

The number of displayed digits (display resolution) for voltage, current, active power, apparent power, reactive power, and so on is as follows:

- If the value is less than or equal to 60000: Five digits.
- If the value is greater than 60000: Four digits.

For details, see appendix 4 in the getting started guide, IM WT1801E-03EN. When the range rating (rated value of the specified measurement range) is specified, the  $\Sigma$  functions of the voltage, current, active power, apparent power, reactive power, and so on, are set to the decimal place and unit of the element with the lowest number of displayed digits (display resolution) in the wiring unit. For details about the display resolution during integration, see “Number of Displayed Digits (Display Resolution)” under “Integrated Power (Watt hours).”

► [Click here.](#)

## Display Item (ITEM)

The display item options vary depending on the current display.

- Numeric data display format
  - [4-, 8-, and 16-value displays \(4 Items/8 Items/16Items\)](#)
  - [Matrix display \(Matrix\)](#)
  - [All Items display \(All Items\)](#)
  - [Single Harmonics and Dual Harmonics Lists \(Hrm List Single/Dual; option\)](#)
  - [Custom display \(Custom\)](#)
- [Waveform display items](#)
- [Trend display items](#)
- [Bar graph display items](#)
- [Vector display items](#)
- [High speed data capturing display items](#)

For a list of the measurement functions and their descriptions, see “Items That This Instrument Can Measure.”

► [Click here.](#)

### Example of How Measurement Functions Are Displayed in the Numeric Data Display

True rms voltage of element 1

Urms1  
 — Element 1  
 — True rms value  
 — Voltage

Simple average of the currents of the elements in wiring unit  $\Sigma A$

Idc $\Sigma A$   
 —  $\Sigma$  function of wiring unit  $\Sigma A$   
 — Simple average  
 — Current

Voltage of the 20<sup>th</sup> order of element 2

U2  
(20)  
 — Voltage  
 — Element 2  
 — Harmonic order 20

Simple average of the fundamental currents of the elements in wiring unit  $\Sigma B$

I $\Sigma B$   
(1)  
 — Current  
 —  $\Sigma$  function of wiring unit  $\Sigma B$   
 — Order 1 (fundamental wave)

### Notes about the Numeric Data Display

- “-----” is displayed if a measurement function is not selected or if there is no numeric data.
- If Urms, Umn, Udc, Urmn, Uac, Irms, Imn, Idc, Irmn, or Iac exceeds 140% of the measurement range, “-OL-” is displayed to indicate an overload value.
- If the voltage or current exceeds 140% of the measurement range, “-OL-” is displayed to indicate an overload value for P.
- If the measured or computed result cannot be displayed using the specified decimal place or unit, “-OF-” (for overflow) is displayed.
- If rounding to zero is on, when the voltage or current measurement meets the following conditions relative to the measurement range, Urms, Umn, Urmn, Irms, Imn, Irmn, and other measurement functions based on these measurement functions are displayed as zero. The  $\lambda$  and  $\Phi$  functions will return errors (“Error” is displayed).
  - When the Crest Factor Is Set to CF3  
When Urms, Uac, Irms, or Iac is 0.3% or less When Umn, Urmn, Imn, or Irmn is 2% or less
  - When the Crest Factor Is Set to CF6 or CF6A  
When Urms, Uac, Irms, or Iac is 0.6% or less When Umn, Urmn, Imn, or Irmn is 4% or less
- When the data update interval is not Auto, if the analysis window width (number of cycles of the fundamental signal) that is determined by the fundamental frequency is shorter than the data update interval, harmonic data is not measured, and “-----” (no data) is displayed. If this happens, increase the data update interval. For example, if the data update interval is 50 ms and the fundamental frequency is 10 Hz (the period is 100 ms), the analysis window will be 1 wave wide (see section 6.6 in the getting started guide, IM WT1801E-03EN), and the data measurement interval will be 100 ms. In this case, the time required for harmonic measurement is approximately 150 ms or greater (data measurement interval + data processing time). To measure and display harmonic data, set the data update interval to a value greater than or equal to 200 ms.
- When the data update interval is Auto, fPLL2, WS, and WQ are not measured and displayed as “-----” (no data).
- There is no overload value indication (“-OL-”) or zero indication (rounding to zero) for the numeric data of harmonic orders 0 (DC) to 500.
- If the measured frequency is outside the measurement range, the fU or fI function returns an error (“Error” is displayed).
- If  $\lambda$  is greater than 1 or less than -1,  $\lambda$  and  $\Phi$  are displayed as follows.

	$\lambda$	$\Phi$
$1 < \lambda \leq 2$	1	0.0
$-2 \leq \lambda < -1$	-1	180.0
$\lambda < -2$ or $2 < \lambda$	Error	Error

## 4-, 8-, and 16-Value Displays (4 Items/8 Items/16Items)

### Item Number to Set (Item No.)

Select the number of the item that you want to configure.

### Function (Function)

You can select any of the measurement function types listed under “Items That This Instrument Can Measure.”

► [Click here.](#)

If you select None, no measurement function is displayed for the selected item.

### Direct Function Selection (U/I/P, S/Q/ $\lambda$ / $\Phi$ , WP/q/TIME, FU/FI/ $\eta$ , and U/I MODE)

When the menu is not displayed, you can change which of the selected measurement functions is displayed using the function select keys (U/I/P, S/Q/ $\lambda$ / $\Phi$ , WP/q/TIME, FU/FI/ $\eta$ , and U/I MODE).

#### U/I/P, S/Q/ $\lambda$ / $\Phi$ , WP/q/TIME, and FU/FI/ $\eta$

Each time you press U/I/P, the selected function switches in order between U, I, and P. The same is true for S/Q/ $\lambda$ / $\Phi$ , WP/q/TIME, and FU/FI/ $\eta$ .



### U/I MODE

Each time you press the key, measurement function U or I switches in order between rms, mean, dc, rmean, and ac.

### Element (Element/ $\Sigma$ )

- You can select the element/wiring unit from the options below. The available options vary depending on the installed elements.  
Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$
- If the selected wiring unit does not have any elements assigned to it, because there is no data, “-----” (no data) is displayed. For example, if elements are assigned to  $\Sigma A$  but not to  $\Sigma B$ , the measurement function for  $\Sigma B$  is displayed as “-----” (no data).

### Directly Selecting Elements (ELEMENT)

When the menu is not displayed, you can change the element number of the selected measurement function by pressing ELEMENT.

### Changing Elements Simultaneously (ALL)

You can change the elements and wiring units of all displayed items at once. The ALL indicator illuminates.

### Order (Order; option)

When you select a function that has harmonic data, you can set the displayed harmonic order within the following range.

Total (Total value) or 0 (dc) to 500

The orders that can be specified vary depending on the measurement function. For details, see “Harmonic Measurement Function Orders.”

► [Click here.](#)

The numeric data corresponding to harmonic orders above the maximum measurable harmonic order is displayed as “-----” (no data). For information about the maximum measurable harmonic order, see “Maximum Harmonic Order to Be Measured (Max Order).”

► [Click here.](#)

### Resetting the Display Items (Reset Items)

#### Reset Patterns (Reset Pattern)

You can select the reset method from the following options.

- Element Origin: The numeric data for each element is displayed on each page. The pattern that the data is arranged in varies depending on the number of installed elements.
- Function Origin: The numeric data for each function is displayed on each page. The pattern that the data is arranged in varies depending on the number of installed elements.
- Clear Current Page: All the display items on the current page are set to None.
- Clear All Pages: All the display items on every page are set to None.

#### Resetting the Items (Reset Items Exec)

Reset the items.

### Turning the Display Frame On and Off (Display Frame)

Set whether to show the display frame.

## Matrix display (Matrix)

### Item Number to Set (Item No.)

This is the same as setting the item number in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

### Function (Function)

This is the same as setting the function in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)




---

In the matrix display, if you choose a measurement function that does not require an element or wiring unit (such as  $\eta 1$  to  $\eta 4$ , F1 to F20, Ev1 to Ev8, etc.), data is displayed in the first column.

---

### Direct Function Selection (U/I/P, S/Q/ $\lambda$ / $\Phi$ , WP/q/TIME, FU/FI/ $\eta$ , and U/I MODE)

This is the same as direct function selection in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

### Order (Order; option)

This is the same as setting the order in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

### Resetting the Display Items (Reset Items)

This is the same as resetting the display items in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

## Columns (Column Settings)

### Number of Columns (Column Num)

You can set the number of columns to 4 or 6.

### Column Number (Column No.)

Select the number of the column that you want to configure.

### Element (Element/ $\Sigma$ )

- You can select the element/wiring unit from the options below. The available options vary depending on the installed elements.  
None, Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$
- If you select None, no measurement data is displayed in the selected column.
- If the selected wiring unit does not have any elements assigned to it, because there is no data, “-----” (no data) is displayed. For example, if elements are assigned to  $\Sigma A$  but not to  $\Sigma B$ , the measurement function for  $\Sigma B$  is displayed as “-----” (no data).

### Directly Selecting Elements (ELEMENT)

This is the same as direct element selection in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

### Resetting the Settings (Reset Items Exec)

Reset the column settings.

### Turning the Display Frame On and Off (Display Frame)

This is the same as turning the display frame on and off in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

## All Items Display (All Items)

You cannot change individual measurement functions. Change the display by pressing PAGE UP and PAGE DOWN or the up and down cursor keys.

The number of displayed pages varies as indicated below depending on the installed options.

Harmonic Measurement Option or Simultaneous Dual Harmonic Measurement Option	
Installed	Not installed
12 pages	8 pages

### Order (Order (k); option)

This setting is valid on the 9<sup>th</sup> or 10<sup>th</sup> page. On the 9<sup>th</sup> or 10<sup>th</sup> page, the order setting appears in the upper left of the screen. This is the same as setting the order in the 4-, 8-, and 16-value displays.

► [Click here.](#)

### Turning the Display of the Numeric Data for All Elements and Wiring Units On and Off (Display All Elements)

- OFF

The numeric data is displayed in six columns. If there is a total of seven or more elements and wiring units, you can change the displayed elements and wiring units by pressing the left and right cursor keys.

- ON

When there is a total of 7 or more elements and wiring units, all the numeric data for the elements and wiring units is displayed in nine columns. If you select ON when the total number of elements and wiring units is six or less, the display is the same as when OFF is selected.

### Turning the Display Frame On and Off (Display Frame)

This is the same as turning the display frame on and off in the 4-, 8-, and 16-value displays.

► [Click here.](#)

## Single Harmonics and Dual Harmonics Lists (Hrm List Single/Dual; option)

For each measurement function, you can display the numeric data for a harmonic order from 0 (DC) to 500 or for all harmonic orders in two columns.

This item is available on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

### Item Number to Set (List Item No.)

- You can specify two lists to show in the harmonic order data display area (the right side of the screen). Select the number—1 or 2—of the list that you want to select.
  - When Hrm List Single is selected, the data of List Item No1 is listed in two columns.
  - When Hrm List Dual is selected, the data of List Item No1 is listed in one column, and the data of List ItemNo2 is listed in another column.
- You cannot change individual items in the measurement function display area (the left side of the screen). Change the display by pressing PAGE UP and PAGE DOWN or the up and down cursor keys.

### Function (Function)

Select the measurement function to show in the harmonic order data display area from the following options.

U, I, P, S, Q,  $\lambda$ ,  $\Phi$ ,  $\Phi U$ ,  $\Phi I$ , Z, Rs, Xs, Rp, and Xp

### Direct Function Selection (U/I/P, S/Q/ $\lambda$ / $\Phi$ , WP/q/TIME, FU/FI/ $\eta$ , and U/I MODE)

Directly select the measurement function to show in the harmonic order data display area. This is the same as [direct function selection](#) in the 4-, 8-, and 16-value displays.

However, when you are displaying the single harmonics or dual harmonics list, you can only select measurement functions that have harmonic order data. You can press U/I/P to select U, I, or P. You can press S/Q/ $\lambda$ / $\Phi$  to select S, Q,  $\lambda$ ,  $\Phi$ ,  $\Phi U$ , or  $\Phi I$ . WP/q/TIME, FU/FI/ $\eta$ , and U/I MODE are invalid.

### Element (Element/ $\Sigma$ )

You can select the element or wiring unit to display in the harmonic order data display area. This is the same as setting the element in the 4-, 8-, and 16-value displays.

► [Click here.](#)

### Directly Selecting Elements (ELEMENT)

You can select the element or wiring unit to display in the harmonic order data display area. This is the same as direct element selection in the 4-, 8-, and 16-value displays.

► [Click here.](#)

### Order

The Total value and 0 (DC) order numeric data is always displayed at the top of the harmonic order data display area. To switch between the displays of the numeric data for harmonic orders 1 to 500, press PAGE UP and PAGE DOWN or use the up and down cursor keys.

The number of harmonic orders that switch when you change the page is indicated below.

	Normal display (1 screen)	Split display
Hrm List Single	40 orders	20 orders
Hrm List Dual	20 orders	10 orders

### Turning the Display Frame On and Off (Display Frame)

This is the same as turning the display frame on and off in the 4-, 8-, and 16-value displays.

► [Click here.](#)

## Custom Display (Custom)

### Loading a Display Configuration File (Load Items)

On the file list, specify a file to load display configuration data from. The extension is .TXT.

For information about how to configure the file list display and how to operate files and folders, see “File Operations (Utility).”

► [Click here.](#)

### Loading a Background File (Load Bmp)

On the file list, specify a background file to load. The extension is .BMP.

If you use a commercial graphics program to create an image that meets the following specifications, you can load the image to this instrument.

- File format: BMP
- Resolution: 800 × 672 pixels
- Color scale: 16-bit high color (R: 5 bits, G: 6 bits, B: 5 bits) or 24-bit true color (R: 8 bits, G: 8 bits, B: 8 bits)
- Size: Approx. 1 MB (16 bit) or approx. 1.6 MB (24 bit)

► [Click here.](#)



- If you attempt to load an image that does not meet the above specifications, the image will not be displayed properly, or an error message will appear and you will not be able to load the image.
  - After you properly load a display configuration file and a background file, if you restart this instrument and the same background file is not in the same location, the background will return to its default.
- 

### Simultaneously Loading a Display Configuration File and a Background File (Load Items & Bmp)

When you select a display configuration file (.TXT) from the file list and load it, if there is a background file with a .BMP extension and the same name as the display configuration file, that file is also loaded.

► [Click here.](#)



If there is no background file with the same name as the display configuration file in the same directory as the display configuration file, an error occurs.

---

## Display Configuration (Edit Items)

### Total Number of Items (Total Items)

You can set the total number of numeric data boxes to display to a number from 1 to 192.\*

### Number of Items per Page (Items Per Page)

You can set the total number of numeric data boxes to display per page to a number from 1 to 192.\*

The total number of pages is Total Items/Items Per Page.

\* The ranges of Total Items and Items Per Page are related as indicated below.

- Total Items: Items Per Page to Items Per Page × 12
- Items Per Page: Total Items/12 to Total Items

### Customizing the Displayed Items (Custom Items)

- **Item Number to Set (Item No.)**

Select the number of the item that you want to configure.

- **Function (Function)**

This is the same as setting the function in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

If you select None, you can display a character string in the numeric data box. Select the [String](#) menu item to enter the string.

- **Element (Element/ $\Sigma$ )**

This setting is valid when Function is not set to None. This is the same as setting the element in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

- **Order (Order; option)**

This is the same as setting the order in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

If you set Function to None, instead of the Order menu item, a menu item for entering a string (String) appears.

- **String (String)**

This menu item appears when you set Function to None. Enter the character string to display in the numeric data box. You can enter a string of up to 15 characters in length.

If you do not set Function to None, instead of the String menu item, the Order menu item appears.

- **X Display Position (X Pos)**

Set the position where the left edge of the numeric data box will appear on the screen to a value from 0 (the left edge of the screen) to 800 (the right edge of the screen).

- **Y Display Position (Y Pos)**

Set the position where the top edge of the numeric data box will appear on the screen to a value from 0 (the top of the screen) to 671 (the bottom of the screen).

- **Font Size (Font Size)**

Select the font size from the options below.

14, 16, 20, 24, 32, 48, 64, 96, and 128

- **Font Color (Font Color)**

Select the font color from the options below.

Yellow, Green, Magenta, Cyan, Red, Orange, Light Blue, Purple, Blue, Pink, Light Green, Dark Blue, Blue Green, Salmon Pink, Mid Green, Gray, White, Dark Gray, Blue Gray, and Black

### **Saving the Display Configuration (Save Custom Items)**

You can save the display configuration that you have created to the specified storage medium. The extension is .TXT.

- **Displaying a File List and Specifying the Save Destination (File List)**

On the file list, specify the save destination. For information about how to configure the file list display and how to operate files and folders, see “File Operations (Utility).”

▶ [Click here.](#)

- **Automatic File Naming (Auto Naming)**

This is the same as the auto naming feature for saving and loading data.

▶ [Click here.](#)

- **File Name (File Name)**

This is the same as file name setting for saving and loading data.

▶ [Click here.](#)

- **Saving (Save Exec)**

Saves the display configuration.



- Note that if there is a file with the same name in the save destination, it will be overwritten without warning.
  - File names are not case sensitive.
- 

### **Turning the Display Frame On and Off (Display Frame)**

This is the same as turning the display frame on and off in the 4-, 8-, and 16-value displays.

▶ [Click here.](#)

---

## 8 Computation

### Computation (MEASURE)

You can set the following items.

- [User-defined functions \(User Defined Function\)](#)
- [Measuring the Average Active Power](#)
- [MAX hold \(Max Hold\)](#)
- [User-defined events \(User Defined Event\)](#)
- [Apparent power, reactive power, and corrected power equations \(Formula\)](#)
- [Sampling frequency \(Sampling Frequency\)](#)
- [Phase difference display format \(Phase\)](#)
- [Master/slave synchronization measurement \(Sync Measure\)](#)
- [Voltages or currents whose frequencies will be measured \(FREQ MEASURE\)](#)

### User-Defined Functions (User Defined Function)

You can combine function symbols to create equations and use the numeric data of the combined functions to determine the value of the equation. It is convenient to use a USB keyboard when entering multiple equations or particularly long equations.



---

User-defined functions allow you to determine physical values other than those of the measurement functions by combining operands. The measurement functions that you can specify for the [efficiency equation](#) are fixed at power and motor output. However, by using user-defined functions, you can create equations consisting of measurement functions other than power and motor output measurement functions to determine ratios other than efficiency.

---

#### Selecting Which User-Defined Function to Configure

Select the number of the user-defined function that you want to configure from the options below.

- User Defined F01 to F05: User-defined functions F1 to F5
- User Defined F06 to F10: User-defined functions F6 to F10
- User Defined F11 to F15: User-defined functions F11 to F15
- User Defined F16 to F20: User-defined functions F16 to F20

#### Turning the Computation of a User-Defined Function On or Off

Selecting Whether to Compute a User-Defined Function

#### User-Defined Function Name (Name)

- Number of characters: Up to eight
- Usable characters: Spaces and all characters that are displayed on the keyboard

#### Unit (Unit)

- Number of characters: Up to eight
- Usable characters: Spaces and all characters that are displayed on the keyboard



## Expression (Expression)

### Operation Type

You can use combinations of measurement functions and element numbers (e.g., Urms1) as operands to configure up to 20 equations (F1 to F20). There can be up to 16 operands in 1 equation.

The different types of operands are listed below (measurement function: operand).

#### • Normal Measurement

Voltage, current, and power

Urms: URMS( )	Irms: IRMS( )	P: P( )
Umn: UMN( )	Imn: IMN( )	S: S( )
Udc: UDC( )	Idc: IDC( )	Q: Q( )
Urmn: URMN( )	Irmn: IRMN( )	$\lambda$ : LAMBDA( )
Uac: UAC( )	Iac: IAC( )	$\Phi$ : PHI( )
U+pk: UPPK( )	I+pk: IPPK( )	Pc: PC( )
U-pk: UMPK( )	I-pk: IMPK( )	P+pk: PPPK( )
CfU: CFU( )	CfI: CFI( )	P-pk: PMPK( )
fU: FU( )	fI: FI( )	—

Integrated power

Wp: WH( )	q: AH( )	Time: TI( )
Wp+: WHP( )	q+: AHP( )	WS: SH( )
Wp-: WHM( )	q-: AHM( )	WQ: QH( )

Efficiency

$\eta$ 1: ETA1( ) to  $\eta$ 4: ETA4( )

User-defined functions

F1: F1( ) to F20: F20( )

User-defined events

Ev1: EV1( ) to Ev8: EV8( )

#### • Harmonic Measurement (Option)

U(k): UK( , )	I(k): IK( , )	P(k): PK( , )
S(k): SK( , )	Q(k): QK( , )	$\lambda$ (k): LAMBDK( , )
$\Phi$ U(k): UPHI( , )	$\Phi$ I(k): IPHI( , )	$\Phi$ (k): PHIK( , )
Z(k): ZK( , )	Rs(k): RSK( , )	Xs(k): XSK( , )
—	Rp(k): RPK( , )	Xp(k): XPK( , )
Uhdf(k): UHDF( , )	Ihdf(k): IHDF( , )	Phdf(k): PHDF( , )
Uthd: UTHD( )	Ithd: ITHD( )	Pthd: PTHD( )
Uthf: UTHF( )	Ithf: ITHF( )	—
Utif: UTIF( )	Itif: ITIF( )	—
hvf: HVF( )	hcf: HCF( )	—
fPLL1: PLLFRQ1( )	fPLL2: PLLFRQ2( )	Kfactor: KFACT( )
$\Phi$ U1-U2: PHIU1U2( )	$\Phi$ U1-U3: PHIU1U3( )	$\Phi$ U1-I1: PHIU1I1( )
$\Phi$ U2-I2: PHIU2I2( )	$\Phi$ U3-I3: PHIU3I3( )	—

### • Delta Computation

$\Delta U1( )$ : DELTAU1( )	$\Delta I( )$ : DELTAI( )	$\Delta P1( )$ : DELTAP1( )
$\Delta U2( )$ : DELTAU2( )	—	$\Delta P2( )$ : DELTAP2( )
$\Delta U3( )$ : DELTAU3( )	—	$\Delta P3( )$ : DELTAP3( )
$\Delta U\Sigma( )$ : DELTAUSIG( )	—	$\Delta P\Sigma( )$ : DELTAPSIG( )
$\Delta U1rms( )$ : DELTAU1RMS( )	$\Delta U1mean( )$ : DELTAU1MN( )	$\Delta U1rmean( )$ : DELTAU1RMN( )
$\Delta U2rms( )$ : DELTAU2RMS( )	$\Delta U2mean( )$ : DELTAU2MN( )	$\Delta U2rmean( )$ : DELTAU2RMN( )
$\Delta U3rms( )$ : DELTAU3RMS( )	$\Delta U3mean( )$ : DELTAU3MN( )	$\Delta U3rmean( )$ : DELTAU3RMN( )
$\Delta U\Sigma rms( )$ : DELTAUSIGRMS( )	$\Delta U\Sigma mean( )$ : DELTAUSIGMN( )	$\Delta U\Sigma rmean( )$ : DELTAUSIGRMN( )
$\Delta U1dc( )$ : DELTAU1DC( )	$\Delta U1ac( )$ : DELTAU1AC( )	$\Delta Irms( )$ : DELTALRMS( )
$\Delta U2dc( )$ : DELTAU2DC( )	$\Delta U2ac( )$ : DELTAU2AC( )	$\Delta Imean( )$ : DELTAIMN( )
$\Delta U3dc( )$ : DELTAU3DC( )	$\Delta U3ac( )$ : DELTAU3AC( )	$\Delta Irmean( )$ : DELTAIRMN( )
$\Delta U\Sigma dc( )$ : DELTAUSIGDC( )	$\Delta U\Sigma ac( )$ : DELTAUSIGAC( )	$\Delta Idc( )$ : DELTAIDC( )
—	—	$\Delta Iac( )$ : DELTAIAC( )

### • Motor Evaluation (Option)

Speed: SPEED( )	Torque: TORQUE( )	Pm: PM( )
Slip: SLIP( )	SyncSp: SYNC( )	EaU: EAU( )
Eal: EAI( )	—	—

### • Auxiliary Input (Option)

Aux1: AUX1( )	Aux2: AUX2( )
---------------	---------------

### Setting Operand Parameters

The parameters that you need to enter depend on whether the function is followed by “( , )” or “( )”.

#### • Setting Parameters for Functions Followed by “( , )”

Specify the element to the left of the comma, and specify the harmonic order to the right of the comma. For example: (E1,OR2).

- Symbols used to represent elements
  - E1 to E6: Elements 1 to 6
  - E7 to E9: Wiring units  $\Sigma A$  to  $\Sigma C$
- Symbols that indicate the harmonic order (Order)\*
  - ORT: Total value
  - OR0: dc
  - OR1: Fundamental wave
  - OR2 to OR500: Harmonic orders 2 to 500

\* On models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

#### • Setting Parameters for Functions Followed by “( )”

Specify the element. You do not need to specify a harmonic order. For example: (E1).

For information about the parameters that you can use with each operand, see appendix 6 in the getting started guide, IM WT1801E-03EN.

**Values Substituted in Operands**

- The unit of TI values is seconds.
- $\eta_1$  to  $\eta_4$  are displayed as percentages (see in appendix 1 in the getting started guide, IM WT1801E-03EN). However, in this section ETA1 to ETA4 are described as ratios.  
Example When  $\eta_1$  is 80%, ETA1 is 0.8
- The U1 in PHIU1U2 represents the voltage signal of the element whose element number is the smallest in the wiring unit ( $\Sigma A$ ,  $\Sigma B$ , or  $\Sigma C$ ). For example, if input elements 2, 3, and 4 are assigned to wiring unit  $\Sigma A$ , PHIU1U2 is the phase difference between the voltage signals of input elements 2 and 3.
- User-defined equations can use other user-defined equations with smaller numbers as operands. For example, the equation for user-defined function F3 can be set to  $F1( ) + F2( )$ . This allows equations that would otherwise exceed 50 characters in length to be computed. This can be accomplished by for example setting equations in F1 and F2, and then adding or dividing those equations in F3. This feature is also convenient when defining multiple equations that include common operands. For example, you can set common operands in F1, and then set F4 as  $F3( )$  divided by  $F1( )$  and set F5 as  $F4( )$  divided by  $F1( )$ . However, if you enter a user-defined equation with a number that is greater than or equal to its own number, correct results will not be obtained. For example, if you set user-defined function F3 to  $F1( ) + F3( )$  or to  $F1( ) + F4( )$ , the computed result will be displayed as "-----" (no data) or "-OF-" (overflow).


**Operators**

The following operators can be used in equations.

Operator	Example	Description
+, -, *, /	$U(E1, OR1) - U(E2, OR1)$	Basic arithmetic
ABS	$ABS(P(E1, ORT) + P(E2, ORT))$	Absolute value
SQR	$SQR(I(E1, OR0))$	Square
SQRT	$SQRT(ABS(I(E1, OR3)))$	Square root
LOG	$LOG(U(E1, OR25))$	Natural logarithm
LOG10	$LOG10(U(E1, OR25))$	Common logarithm
EXP	$EXP(U(E1, OR12))$	Exponent
NEG	$NEG(U(E1, OR12))$	Negation

**Number and Type of Characters That Can Be Used in Equations**

- Number of characters: Up to 50
- Usable characters: Spaces and all characters that are displayed on the keyboard

On the keyboard, press  to enter operand and equation characters. The characters that you can select are indicated below.

ABS(	PPK(	HVF(	RMS(
SQR(	MPK(	HCF(	MN(
SQRT(	CF	KFACT(	RMN(
LOG(	TI(	EAU(	DC(
LOG10(	THD(	EAI(	AC(
EXP(	THF(	PLLFRQ(	PC(
NEG(	TIF(	—	—

**Equation Examples**

An equation to determine the rms value of the harmonic components of the voltage signal of input element 2.

$$\sqrt{(\text{Total rms voltage value})^2 - (\text{Rms value of the fundamental voltage signal})^2}$$

$$SQRT(SQR(U(E2, ORT)) - SQR(U(E2, OR1)))$$



If an operand in an equation is undetermined, the computed result is displayed as “-----” (no data). This occurs when a delta computation measurement function is in the equation, but delta computation is turned OFF, or when a measurement function of an element that is not installed is in the equation.

## Measuring the Average Active Power

The average active power can be computed for devices, such as intermittent control devices, whose power fluctuates. Use a user-defined function to specify the equation for computing the average active power.

$$\text{Average active power} = \frac{\text{Integrated power}}{\text{Elapsed integration time}}$$

Use the equation above. For example, to determine the average active power of element 1, set the equation of a user-defined function as follows:

$$\text{WH(E1)}/(\text{TI(E1)}/3600)$$

The unit of TI values is seconds.

## MAX Hold (Max Hold)

Selecting Whether to Hold the Maximum Numeric Value (MAX value) You can determine the measurement functions whose maximum values will be held using a user-defined function. The different types of operands are listed below (measurement function: operand).

Urms: URMSMAX( )	Irms: IRMSMAX( )	P: PMAX( )
Umn: UMEANMAX( )	Imn: IMEANMAX( )	S: SMAX( )
Udc: UDCMAX( )	Idc: IDCMA( )	Q: QMAX( )
Urmn: URMEANMAX( )	Irnm: IRMEANMAX( )	—
Uac: UACMAX( )	Iac: IACMAX( )	—
U+pk: UPPEAKMAX( )	I+pk: IPPEAKMAX( )	P+pk: PPPEAKMAX( )
U-pk: UMPEAKMAX( )	I-pk: IMPEAKMAX( )	P-pk: PMPEAKMAX( )

To hold the maximum value of the Urms for element 1, enter URMSMAX(E1) in the equation for a user-defined function, and enable MAX hold.

- For information about the parameters that you can use with each operand, see appendix 6 in the getting started guide, IM WT1801E-03EN.
- The maximum values of the data above are held while the MAX hold function is enabled.
- The D/A output values, the values in the data lists printed by the built-in printer, and the communication values all reflect the held maximum values.



- When MAX hold is applied to measurement functions that have positive and negative values, this instrument compares the absolute values to determine the maximum value.
- To reset held maximum values, turn MAX hold off, and then turn it on again.

## User-Defined Events (User Defined Event)

User-defined events can be used to trigger data storage and automatic printing (option). You can define up to eight user-defined events.

### User-Defined Event Number (Event No.)

Select a user-defined event number from 1 to 8.

### Turning User-Defined Events On and Off

Select whether to enable user-defined events.

### User-Defined Event Name (Event Name)

- Number of characters: Up to eight
- Usable characters: Spaces and all characters that are displayed on the keyboard

### Indication of User-Defined Event Occurrence (TRUE/FALSE)

Set the character strings to show when a user-defined event occurs and when it does not occur.

- Number of characters: Up to six
- Usable characters: Spaces and all characters that are displayed on the keyboard

### Judgment Condition Specification Method (Expression)

Select the method for specifying judgment conditions from the following options.

- Range (Range): Specify judgment conditions using ranges of measurement function values or differences from a reference value.
- Condition (Condition): Specify judgment conditions using user-defined events.

### Range (Range)

Specify the judgment condition here when you have set the judgment condition specification method to Range.

- **Function (Function)**

You can select any of the measurement function types listed under “Items That This Instrument Can Measure.”

► [Click here.](#)

- **Element (Element/ $\Sigma$ )**

You can select the element/wiring unit from the options below. The available options vary depending on the installed elements.

Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$

- **Order (Order; option)**

This is the same as setting the harmonic order in the 4-, 8-, and 16-value displays.

► [Click here.](#)

- **Judgment Condition**

Select the method for comparing the measured value and the reference value from the following options.

OFF, <, <=, =, >, >=, != (not equal)

- **Reference Value**

Select a number from -9.9999 T to 9.9999 T.


For example, a condition that is true when  $150 < \text{the measured power value of element 1} < 160 \text{ W}$  and false otherwise would be configured as shown below.

Expression **Range** Condition

Range	Function	Element/ $\Sigma$	Order		
	P	Element 1	Total	>	150.00
				<	160.00

## Condition (Condition)

Specify the judgment condition here when you have set the judgment condition specification method to Condition.



## Inverting the Condition (Inverse)

You can invert the judgment of the condition indicated to the right of the check box.

## Event Specification Boxes

You can select the number of a user-defined event that is smaller than the number of the user-defined event that you are currently configuring. For example, when you are configuring the conditions of user-defined event Ev3, you can select Ev1 or Ev2.

## AND/OR/END Specification Boxes

### • AND and OR

To use multiple user-defined events to configure a condition, set the method of combining the events to logical AND or logical OR. When you select AND or OR, an event specification box appears to the right of the AND/OR/END specification box. The number of user-defined events that you can combine is indicated below. When you reach the maximum number of combinable user-defined events, no AND/OR/END specification box appears to the right of the last event.

- Ev1: 0. You cannot use other user-defined events as conditions. Set the judgment condition using a range.
- Ev2: 1 (Ev1)
- Ev3: 2 (Ev1 and Ev2)
- Ev4: 3 (Ev1 to Ev3)
- Ev5: 4 (Ev1 to Ev4)
- Ev6: 5 (Ev1 to Ev5)
- Ev7: 6 (Ev1 to Ev6)
- Ev8: 7 (Ev1 to Ev7)

### • END

Select END to end the definition of the condition. No event specification box appears to the right of an AND/OR/END specification box that has been set to END.



If you set the event judgment condition to a range and the function of the judgment condition returns a value of "-----" (no data), because judgment cannot be performed, the judgment result is FALSE. For example, when integration is not being performed, if the function of event Ev1 is set to integrated power (WP) and the judgment condition is  $WH(E1) > 0$ , the measured data is displayed as "-----" (no data), so the judgment for Ev1 is FALSE. Also, if you set the judgment condition specification method to Condition and events that cannot be judged are included in the judgment conditions, the judgment result is FALSE. For example, if you set the judgment condition of event Ev2 to  $NOT(EV1())$ , if the judgment for Ev1 is FALSE because of the reason given in the example above, the result for Ev2 is not TRUE but FALSE.

## Apparent Power, Reactive Power, and Corrected Power Equations (Formula)

### Equation for Apparent Power (S Formula)

You can select the voltage and current to use to compute the apparent power (voltage × current) from the following options.

- $U_{rms} \times I_{rms}$   
The product of the true rms values of the voltage and current
- $U_{mean} \times I_{mean}$   
The product of the voltage's and current's rectified mean values calibrated to the rms values
- $U_{dc} \times I_{dc}$   
The product of the simple averages of the voltage and current
- $U_{mean} \times I_{rms}$   
The product of the voltage's rectified mean value calibrated to the rms value and the current's true rms value
- $U_{rmean} \times I_{rmean}$   
The product of the voltage's and current's rectified mean values

### Apparent Power and Reactive Power Computation Types (S,Q Formula)

There are three types of power: active power, reactive power, and apparent power. In general, they are defined by the following equations.

$$\text{Active power } P = UI \cos \Phi \quad (1)$$

$$\text{Reactive power } Q = UI \sin \Phi \quad (2)$$

$$\text{Apparent power } S = UI \quad (3)$$

$U$  = rms voltage;  $I$  = rms current;  $\Phi$  = Phase difference between voltage and current

The power values are related as follows:

$$(\text{Apparent power } S)^2 = (\text{Active power } P)^2 + (\text{Reactive power } Q)^2 \quad (4)$$

The three-phase power is the sum of the power of each phase.

These definitions only apply for sine waves. The measured values for apparent power and reactive power vary for distorted waveform measurement depending on which of the above definitions are combined for the computation. Because the equations for deriving the apparent and reactive power for distorted waveforms are not defined, none of the equations can be said to be more correct than the other. Therefore, this instrument provides three equations, Type 1 to Type 3, for determining the apparent power and reactive power.

Unlike apparent power and reactive power, active power is derived directly from the sampled data, so errors resulting from different definitions do not occur.

#### Type 1 (The method used in the normal mode of conventional WT series power meters)

This instrument calculates the apparent power of each phase using equation 3, calculates the reactive power of each phase using equation 2, and sums the results to derive the power.

$$\text{Active power for a three-phase, four-wire system} \quad P\Sigma = P1 + P2 + P3$$

$$\text{Apparent power for a three-phase, four-wire system} \quad S\Sigma = S1 + S2 + S3 (= U1 \times I1 + U2 \times I2 + U3 \times I3)$$

$$\text{Reactive power for a three-phase, four-wire system} \quad Q\Sigma = Q1 + Q2 + Q3$$

$$(\text{= } s1 \times \sqrt{(U1 \times I1)^2 - P1^2} + s2 \times \sqrt{(U2 \times I2)^2 - P2^2} + s3 \times \sqrt{(U3 \times I3)^2 - P3^2} )$$

The signs for  $s1$ ,  $s2$ , and  $s3$  are negative when the current leads the voltage and positive when the current lags the voltage.

#### Type 2

This instrument calculates the apparent power of each phase using equation 3 and sums the results to derive the three-phase apparent power. This instrument calculates the three-phase reactive power from the three-phase apparent power and the three-phase active power using equation 4.

$$\text{Active power for a three-phase, four-wire system} \quad P\Sigma = P1 + P2 + P3$$

$$\text{Apparent power for a three-phase, four-wire system} \quad S\Sigma = S1 + S2 + S3 (= U1 \times I1 + U2 \times I2 + U3 \times I3)$$

$$\text{Reactive power for a three-phase, four-wire system} \quad Q\Sigma = \sqrt{S\Sigma^2 - P\Sigma^2}$$

**Type 3 (The method used in the harmonic measurement modes of the WT1600, WT3000 and PZ4000)**

This instrument calculates the reactive power of each phase using equation 2 and calculates the three-phase apparent power using equation 4. This equation is available on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

Active power for a three-phase, four-wire system  $P\Sigma = P1 + P2 + P3$

Apparent power for a three-phase, four-wire system  $S\Sigma = \sqrt{P\Sigma^2 + Q\Sigma^2}$

Reactive power for a three-phase, four-wire system  $Q\Sigma = Q1 + Q2 + Q3$

**Corrected Power Equation (Pc Formula)**

Some standards require that a voltage transformer's active power be corrected when the load connected to the voltage transformer is very small. You can select an equation to use for this correction and specify the coefficient.

**Applicable Standard (Select standard)**

Select from the following.

- IEC76-1 (1976)
- IEC76-1 (1993)

Equations for each applicable standard

**IEC76-1(1976)**

$$P_c = \frac{P}{P_1 + P_2 \left( \frac{U_{rms}}{U_{mn}} \right)^2}$$

**IEC76-1(1993)**

$$P_c = P \left( 1 + \frac{U_{mn} - U_{rms}}{U_{mn}} \right)$$

Pc: Corrected power

P: Active power

Urms: True rms voltage

Umn: Voltage's rectified mean calibrated to the rms value

P1, P2: Coefficients specified by the applicable standard

**Coefficients (P1 and P2)**

You can set coefficients P1 and P2 to values within the range of 0.0001 to 9.9999.



The IEEE C57.12.90-1993 equation is the same as IEC761(1976).

**Sampling Frequency (Sampling Frequency)**

This instrument offers three types of sampling frequencies, each approximately 2 MHz, to prevent the input waveform from being measured as a DC signal because of [aliasing](#). You can choose to automatically switch the sampling frequency or choose to use a fixed frequency.

- Auto:
  - This instrument automatically switches between clocks A, B, and C.
  - In the following situations, setting sampling frequency to Auto will fix the sampling frequency to Clock C.
    - When the data update interval is Auto
    - When the line filter of the input element is set to a value in the 100 Hz to 100 kHz range
    - When the line filter of motor evaluation or auxiliary signal input is not set to OFF
    - For high speed data capturing
- Clock A: 2.000000 MHz
- Clock B: 1.941176 MHz
- Clock C: 1.885714 MHz





- Set the sampling frequency to Auto to prevent the measured values from being distorted by aliasing.
  - If you want to use a fixed sampling frequency, select a frequency from Clock A to Clock C.
- 

## Phase Difference Display Format (Phase)

The phase difference  $\Phi$  between the voltage and current indicates the current phase relative to the voltage of each element. Set the display format to one of the options below.

- **180 degrees**

If the current phase is in the counterclockwise direction with respect to voltage, the current is leading (D) the voltage. If the current phase is in the clockwise direction with respect to the voltage, the current is lagging (G) the voltage. The phase difference is expressed by an angle between 0 and 180° (see appendix 2 in the getting started guide, IM WT1801E-03EN).

- **360 degrees**

The phase difference is expressed as an angle between 0 and 360° in the clockwise direction.



- If the measured voltage or current value is zero, "Error" is displayed.
  - When both the voltage and current signals are sinusoidal waves and the ratios of the voltage and current inputs with respect to the measurement range do not differ greatly, the phase difference  $\Phi$  lead and lag are still detected and displayed correctly.
  - If the computation result of power factor  $\lambda$  exceeds 1,  $\Phi$  is displayed as follows:
    - If the power factor  $\lambda$  is greater than 1 and less than or equal to 2,  $\Phi$  returns 0.
    - If  $\lambda$  is greater than 2,  $\Phi$  returns an error ("Error" is displayed).
  - On models with the harmonic measurement option, the phase differences  $\Phi_U$  and  $\Phi_I$  of harmonic orders 1 to 500 of the voltage and current are always displayed using an angle between 0 and 180° (no sign for lead and negative sign for lag).
- 

## Master/Slave Synchronization Measurement (Sync Measure)

Connect the external start signal input/output connectors (MEAS. START) of the master and slave instruments using a BNC cable (sold separately). You can synchronize the measurement of two WTs making one WT the master and the other WT the slave. The master outputs a measurement start signal, and the slave receives the signal.

For the specifications of the external start signal input/output connectors, see section 4.4 in the getting started guide, IM WT1801E-03EN.



The measurement of the master and slave cannot be synchronized under the following conditions:

- When the data update interval differs between the master and slave.
- When the data update interval is Auto.
- During real-time integration mode or real-time storage mode.

Follow the procedure below to hold the display during synchronized measurement.

- To hold the display: Hold the display of the master first.
  - To unhold the display: Unhold the display of the slave first.
-

## **Voltages or Currents Whose Frequencies Will Be Measured (FREQ MEASURE)**

This instrument can measure the frequencies of the voltages or currents of all elements. Thus, even if you press SHIFT+MEASURE(FREQ MEASURE), the Freq Items menu will not appear.

## 9 Integrated Power (Watt hours)

This instrument can integrate the active power (watt hour), the current (ampere hour), the apparent power (volt-ampere hour), and the reactive power (var hour) values.

For a list of the measurement functions related to integrated power (watt hours) and their descriptions, see “Items That This Instrument Can Measure.”

► [Click here.](#)

You can set the following items.

- [Enabling or Disabling Independent Integration \(Independent Control\)](#)
- [Independently integrated elements \(Element Object\)](#)
- [Starting, Stopping, and Resetting Integration \(Start/Stop/Reset\)](#)
- [Integration Conditions \(Integ Set\)](#)

### Integration-Related Display Indications



#### Reset

Displayed when the integrated value is reset and integration can be started.

#### Start

Displayed along with the elapsed integration time when integration has been started.

#### Stop

Displayed along with the elapsed integration time when integration has been stopped.

- When integration has been stopped forcibly through the pressing of the Stop soft key, “Stop” appears in yellow. You can press Start to resume integration.
- In real-time normal integration mode and real-time continuous integration mode, once the scheduled integration stop time is reached, “Stop” appears in orange. Even if you press Start, integration is not resumed. To start integration, you must first reset it.

#### Ready

In real-time normal integration mode, when you press Start, before the scheduled integration start time is reached, “Ready” and the scheduled integration start time appear.



#### TimeUp

After the specified integration timer time elapses, integration stops automatically, and “TimeUp” and the elapsed integration time appear.

#### Error

In the following situations, integration stops automatically, and “Error” and the elapsed integration time appear.

- The integration time reaches the maximum integration time (10000 hours).
- The integrated value reaches its maximum or minimum displayable value.
- A power failure occurs when integration is in progress. Even when a power failure occurs, this instrument stores and holds the integration result. When the power returns, integration is stopped, and the integration result calculated up to the point when the power failure occurred is displayed.


#### Example of the Display When the Integration Time Is Set to a Non-Zero Value



**Example of the Display When Independent Integration Is Enabled**

The integration status of the input element or wiring unit selected with the ELEMENT key for setting ranges.

When a wiring unit is selected, the element number at the top is the number of the smallest input element in the wiring unit.



Integration status of each element

**Number of Displayed Digits (Display Resolution)**

The number of displayed digits (display resolution) for an integrated value is six (the maximum value is 999999). When an integrated value reaches 1000000 counts, the decimal point shifts automatically. For example, if 0.001 mWh is added to 999.999 mWh, the display shows 1.00000 Wh.

**Maximum and Minimum Displayable Integrated Values**

Active power (WP):  $\pm 999999$  MWh  
 Current (q):  $\pm 999999$  MAh  
 Apparent power (WS):  $\pm 999999$  MVAh  
 Reactive power (WQ):  $\pm 999999$  Mvarh

**Display When Integration Overflow Occurs**

If either of the conditions below is met, integration is stopped, and the integration time and integrated value are held.

- The integration time reaches the maximum integration time (10000 hours).
- The integrated value of WP, q, WS, or WQ reaches the maximum or minimum displayable value given above.

**Display When the Data Update Interval is Auto**

WS and WQ are not measured and displayed as “-----” (no data).

**Integration When the MAX Hold Feature Is Enabled**

This instrument determines and displays the integrated value by summing the value that is measured at every data update interval, irrespective of the [MAX hold](#) feature.

**Integration When the Measured Value Exceeds the Measurement Limit**

If a sampled instantaneous current or voltage exceeds the maximum or minimum measurement range limits of the AD circuit, the value is measured as the maximum or minimum measurement range limit value.

**Integration When Current Input Is Small**

If rounding to zero is on, when the current input meets the following conditions relative to the measurement range, integration is performed assuming the current to be zero.

- When the Crest Factor Is Set to CF3  
 When Irms or Iac is 0.3% or less When Imn or Irmn is 2% or less
- When the Crest Factor Is Set to CF6 or CF6A  
 When Irms or Iac is 0.6% or less When Imn or Irmn is 4% or less

## Sample Rate, and Valid Frequency Ranges for Integration

The sample rate is approximately 2 MHz. The voltage/current signal frequencies that are valid for integration are as follows:

Integrated Item		Valid Frequency Range for Integration
Active power		DC to approximately 1 MHz
Current	When integrating Irms	DC or the lower frequency limit determined by the data update interval to approximately 1 MHz
	When integrating Imn	DC or the lower frequency limit determined by the data update interval to approximately 1 MHz
	When integrating Idc	DC to approximately 1 MHz
	When integrating Irmn	DC or the lower frequency limit determined by the data update interval to approximately 1 MHz
	When integrating Iac	The lower frequency limit determined by the data update interval to approximately 1 MHz

## Using an External Signal to Control Integration (Option)

On models with the 20-channel D/A output option, you can use the remote control feature to use an external signal to start, stop, and reset integration. For details about the remote control feature, see appendix 4.6 in the getting started guide, IM WT1801E-03EN.

## Limitations on Modifying the Settings during Integration

During integration, there are some settings that you cannot change and functions that you cannot execute. For details, see appendix 9 in the getting started guide, IM WT1801E-03EN.

## Limitations on Waveform Display during Integration

- During integration, the waveform display [trigger](#) does not function. Therefore, the signal level of the waveform display at the left end of the screen may not be stable.
- During integration, the shortest possible waveform data update interval is 1 s. If you select an update interval shorter than 1 s, the numeric data and waveform data will contain measured values for different measurement periods.

## Auto Range Feature and Range Skipping

If you start integration when the auto range feature is enabled, integration will take place with the auto range feature enabled. This state is called integration auto range.

- When the auto range feature is enabled, the measurement ranges for both the voltage and current will be automatically switched in accordance with the size of the input signal.
- For information about the conditions under which the range is automatically increased or decreased, see “Auto Voltage Range (AUTO (V)).”  
▶ [Click here.](#)
- When the auto range feature is enabled, you can enable range skipping, in which measurement ranges that are not used are skipped, and this instrument switches between the measurement ranges that you have chosen to enable. For details, see “Valid Measurement Range (CONFIG(V)/CONFIG(A)).”  
▶ [Click here.](#)
- When an irregular pulse waveform is applied, a steady range may not be maintained. If this occurs, use a fixed range.

## Data Correction When the Auto Range Feature Switches the Range

Measurement does not take place while the range is being switched by the auto range feature. After the measurement range is determined, the first measured data for the period of time over which measurement did not take place is added to the integrated value. Measurement also does not take place while the range is being switched for elements that are not applicable to range increasing or decreasing. Power or current value measured immediately before is added to the integrated value.

- When the Range Is Increased  
Each time the range is increased, up to three of the first items of data measured after the determination of the measurement range is added to the integrated value immediately before the conditions for increasing the range were met.
- When the Range Is Decreased  
Each time the range is decreased, up to two of the first items of data measured after the determination of the measurement range is added to the integrated value immediately before the conditions for reducing the range were met.

### Checking Whether the Range Has Been Changed by the Auto Range Feature

During integration, when the measurement range is changed by the auto range feature, a hyphen is added to the measurement range information that is output through communication.

### Integration Auto Range Limitations

- Integration is not possible using auto range for the following measurement ranges. The measurement ranges are fixed to those that are being used at the start of integration.
  - Voltage range, current range (when the data update interval is set to Auto)
  - Analog input range of the revolution signal for the motor evaluation option and torque signal
  - Analog input range of the auxiliary input option
- If independent input element configuration is on, integration cannot be started.
- If apparent power and reactive power computation types is type 3, integration cannot be started.



We recommend that you select a short data update interval to measure integration with higher accuracy when using auto range.

## Enabling or Disabling Independent Integration (Independent Control)

You can select whether to start, stop, and reset integration on all elements simultaneously or separately.

- OFF: Integration starts, stops, and is reset simultaneously on all elements.
- ON: Integration works differently depending on the [independent input element configuration](#) (Element Independent) setting.
  - When independent input element configuration is disabled  
Elements whose wiring system is 1P2W are controlled separately. For elements whose wiring system is not 1P2W, integration starts, stops, and is reset at the same time for all elements in the same wiring unit.
  - When independent input element configuration is enabled  
The integration of each element is controlled separately.
- When the data update interval is Auto and independent integration is on, integration cannot be started.



When independent integration and independent input element configuration are enabled and integration is controlled separately for elements in the same wiring unit, because the elements' integration periods differ, the  $\Sigma$  functions for those elements (the functions that deal with wiring unit integration, such as the integrated active power and apparent power functions) return errors.

## Independently Integrated Elements (Element Object)

This setting is valid when independent integration is enabled.

- You can select which elements to start, stop, and reset the integration of by selecting the elements' check boxes.
- All ON: All elements are controlled.
- All OFF: No elements are controlled.



Even if you enable independent integration, when [independent input element configuration](#) is disabled, the integration of elements in the same wiring unit is controlled simultaneously regardless of whether the elements' check boxes are selected.

Example:


- Elements 1, 2, and 3 are assigned to wiring unit  $\Sigma A$  as a three-phase, four-wire system.
- Under Element Object, the check box of element 1 is selected, but the check boxes of elements 2 and 3 are not.

If you start or stop the integration of element 1 under the above conditions, the integration of elements 2 and 3, whose check boxes are not selected, also starts or stops.

To independently control the integration of input elements that are assigned to the same wiring unit, you must enable independent integration and independent input element configuration.

## Starting, Stopping, and Resetting Integration (Start/Stop/Reset)

You can start, stop, and reset integration using the soft keys on the front panel or communication commands. The relationships between integration and starting, stopping, and resetting are indicated below.



### Starting Integration (Start)

- Integration starts under the different conditions indicated below depending on the integration mode.
  - Manual integration mode, standard integration mode, and continuous integration mode  
Integration starts immediately.
  - Real-time normal integration mode and real-time continuous integration mode  
This instrument enters into an integration-ready state when you press Start. Integration starts when the scheduled start time is reached.
- When integration starts, the START indicator to the right of the INTEG key illuminates, and the integration status indication is "Start."
- When this instrument is in an integration-ready state, the START indicator blinks, and the integration status indication is "Ready."

### Stopping Integration (Stop)

- You can force integration to stop. The integration time and integrated value are held.
- When you force integration to stop, the STOP indicator blinks, and "Stop" appears in yellow as the integration status indication. You can press Start to resume integration. However, after the automatic stopping of integration, which is discussed later, you cannot press Start to resume integration.

### Automatic Stopping of Integration

- Integration stops automatically under the different conditions indicated below depending on the integration mode. The integration time and integrated value are held. After integration stops automatically, you cannot resume it by pressing Start. To start integration, you must first reset it.
  - When the integration mode is manual integration mode, standard integration mode, or real-time normal integration mode  
After the specified timer time elapses, integration stops automatically. The STOP indicator illuminates, and the integration status indication is "TimeUp."
  - When the integration mode is real-time normal integration mode or real-time continuous integration mode  
Integration stops automatically when the scheduled integration end time is reached. The STOP indicator illuminates, and "Stop" appears in orange as the integration status indication.

## Resetting Integration (Reset)

The integration time and integrated value are reset. The STOP indicator turns off. The displays for integration-related functions change to “-----” (no data).



When an integration error occurs, the START and STOP indicators blink, and the integration status indication is “Error.”

## Holding Integration and Releasing the Hold

### Holding Integration


When you press the HOLD key, it illuminates, and the display and communication output of the integration result are held. Integration continues regardless of whether the display is held.

### Releasing the Hold on Integration


If you press the HOLD key when integration is held, the HOLD key light turns off, and the numeric data display is updated. While the display is held, you can update the display by pressing SINGLE to execute a single measurement.

The relationship between the hold function and the start and stop operations is as follows:

- If you start integration while the display is held, the display and communication output do not change. When you release the hold function (turn it off) or make a single measurement by pressing SINGLE, the integration result at that point is displayed and transmitted.



- If you stop integration while the display is held, the displayed and transmitted values do not change. When you release the hold function (turn it off) or make a single measurement by pressing SINGLE, the integration result at the point when integration was stopped is displayed and transmitted.





## Integration Conditions (Integ Set)

You can configure the following integration conditions.

- [Integration mode \(Mode\)](#)
- [Integration timer \(Integ Timer\)](#)
- [Scheduled times for real-time integration \(Real-time Control\)](#)
- [Integration auto calibration on/off \(Auto Cal\)](#)
- [Watt hour integration method for each polarity \(WP  \$\pm\$  Type\)](#)
- [Current mode for current integration \(q Mode\)](#)
- [Rated time of integrated D/A output \(D/A Output Rated Time; option\)](#)

## Integration Mode (Mode)

The integration feature has the following five modes.


Integration mode	Start	Stop	Repetition
Manual integration mode (Normal)	Key operation	Key operation	—
Normal integration mode (Normal)	Key operation	Stopped by the timer	—
Continuous integration mode (Continuous)	Key operation	Key operation	Repeats when the timer expires
Real-time normal integration mode (R-Normal)	Date and time	Date and time	—
Real-time continuous integration mode (R-Continuous)	Date and time	Date and time	Repeats when the timer expires

When the data update interval is Auto, only manual integration mode and standard integration mode can be used.

### Manual integration mode

When you set the integration mode to normal integration mode (Normal) and set the integration timer to 00000:00:00, this instrument performs integration in manual integration mode. After integration is started, it continues until you press Stop. However, if either of the conditions below is met, integration is stopped, and the integration time and integrated value are held.


- The integration time reaches the maximum integration time (10000 hours).
- The integrated value reaches its maximum or minimum displayable value.




**Normal Integration Mode (Normal)**

You can set a relative integration time (set a timer). Integration starts when you press Start. When one of the conditions below is met, integration is stopped, and the integration time and integrated value are held.

- The specified timer time elapses.
- The Stop soft key is pressed.
- The integrated value reaches its maximum or minimum displayable value.

**Continuous Integration Mode (Continuous integration; Continuous)**


You can set a relative integration time. Integration starts when you press Start. When the specified timer time elapses, integration is automatically reset and restarted. Integration repeats until you press Stop. However, if the integrated value reaches its maximum or minimum displayable value before the specified amount of time has elapsed, integration is stopped, and the integration time and integrated value at that point are held.



**Real-Time Normal Integration Mode (R-Normal)**

Set the date and time when integration starts and stops and the duration of integration. Integration starts at the scheduled start time. When one of the conditions below is met, integration is stopped, and the integration time and integrated value are held.

- The scheduled stop time is reached.
- The specified timer time elapses.
- The integration time reaches the maximum integration time (10000 hours).
- The integrated value reaches its maximum or minimum displayable value.




In real-time integration mode, when you set the integration time to 00000:00:00, integration starts at the scheduled start time. When one of the conditions below is met, integration is stopped, and the integration time and integrated value are held.

- The scheduled stop time is reached.
- The integration time reaches the maximum integration time (10000 hours).
- The integrated value reaches its maximum or minimum displayable value.

**Real-Time Continuous Integration Mode (Continuous integration; R-Continuous)**

Set the date and time when integration starts and stops and the duration of integration. Integration starts at the scheduled start time. When the specified timer time elapses, integration is automatically reset and restarted. If either of the conditions below is met, integration is stopped, and the integration time and integrated value are held.

- The scheduled stop time is reached.
- The integrated value reaches its maximum or minimum displayable value.



## Integration Timer (Integ Timer)

You can set the hour, minute, and second within the following range.  
00000:00:00 to 10000:00:00

### When Independent Integration Is Disabled

The integration timer that you specified above applies to every element.

### When Independent Integration Is Enabled

- **Setting**

You can select the method for setting the integration timer from the following options.

- Each: Set it separately for each input element.
- All: Set it for all installed input elements at the same time.

- **Element1 to Element6**

You can set the integration timers for each element within the range given above.

## Scheduled Times for Real-Time Integration (Real-time Control)

This setting is valid in real-time normal integration mode and real-time continuous integration mode.

You can set the year, month, day, hour, minute, and second of the integration start and stop times. Be sure to set the integration stop time to a time after the integration start time. You can set the values within the following ranges.

- Year: Any four-digit Gregorian calendar value
- Hour:Minute:Second: 00:00:00 to 23:59:59
- Now: The scheduled integration start time is set to the current time.
- Copy: The scheduled integration start time is copied to the scheduled integration stop time.

### When Independent Integration Is Disabled

The scheduled times that you specified above apply to every element.

### When Independent Integration Is Enabled

- **Setting**

You can select the method for setting the scheduled times from the following options.

- Each: Set them separately for each input element.
- All: Set them for all installed input elements at the same time.

- **Element1 to Element6**

You can set the scheduled times for each element within the range given above.



- You can set the day for the scheduled start or stop time in February to a value as high as the 31st day. If you do so, an error message will appear when you start integration. Reset the scheduled stop time.
  - This instrument recognizes leap years when it executes the integration operation.
  - In real-time normal integration mode and real-time continuous integration mode, after you press Start and this instrument enters into an integration-ready state, the numeric data may not be updated immediately. This is because the numeric data is updated in sync with the clock of this instrument. This ensures that the numeric data is updated at the same time as the scheduled integration start time and that the integration time is accurate.
-

## Integration Auto Calibration On/Off (Auto Cal)

Ordinary zero-level compensation takes place when the measurement range or line filter is changed, but you can also automatically calibrate the zero level during integration.

- ON: Zero-level compensation takes place approximately once every hour during integration.
- OFF: Zero-level compensation does not take place during integration.

When the data update interval is Auto, integration auto calibration is set to OFF.



- When integration auto calibration is on and zero-level compensation is in progress, the power or current value measured immediately before is integrated.
- When integration auto range is in use, integration calibration takes the sum of the following times.
  - Zero-level compensation time: Data update interval × about 30
  - Internal processing time: About 2 s

## Watt Hour Integration Method for Each Polarity (WP ± Type)

### Setting

You can select the method for setting the integration method from the following options.

- Each: Set it separately for each input element.
- All: Set it for all installed input elements at the same time.

### Element1 to Element6

Set the integration method to one of the options below.

- Charge/Discharge: Measure DC watt hours (for each sampled data item) by polarity.
- Sold/Bought: Measure AC watt hours (for each sampled data item) by polarity.

For information about the equations used in each method, see appendix 1 in the getting started guide, IM WT1801E-03EN.

When the data update interval is Auto, the integration method is set to Charge/Discharge.

## Current Mode for Current Integration (q Mode)

### Setting

You can select the method for setting the current mode from the following options.

- Each: Set it separately for each input element.
- All: Set it for all installed input elements at the same time.

### Element1 to Element6

You can select the current mode from the following options. For information about the equations used in each mode, see appendix 1 in the getting started guide, IM WT1801E-03EN.

- rms: True rms value
- mean: Rectified mean value calibrated to the rms value
- dc: Simple average
- r-mean: Rectified mean value
- ac: AC component

When the current mode is dc, the polarity (+ or -) is displayed.

## Rated Time of Integrated D/A Output (D/A Output Rated Time; Option)

This setting appears on models with the 20-channel D/A output option. When integrated values are output through [D/A output](#), a rating value (the same value as the measurement range) is continuously applied, the integrated value after the specified amount of time has elapsed is taken to be 100%, and the D/A output at that point is 5 V. It is assumed that the change in the D/A output from 0% of the integrated value (0 V) to 100% of the integrated value (5 V) will occur linearly over time, and the D/A output value is determined by the ratio of the actual input level to this assumed straight line.

For information about the relationship between the measured integrated D/A output value and the voltage, see “Relationship between Output Items and the D/A Output Voltage.”

► [Click here.](#)

### Setting the Rated Time for Integrated D/A Output

- You can set the hour, minute, and second within the following range.  
00000:00:00 to 10000:00:00
- This setting is valid in the following integration modes.
  - Manual integration mode
  - Real-time normal integration mode when the integration timer is set to 00000:00:00
- In the following integration modes, the rated time for integrated D/A output is set to the same time that the timer is set to.
  - Normal integration mode
  - Continuous integration mode
  - Real-time normal integration mode when the integration timer is not set to 00000:00:00
  - Real-time continuous integration mode



When the rated time for integrated D/A output is set to 00000:00:00, the D/A output for the integrated value is fixed at 0 V.

## Integration Resume Action at Power Failure Recovery (Integration Resume Action)

You can set how to resume the integration operation when the instrument is turned off due to a power failure or interruption and then turns back on.

### Start

The integration result at the time the power is turned off is stored. When the power recovers, integration starts (continues) automatically.

### Stop

The integration result at the time the power is turned off is stored. When the power recovers, the integration result up to the point when the power was turned off is displayed in the integration stopped state. You can start (continue) integration.

### Error

The integration result at the time the power is turned off is stored. When the power recovers, the integration result up to the point when the power was turned off is displayed in the integration error state. You can start integration by resetting it. When integration is reset, the measurement result is displayed as “-----” (no data). If necessary, record the integration result up to that point before resetting it.

When the data update interval is Auto, integration resume action at power failure recovery is according to the action described for “Error.”

## 10 Waveform Display

### Waveform Display (WAVE)

You can press WAVE to make the waveform displays of the following types of input signals.


- Input element voltage and current
- Motor evaluation function (option) speed and torque
- Auxiliary inputs (option) Aux1 and Aux2

Each time you press WAVE, the number of split screens switches in order between none, 2, 3, 4, and 6.

#### Waveform Display Example

##### Scale Value

The measurement function, element number, and upper limit of the displayed waveform



##### Scale Value

The measurement function, element number, and lower limit of the displayed waveform

#### Measurement Mode during Waveform Display

If the measurement mode display is set to Normal Mode (Trg), measurement takes place from when a trigger is detected over the data update interval. The following amount of time is required for this instrument to compute the measured data, process it for displaying, and so on, and become ready for the next trigger.

- When the data update interval is 50 ms to 500 ms: Approx. 1 s
- When the data update interval is 1 s to 5 s: Data update interval + 500 ms

In this case, storage, communication output, and D/A output operate in sync with the triggers.

If the measurement mode display is set to Normal Mode, storage, communication output, and D/A output operate in sync with the data update interval.



- If you do not set the trigger level properly, the waveform display start point (the signal level on the left edge of the screen) may be unstable, or waveforms may not appear.
- Even when waveforms are displayed, in the following situations, the measurement mode indication at the upper left of the screen is Normal Mode.
  - During integration
  - When the trigger mode is OFF

In Normal Mode, measurements are taken and the sampled data is updated automatically at the data update interval. In this mode, there are limitations on the waveform display feature.

▶ [Click here.](#)

## Display Format (FORM)

You can configure the following display format settings.

- [Number of windows \(Format\)](#)
- [Time axis \(Time/div\)](#)
- [Trigger \(Trigger Settings\)](#)
- [Advanced waveform display settings \(Display Settings\)](#)
- [Waveform mapping \(Wave Mapping\)](#)

## Number of Windows (Format)

You can divide the screen equally into windows, and assign waveforms to those windows. This function is useful when there are many waveforms and it is difficult to view them all in a single display.

You can choose the number of windows from one of the following options:

- Single: No windows
- Dual: Two windows
- Triad: Three windows
- Quad: Four windows
- Hexa: Six windows

Depending on the number of windows, the number of displayed points in each window changes as described below.

Single: 672 points, Dual: 336 points, Triad: 224 points, Quad: 168 points, Hexa: 112 points

When the screen is split, the number of displayed points along the vertical axis of a single window is halved.

For information about how to assign waveforms to windows, see “Waveform Mapping.”

► [Click here.](#)

## Time Axis (Time/div)


The time axis is set in Time/div (time per grid division).

- When the data update interval is not Auto

The time axis can be set up to the point in which the time corresponding to one screen is equal to the data update interval, in 1, 2, 5 steps. For example, when the data update interval is 500 ms, if you change the time-per-division in this order: 0.05 ms > 0.1 ms > 0.2 ms > 0.5 ms > 1 ms > 2 ms > 5 ms > 10 ms > 20 ms > 50 ms, the time corresponding to one screen changes in this order: 0.5 ms > 1 ms > 2 ms > 5 ms > 10 ms > 20 ms > 50 ms > 100 ms > 200 ms > 500 ms.

- When the data update interval is Auto

The time per division can be changed in the range of 0.05 ms to 5 ms in 1, 2, 5 steps. This allows the time per screen to be changed in the range of 0.5 ms to 50 ms.





## Difference between Waveform Sampling Data and Waveform Display Data

Waveform sampling data and waveform display data are both measured waveform data, but they differ as described below.

- **Waveform sampling data: Data derived through A/D conversion of the input signal**


The A/D conversion rate of this instrument is approximately 2 MS/s. Therefore, if the data update interval is set to 1 s, the number of data points sampled from a single input signal in a single measurement is approximately 2,000,000 (see the figure below). Waveform sampling data is also called acquisition data or raw wave data.

- **Waveform display data: Waveform data displayed on this instrument's screen (1602 points)**

When this instrument displays waveforms, data points (of waveform display data) are displayed in horizontal rasters (along the time axis). The number of rasters is 801. Each raster contains two points of waveform display data. The two data points are the maximum and minimum values of the waveform data in each raster. Therefore, the number of waveform display data points (the number of points displayed on the screen) for a single input signal is 1602.


## p-p Compression

p-p compression is the compression method used to derive waveform display data from waveform sampling data. For example, if a 2-Hz sine wave is measured at a data update rate of 1 s, to display this waveform, this instrument converts the number of data points from approximately 2,000,000 to 1602 (801 pairs of maximum and minimum values). Thus, two points (a pair) of waveform display data are derived from approximately 2500 points of waveform sampling data. This conversion is called p-p (peak-peak) compression. The compression ratio of p-p compression varies depending on the data update interval and the horizontal scale (time axis) of the waveform display.



## Aliasing

When the sample rate is low compared to the frequency of the input signal, the high frequency components of the signal are lost. In accordance with the Nyquist sampling theorem, the high frequency components in the signal are misread as low frequency components. This is called aliasing.





## Vertical Axis (Amplitude)

The height (display range) of the vertical axis is based on the specified crest factor and measurement range.

For example, if the crest factor is set to CF3 and the voltage measurement range is set to 100 Vrms, the display range is set to  $\pm 300$  Vpk ( $\pm 3 \times 100$  Vrms) with the zero input line at the center. The waveform is clipped if this range is exceeded.

In the same way, if the crest factor is set to CF6 or CF6A and the voltage measurement range is set to 50 Vrms, the display range is set to  $\pm 300$  Vpk ( $\pm 6 \times 50$  Vrms) with the zero input line at the center.



## Trigger (Trigger Settings)

The trigger determines when a waveform is displayed. A trigger is said to “occur” when the trigger condition is met and a waveform is displayed.

### Trigger Mode (Mode)

The trigger mode determines the conditions for updating the display. Select from the following options.

- **Auto (Auto mode)**

If the trigger conditions are met before an approximately 100 ms timeout, this instrument updates the displayed waveforms on each trigger occurrence. If not, this instrument automatically updates the displayed waveforms. If the period of the trigger signal is greater than 100 ms, the display is updated as the two conditions described above alternate. If this occurs, use Normal mode.

- **Normal (Normal mode)**

This instrument only updates the waveform display when the trigger conditions are met. If no triggers occur, the display is not updated. If you want to view waveforms that this instrument cannot trigger on, or if you want to check the ground level, use Auto mode.

- **OFF**

The trigger feature does not function. The display is updated at the data update interval. There are limitations on the waveform display feature.

► [Click here.](#)

When the data update interval is Auto, the trigger mode is set to OFF.

### Trigger Source (Source)

The signal that this instrument checks for the trigger condition is referred to as the trigger source. Select from the following options. The available options vary depending on the installed elements.




U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, and Ext Clk (external clock)\*

- \* When you select Ext Clk, the external signal applied to the external clock input connector (EXT CLK) on the rear panel is used as the trigger source. For the EXT CLK connector specifications, see section 4.3 in the getting started guide, IM WT1801E-03EN. When Ext Clk is set as the trigger source, the trigger level setting is invalid.

### Trigger Slope (Slope)

Slope refers to the signal movement from a low level to a high level (rising slope) or from a high level to a low level (falling slope). When the slope is used as one of the trigger conditions, it is called a trigger slope.


The following trigger slope settings are available for triggering this instrument.

- : An edge is detected when the trigger source changes from a level below the trigger level to a level above the trigger level (rising).
- : An edge is detected when the trigger source changes from a level above the trigger level to a level below the trigger level (falling).
- : This instrument triggers on both rising and falling edges.


### Trigger Level (Level)

The trigger level is the level at which the trigger slope is determined. When the trigger source passes through the trigger level on a rising or falling edge, a trigger occurs.

- You can select a value between 0.0 and  $\pm 100.0\%$ .
- A value of 100% corresponds to half the height of the waveform display. If the zero level of the input signal is set to the center of the vertical axis, 100% corresponds to the top of the waveform display, and  $-100\%$  corresponds to the bottom of the waveform display. The upper and lower limits of the waveform display correspond to three times the voltage or current measurement range of each element when the crest factor is set to CF3 and six times when the crest factor is set to CF6 or CF6A. When scaling is used, the upper and lower limits correspond to three or six times the scaled ranges.
- When Ext Clk is set as the trigger source, the trigger level setting is invalid.



- Measurement range: 100 Vrms when the crest factor is set to CF3.  
50 Vrms when the crest factor is set to CF6 or CF6A.
- Trigger level: 25%




### Trigger Point

The trigger point is the point at which a trigger occurs. The trigger point is always displayed at the left end of the screen.

After the trigger is activated, the waveform display continues from the left of the screen to the right of the screen with the passage of time.

(The arrow below the word "Trigger point" in the figure below is just for illustration. The arrow does not appear on the actual display.)





- To prevent noise-related errors, the trigger feature has a hysteresis of approximately 1% when the crest factor is set to CF3. For example, when the trigger slope is set to  $\uparrow$ , a trigger will occur if the input signal level falls approximately 1% below the trigger level and then passes through the trigger level on a rising edge. The trigger feature has a hysteresis of approximately 2% when the crest factor is set to CF6 or CF6A.
- When integration is in progress or has been stopped, the trigger feature does not function. Therefore, the waveform display start point (the signal level at the left edge of the screen) may not be stable. Also, the numeric data measurement period may not be synchronized with the waveform data measurement period.

## Advanced Waveform Display Settings (Display Settings)


### Display Interpolation (Interpolate)

When there are less than 800 points of sampled data on the time axis, the displayed points (rasters) do not connect with each other. Numbers of sampled points below 800 are said to be within the interpolation range. Display interpolation is a feature that connects the points linearly so that the waveform display is smooth. You can set the interpolation method to one of the settings below.


-  No interpolation is performed. Only the data points are displayed.
-  The spaces between data points are connected with straight lines.

### Outside of the Interpolation Zone

The spaces between vertically aligned dots are filled. If the number of data points is 1602 or greater, this instrument determines the P-P compression values (the maximum and minimum sampled-data values in a given interval), and displays vertical lines (rasters) connecting each pair of maximum and minimum P-P compression values.






### In the Interpolation Zone



### Grid (Graticule)

You can set the window grid to one of the following options.

-  The grid is displayed with dotted lines.
-  The grid frame is displayed.
-  The grid is displayed with a cross hair.

### Turning the Scale Value Display On and Off (Scale Value)

You can select whether to display the following values for each waveform.

- The upper and lower limits of the vertical axis.
- The values at the left and right edges of the horizontal axis (time axis).

### Turning the Display of Waveform Labels On and Off (Wave Label)

Select whether to display waveform labels.

## Waveform Mapping (Wave Mapping)

### Assignment Method (Mode)

You can assign waveforms to windows on the screen. Choose one of the following methods for assigning the waveforms to the windows.

- **Auto**  
The waveforms whose displays are turned on are assigned in order according to their element numbers, with an element's voltage waveform (U) coming first, followed by its current (I), speed, torque, Aux1, and then Aux2 waveform.<sup>1, 2</sup>
- **Fixed**  
Regardless of whether their displays are on or off, waveforms are assigned in order according to their element numbers, with an element's voltage waveform (U) coming before its current waveform (I). The speed and Aux1 waveforms appear in the top window.<sup>1, 2</sup> The torque and Aux2 waveforms appear in the second window from the top.<sup>1, 2</sup>
- **User**  
You can pick which waveforms to assign to which windows, regardless of whether the waveform's displays are on or off. You can set the display position to a number from 0 to 5. Number 0 corresponds to the window at the top of the screen, and the window number increases for each successively lower window.

1 Speed and torque waveforms are available on models with the motor evaluation option.

2 Aux1 and Aux2 waveforms are available on models with the auxiliary input option.

## Display Item (ITEM)

### Displaying All Waveforms (All ON)

The waveforms of all input signals are displayed.

### Displaying No Waveforms (All OFF)

No waveforms are displayed.

### Selecting Which Waveforms to Display (Display ON/OFF)

- You can select whether to display the waveform of each input signal of each element by selecting or clearing the signal's check box. Only the input signals of installed elements appear.
- On models with the motor evaluation option, you can turn the displays of the waveforms of the speed and torque input signals on and off.
- On models with the auxiliary input option, you can turn the displays of the waveforms of the Aux1 and Aux2 input signal on and off.

### Vertical Zoom (Vertical Zoom)


Each displayed waveform can be scaled. You can select one of the following zoom factors:

0.1, 0.2, 0.25, 0.4, 0.5, 0.75, 0.8, 1, 1.14, 1.25, 1.33, 1.41, 1.5, 1.6, 1.77, 2, 2.28, 2.66, 2.83, 3.2, 3.54, 4, 5, 8, 10, 12.5, 16, 20, 25, 40, 50, or 100


## Vertical Position (Vertical Position)

You can vertically shift the displayed position (vertical position) of a waveform. This is useful when you want to view the relationship between voltage and current waveforms, or when the section of the waveform that you want to view does not fit into the display frame.

- You can select a value between 0.000 and  $\pm 130.000\%$ .
- When the zoom factor is set to 1, a value of 100% corresponds to half the height (display range) of the waveform display (which is three times the measurement range when the crest factor is set to CF3 and six times the measurement range when the crest factor is set to CF6 or CF6A). The upper and lower vertical display limits of the screen are 100% and  $-100\%$ .



- As shown in the figure below, when the zoom factor is set to a value other than 1, the upper and lower display limits of the screen do not correspond to three times the measurement range (or to  $\pm 100\%$ ) when the crest factor is set to CF3 and six times the measurement range (or to  $\pm 100\%$ ) when the crest factor is set to CF6 or CF6A. You must take the zoom factor into account when setting a waveform's position. In the figure below, the crest factor is set to CF3, the voltage range is 100 V, the zoom factor is 2, and the vertical position has been shifted by  $-25\%$ . The waveform is shifted by the same amount that it would be if the zoom factor were set to 1 and the vertical position was shifted by  $-50\%$ .



When you want to zoom in on part of a waveform, we recommend that you take the steps below.

- Set the zoom factor to 1.
- Following the instructions in this section for shifting a waveform's vertical position, shift the part of the waveform that you want to view to the center of the display.
- Set the vertical zoom factor.

# 11 Trend Display

## Other Displays (OTHERS)

You can press OTHERS to make the following displays appear.

- Trend display (Trend)
- Bar graph display (Bar)
- Vector display (Vector)
- Split display (with the numeric value display; Numeric+\*\*\*)
- Split display (with the waveform display; Wave+\*\*\*)
- Split display (with the trend display; Trend+\*\*\*)
- High speed data capturing (High Speed Data Capturing)

Each time you press OTHER, the display switches in order between the trend display, the bar graph display (option), the vector display (option), and the split display (the split display that you set previously).\*

\* In the default split display setting, the numeric value display and waveform display are shown.

## Trend Display (Trend)

You can display the trends of measurement functions.


### Trend Display Example

#### Scale Value

The trend number, measurement function, element, and upper limit of the displayed trend

When the display is held, trend values behave the same as numeric values. When the display is un-held, the trend data from when the display was held appears.

#### Waveform label



Time at the left edge of the screen (fixed at 0 seconds)

Time at the right edge of the screen (amount of time contained in the screen)

- The number of data points between the left and right edges of the display.
- "P-P"s indicates that the displayed trend has been P-P compressed.

#### Scale Value

The trend number, measurement function, element, and lower limit of the displayed trend



## Display Format (FORM)

### Number of Trend Display Windows (Format)

You can choose the number of windows from one of the following options:

- Single: No windows
- Dual: Two windows
- Triad: Three windows
- Quad: Four windows

Depending on the number of windows, the number of displayed points in each window changes as described below.

Single: 672 points, Dual: 336 points, Triad: 224 points, Quad: 168 points

When the screen is split, the number of displayed points along the vertical axis of a single window is halved.

### Methods for Assigning Waveforms to Screens

Trends whose displays are turned on are assigned in numeric order (T1 to T16) to the split screens. The assignment method corresponds to the [Auto](#) option in the waveform display.

### Time Axis (Time/div)

The time axis is set in Time/div (time per grid division). The time per division can be set in the range of 3 s to 1 day.

The trend data update interval is determined by the data update interval and the time axis (Time/div). For example, if the data update interval is 50 ms and you set Time/div to 3 s/div, the trend display is updated every 1 s. If you set the data update interval to 10 s and Time/div to 3 s/div, the trend display is updated every 10 s, and the trend data is displayed as a line graph, with each point separated by 10 s. If you set Time/div to 1 day/div, the trend display will be updated once every 1080 s regardless of the data update interval.



---

One division (1 div) on the trend display is equivalent to 80 rasters. For example, if you set Time/div to 1 day/div, one raster is 1080 s (which is equal to 1 day/80), the trend data update interval is 1080 s, and the displayed data is P-P compressed. For information about rasters and P-P compression, see “p-p Compression.”

▶ [Click here.](#)

---

### Restarting Trends (Clear Trend Exec)

When you restart trends, the trend display up to that point is cleared, and the trends start over from the right end of the screen.

In addition to when you execute Clear Trend Exec, trends will also restart when:

- You change a trend display function, element, or harmonic (option) setting.
- You change the trend time axis (horizontal axis) setting.

### Advanced Trend Display Settings (Display Settings)

These are the same as the advanced waveform display settings.

▶ [Click here.](#)



---

All advanced trend display settings are shared with the advanced waveform display settings. If you change the advanced settings in the trend display, the advanced settings in the waveform display also change. For example, if you set the display of the scale values to OFF in the trend display, the display of the scale values will also be set to OFF in the waveform display.

---

## Display Item (ITEM)

### Turning Trend Displays On and Off

#### Display (The upper left of the list)

You can set whether to display (All ON) or hide (All OFF) all trends, from trend 1 (T1) to trend 16 (T16).

#### Trend Numbers (T1 to T16)

You can select whether to display each trend, from trend 1 (T1) to trend 16 (T16), by selecting or clearing its check box.

### Function (Function)

You can select any of the measurement functions listed under “Items That This Instrument Can Measure.”

► [Click here.](#)

### Element (Element/ $\Sigma$ )

- You can select the element/wiring unit from the options below. The available options vary depending on the installed elements.  
Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$
- If there are no elements assigned to a selected wiring unit, because the wiring unit has no data, its trend is displayed at the top or bottom of the screen. For example, if elements are assigned to  $\Sigma A$  but not to  $\Sigma B$ , the trends of measurement functions for  $\Sigma B$  appear at the top or bottom of the screen.

### Order (Order; option)

When you select a function that has harmonic data, you can set the displayed harmonic order within the following range.

Total (Total value) or 0 (DC) to 500

The orders that can be specified vary depending on the measurement function. For details, see “Harmonic Measurement Function Orders.”

► [Click here.](#)

The trends of orders that exceed the maximum measurable order are displayed at the top or bottom of the screen. For information about the maximum measurable harmonic order, see “Maximum Harmonic Order to Be Measured (Max Order).”

► [Click here.](#)



- Trends for which there is no corresponding numeric data are displayed at the top or bottom of the screen.
- If you choose to display the trend of a user-defined event (Ev1 to Ev8), the trend display shows 1 when the user-defined event is occurring and 0 when it is not occurring.

## Trend Display Scale

### Setting the Vertical Scale (Scaling)

You can set the upper and lower limits of a trend window. Set the display mode to one of the options below.

- Auto: The upper and lower limits of the trend window are automatically determined based on the maximum and minimum trend display data values.
- Manual: You can set the upper and lower limits manually.

### Upper and Lower Limits for Manual Scaling (Upper Scale and Lower Scale)

You can set the upper and lower limits within the range of  $-9.9999 T$  to  $9.999 T$ .

---

## 12 Bar Graph Display (Option)


### Bar Graph Display (OTHERS (Bar))

On models with the harmonic measurement option or the simultaneous dual harmonic measurement option, you can display harmonics using bar graphs. The harmonic orders are lined up on the horizontal axis, and the vertical axis represents the amplitude of each harmonic.

You can configure three different bar graphs.

#### Bar Graph Display Example

The bar graph number, measurement function, element, and upper limit of the displayed bar graph



The bar graph number, measurement function, element, and lower limit of the displayed bar graph



- When logarithmic coordinates are used (Log Scale), if a value is negative, its absolute value is displayed with a red bar graph.
- If the analysis window width (number of cycles of the fundamental signal) that is determined by the fundamental frequency is shorter than the data update interval, bar graphs are not displayed. Set a longer data update interval. For details, see “Notes about the Numeric Data Display.”  
▶ [Click here.](#)
- The bar graphs of harmonic orders that exceed the maximum measurable order are not displayed. For information about the maximum measurable harmonic order, see “Maximum Harmonic Order to Be Measured (Max Order).”  
▶ [Click here.](#)

---

## Display Format (FORM)

### Number of Bar Graph Display Windows (Format)

You can choose the number of windows from one of the following options:

- Single: No windows. The data of bar graph (Item No.) 1 is displayed.
- Dual: Two windows. The data of bar graphs (Item No.) 1 and 2 is displayed.
- Triad: Three windows. The data of bar graphs (Item No.) 1 to 3 is displayed.

**Bar Graph Display Range (Start Order/End Order)**

- You can configure the range of harmonic orders to show in a bar graph.
- The range is the same for bar graphs 1 to 3.

**Starting Harmonic Order (Start Order)**

- You can select a value between 0 and 490. However, the starting harmonic order cannot be more than 10 orders less than the ending order.
- When the measurement function of a bar graph is  $\Phi$ , order 0 has no values, so you cannot display it in the bar graph.
- When the measurement function of a bar graph is  $\Phi U$  or  $\Phi I$ , orders 0 and 1 have no values, so you cannot display them in the bar graph.

**Ending Harmonic Order (End Order)**

You can select a value between 10 and 500. However, the ending harmonic order cannot be more than 10 orders greater than the starting order. You cannot display bar graphs containing harmonic orders that are greater than the maximum measurable order (see section 6.6 in the getting started guide, IM WT1801E-03EN).

## Display Item (ITEM)

**Bar Graph Number (Item No.)**

Select the number, from 1 to 3, of the bar graph that you want to select.

**Function (Function)**

You can select the measurement function to display from the following options.

U, I, P, S, Q,  $\lambda$ ,  $\Phi$ ,  $\Phi U$ ,  $\Phi I$ , Z, Rs, Xs, Rp, and Xp

**Element (Element)**

You can select the element from the following options. The available options vary depending on the installed elements.

Element1, Element2, Element3, Element4, Element5, and Element6

**Bar Graph Display Scale****Setting the Vertical Scale Mode (Scale Mode)**

You can set the upper and lower limits of a bar graph window. Set the display mode to one of the options below.

- Fixed
  - When the function is U, I, P, S, or Q, the scaling is logarithmic (Log).
  - When the function is  $\lambda$ ,  $\Phi$ ,  $\Phi U$ ,  $\Phi I$ , Z, Rs, Xs, Rp, or Xp, the scaling is linear (Linear).
  - The upper and lower limits of the bar graph window are automatically determined based on the maximum and minimum displayed trend data values. The lower and upper limits for  $\lambda$  are  $-1$  and  $1$ . For  $\Phi$ ,  $\Phi U$ , and  $\Phi I$ , the minimum and maximum values are  $-180$  to  $180^\circ$ . Negative values correspond to phase lagging and positive values correspond to phase leading.
- Manual

You can set the type, upper limit, and X-axis position of the vertical scale.

**Vertical Scale Type (Vertical Scale)**

This setting is valid when the vertical scale mode is set to Manual. You can set the scale type to linear (Linear) or logarithmic (Log).

**Upper Limit (Upper Scale)**

This setting is valid when the vertical scale mode is set to Manual. You can set the upper limit to a value from 0 to 9.999 T.

**X-Axis Position (X Axis Position)**

This setting is valid when you set the vertical scale mode to Manual and the vertical scale type to Linear. You can set the point at which the Y-axis coordinate is 0 to Bottom (the bottom of the screen) or Center (the center of the screen).

## 13 Vector Display (Option)


### Vector Display (OTHERS (Vector))

On models with the harmonic measurement option or the simultaneous dual harmonic measurement option, you can select a wiring unit to display vectors of the phase differences and amplitudes (rms values) of the fundamental signals, U(1) and I(1), in each element in the unit. The positive vertical axis is set to zero (angle zero), and the vector of each input signal is displayed.

#### Vector Display Example

For a 3P3W system with a three-voltage, three-current method

- U1(1), U2(1), and U3(1) are line voltages.
- I1(1), I2(1), and I3(1) are line currents.




For a 3P4W (three-phase, four-wire system)

- U1(1), U2(1), and U3(1) are line voltages.
- I1(1), I2(1), and I3(1) are line currents.

For a 3P3W (three-phase, three-wire system)

- U1(1), U2(1), and U3(1) are line voltages.
- I1(1), I2(1), and I3(1) are line currents.

However, U3(1) and I3(1) are not actually measured for the 3P3W system. The vectors are displayed through computation.



If the analysis window width (number of cycles of the fundamental signal) that is determined by the fundamental frequency is shorter than the data update interval, vectors are not displayed. Set a longer data update interval. For details, see “Notes about the Numeric Data Display.”

► [Click here.](#)

## Display Format (FORM)

### Number of Vector Display Windows (Format)

You can choose the number of windows from one of the following options:

- Single: No windows. The data of vector (Item No.) 1 is displayed.
- Dual: Two windows. The data of vectors (Item No.) 1 and 2 is displayed. However, in the split display, the data of vector 1 is displayed.

### Turning the Display of Numeric Data On and Off (Numeric)

You can select whether to show (ON) or hide (OFF) numeric data. You can display the size of each signal and the phase differences between signals. For information about phase difference display formats, see “Phase Difference Display Formats.”

▶ [Click here.](#)

## Display Item (ITEM)

### Vector Number (Item No.)

Select the vector you want to set: 1 or 2.

### Element or Wiring Unit (Object)

You can select the element or wiring unit to display from the options below. The available options vary depending on the installed elements.

Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$

### Setting Vector Zoom Factors (U Mag/I Mag)

You can change the sizes of the vectors. You can specify separate zoom factors for the fundamental waves U(1) and I(1). When you zoom a vector, the value for the size of the peripheral circle of the vector changes according to the zoom factor.

#### Setting the Zoom Factor of the Vector of Fundamental Waveform U (1) (U Mag)

You can set the zoom factor to a value between 0.100 and 100.000.

#### Setting the Zoom Factor of the Vector of Fundamental Waveform I (1) (I Mag)

You can set the zoom factor to a value between 0.100 and 100.000.



---

If the zoom factor is too large, the vector will exceed the display range and will not be displayed properly. Reduce the zoom factor so that the vector is displayed within the display range.

---

---

## 14 Split Display

### Split Display (OTHERS)

You can split the screen into top and bottom halves, and select a display to show in each half. You can select the following items.

- Split displays with the numeric display (Numeric+\*\*\*)
- Split displays with the waveform display (Wave+\*\*\*)
- Split displays with the trend display (Trend+\*\*\*)

### Split Displays with the Numeric Display (Numeric+\*\*\*)

Numeric data is displayed in the top half of the screen. Select the display to show in the bottom half of the screen from the following options.

- Wave: Waveform
- Trend: Trend
- Bar: Bar graph\*
- Vector: Vector\*

\* This item is available on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

### Split Displays with the Waveform Display (Wave+\*\*\*)

Waveforms are displayed in the top half of the screen. Select the display to show in the bottom half of the screen from the following options.

- Numeric: Numeric data
- Trend: Trend
- Bar: Bar graph\*
- Vector: Vector\*

\* This item is available on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

### Split Displays with the Trend Display (Trend+\*\*\*)

Trends are displayed in the top half of the screen. Select the display to show in the bottom half of the screen from the following options.

- Numeric: Numeric data
- Wave: Waveform
- Bar: Bar graph\*
- Vector: Vector\*

\* This item is available on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.



---

When the setup parameter list is displayed (the INPUT INFO key is lit), it appears in the top half of the screen, and the display that you assigned in the Others menu to the top window in the split display is displayed in the bottom half of the screen.

---

### Split Display Settings


Press FORM to switch between the FORM menus of the display that you assigned to the top half of the screen in the split display and the display that you assigned to the bottom half of the screen in the split display. Likewise, press ITEM to switch between ITEM menus.

## 15 Cursor Measurement

### Cursor Measurement (CURSOR)

You can place cursors on displayed waveforms, trends, and bar graphs and display the values at the cursor locations.

Example of cursors in the waveform display



You can set the following items.

- [Turning Cursor measurement on and off \(Cursor\)](#)
- [Waveform measured by cursor 1 \(C1+ Trace\)](#)
- [Waveform measured by cursor 2 \(C2x Trace\)](#)
- [Cursor path \(Cursor Path\)](#)
- [Position of cursor 1 \(C1+ Position\)](#)
- [Position of cursor 2 \(C2x Position\)](#)
- [Linking cursor movement \(Linkage\)](#)

### Turning Cursor Measurement On and Off (Cursor)

- ON: Cursor measurement is performed.
- OFF: Cursor measurement is not performed.

### Waveform Measured by Cursor 1 (+; C1+ Trace)

This item only appears in the waveform and trend displays. It does not appear in the bar graph display.

#### In the Waveform Display

You can select the waveform to measure with cursor 1 (+) from the following options. The available options vary depending on the installed elements.

U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Speed, Torque, Aux1, and Aux2<sup>1, 2</sup>

1 Speed and torque waveforms are available on models with the motor evaluation option.

2 Aux1 and Aux2 waveforms are available on models with the auxiliary input option.

#### In the Trend Display

You can set the trend to measure with cursor 1 (+) to a trend from T1 to T16.

### Waveform Measured by Cursor 2 (x; C2x Trace)

You can select the waveform to measure with cursor 2 (x). The options are the same as those for cursor 1 (+; C1+ Trace).

► [Click here.](#)



## Cursor Path (Cursor Path)

Because this instrument uses [P-P compression](#) on sampled data, two values (a maximum and a minimum value) are displayed at each time-axis point. You can choose the path that the cursors move through and the data points that are measured by the cursors from one of the options below.

- Max: Cursors move along and measure the maximum values on the time axis.
- Min: Cursors move along and measure the minimum values on the time axis.
- Mid: Cursors move through the middles of the maximum and minimum values on the time axis, and they measure the values in the middle of the maximum and minimum values.

This item only appears in the waveform display. It does not appear in the trend or bar graph display.

## Position of Cursor 1 (+; C1+ Position)

Set the position of cursor 1 (+) to a value within one of the following ranges.

- Waveform display: 0 (the left edge of the screen) to 800 (the right edge of the screen)
- Trend display: 0 (the left edge of the screen) to 1601 (the right edge of the screen)
- Bar graph display: 0 (DC) to 500 (the 500th order)

## Position of Cursor 2 (x; C2x Position)

Set the position of cursor 2 (x). The ranges within which you can set the position are the same as those for cursor 1 (+; C1+ Position).

► [Click here.](#)

## Linking Cursor Movement (Linkage)

Set Linkage to ON to move cursor 1 (+) and cursor 2 (x) without changing the distance between them. Set the positions of the cursors by setting C1+Position.

## Measured Items

### In the Waveform Display

Y+	The vertical-axis (Y-axis) value of cursor 1 (+)
Yx	The vertical-axis (Y-axis) value of cursor 2 (x)
$\Delta Y$	The difference between the vertical-axis (Y-axis) values of cursor 1 (+) and cursor 2 (x)
X+	The horizontal-axis (X-axis) value of cursor 1 (+)
Xx	The horizontal-axis (X-axis) value of cursor 2 (x)
$\Delta X$	The difference between the horizontal-axis (X-axis) values of cursor 1 (+) and cursor 2 (x)
$1/\Delta X$	The reciprocal of the difference between the horizontal-axis (X-axis) values of cursor 1 (+) and cursor 2 (x)

## In the Trend Display

---

Y+	The vertical-axis (Y-axis) value of cursor 1 (+)
Yx	The vertical-axis (Y-axis) value of cursor 2 (x)
$\Delta Y$	The difference between the vertical-axis (Y-axis) values of cursor 1 (+) and cursor 2 (x)
X+	The horizontal-axis (X-axis) value of cursor 1 (+) With the left edge of the screen being 0 seconds, the time from the left edge of the screen is indicated.
Xx	The horizontal-axis (X-axis) value of cursor 2 (x) With the left edge of the screen being 0 seconds, the time from the left edge of the screen is indicated.
$\Delta X$	The difference between the horizontal-axis (X-axis) values of cursor 1 (+) and cursor 2 (x)
D+	The date and time at the position of cursor 1 (+) The date and time of measurement are displayed in this format: Year/ Month/Day Hour:Minute:Second.
Dx	The date and time at the position of cursor 2 (x) The date and time of measurement are displayed in this format: Year/ Month/Day Hour:Minute:Second.

---



- If immeasurable data exists, "\*\*\*\*" is displayed in the measured value display area.
  - $\Delta Y$  can be measured even when the units of the cursors are different. The measured result will not have a unit.
- 

## In the Bar Graph Display

---

Y1+	The vertical-axis (Y-axis) value of cursor 1 (+) of bar graph 1
Y1x	The vertical-axis (Y-axis) value of cursor 2 (x) of bar graph 1
$\Delta Y1$	The difference between the vertical-axis (Y-axis) values of cursor 1 (+) and cursor 2 (x) of bar graph 1
Y2+	The vertical-axis (Y-axis) value of cursor 1 (+) of bar graph 2
Y2x	The vertical-axis (Y-axis) value of cursor 2 (x) of bar graph 2
$\Delta Y2$	The difference between the vertical-axis (Y-axis) values of cursor 1 (+) and cursor 2 (x) of bar graph 2
Y3+	The vertical-axis (Y-axis) value of cursor 1 (+) of bar graph 3
Y3x	The vertical-axis (Y-axis) value of cursor 2 (x) of bar graph 3
$\Delta Y3$	The difference between the vertical-axis (Y-axis) values of cursor 1 (+) and cursor 2 (x) of bar graph 3

---

## Cursor Movement

### In the Waveform Display

- Cursors move along the selected waveform.
- The unit of cursor movement is the amount of time contained in one screen  $\div$  800.



- 
- If immeasurable data exists, "\*\*\*\*" is displayed in the measured value display area.
  - $\Delta Y$  can be measured even when the units of the cursors are different. The measured result will not have a unit.
  - The range of the vertical axis that can be measured using cursors is within  $\pm 300\%$  when the crest factor is set to CF3 and within  $\pm 600\%$  when the crest factor is set to CF6 or CF6A.
- 

### In the Trend Display

- Cursors move along the selected trend.
- You can set the cursor position relative to the left edge of the screen in points, with the left edge itself being 0 points and the right edge being 1601 points.
- You can move through the displayed data one point at a time.

### In the Bar Graph Display

- Two cursors (+ and x) are displayed in each graph (Graph1 to Graph3).
- You can set the cursor positions as orders.
- The bar graph display indicates what harmonic order each cursor is located in. For example:
  - The location of cursor 1 (+) is indicated in this format: "Order+:2."
  - The location of cursor 2 (x) is indicated in this format: "Orderx:55."
- The orders indicating the locations of cursors 1 (+) and 2 (x) are the same for each bar graph, from 1 to 3.



---

If immeasurable data exists, "\*\*\*\*" is displayed in the measured value display area.

---

## 16 High Speed Data Capturing


## High Speed Data Capturing (OTHERS(High Speed Data Capturing))

This Instrument can measure every 5 ms and save the measured data to a file. Also, you can synchronize this instrument with another device during measurement by applying an external sync signal to the external start signal I/O (MEAS START) connector.

High speed data capturing takes advantage of the fact that in a balanced three-phase circuit, the instantaneous values of the three phases of the rms voltage ( $U_{rms\Sigma}$ ), the rms current ( $I_{rms\Sigma}$ ), and the power ( $P\Sigma$ ) add up to a direct current. For a three-phase, three-wire system or three-phase, four-wire system, this instrument can measure the rms voltage ( $U_{rms\Sigma}$ ), the rms current ( $I_{rms\Sigma}$ ), and the power ( $P\Sigma$ ) at a high response speed. In an unbalanced three-phase circuit, the measured values fluctuate. This indicates that the power consumed by the load varies instantaneously.

When the measured values fluctuate, you can stabilize the measured voltage (U), current (I), and power (P) values for each element and the measured  $U_{mean\Sigma}$ ,  $I_{mean\Sigma}$ ,  $U_{r-mean\Sigma}$ , and  $I_{r-mean\Sigma}$  values for each wiring unit by setting a low cutoff frequency for the HS filter. However, if you set a low cutoff frequency for the HS filter, the response to changes in the measured values becomes slower.

## Display Indications for High Speed Data Capturing



## High Speed Data Capturing State


- **Ready**

- “Ready” appears when high speed data capturing has been reset and this instrument is ready to begin high speed data capturing.
- When the number of data captures has been set to a value other than Infinite, the number of data captures appears to the right of Count.



- **Start**

- “Start” appears when high speed data capturing has been started.
- The number of data captures that have been performed appears to the right of “Captured.”



- **Init(Initialize)**

- “Init” appears when high speed data capturing is being initialized.
- A bar appears that indicates the initialization progress.
- The time remaining for the initialization appears to the right of “Remaining.”




### File Recording State

This indication appears when you set [Record to File](#) to ON.

- **Ready**

- “Ready” appears when recording to a file is possible and this instrument is ready to begin high speed data capturing.
- Ready appears when you stop high speed data capturing and all processing for recording to a file finishes.



- **Rec(Record)**

- “Rec” appears when this instrument has begun recording to a file and while this instrument is regularly recording data.
- The name of the file that is being recorded to appears to the right of “Name.”



- **Stop**

“Stop” appears when this instrument has finished recording to a file and when recording to a file is stopped.

- **Error**

- When a write error occurs while this instrument is recording to a file, this instrument stops recording to the file, and “Error” appears.
- The measurement operations for high speed data capturing continue without stopping.

### Initializing High Speed Data Capturing

- High speed data capturing is initialized when:
  - You switch from normal measurement to high speed data capturing.
  - You change one of the following settings.
    - [A voltage or current measurement mode](#)
    - Whether the [HS filter](#) is on or off
    - The HS filter's cutoff frequency
    - [Trigger](#)
    - [Fundamental measurement conditions](#) such as the measurement range and wiring system.
- The time required for initialization is as indicated below. For example, when the cutoff frequency is 1 Hz, the time required for initialization is approximately 2.7 s.

$$\frac{2.7}{\text{The HS filter's cutoff frequency}} \text{ [s]}$$

However, when the above formula results in a value of 250 ms or less, the time required for initialization is 250 ms.

### Measurement Functions

For the symbols and meanings of the measurement functions that you can measure using high speed data capturing, see "High Speed Data Capturing Measurement Functions" under "Items That This Instrument Can Measure."

► [Click here.](#)

## Data Capturing Interval

The interval at which data is captured varies as shown below depending on how [External Sync](#) is set.

- When External Sync is set to OFF: 5 ms
- When External Sync is set to ON: The interval at which data is captured depends on the sync signal that is applied to the external start signal I/O (MEAS START) connector. This instrument can sync with a signal whose period is 1 ms to 100 ms.

## Display Update Rate

The display update rate is approximately 1 s.

## Numeric Data Display

The numeric data for each measurement function that was last measured within the display update interval is displayed.

You cannot make individual changes to the displayed measurement functions. Use the PAGE UP and PAGE DOWN keys to change the display.

The number of pages varies as indicated below depending on the installed options.

Motor Evaluation Function	External Signal Input	Number of Pages
Not installed	Not installed	2 pages
Installed	Not installed	4 pages
Not installed	Installed	4 pages



- If the measured value exceeds 300%, “-OL-” (for over range) is displayed for U or I. When you are measuring with the highest measurement range, if the measured value exceeds 140%, “-OL-” (for over range) is displayed for U or I.
- If the measured value for the voltage or current is over range, “-OL-” (for over range) is displayed for P.
- “-OL-” (for over range) is displayed for  $U\Sigma$  if even one of the measured voltage values for an input element in a single wiring unit is over range. The same is true for  $I\Sigma$  and  $P\Sigma$ .
- When the Rounding to Zero is on,  $U\Sigma$  and  $I\Sigma$  are displayed as zero when they are the following percentage of the maximum voltage range or current range out of the input elements assigned to the same wiring unit.
  - When the Crest Factor Is Set to CF3  
0.3% or less for Urms and Irms. 2% or less for Umn, Urmn, Imn, and Irmn.
  - When the Crest Factor Is Set to CF6 or CF6A  
0.6% or less for Urms and Irms. 4% or less for Umn, Urmn, Imn, and Irmn.

## Fundamental Measurement Conditions

All the settings for the [fundamental measurement conditions](#) for high speed data capturing are the same as those for normal measurement.

However, the following limitations apply to the wiring system and line filter.

### Wiring System during High Speed Data Capturing

- When the [wiring system](#) is set to one of the following settings, you can measure the voltage (U), current (I), and power (P).
  - 1P2W: Single-phase, two-wire system (DC signal)
  - 3P4W: Three-phase, four-wire system
  - 3P3W (3V3A): Three-voltage, three-current method
- When the wiring system is set to one of the following settings, the voltage ( $U\Sigma$ ), current ( $I\Sigma$ ), and power ( $P\Sigma$ ) for the wiring unit are not measured and are displayed as “-----” (no data). When the wiring system is being set or high speed data capturing has been started, an error message appears.
  - 1P3W: Single-phase, three-wire system
  - 3P3W: Three-phase, three-wire system

**Line Filter for High Speed Data Capturing**

- You can also set a [line filter](#) for high speed data capturing. The setting is not shared with normal measurement. Even if you change the line filter setting during high speed data capturing, the line filter setting for normal measurement will remain unchanged.
- In high speed data capturing, the line filter is always on. You cannot select OFF. The LINE FILTER key and the Line Filter indicator at the top of the screen illuminate.
- You can set the cutoff frequency within the following range. For normal measurement, you can select 1 MHz, but you cannot select 1 MHz for high speed data capturing.  
0.1 kHz to 100.0 kHz (in 0.1 kHz steps), 300 kHz

**Limitations on Setting Changes during High Speed Data Capturing**

During high speed data capturing, there are some settings that you cannot change and functions that you cannot execute. For details, see appendix 10 in the getting started guide, IM WT1801E-03EN.

## High Speed Data Capturing (HS) Settings (FORM)

The high speed data capturing (HS) settings are listed below.

- [Number of data captures \(Capture Count\)](#)
- [Viewing and optimizing the maximum capturing count \(Optimize Count\)](#)
- [Capture control settings \(Control Settings\)](#)
- [Recording to a file \(Record to File\)](#)
- [Starting and stopping high speed data capturing \(Start/Stop\)](#)

### Number of Data Captures (Capture Count)

The number of captures can be set to infinity or to a value from 1 to 10000000.

### Viewing and Optimizing the Maximum Capturing Count (Optimize Count)

- This instrument computes the maximum capturing count for the save destination of the captured data file according to the number of numeric data items specified in [Item Settings](#).
- You can set the capturing count to a value from 0 to the computed maximum capturing count.
- If you select Set, the maximum capturing count is set to the number of data captures. However, you cannot do this if the current number of data captures is 0.
- This setting is not valid when [Record to File](#) is set to OFF.



- If you enable automatic CSV conversion (Auto CSV Conversion) and set the storage destination for the high speed data capturing files to a USB memory device, the maximum capturing count is computed with approximately 20% of the available USB memory designated as valid for the high speed data capturing files (\*.WTS and \*.HDS files).
  - When the maximum capturing count is displayed as 0, the save destination device for the high speed data capturing file does not have enough free space. Make more space available, by deleting files for example.
  - If you change the number of numeric data items specified in [Item Settings](#) after you set the number of data captures, the maximum capturing count will change, and you will need to set the number of data captures again.
-

## Capture Control Settings (Control Settings)

### Voltage and Current Measurement Modes (U/I Measuring Mode)

Select the modes for measuring voltage and current.

#### Setting

Select the method for setting the voltage and current measurement modes from the following options.


- Each: Set the mode separately for the voltage and current of each input element.
- All: Set the mode for the voltages and currents of all installed input elements at the same time.

#### U1 to I6

Select the voltage and current measurement modes from the following options.

rms, mean, dc, r-mean

For details about how the voltage and current values are determined in each measurement mode, see appendix 1 in the getting started guide, IM WT1801E-03EN.



If the voltage and current measurement mode settings differ for elements assigned to the same wiring unit, the voltage (UΣ) and current (IΣ) of the wiring unit are not measured and are displayed as "-----" (no data).

### HS Filter (HS Filter)

Turning on the HS (high speed) filter stabilizes the measured values. The HS filter averages the measured values. The HS filter is different from the [line filter](#).

Set whether to enable the HS filter, and set the cutoff frequency. You can set the cutoff frequency within the following range.

1 Hz to 1000 Hz (in 1 Hz steps)

Selecting OFF disables the HS filter.



You can stabilize the measured voltage (U), current (I), and power (P) values for each element and the measured UmeanΣ, ImeanΣ, Ur-meanΣ, and Ir-meanΣ values for each wiring unit by specifying a low cutoff frequency for the HS filter. However, the response to changes in the measurement data becomes slower.



### Trigger (Trigger Settings)

The trigger is what starts high speed data capturing. The act of starting high speed data capturing when the trigger conditions are met is referred to as “triggering.”



---

All the trigger settings for high speed data capturing are shared with those for displaying waveforms. If you change these settings in the menu for high speed data capturing, the waveform display trigger settings will also change. For example, if you set the trigger mode to off in the high speed data capturing menu, the trigger mode for waveform display will also be set to OFF.

---

#### Trigger Mode (Mode)

This setting is the same as the waveform display trigger mode setting.

▶ [Click here.](#)

#### Trigger Source (Source)

This setting is the same as the waveform display trigger source setting.

▶ [Click here.](#)

#### Trigger Slope (Slope)

This setting is the same as the waveform display trigger slope setting.

▶ [Click here.](#)

#### Trigger Level (Level)

This setting is the same as the waveform display trigger level setting.

▶ [Click here.](#)

### External Sync (External Sync)

You can synchronize this instrument with another device during measurement by applying an external sync signal to the external start signal I/O (MEAS START) connector.

- OFF: This instrument does not synchronize with an external start signal but instead captures data every 5 ms.
- ON: This instrument captures data in sync with an external start signal.

For the specifications of the external start signal I/O connector, see section 4.4 in the getting started guide, IM WT1801E-03EN.



- 
- When External Sync is set to ON, the trigger settings are invalid. The trigger feature operates as if the trigger mode was set to OFF.
  - To measure in sync with an external signal, set External Sync to ON and apply a number of pulses equal to or greater than the specified number of data captures + 1 to the external start signal I/O (MEAS START) connector.
  - To synchronize multiple these instruments and perform high speed data capturing, synchronize the instrument on which External Sync has been set to ON to the instrument on which External Sync has been set to OFF. When you synchronize these instruments, make sure that they are set to the same number of data captures.
-

## Recording to a File (Record to File)

- If you set Record to File to ON, when high speed data capturing starts, this instrument saves the following two files in binary format.
  - High speed data capturing data file (.WTS): The measured data is saved to this file.
  - High speed data capturing header file (.HDS): The measurement conditions, settings, and recording information are saved to this file.
- File name extensions are added automatically.
- The [file recording state](#) (File State) appears in the upper left of the screen. The file recording state appears as "Ready," "Rec," "Stop," or "Error," depending on the state of high speed data capturing.
- If you set the save destination to a USB memory device, a high speed data capturing data file (.WTS) can contain up to 1 GB of data or 10,000,000 data captures.
- This instrument cannot load the measurement data that has been recorded on a file.



- Under the following circumstances, recording to a file stops, and the file recording state changes to Stop. The measurement operations for high speed data capturing continue without stopping.
  - When the file save destination runs out of free space.
  - When the size of the high speed data capturing data file exceeds the maximum value (1 GB).
  - When high speed data capturing is performed 10,000,000 times.
- Do not output captured data through communication and record it to a file at the same time. Doing so can lead to a reduction in the communication output speed and a reduction in the recording speed, can cause recording to a file to stop, and can make the file recording state change to Error.
- In the following circumstances, it is possible for the data update speed to surpass the speed at which the file is being recorded to, for recording to the file to stop, and for the file recording state to change to Error.
  - When you perform consecutive operations in the setup menu.
  - When this instrument receives consecutive communication commands.
  - When you operate this instrument over FTP.
  - When you save to a USB memory device with a slow write speed.
- When the write speed to the USB memory device that has been specified as the save destination is slow, the data update speed exceeds the speed at which the file is being recorded to, and recording to the file stops, you may be able to remedy the situation by using the methods described below.
  - Reduce the number of items that are being saved.
  - Using a faster USB memory device.
- When it takes a long time for data to be written to the USB memory device, recording to the file may be stopped forcefully, and some data may not be saved. When this happens, the file state indication is "Error."
- Conversion to ASCII format (.csv) uses a pair of files that consists of a high speed data capturing data file (.wts) and a high speed data capturing header file (.hds) with the same name. Do not change the names of high speed data capturing data files (.wts) and high speed data capturing header files (.hds) for different sets of data to the same name. If you do so, this instrument may malfunction and the USB memory may be damaged when you convert the data to ASCII format (.csv).
- If you disconnect a USB memory device while a file is being recorded to and the file recording state changes to Error, the high speed data capturing file may be incomplete or damaged. If this is the case, you will not be able to convert the data to ASCII format (.csv). Be sure to only disconnect the USB memory device when the file recording state is Ready.
- When you turn off this instrument power, the contents of the internal RAM disk are lost. Save the contents of the RAM disk to a USB memory device or network drive before you turn off this instrument.
- Please be aware that the number of times that you can write to USB memory is limited.

## Save Conditions (File Settings)

### File List Display and Save Destination Settings (File List)

On the file list, specify the save destination for the measured data. You can set the storage medium to the internal RAM disk or to a USB memory device. You cannot set the storage medium to a network drive. For information about how to configure the file list display and how to operate files and folders, see “File Operations (Utility).”

▶ [Click here.](#)



---

If you set the storage medium to a USB memory device, when you remove the USB memory device, the storage medium automatically changes to the internal RAM disk.

---

### Automatic CSV Conversion (Auto CSV Conversion)

You can choose whether to automatically create an ASCII format high speed data capturing file (.csv) from the high speed data capturing data file (.wts) and the high speed data capturing header file (.hds) that are saved when high speed data capturing stops.

- When the storage destination is the internal RAM disk ([RAM-0])  
A CSV file is created in the root folder of the USB memory device whose ID number is 0 ([USB-0]). An error message appears when USB memory is not connected.
- When the storage destination is a USB memory device ([USB-0] or [USB-1])  
A CSV file is saved in the same folder as the high speed data capturing data file.



---

This instrument will not create a CSV file whose size exceeds 2 GB but will instead create a CSV file for 2 GB worth of captured data. To convert the data into a CSV file whose size exceeds 2 GB, use the file reader software available from the following Yokogawa webpage.

<http://tmi.yokogawa.com/>

---

### Saved Items (Item Settings)

Select whether to store a numeric data item by selecting or clearing its check box.



---

Items for which there is no measurement data are displayed as “-----” (no data), and no data is saved for them.

---

### Automatic File Naming (Auto Naming)

This is the same as the auto naming feature for saving and loading data.

▶ [Click here.](#)

### File Name (File Name)

This is the same as the file name setting for saving and loading data.

▶ [Click here.](#)

### Comment (Comment)

This is the same as the comment setting for saving and loading data.

▶ [Click here.](#)

### Manually Converting to CSV Format (CSV Convert)

You can convert the selected high speed data capturing data to ASCII format (.csv). This menu item appears when you press File List to display the file list.

- When you convert high speed data capturing data on the internal RAM disk ([RAM-0])  
A CSV file is created in the root folder of the USB memory device whose ID number is 0 ([USB-0]). An error message appears when USB memory is not connected.
- When you convert high speed data capturing data on a USB memory device ([USB-0] or [USB-1])  
A CSV file is saved in the same folder as the high speed data capturing data file that is being converted.

## Starting and Stopping High Speed Data Capturing (Start/Stop)

### Starting High Speed Data Capturing (Start)

- High speed data capturing starts.
- When high speed data capturing starts, the following operations are performed.
  - If the trigger mode is set to OFF, data is captured.
  - If the trigger mode is set to Auto or Normal, this instrument waits for a trigger to occur. When a trigger occurs, this instrument begins capturing data.
  - "HS State: Start" appears in the upper right of the screen.
  - When recording to a file is enabled, this instrument creates a high speed data capturing data file (.WTS) and a high speed data capturing header file (.HDS). "File State: Rec" and the file name appear in the upper left of the screen.



While "File State: Rec" is displayed, the storage medium is constantly being accessed, even though the icon that indicates this is not displayed, so do not remove the USB memory device or turn off the power. Doing so may damage the storage medium and corrupt its data.

### Stopping High Speed Data Capturing (Stop)

- High speed data capturing stops.
- When high speed data capturing stops, the following operations are performed.
  - "HS State: Ready" appears in the upper right of the screen.
  - When recording to a file is enabled, this instrument finishes writing to the high speed data capturing data file (.WTS) and high speed data capturing header file (.HDS) and closes them. "File State: Ready" appears in the upper left of the screen.
  - When recording to a file and automatic CSV conversion are enabled, this instrument creates an ASCII format high speed data capturing file (.CSV).

### Automatically Stopping High Speed Data Capturing


- After the specified number of high speed data captures have been made, high speed data capturing automatically stops.
- The same operations are performed as those listed above for when high speed data capturing stops.



- When External Sync is set to ON and the following conditions regarding the external start signal applied to this instrument are met, high speed data capturing automatically stops.
  - When the external start signal is not applied for 1 s or longer.
  - When the period of the external start signal is less than 1 ms.

## High Speed Data Capturing Operations

Examples for when the trigger mode is Auto or Normal.



## Display Items (ITEM)

### Number of Columns (Column Num)

You can select four or six columns.

### Column Number (Column No.)

Select the number of the column that you want to configure.

### Element (Element/ $\Sigma$ )

This is the same as the element (Element/ $\Sigma$ ) item in the Matrix display.

► [Click here.](#)

### Directly Selecting Elements (ELEMENT)

This is the same as direct element selection in the 4-, 8-, and 16-value displays.

► [Click here.](#)

### Resetting the Settings (Reset Items Exec)

Reset the column settings.

### Turning the Display Frame On and Off (Display Frame)

This is the same as turning the display frame on and off in the 4-, 8-, and 16-value displays.

► [Click here.](#)


### Displaying Peak Over-Range Occurrence Information (Display Peak Over Status)

You can select whether to show (ON) or hide (OFF) peak over-range occurrence information.

#### Peak Over-Range Occurrence Information (Peak Over Status)

- If a peak over-range occurs in an input signal even once from the time when high speed data capturing starts until it stops, the input signal is displayed in red.

Display example for when a peak over-range has occurred in U1 and I2.



- When display frames for measured values are displayed, display frames of measured values within which a peak over-range has occurred are displayed in red.
- Even if you stop high speed data capturing, the peak over-range occurrence information does not disappear. The peak over-range occurrence information will disappear (be reset) when after you stop high speed data capturing, you restart high speed data capturing or change the settings.



The input peak over-range indicator in the center of the top section of the screen lights in red when a peak over-range occurs.

## 17 Data Storage

You can store numeric data in binary format to the internal RAM disk or a USB memory device. You can store the data at the data update interval or at a specified time interval (if the waveform display is enabled and the trigger mode is set to Auto or Normal, the data update interval depends on the trigger operation). You can convert stored binary data to ASCII (.csv) format. You can analyze the converted data on a PC. You cannot use this instrument to recall stored data.

### Storage-Related Display Indications

When the storage state is any state other than that of being reset, the storage state and store count appear in the upper left of the screen.

Store state	Storage count
Store: Stop	100

#### Start

Storage has been started.

#### Stop

Storage has been stopped.

#### Ready

The storage mode is real-time storage mode, integration-synchronized storage mode, or event-synchronized storage mode, and this instrument is ready to begin storing.

#### Cmpl (Complete)

- This instrument has completed the specified number of storage operations.
- This instrument is in real-time storage mode and the scheduled storage stop time has passed.

When storage is reset, no storage state is displayed in the upper left of the screen.

### Limitations on Changing the Settings during Storage

While data is being stored, there are some settings that you cannot change and functions that you cannot execute. For details, see appendix 9 in the getting started guide, IM WT1801E-03EN.

### Storage Conditions (STORE SET)

The following storage configuration menus are available.

- [Storage control \(Control Settings\)](#)
- [Stored items \(Item Settings\)](#)
- [Save conditions \(File Settings\)](#)

## Storage Control (Control Settings)

### Storage Mode (Store Mode)

You can choose from one of the following methods for starting and stopping storage.

- **Manual (Manual storage mode)**

When you press STORE START, numeric data is stored at the storage interval for the number of times specified by the storage count.

- **Real Time (Real-time storage mode)**

Storage starts after you press STORE START and the scheduled storage start time is reached. You can store numeric data at the storage interval until the storage stop time (or just the storage count) is reached.

- **Integ Sync (Integration-synchronized storage mode)**

- Storage starts after you press STORE START and integration starts. You can store numeric data at the storage interval until integration stops (or just until the storage count is reached) is reached.
- Storage continues even when integration is reset by the [integration timer](#). When the integration timer is reset, the storage interval timer is also reset.



- When independent integration is enabled or the data update interval is Auto, storage cannot be performed in integration-synchronized storage mode.
- When the data update interval is Auto and storage interval is not 00:00:00, storage cannot be performed .

- **Event (Event-synchronized storage mode)**

Storage starts after you press STORE START, the measured data is updated, and a user-defined event occurs. You can store numeric data each time the measured data is updated until the storage count is reached.

- **Single Shot (Single-shot storage mode)**

Numeric data is stored whenever you press STORE START. You can store numeric data until the storage count is reached.

### Storage Count (Store Count)

- The storage count can be set to infinity or to a value from 1 to 99999999.
- When the storage count is set to infinity, it is set to 99999999.
- Storage will stop before the specified storage count if the storage destination runs out of available memory or the stored data size exceeds the maximum value (1 GB).

### Viewing and Optimizing the Maximum Storage Count (Optimize Count)

- This instrument computes the maximum storage count for the storage destination according to the number of data types specified in the [Item Settings](#).
- You can set the storage count to a value from 0 to the computed maximum storage count.
- You can select Set to set the maximum storage count to the current storage count. However, you cannot do this if the current storage count is 0.





- If you enable automatic CSV conversion (Auto CSV Conversion) and set the storage destination to a USB memory device, the maximum storage count is computed with 20% of the available USB memory designated as valid for stored data (\*.WTS and \*.HDS files).
- If the maximum storage count is displayed as 0, there is not enough available memory in the storage destination. Make more space available, by deleting files for example.
- If you change the number of stored items specified in [Item Settings](#) after you set the storage count, the maximum storage count will change, and you will need to set the storage count again.

### Storage Interval (Interval)

You can set the interval at which numeric data is stored.

- You can set the hour, minute, and second within the following range. If you set the interval to 00:00:00, the numeric data will be stored at the numeric data update interval.  
00:00:00 to 99:59:59
- When the storage mode is set to Integ Sync, storage continues even when integration is reset by the [integration timer](#). When the integration timer is reset, the storage interval timer is also reset.
- This setting is invalid when the storage mode is set to Event or Single Shot.
- When the data update interval is Auto, the interval is set to 50 ms.
- If the waveform display is enabled and the trigger mode is set to Auto or Normal, the data update interval depends on the trigger operation.

► [Click here.](#)

### Scheduled Storage Times for Real-Time Storage Mode (Real Time Control)

These settings are only valid when the storage mode is set to Real Time. You can set the year, month, day, hour, minute, and second of the storage start and stop times. Be sure to set the storage stop time to a time after the storage start time. You can set the values within the following ranges.

- Year: Any four-digit Gregorian calendar value
- Hour:Minute:Second: 00:00:00 to 23:59:59
- Now: The scheduled storage start time is set to the current time.
- Copy: The scheduled storage start time is copied into the scheduled storage stop time.



- You can set the day for the scheduled start or stop time in February to a value as high as the 31st day. If you do so, an error message will appear when you start storage. Reset the scheduled start and stop times.
- This instrument recognizes leap years when it executes the storage operation.

### Trigger Event for Event-Synchronized Storage Mode (Trigger Event)

This setting is only valid when the storage mode is set to Event. You can select the user-defined event whose occurrence will cause storage to start. If you select a disabled user-defined event, storage cannot start.

For information about configuring user-defined events, see “User-Defined Events.”

► [Click here.](#)

### Storage of the Numeric Data at Store Start (Store At Start)

- Select whether to store the numeric data at store start.
- You can configure this setting when:
  - The storage mode is set to Manual, and the storage interval is not 00:00:00.
  - The storage mode is set to Real Time, and the storage interval is not 00:00:00.
  - The storage mode is set to Integ Sync.

## Stored Items (Item Settings)

You can set which numeric data items to store. You can choose to store the displayed numeric items (Displayed Numeric Items) or the selected items (Selected Items).

### Displayed Numeric Items (Displayed Numeric Items)

The numeric data items displayed on the screen are stored. The stored items vary as indicated below depending on the display.

- When Numeric Values Are Displayed in the 4-, 8-, or 16-Value Display or the Matrix Display  
All the measurement functions on the page that is displayed when storage starts are stored in the order that they are displayed.
- When Numeric Values Are Displayed in the Single or Dual Harmonics List  
In addition to the data described above, the data of harmonics that are not displayed on the screen is stored up to the maximum measurable order (Max Order).
- When Numeric Values Are Displayed in the All Items or Custom Display  
Storage cannot be performed. An error message is displayed at store start.
- In Non-Numeric Displays (Waveform display, trend display, etc.)  
This instrument stores data according to the numeric display settings. For example, when the waveform display is shown, if the 16-value display would appear when you pressed NUMERIC, then the data for the measurement functions on the page of the 16-value display that would appear is stored.



During storage, even if you change the numeric data display format or the displayed items, the data is stored according to the numeric data that was displayed at store start.

### Selected Items (Selected Items)

You can select the types of numeric data to store. To select which types of numeric data to store, click Items.

#### Items (Items)

If you set the numeric data items to store to Selected Items, you can select which types of numeric data to store.

#### Element (Element)

To select an element or wiring unit that you want to store the data of, select or clear its check box. You can select from the following options.

Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$

#### Function (Function)

Select whether to store the data of a function by selecting or clearing its check box. You can select any of the measurement function types listed under "Items That This Instrument Can Measure."

► [Click here.](#)

- \* When the data update interval is set to Auto, the following data update status information is saved automatically.
  - UpdateStsPwr: Input element data update status for normal measurement  
This is saved automatically.
  - UpdateStsMtr: Motor evaluation data update status for normal measurement  
This is saved automatically on models with the motor evaluation function (option).
  - UpdateStsAux: Auxiliary signal input data update status for normal measurement  
This is saved automatically on models with the auxiliary input option.
  - UpdateStsHrm: Input element data update status for harmonic measurement  
This is saved automatically on models with the harmonic measurement option or the simultaneous dual harmonic measurement option.

#### Selecting All Functions (All ON)

The data of all measurement functions is stored.

#### Deselecting All Functions (All OFF)

None of the data for any of the measurement functions is stored.

**Preset 1 (Preset 1)**

The data of the following measurement functions is stored for all elements and wiring units.\*

Urms, Irms, FreqU, FreqI, P, S, Q,  $\lambda$ , and  $\Phi$

**Preset 2 (Preset 2)**

The data of the following measurement functions is stored for all elements and wiring units.\*

WP, WP+, WP–, q, q+, q–, Time, WS, and WQ

- \* If the wiring system setting (Wiring) is configured so that a wiring unit does not exist, the data for the functions of that wiring unit is not stored. For example, if  $\Sigma C$  does not exist, the data for  $\Sigma C$  is not stored.

## Save Conditions (File Settings)

- Stored measurement data is saved to files in binary format (with .wts extensions).
- Measurement conditions, settings, and storage information are saved in binary format to header files (with .hds extensions).
- File name extensions are added automatically.
- When the storage destination is a USB memory device, the maximum stored data file (.wts) file size is 1 GB.
- You cannot load stored data using this instrument.

► [Click here.](#)

### Displaying a File List and Specifying the Save Destination (File List)

On the file list, specify the save destination. You can set the storage medium to the internal RAM disk or to a USB memory device. You cannot set the storage medium to a network drive. For information about how to configure the file list display and how to operate files and folders, see “File Operations (Utility).”

► [Click here.](#)




---

If you set the storage medium to a USB memory device, when you remove the USB memory device, the storage medium automatically changes to the internal RAM disk.

---

### Automatic CSV Conversion (Auto CSV Conversion)

You can choose whether to automatically create an ASCII format stored data file (.csv) from the stored data file (.wts) and the header file (.hds) that are saved when storage finishes or is reset.

- When the storage destination is the internal RAM disk ([RAM-0])  
A CSV file is created in the root folder of the USB memory device whose ID number is 0 ([USB-0]).
- When the storage destination is a USB memory device ([USB-0] or [USB-1])  
A CSV file is saved in the same folder as the stored data file.

### Automatic File Naming (Auto Naming)

This is the same as the auto naming feature for saving and loading data.

► [Click here.](#)

### File Name (File Name)

This is the same as the file name setting for saving and loading data.

► [Click here.](#)

### Comment (Comment)

This is the same as the comment setting for saving and loading data.

► [Click here.](#)

### Manually Converting to CSV Format (CSV Convert)

You can convert the selected stored data to ASCII format (.csv). This menu item appears when you press File List to display the file list.

- When you convert stored data on the internal RAM disk ([RAM-0])  
A CSV file is created in the root folder of the USB memory device whose ID number is 0 ([USB-0]).
- When you convert stored data on a USB memory device ([USB-0] or [USB-1])  
A CSV file is saved in the same folder as the stored data file you are converting.



- Data storage may fail under the following circumstances. When this happens, an asterisk appears in the storage state indication. The storage count includes the missing stored data.
    - When you perform consecutive operations in the setup menu.
    - When this instrument receives consecutive communication commands.
    - When you operate this instrument over FTP.
  - If you choose to store data through USB and the write speed of the connected USB device is slow, a new numeric data storage operation may begin before the previous operation is finished, and some of the numeric data may be lost. When this happens, an asterisk appears in the storage state indication. The storage count includes the missing stored data. You can avoid the loss of numeric data during storage by:
    - Setting a longer data update interval.
    - Reducing the number of stored data types.
    - Using a faster USB memory device.
  - When it takes a long time for data to be written to the USB, storage may be stopped forcefully, and some data may not be saved. When this happens, the storage state indication is "Error."
  - Conversion to ASCII format (.csv) uses a pair of files that consists of a stored numeric data file (.wts) and a header file (.hds) with the same name. Do not change the names of stored numeric data (.wts) and header (.hds) files for different sets of data to the same name. If you do so, this instrument may malfunction and the USB memory may be damaged when you convert the data to ASCII format (.csv).
  - If you remove the USB memory during storage and the storage state indication is "Error," the stored data file may be incomplete or corrupted. If this is the case, you will not be able to convert the data to ASCII format (.csv). Be sure to remove the USB memory after storage has been reset or has completed (Cmpl).
  - When you turn off the power of this instrument, the contents of the internal RAM disk are lost. Save the contents of the RAM disk to a USB memory device or network drive before you turn off this instrument.
  - Please be aware that the number of times that you can write to USB memory is limited.
- 

## Starting, Stopping, and Resetting Storage (STORE START, STORE STOP, and STORE RESET)

### Starting Storage (STORE START)

- When you press STORE START, storage starts under one of the conditions described below, depending on the storage mode.
  - Manual storage mode (Manual)  
Storage starts immediately.
  - Real-time storage mode (Real Time)  
This instrument enters into a storage-ready state. Storage starts when the scheduled storage start time is reached.
  - Integration-synchronized storage mode (Integ Sync)  
This instrument enters into a storage-ready state. Storage starts when integration starts.
  - Event-synchronized storage mode (Event)  
This instrument enters into a storage-ready state. Storage starts when a user-defined event occurs.
  - Single-shot storage mode (Single Shot)  
Storage starts immediately. Numeric data is stored whenever you press STORE START.
- When storage starts, the STORE START key illuminates, and "Store:Start" appears in the upper left of the screen.

- When this instrument is in a storage-ready state, the STORE START key blinks, and “Store:Ready” appears in the upper left of the screen.
- After storage is reset, a stored data file (.wts) and header file (.hds) are created when storage starts again.
- When the storage state is “Stop,” you can restart storage. When you restart storage, the stored data continues to be written to the file from before storage was stopped.
- When the store state is “Cmpl,” you cannot restart storage until you reset it. After you reset storage and then start it, a new stored data file is created and written to.

### Stopping Storage (STORE STOP)

- You can temporarily stop storage by pressing STORE STOP.
- When storage stops, the STORE STOP key blinks, and “Store:Stop” appears in the upper left of the screen.
- When the storage count is zero and this instrument is in a storage-ready state (Ready)\* and you press STORE STOP, storage is reset. The storage data file (.wts) and storage header file (.hds) are deleted.

\* This state can occur in real-time storage mode when you have pressed STORE START but the scheduled storage start time has not yet arrived (the storage operation has not begun).

### Ending Storage

- Depending on the storage mode, storage automatically stops and the storage state changes to “Cmpl” under one of the following conditions.
  - Manual storage mode (Manual)  
Storage continues until the storage count is reached.
  - Real-time storage mode (Real Time)  
Storage continues until the storage count or the scheduled storage stop time.
  - Integration-synchronized storage mode (Integ Sync)  
Storage continues until the storage count is reached, and then storage is completed (Cmpl). When integration stops, the following occurs.
    - If integration cannot be restarted without being reset, the storage state changes to “Stop.”
    - If integration can be restarted without being reset, the storage state changes to “Ready.”
  - Event-synchronized storage mode (Event)  
Storage continues until the storage count is reached.
  - Single-shot storage mode (Single Shot)  
Storage continues until the storage count is reached.
- After storage is completed, the following occurs.
  - The STORE STOP key illuminates, and “Store:Cmpl” appears in the upper left of the screen.
  - Writing to the stored data file (.wts) and header file (.hds) finishes, and the files are closed.
  - When automatic CSV conversion (Auto CSV Conversion) is enabled, an ASCII format stored data file (.csv) is created.




Storage will stop before the specified storage count if the storage destination runs out of available memory or the stored data size exceeds the maximum value (1 GB).

### Resetting Storage (STORE RESET)


- When you reset storage, this instrument enters into the reset store state, in which the store state indicator is blank.
- If you reset storage when the store state is “Stop,” writing to the stored data file (.wts) and header file (.hds) finishes, and the files are closed. When automatic CSV conversion (Auto CSV Conversion) is enabled, an ASCII format stored data file (.csv) is created.
- When the store state is “Cmpl,” the stored data file (.wts) and header file (.hds) are already closed, so no file operations are performed when storage is reset.

## Storage Operations in Each Storage Mode

### Manual (Manual storage mode)




### Real Time (Real-time storage mode)




### Integ Sync (Integration-synchronized storage mode)

When the storage count is reached before integration stops





When integration stops before the storage count is reached (illustration of operations after integration starts)




- If you reset integration after it has been stopped, the store state changes to "Cmpl." Writing to the stored data file (.wts) and header file (.hds) finishes, and the files are closed.
- If you restart integration after it has been stopped, the store state changes to "Start." The stored data continues to be written to the file from before storage was stopped.

### Event (Event-synchronized storage mode)




**Single Shot (Single-shot storage mode)****Storage Operations Performed When You Press STORE STOP After Storage Has Been Started****Restarting Storage**

When you press STORE START, STORE STOP, and then STORE START

**Resetting Storage**


When you press STORE START, STORE STOP, and then STORE RESET

**Storage Operation When the Storage Interval Is Not an Integer Multiple of the Data Update Interval**


Here we will use the case when the data update interval is 5 s and the storage interval is 7 s as an example. How storage is performed varies as indicated below depending on the storage mode.

**When the Storage Mode Is Not Set to Integ Sync**

Storage is performed according to the storage interval.


**When the Storage Mode Is Integ Sync and the Integration Mode Is Not Continuous or R-Continuous**

Storage is performed at the first data update after the storage interval passes.



### When the Storage Mode Is Integ Sync and the Integration Mode Is Continuous or R-Continuous

Storage is performed at the first data update after the storage interval passes. Storage continues even when integration is reset by the integration timer. When the integration timer is reset, the storage interval timer is also reset. The figure below is an example for when the integration timer is set to 20 s.



- When the storage of numeric data at store start (Store At Start) is enabled, storage starts when the time is at 0 s (store start).
- Storage is performed when the integration mode is continuous integration mode or real-time continuous integration mode, the integration timer time elapses, and the integrated values are reset. In the above example, the integration timer is set to 20 s, so the data is stored after 20 s have passed, and then the integrated values are reset.

### Operations when Values Are Held

If you press HOLD after storage has been started, the displayed values are held, and storage is performed as indicated below.

- When the storage mode is set to Manual and the storage interval is 00:00:00, when the storage mode is set to Real Time and the storage interval is 00:00:00, or when Storage Mode is set to Event  
The storage operation stops, but integration does not.
- When the storage mode is set to Single Shot  
The held display values are stored. Even during integration, the held display values are stored.
- In All Other Cases  
The held display values are stored. During integration, the values being measured are stored.



- Media access indication icon only illuminates when this instrument creates files at the start of storage and closes them at the end of storage, but this instrument is actually always accessing the storage medium. During the period between when the files are created and when they are closed, do not remove the USB memory or turn off the power. Doing so may damage the storage medium and corrupt its data.
- When a point has no numeric data, NAN, OL, OF, ERROR, or a blank space will be stored instead. The places that contain blank spaces are in measurement functions such as the ones for the 0th (DC) and 1st harmonic orders of  $\Phi U$  and  $\Phi I$ , where the screen display is also blank.
- Functions  $\Delta U1$  to  $\Delta P\Sigma$  are stored according to the delta computation type that you selected in the delta computation settings.
- When this instrument automatically changes the range during storage, because measured data cannot be acquired, the store operation is paused and no measured data is stored. After this instrument finishes changing the range, storage resumes.
- You cannot use the auto print feature during storage.



## 18 Saving and Loading Data

You can save numeric data, waveform display data, screen image data, and setup parameters to USB memory or a network drive.


For information about saving screen image data, see “Saving Screen Images”

► [Click here.](#)

You can load the setup data from a storage medium into this instrument.

You can also rename, copy, and delete data files.

### Using a PC to Load Numeric Data, Waveform Display Data, or Screen Image Data



## Storage Media

This instrument can access the following three types of storage media for saving and loading data.

### Internal RAM Disk (RAM-0)

The internal RAM disk of this instrument.

### USB Memory (USB-0 or USB-1)

A USB memory device that is connected to the USB port of this instrument. USB2.0 mass storage devices compatible with USB Mass Storage Class Ver. 1.1 can be connected to this instrument.

### Network Drive (Network)

A storage device on the network. You can use a network storage device by connecting this instrument to an Ethernet network.



When you turn off the power of this instrument, the contents of the internal RAM disk are lost. Save the contents of the RAM disk to a USB memory device or network drive before you turn off this instrument.



---

**Notes about Using USB Devices**

- Connect the USB memory device to the USB port for peripherals (type A) directly, not through a USB hub.
  - Use portable USB storage media that are compatible with USB Mass Storage Class version 1.1.
  - You cannot use protected USB storage devices (such as those that contain encrypted content).
  - Only connect compatible USB keyboards, mouse devices, or memory devices to the USB ports for peripherals.
  - Do not connect and disconnect multiple USB devices repetitively. Provide a 10-second interval between removal and connection.
  - Do not connect or remove USB devices from the time when this instrument is turned on until key operation becomes available (approximately 20 to 30 seconds).
  - This instrument can handle up to two USB memory devices.
- 

## Saving Setup Data (Save Setup)

You can save the setup data of this instrument to the specified storage medium. The date, time, and communication setup parameters are not saved.

The extension is .SET.

For information about the file save conditions, see “File Save Conditions.”

▶ [Click here.](#)

## Saving Waveform Display Data (Save Wave)

You can save the waveform data that this instrument has measured to a file in ASCII format (.csv). The waveform displayed on the screen is saved.

For information about the file save conditions, see “File Save Conditions.”

▶ [Click here.](#)



---

The waveform display data that this instrument saves is not the sampled waveform data that is acquired at this instrument's sample rate (of approximately 2 MS/s). This instrument performs [P-P compression](#) on the sampled waveform data, to produce 1602 points of waveform display data that are used to display the waveform on the screen.

---

## Saving Numeric Data (Save Numeric)

You can save the numeric data that this instrument has measured to a file in ASCII format (.csv).

For information about the file save conditions, see “File Save Conditions.”

▶ [Click here.](#)



---

When you save numeric data and a point has no numeric data, NAN, OL, OF, ERROR, or a blank space will be saved instead. The places that contain blank spaces are in measurement functions such as the ones for the 0th (DC) and 1st harmonic orders of  $\Phi U$  and  $\Phi I$ , where the screen display is also blank.

---

## File Save Conditions

### Displaying a File List and Specifying the Save Destination (File List)

On the file list, specify the save destination. For information about how to configure the file list display and how to operate files and folders, see “File Operations (Utility).”

► [Click here.](#)

### Saved Items (Item Settings)

This menu item only appears when you select Save Numeric.

#### Displayed Numeric Items (Displayed Numeric Items)

The saved items vary as indicated below depending on the display.

- **When Numeric Values Are Displayed in the 4-, 8-, or 16-Value Display or the Matrix Display**  
All the measurement functions on the page that is displayed when saving starts are saved in the order that they are displayed.
- **When Numeric Values Are Displayed in the Single or Dual Harmonics List**  
In addition to the data described above, the data of harmonics that are not displayed on the screen is saved up to the maximum measurable order (Max Order).
- **When Numeric Values Are Displayed in the All Items or Custom Display**  
The data cannot be saved. If you attempt to save the data, an error message is displayed.
- **In Non-Numeric Displays (Waveform display, trend display, etc.)**  
This instrument saves data according to the numeric display settings. For example, when the waveform display is shown, if the 16-value display would appear when you pressed NUMERIC, then the data for the measurement functions on the page of the 16-value display that would appear is saved.

#### Selected Items (Selected Items)

You can select the types of numeric data to save.

#### Items (Items)

If you selected Selected Items, select which numeric data to save.

- **Element (Element)**

To select an element or wiring unit that you want to store the data of, select or clear its check box. You can select from the following options.

Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$

- **Function (Function)**

Select whether to store the data of a function by selecting or clearing its check box. You can select any of the measurement function types listed under “Items That This Instrument Can Measure.”

► [Click here.](#)

- **Selecting All Functions (All ON)**

The data of all measurement functions is saved.

- **Deselecting All Functions (All OFF)**

None of the data for any of the measurement functions is saved.

- **Preset 1 (Preset 1)**

The data of the following measurement functions is saved for all elements and wiring units.\*  
Urms, Irms, FreqU, FreqI, P, S, Q,  $\lambda$ , and  $\Phi$

- **Preset 2 (Preset 2)**

The data of the following measurement functions is saved for all elements and wiring units.\*  
WP, WP+, WP–, q, q+, q–, Time, WS, and WQ

\* If the wiring system setting (Wiring) is configured so that a wiring unit does not exist, the data for the functions of that wiring unit is not saved. For example, if  $\Sigma C$  does not exist, the data for  $\Sigma C$  is not saved.


## Automatic File Naming (Auto Naming)

### Numbering (Numbering)

This instrument automatically adds a four-digit number from 0000 to 0999 after the common name specified using the File Name setting and saves files.

### Date (Date)

The date and time when the file is saved are used as its name. The file name specified for the File Name setting is ignored.



A sequence number is appended to the date and time when multiple files are saved at the same time (second). The number starts at 0 and is incremented by one each time a file is added. The number 9 is followed by letters of the alphabet.

### OFF

Disables the auto naming feature. The name that you specify using the File Name setting is used. If there is a file with the same name in the save destination folder, you cannot save the data.

### Save Destination Folder for Storage Caused by User-Defined Events

In the drive specified in the Store Set menu, a folder is automatically created with the date (year, month, and day) as its name, and data is saved to files in that folder whose names are specified by the auto naming feature. If the number of files in the save destination folder exceeds 1000, a new folder is automatically created with the date and an incremented sequence number (000 to 999) as its name, and the data continues to be saved in the new folder.

## File Name (File Name)

You can set the common file name that is used when the auto naming feature is turned off or when the auto naming feature is set to Numbering. The maximum number of characters that you can use for file names and folder names is 32 characters. The following restrictions apply.

- The following types of characters can be used: 0 to 9, A to Z, a to z, \_, -, =, (, ), {, }, [, ], #, \$, %, &, ~, !, `, and @. @ cannot be entered consecutively.
- The following character strings cannot be used due to MS-DOS limitations.  
AUX, CON, PRN, NUL, CLOCK, LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9, COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, and COM9
- Make sure that the full file path (absolute path from the root directory) is less than or equal to 255 characters in length. If it exceeds 255 characters, an error occurs when you perform a file operation (such as save, copy, rename, or create folder). When an operation is being performed on a folder, the full path is up to the name of the folder. When an operation is being performed on a file, the full path is up to the name of the file.

The following additional restrictions apply when you use the file name auto naming feature.

- If you set auto naming to Numbering, a file name will consist of the characters that you entered for the file name and a four-character sequence number.
- If you set auto naming to Date (date and time), the characters that you entered for the file name will not be used. File names will only consist of the date information.

### Comment (Comment)

You can add a comment that consists of up to 30 characters when saving files. You do not have to enter a comment. In the comment, you can include spaces and all characters that are displayed on the keyboard. The comment appears in the bottom of the screen.

### Settings That Are Shared with Those of Other Menus

The following settings are shared by the menus for saving the custom display configuration, storing data, saving and loading data, and saving screen images.

- File list display and save destination settings (File List)
- Automatic file naming settings (Auto Naming)
- File name (File Name)

The comment settings (Comment) are shared by the menus for storing data, saving and loading data, saving screen images, and the menus for printing screen images and numeric data.

### Saving (Save Exec)

Saves the data to the specified save destination with the specified file name.

- It can take anywhere from a few seconds to a few tens of seconds for this instrument to save the data, depending on the number of waveforms being saved, the data update interval, and the transfer speed to the save destination medium. It will take longer for this instrument to save the data when there many waveforms are saved or the data update interval is long.
- Measurement stops while this instrument is saving data. After this instrument finishes saving or saving is cancelled, measurement resumes.
- To save data when the data update interval is 20 s, enable the hold feature, perform a single-shot measurement, and then save the data after the data update for the single-shot measurement has completed.



Because the header files saved by this instrument use a format that is common to YOKOGAWA measurement devices, they contain some data that is not used by this instrument.

## Loading Setup Data (Load Setup)

On the file list, specify a file to load setup data from. The extension is .SET. For information about how to configure the file list display and how to operate files and folders, see “File Operations (Utility).”

► [Click here.](#)

### Loading (Load Exec)

Loads the data of the specified file.



- If you change the extension of the saved data file, by using a PC or some other device, this instrument will no longer be able to load it.
- When setup information is loaded from a file, the setup data for each key is changed to match the loaded settings, and it cannot be changed back. We recommend that you save the current settings before loading different setup information.
- The date, time, and communication setup parameters are not saved. So even if you load setup parameters from a file, the date, time, and communication settings will not change.
- This instrument cannot load setup parameters that have been saved by a product with an incompatible firmware version.
- This instrument cannot load setup parameters that were saved by an instrument with a different element configuration, different options, etc.

## File Operations (Utility)

You can perform file operations such as creating folders on the storage medium, deleting and copying files, and changing file names.

Use the up and down cursor keys to select from the file list the file or folder that you want to perform an operation on.

### Storage Media Displayed in the File List

► [Click here.](#)



- Up to 512 files and folders can be displayed in the file list. If there are more than a total of 512 files and folders in a given folder, the file list for that folder will only display 512 files and folders. There is no way to set which files and folders are displayed.
  - When you turn off the power of this instrument, the contents of the internal RAM disk are lost. Save the contents of the RAM disk to a USB memory device or network drive before you turn off this instrument.
- 

### Sorting the File List (Sort To)

You can sort the file list by file name, size, or date and time.

### Display Format

Select whether to display a list of files or to display thumbnails.

### Selecting the Type of File to List (File Filter)

You can limit the type of files that appear in the list by selecting an extension.

### Changing the Storage Medium (Change Drive)

You can select the storage medium that you want to access. This instrument displays the storage media as follows:

- RAM-0: The internal RAM disk of this instrument
- USB-0: The first USB memory device connected to a USB port of this instrument
- USB-1: The second USB memory device connected to a USB port of this instrument
- Network: A storage device on the network

### Deleting Files and Folders (Delete)

You can delete the selected files and folders.

### Renaming Files and Folders (Rename)

You can rename a selected file or folder.

### Making Folders (Make Dir)

Make a folder. You can use the same characters in folder names that you can in file names.

### Copying and Moving Files and Folders (Copy and Move)

You can copy or move the selected files and folders to other storage media or folders. You can copy or move multiple files at the same time.

### Operations (Operation)

You can select from the following operations.

- Delete: Delete files and folders.
- Rename: Rename a file or folder
- Make Dir: Make a folder
- Copy: Copy files and folders
- Move: Move files and folders

**File Selection (Set/Reset)**

Select or deselect files and folders. Selecting multiple files is useful when you want to copy or delete multiple files at the same time.

**Simultaneous File Selection (All Set/All Reset)**

- **Selecting All Files (ALL Set)**

When the cursor is on a drive or folder in the file list, select ALL Set to select all of the files and folders within the drive or folder that the cursor is on.

- **Deselecting All Files (ALL Reset)**

All of the selected files and folders are deselected.

**Jumping to a Specified File or Folder (Jump To)**

You can make the cursor jump to a file or folder at a specified numeric position in the file list. The numeric position at the top of the file list is 0.

Range: 0 to 999

**Other Operations (More...)**

You can select from the following operations.

- Sort To: Sort the file list.
- Display Type: Select the display format (list or thumbnail).
- Filter: Select the type of file to list.
- Change Drive: Change the storage medium.

**Executing an Operation**

Execute the operation that you specified for the Operation setting.

---

## 19 Saving Screen Images

You can save screen image data to files in BMP, PNG, and JPEG formats.

### Conditions for Saving Screen Image Data (IMAGE SAVE MENU)

#### File List Display and Save Destination Settings (File List)

On the file list, specify the save destination. For information about how to configure the file list display and how to operate files and folders, see “File Operations (Utility).”

► [Click here.](#)



---

When you turn off the power of this instrument, the contents of the internal RAM disk are lost. Save the contents of the RAM disk to a USB memory device or network drive before you turn off this instrument.

---

#### Format of Screen Image Data (Format)

You can select the format to save to from the options listed below.

- BMP: The extension is .BMP. The file size is approximately 100 KB for black and white mode and approximately 1.5 MB for color mode.
- PNG: The extension is .PNG. The file size is approximately 25 KB for black and white mode and approximately 100 KB for color mode.
- JPEG: The extension is .JPG. The file size is approximately 200 KB for color mode.



---

The file sizes listed here are for reference. Actual file sizes will vary depending on the image that is saved.

---

#### Screen Image Colors (Color)

You can select the color format to save to from the options below.

- OFF: Data is saved in black and white.
- Color: Data is saved in 65536 colors.
- Reverse: Data is saved in 65536 colors. The image background is set to white.
- Gray: Data is saved in 16 grayscale levels.

#### Automatic File Naming (Auto Naming)

This is the same as the auto naming feature for saving and loading data.

► [Click here.](#)

#### File Name (File Name)

This is the same as the file name setting for saving and loading data.

► [Click here.](#)

#### Comment Displayed at the Bottom of the Screen (Comment)

This is the same as the comment setting for saving and loading data.

► [Click here.](#)

### Saving a Screen Image (IMAGE SAVE)

Save the screen image to a file.



---

## 20 Printing Screen Images and Numeric Data (Option)

You can use the built-in printer to print screen images and numeric data lists. You can also add comments to screen images.

If you use automatic printing, screen images and numeric data lists are printed automatically at the specified print interval. Also, you can set scheduled automatic printing start and stop times to print at a specific time.

### Printing Conditions (PRINT MENU)

You can configure the following printing conditions.

- [Output format \(Format\)](#)
- [Automatic printing execution \(Auto Print ON\)](#)
- [Automatic printing \(Auto Print Settings\)](#)
- [Comment \(Comment\)](#)
- [Paper feed \(Paper Feed\)](#)

### Output Format (Format)

You can select the data format to print from the options listed below.

- Screen: Screen image data
- List: Numeric list data

### Printed Items

If you set the output format to numeric data list (List), the printed items vary as indicated below depending on the display that is shown.

- When numeric values are displayed in the 4-, 8-, or 16-value display or the matrix display  
All the measurement functions on the page that is displayed when printing starts are printed in the order that they are displayed.
- When numeric values are displayed in the single or dual harmonics list  
In addition to the data described above, the data of harmonics that are not displayed on the screen is printed up to the maximum measurable order (Max Order).
- When numeric values are displayed in the All Items or Custom display  
Printing cannot be performed. If you attempt to print the data, an error message is displayed.
- In non-numeric displays (waveform display, trend display, etc.)  
This Instrument prints data according to the numeric display settings. For example, when the waveform display is shown, if the 16-value display would appear when you pressed NUMERIC, then the data for the measurement functions on the page of the 16-value display that would appear is printed.



- 
- For items with no numeric data, "-----" (no data) is printed.
  - If integration is not being performed and thus there is no integrated value, "-----" (no data) is printed. "-----" (no data) is also printed for the integration time.
  - The maximum harmonic order that can be printed is determined by the maximum harmonic order set in the harmonic measurement (option) menu. For orders with no numeric data, "-----" (no data) is printed.
  - Functions  $\Delta U1$  to  $\Delta P\Sigma$  are printed according to the delta computation type that you selected in the delta computation settings.
-

## Automatic Printing Execution (Auto Print ON)

Enable automatic printing. When you enable automatic printing, the timing at which printing occurs and at which the PRINT key illuminates varied depending on the print mode. For details, see “Print Timing for Different Print Modes.”

► [Click here.](#)

### Limitations on Changing the Settings during Automatic Printing

While automatic printing is enabled, there are some setting that you cannot change and functions that you cannot execute. For details, see appendix 9 in the getting started guide, IM WT1801E-03EN.

If you perform the following operations while automatic printing is enabled, automatic printing will not be performed.

- Save data or settings or access a storage medium in some other way
- Execute an FTP server command
- Manually start printing or start printing using communication commands

## Automatic Printing (Auto Print Settings)

### Print Mode (Print Mode)

You can specify the method for starting, stopping, and executing printing from the options below.

- **Interval: Interval Print Mode**  
Printing starts when you enable automatic printing. Data is printed at each print interval.
- **Real Time: Real-Time Print Mode**  
Printing starts and stops in synch with the scheduled printing start and stop times. Data is printed at each print interval.
- **Integ Sync: Integration Synchronization Print Mode**  
Printing starts and stops in synch with the starting and stopping of integration. Data is printed at each print interval.



When the data update interval is Auto, printing cannot be performed in integration synchronization print mode.

- **Event: Event Synchronization Print Mode**  
When you enable automatic printing, printing is executed when the measurement data is updated and a user-defined event occurs. Printing is executed at the data update interval for as long as the event continues. However, if the time it takes to print is longer than the data update interval, after printing stops, it starts again at the next data update.

### Print Count (Print Count)

This setting is valid when Print Mode is set to Interval, Real Time, or Event.

You can set the print count within the following range.

Infinite, or 1 to 9999

### Print Interval (Print Interval)

This setting is valid when Print Mode is set to Interval, Real Time, or Integ Sync.

You can set print interval hour, minute, and second within the following range.

00:00:10 to 99:59:59

When the print interval is not an integer multiple of the data update interval, the print operation behaves in the same manner described in “Storage Operation When the Storage Interval Is Not an Integer Multiple of the Data Update Interval.”

► [Click here.](#)



- If you specify a number of measurement functions as items to be printed, it may take a long time to print the data. Set the print interval to a time that is longer than the time required to print the data.
- If you touch the keys or execute communication commands during printing, printing may slow down.

### Scheduled Start and Stop Times (Real Time Control)

You can configure these settings when Print Mode is set to Real Time. You can set the year, month, day, hour, minute, and second of the print start and stop times. Be sure to set the scheduled printing stop time to a time after the printing start time.

You can set the values within the following ranges.

- Year: Any four-digit Gregorian calendar value
- Hour:Minute:Second: 00:00:00 to 23:59:59
- Now: The scheduled printing start time is set to the current time.
- Copy: The scheduled printing start time is copied into the scheduled printing stop time.



- You can set the day for the scheduled start or stop time in February to a value as high as the 31st day. If you do so, an error message will appear when you enable automatic printing. Reset the scheduled start and stop times.
- This Instrument recognizes leap years when it executes automatic printing.

### Trigger Event (Trigger Event)

You can configure this setting when Print Mode is set to Event. You can select an event from Event1 to Event8. Printing is executed whenever the user-defined event specified here occurs.

### Printing of the Data at Print Start (Print At Start)

This setting is valid when Print Mode is set to Interval, Real Time, or Integ Sync.

Select whether to print the data at print start.

## Comment (Comment)

This is the same as the comment setting for saving and loading data.

▶ [Click here.](#)

## Paper Feed (Paper Feed)


Each time you press Paper Feed, the paper roll is fed through by approximately 3 cm.

# Print Timing for Different Print Modes

The timings at which automatic printing can be executed are indicated below.


## Interval Print Mode

When the scheduled start time is before Auto Print ON




## Real-Time Print Mode

When the scheduled start time is before Auto Print ON




When the scheduled start time is after Auto Print ON




## Integration Synchronization Print Mode

Printing is executed in sync with the integration start time.

### When integration starts before Auto Print ON




### When integration starts after Auto Print ON



## Integration Timer and Print Interval in Continuous Integration Mode and Real-Time Continuous Integration Mode

Printing is executed whenever the integration timer time elapses.




If integration stops for one of the following reasons, printing is executed, and Auto Print is automatically set to OFF.

- The integration timer time elapses: TimeUp
- The scheduled stop time is reached: Stop (in orange text)


### Event Synchronization Print Mode

Printing is executed whenever a user-defined event occurs.

When the time it takes to print is shorter than the data update interval



When the time it takes to print is longer than the data update interval



## Printing (PRINT)

Prints the screen image data or numeric data list.

### Using an External Signal to Control Printing (Option)

On models with the 20-channel D/A output option, you can use the remote control feature to print data. For details about the remote control feature, see appendix 4.6 in the getting started guide, IM WT1801E-03EN.

---

## 21 Ethernet Communication (Network)

You can configure TCP/IP parameters and use the optional Ethernet interface to perform the following tasks.

### **TCP/IP**

TCP/IP settings for connecting to an Ethernet network.

Set the IP address, subnet mask, and default gateway.

▶ [Click here.](#)

### **FTP Server (FTP Server)**

You can connect this Instrument as an FTP server to a network.

You can connect to this Instrument from a PC on the same network and retrieve setup data, numeric data, waveform display data, and screen image data.

▶ [Click here.](#)

### **Web Server (Web Server)**

You can connect this Instrument as an Web server to a network.

You can connect to this Instrument from a PC on the same network and monitor the display of this instrument from the PC.

▶ [Click here.](#)

### **Network Drive (Net Drive)**

You can save the setup data of this Instrument, numeric data, waveform display data, and screen image data to a network drive. You can also load the setup data from a network drive into this Instrument.

▶ [Click here.](#)

### **SNTP**

The clock of this Instrument can be set using SNTP. When this Instrument is turned on, the date and time are set automatically.

▶ [Click here.](#)



---

To connect a PC to this Instrument, use a hub or router, and connect to a network. Do not connect a PC directly to this Instrument.

---

## TCP/IP (TCP/IP)

Configure the settings that this Instrument needs to connect to a network.

### DHCP

DHCP is a protocol that temporarily allocates settings that a PC needs to connect to the Internet.

To connect to a network that has a DHCP server, turn the DHCP setting on. When DHCP is turned on, the IP address can be automatically obtained when this Instrument is connected to a network. (You do not have to set it manually.)

When DHCP is turned off, you must set the appropriate IP address, subnet mask, and default gateway for the network.

### DNS

DNS is a system used to associate Internet host names and domain names with IP addresses. Given AAA.BBBBBB.com, AAA is the host name and BBBBBB.com is the domain name. You can use host names and domain names to access the network instead of using IP addresses, which are just numbers. This Instrument allows you to specify the host by name, instead of by IP address. Set the domain name and the DNS server address (0.0.0.0 by default). For details, consult your network administrator.

#### DNS Servers (DNS Server1/DNS Server2)

You can specify up to two DNS server addresses: primary and secondary. If querying fails with the primary DNS server, the secondary DNS server is automatically used to find the mapping of the host name and domain name to the IP address.

#### Domain Suffixes (Domain Suffix1/Domain Suffix2)

The domain suffix is a piece of information that is automatically added when a query is made to a DNS server using only a portion of the domain name. For example, if BBBBBB.co.jp is registered as a domain suffix and a query is made using "AAA," the name "AAA.BBBBBB.co.jp" is searched.

You can specify up to two domain suffixes: Domain Suffix1 and Domain Suffix 2.

You can use up to 127 characters. The characters that you can use are 0 to 9, A to Z, a to z, and hyphens.

TCP/IP settings are applied when you press Bind and then SET or when you turn on this Instrument the next time.



## FTP Server (FTP/Web Server)

You can connect this Instrument as an FTP server to a network.

Set the user name and password that will be used by devices on the network to access this Instrument. Also, set the access timeout value.

### User Name (User Name)

Set the user name that will be used to access this Instrument from a PC. If you set the user name to “anonymous,” you can connect to this Instrument without entering a password.

- Number of characters: Up to 32
- Usable characters: All ASCII characters that are displayed on the keyboard

### Password (Password)

Set the password that will be used to access this Instrument from a PC.

- Number of characters: Up to 32
- Usable characters: All ASCII characters that are displayed on the keyboard

### Timeout (Time Out)

If an connection cannot be established between this Instrument and the PC within the amount of time specified here, this Instrument aborts the connection process.

You can set the timeout time to a value between 1 and 3600.



---

To apply the settings that you specified, press Entry.

---

## FTP Server Overview

When this instrument is connected to the network as an FTP server, the following features become available.

### FTP Server Feature

From a PC, you can view a list of files that are stored in the storage media of this instrument (the internal RAM disk and the storage media that are connected to this instrument) and retrieve files.

## Web Server (FTP/Web Server)

You can connect this instrument as a Web server to a network.

Set the user name and password that will be used by devices on the network to access this instrument. Also, set the access timeout value.

### User Name (User Name)

Set the user name that will be used to access this Instrument from a PC. If you set the user name to “anonymous,” you can connect to this Instrument without entering a password.

- Number of characters: Up to 32
- Usable characters: All ASCII characters that are displayed on the keyboard

### Password (Password)

Set the password that will be used to access this Instrument from a PC.

- Number of characters: Up to 32
- Usable characters: All ASCII characters that are displayed on the keyboard



- 
- Time Out is a setting used by the FTP server feature. It is not necessary for the Web server feature.
  - To apply the settings that you specified, press Entry.
- 

## Web Server Overview

When this instrument is connected to the network as an Web server, the following features become available.

### Web Server

You can display the screen of this instrument on the PC and control this instrument through the Ethernet network.

There are three types of screens: Home, Control, and Links.

### Instrument Information (Home)

Information about the instrument is displayed.

### Control from the PC (Control)

- LCD area: The same information as that on the instrument's LCD is displayed. You can perform the same operations as when a USB mouse is connected to this instrument (see section 3.3 in the getting started guide, IM WT1801E-03EN).
- Resolution setting: Set the resolution of the LCD area.
  - LOW: 512×384
  - HIGH: 1024×768
- Message: Messages are displayed.
- Control panel area: You can control the instrument in the same manner as if you were using the keys on the instrument.
- Auto refresh start/stop button: You can start or stop the auto refreshing of the LCD area and control panel area.
- Screen refresh interval setting: You can set the auto refresh interval of the LCD area and control panel area in the range of 5 to 60 s.

**Links to Related Web Pages (Links)**

Links to the following web pages are provided.

- Power Analyzers Entrance: Power analyzer website
  - English  
<http://tmi.yokogawa.com/products/digital-power-analyzers/>
  - Japanese  
<http://www.yokogawa.com/jp-ymi/tm/Bu/WTPZ/X>
- Yokogawa Meters & Instruments Corporation: Yokogawa Test & Measurement Corporation website
  - English  
<http://www.yokogawa.com/ymi/>
  - Japanese  
<http://www.yokogawa.com/jp-ymi/index.htm>



- Flash Player by Adobe (version 8 or later) is required when using the Web server function. When visiting this website, the most recent Flash Player is automatically downloaded. If the download does not begin, please obtain the latest Flash Player from the Adobe website.
  - The Web server function is unavailable when printing on the instrument or manipulating files.
-

## Network Drive (Net Drive)

You can save the setup data of this Instrument, numeric data, waveform display data, and screen image data to a network drive. You can also load the setup data from a network drive into this Instrument.

### FTP Server (FTP Server)

Specify the IP address of an FTP server on the network. You can save numeric data, waveform display data, and screen image data to the server and load setup data from it. In a network with a DNS server, you can specify the host name and domain name instead of the IP address.

### Login Name (Login Name)

Specify the login name.

- Number of characters: Up to 32
- Usable characters: All ASCII characters that are displayed on the keyboard

### Password (Password)

Specify the password that corresponds to the login name.

- Number of characters: Up to 32
- Usable characters: All ASCII characters that are displayed on the keyboard

### Passive Mode (Passive)

Turn passive FTP on or off.

In passive mode, the FTP client sets the port number for data transfer. Enable passive mode when you have set an external FTP server as a network drive or when you are accessing an FTP server through a firewall.

### Timeout (Time Out)

If this Instrument cannot transfer files for a certain amount of time, it disconnects from the FTP server.

You can set the timeout time to a value between 1 and 3600.

### Connecting to the Network Drive(Connect/Disconnect)

When you press Connect, this Instrument connects to the specified network drive. When you press Disconnect, the network drive is disconnected.

## SNTP (SNTP)

The clock of this Instrument can be set using Simple Network Time Protocol (SNTP). When this Instrument is turned on, the date and time are set automatically.

### SNTP Server (SNTP Server)

Specify the IP address of the SNTP server that this Instrument will use. In a network with a DNS server, you can specify the host name and domain name instead of the IP address.

### Timeout (Time Out)

If this Instrument cannot connect to the SNTP server for a certain amount of time, it aborts the operation. You can set the timeout time to a value between 1 and 60.

### Executing Time Adjustment (Adjust)

The clock of this Instrument is synchronized to the SNTP server clock.

### Automatic Adjustment (Adjust at Power ON)

You can configure this Instrument so that its clock is automatically synchronized to the SNTP server clock when this Instrument is turned on when it is connected to the network.

### Setting the Time Difference from Greenwich Mean Time (Time Difference From GMT)

This is the same as the "Setting the Time Difference from Greenwich Mean Time (Time Difference From GMT)" setting in the date and time settings.

► [Click here.](#)



---

The Time Difference From GMT setting is shared with the same setting found in the SNTP settings in the date and time settings (Date/Time). If you change this setting in the Ethernet communication (Network) settings, the Time Difference From GMT in the date and time settings (Date/Time) also changes.

---

---

## 22 Utility

### Utility (UTILITY)

You can specify the following settings.

#### Overview (System Overview)

You can view the system and setup information of this Instrument.

▶ [Click here.](#)

#### Initializing the Settings (Initialize Settings)

You can reset the settings of this Instrument to their factory default values.

▶ [Click here.](#)

#### Remote Control (Remote Control)

You can select the method for connecting a PC to this Instrument to control it.

▶ [Click here.](#)

#### System Configuration (System Config)

You can set the date and time, time synchronization, the menu and message languages, the LCD intensity, whether the backlight is on or off, the USB keyboard language, and USB communication, and you can format storage media.

▶ [Click here.](#)

#### Ethernet Communication (Network)

You can configure TCP/IP, FTP server, network drive, and SNTP settings.

▶ [Click here.](#)

#### D/A Output (D/A Output Items; option)

Configure D/A output.

▶ [Click here.](#)

#### Self-Test (Selftest)

You can test the keyboard and memory operations.

▶ [Click here.](#)

## Overview (System Overview)

You can display the following information about this Instrument.

Item	Description
Model	The model number
Suffix	The suffix code
No.	The instrument number
Version	The firmware version
Element Configuration	The input element type
Options	The options
Link Date	The firmware date
Product ID	A unique device ID that is assigned to each unit (This number is necessary for the purchase of additional options.)

## Initializing the Settings (Initialize Settings)

You can reset the settings of this Instrument to their factory default values. This feature is useful when you want to cancel all of the settings that you have entered or when you want to redo measurement from scratch.



Only initialize this Instrument if you are sure that it is okay for all of the settings to return to their initial values. You cannot undo an initialization. We recommend that you save the setup parameters before initializing this Instrument.

### Items That Cannot Be Reset

The following settings cannot be reset.

Date and time settings, communication settings, the menu language setting, the message language setting, and environment settings

### To Reset All Settings to Their Default Values

While holding down RESET, turn the power switch on. All settings except the date and time settings (display on/off setting will be reset) will be reset to their factory default values.

## Remote Control (Remote Control)

Communication interface for controlling this Instrument from a PC. GP-IB, USB, and Network are the available communication interfaces.

For details, see the communication interface user's manual, IM WT1801E-17EN.



- Only use one communication interface: GP-IB, USB, or Network. If you send commands simultaneously from more than one communication interface, this Instrument will not execute the commands properly.
- When this Instrument is in remote mode and is communicating with a PC, "REMOTE" appears in the center of the screen of this Instrument. All keys except LOCAL are disabled in Remote mode.

### GP-IB

Connects this Instrument to a PC using GP-IB.

#### Address (Address)

- You can select a value between 0 and 30.
- Each device that is connected by GP-IB has its own unique address in the GP-IB system. This address is used to distinguish one device from other devices. Therefore, you must assign a unique address to this Instrument when connecting it to a PC or other device.



When the controller is communicating with this Instrument or with other devices through GP-IB, do not change the address.

#### Notes about Connections

- Several cables can be used to connect multiple devices. However, no more than 15 devices, including the controller, can be connected on a single bus.
- When connecting multiple devices, you must assign a unique address to each device.
- Use cables that are 2 m or shorter in length to connect devices.
- Keep the total length of the cables under 20 m.
- When devices are communicating, have at least two-thirds of the devices on the bus turned on.
- To connect multiple devices, use a star or daisy-chain configuration. Loop and parallel configurations are not allowed.

### USB

Connects this Instrument to a PC using USB.

To remotely control this Instrument using communication commands through the USB port, select USBTMC, and then carry out the following procedure.

- Install the YOKOGAWA USB TMC (Test and Measurement Class) driver on your PC. For information about how to obtain the YOKOGAWA USB TMC driver, contact your nearest YOKOGAWA dealer. You can also access the YOKOGAWA USB driver download webpage and download the driver (<http://tmi.yokogawa.com/service-support/downloads/>).
- Do not use USB TMC drivers (or software) supplied by other companies.



**Network**

Connects this Instrument to a PC using Ethernet.

**IP Address (IP Address)**

Displays the TCP/IP setting that you specified in the Ethernet communication settings.

▶ [Click here.](#)

**Timeout (Time Out)**

If a connection cannot be established between this Instrument and the PC within the amount of time specified here, this Instrument aborts the connection process.

You can set the timeout time to infinity or a value between 1 and 3600.



---

You must set TCP/IP parameters to connect this Instrument to an Ethernet network.

▶ [Click here.](#)

---

**Notes about Connections**

- To connect this Instrument to a PC, be sure to use straight cables through a hub. Correct operation is not guaranteed for a one-to-one connection using a crossover cable.
- Use one of the following types of network cables that support the data rate of your network.
  - UTP (Unshielded Twisted-Pair) cable
  - STP (Shielded Twisted-Pair) cable

**Clearing Remote Mode (LOCAL)**

To clear remote mode, press LOCAL.

▶ [Click here.](#)

## System Configuration (System Config)

You can specify the following settings.

- Date and time
- Language
- LCD adjustment
- USB keyboard language
- Environment settings (Preference)
- Crest factor

### Date and Time Settings (Date/Time)

The date and time of this Instrument.

#### Turning the Display On and Off (Display)

Set whether to show the date and time on this Instrument.

#### Method for Setting the Date and Time (Type)

You can set the method for setting the date and time to one of the following options.

- Manual: Set the date or time manually.
- SNTP: Use an SNTP server to set the time (valid when Ethernet communication is being used).

#### Date and Time (Date/Time)

This setting is valid when the method for setting the date and time is set to Manual.

Set the date and time.

- Setting the date  
The format for setting the date is YYYY/MM/DD (year/month/day). Set the year using the last two digits of the year according to the Gregorian calendar.
- Setting the time  
The format for setting the time is HH:MM:SS (hour:minute:second). The hour can be set to a value from 0 to 23.

#### Setting the Time Difference from Greenwich Mean Time (Time Difference From GMT)

This setting appears when the method for setting the date and time is set to SNTP.

Set the time difference between the region where you are using this Instrument and Greenwich Mean Time to a value within the following range.

-12 hours 00 minutes to 13 hours 00 minutes

For example, Japan standard time is ahead of GMT by 9 hours. In this case, set Hour to 9 and Minute to 00.

#### Checking the Standard Time

Using one of the methods below, check the standard time of the region where you are using the instrument.

- Check the Date, Time, Language, Regional Options on your PC.
- Check the standard time at the URL on the right.<http://www.worldtimeserver.com/>



- This Instrument does not support Daylight Savings Time. To set the Daylight Savings Time, reset the time difference from Greenwich Mean Time.
- Date and time settings are backed up using the internal lithium battery. They are retained even if the power is turned off.
- This Instrument has leap-year information.
- The Time Difference From GMT setting is shared with the same setting found in the SNTP settings in the Ethernet communication (Network) settings. If you change this setting in the date and time settings, the Time Difference From GMT in the Ethernet communication (Network) settings also changes.

## Language (Language)

Set the language that is used in the setup menus and messages.

### Menu Language (Menu Language)

You can choose to display menus using one of the following languages.

- English
- Japanese
- Chinese
- German

### Message Language (Message Language)

Error messages appear when errors occur. You can choose to display these messages and the help using one of the following languages. The error codes that accompany error messages are the same for all languages. For details about error messages, see appendix 6 in the getting started guide, IM WT1801E-03EN.

- English
- Japanese
- Chinese
- German



- Even if you set the menu or message language to a language other than English, some terms will be displayed in English.
  - You can specify different menu and message languages. However, you cannot set Japanese and Chinese to the menu language and the message language at the same time. For example, if you specify Japanese as the menu language and Chinese as the message language, the menu language will also be set to Chinese.
- 

## Adjusting the LCD (LCD)

You can turn off the LCD and adjust its brightness.

### Turning Off the LCD (LCD Turn OFF)

You can turn off the LCD. When the LCD is off, you can turn it back on by pressing a key.

### Automatically Turning Off the LCD (Auto OFF)

The LCD turns off automatically when there are no key operations for a given time period. The LCD turns back on when you press a key.

### Auto Off Time (Auto OFF Time)

You can set the time after which the LCD turns off automatically to a value within the following range.

1 min to 60 min

### Adjusting the Brightness (Brightness)

You can set the brightness to a value from 1 (darkest) to 10 (brightest). You can prolong the LCD service life by decreasing the LCD brightness or by turning off the LCD when you do not need to view it.

### Display Color (Color Settings)

- **Graph Colors (Graph Color)**

You can choose the colors that are used to display the data in the waveform, trend, and vector displays from the following options.

- Default (Default)  
CH1 to CH16 are displayed with different colors.
- Classic (Classic)

The color scheme is the same as that of the WT1600. Some channels from CH1 to CH16 share the same color.

The display data that corresponds to CH1 to CH16 in the waveform, trend, and vector displays is indicated below.

	Waveform Display	Trend Display	Vector Display
CH1	U1	T1	U1
CH2	I1	T2	I1
CH3	U2	T3	U2
CH4	I2	T4	I2
CH5	U3	T5	U3
CH6	I3	T6	I3
CH7	U4	T7	U4
CH8	I4	T8	I4
CH9	U5	T9	U5
CH10	I5	T10	I5
CH11	U6	T11	U6
CH12	I6	T12	I6
CH13	Speed/Aux1	T13	—
CH14	Torque/Aux2	T14	—
CH15	—	T15	—
CH16	—	T16	—

- **Grid Intensity (Grid Intensity)**

You can set the grid intensity to a value from 1 (darkest) to 8 (brightest).

- **Menu Background Color (Base Color)**

You can set the background color of the menu to Blue or Gray.

## USB Keyboard Language (USB Keyboard)

Select the USB keyboard language to use when entering file names, comments, etc. You can use the following keyboards conforming to USB Human Interface Devices (HID) Class Ver. 1.1.

- English: 104 keyboard
- Japanese: 109 Keyboard

For details on how the keys of this instrument are mapped to the keys on a USB keyboard, see appendix 7 in the getting started guide, IM WT1801E-03EN.

## Environment Settings (Preference)

### Display Digits (Resolution)

You can choose to display four digits or five digits of the numeric data. The number of displayed digits for integration measurement functions is fixed at six.

### Frequency Display When the Frequency Measurement Is Less Than Lower Limit (Freq Display at Frequency Low)

When the frequency of the input signal is lower than the frequency that this Instrument can measure, you can choose to display the frequency as “0” or “Error.”

### Motor Display When the Pulse Frequency Measurement Is Less Than the Lower Limit (Motor Display at Pulse Freq Low)

When the pulse frequency of the torque or speed input signal is lower than the frequency that this Instrument can measure, you can choose to display the values of motor evaluation measurement functions as “0” or “Error.”

### Separator and Decimal Point When Data Is Saved in ASCII Format (.csv; Decimal Point for CSV File)

When you save data in ASCII format (.csv), you can choose what type of decimal point to use and how to separate the data.

- Period (Period): The decimal point is a period, and the separator is a comma.
- Comma (Comma): The decimal point is a comma, and the separator is a semicolon.

### Integration Resume Action at Power Failure Recovery (Integration Resume Action at Power Failure Recovery)

► [Click here.](#)

### Menu Font Size (Menu Font Size)

You can set the menu font size to Small or Large.

**Rounding to Zero (Rounding to Zero)**

## • ON

When the voltage or current measurement is one of the following values ???, Urms, Umn, Urmn, Irms, Imn, Irmn, and other measurement functions based on these measurement functions are displayed and output as zero.  $\lambda$  or  $\Phi$  is displayed and output as error [Error].

## • When the Crest Factor Is Set to CF3

When Urms, Uac, Irms, or Iac is 0.3% or less When Umn, Urmn, Imn, or Irmn is 2% or less

## • When the Crest Factor Is Set to CF6 or CF6A

When Urms, Uac, Irms, or Iac is 0.6% or less When Umn, Urmn, Imn, or Irmn is 4% or less

## • ON

The measured values are displayed and output as they are.

**Crest Factor (Crest Factor)**

► [Click here.](#)

## D/A Output (D/A Output Items; option)

You can generate numeric data as  $\pm 5$  V FS DC voltage signals from the rear panel D/A output connector. You can set up to 20 items (channels).

### Output Items (Item)

The measurement functions that you select under Function and Element/ $\Sigma$  appear here.

### Function (Function)

- You can select any of the measurement functions listed under “Items That This Instrument Can Measure.”  
▶ [Click here.](#)
- To output integrated values through D/A conversion, set the rated time of integrated D/A output.  
▶ [Click here.](#)
- You can also choose not to output a measurement function (None). The output for channels that have been set to none is 0 V, because they have no corresponding numeric data.
- When the [D/A output range mode](#) is set to Fixed, the D/A output of channels whose measurement function has been set to Z, Rs, Xs, Rp, Xp, or F1 to F20 is Fixed at 0 V. When the range mode is set to Manual, the channels produce voltages.

### Element (Element/ $\Sigma$ )

- You can select the element/wiring unit from the choices below. The available options vary depending on the installed elements.  
Element1, Element2, Element3, Element4, Element5, Element6,  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$
- If an element in the selected wiring unit does not exist, because there is no data, the output is 0 V. For example, if elements are assigned to  $\Sigma A$  but not to  $\Sigma B$ , the output for the measurement function for  $\Sigma B$  is 0 V.

### Order (Order; option)

When you select a function that has harmonic data, you can set the displayed harmonic order within the following range.

Total (Total value) or 0 (DC) to 500

The orders that can be specified vary depending on the measurement function. For details, see “Harmonic Measurement Function Orders.”

▶ [Click here.](#)

The outputs of orders that exceed the maximum measurable order are 0 V. For information about the maximum measurable harmonic order, see “Maximum Harmonic Order to Be Measured (Max Order).”

▶ [Click here.](#)

### D/A Output Range Mode (Range Mode)

You can select the D/A output range mode from the following options.

#### Fixed (Fixed range mode)


When a measurement function’s rated value is received, +5 V is output. For details, see “Relationship between Output Items and the D/A Output Voltage.”

▶ [Click here.](#)

#### Manual (Manual range mode)

You can set which measurement function values result in a D/A output of -5 V, and which result in a D/A output of +5 V.

By doing so, you can enlarge or reduce (zoom) the D/A output of each channel. For example, if you are measuring a current that fluctuates between 0.6 A and 0.8 A with a measurement range of 1 A, when the D/A output range mode is Fixed, the D/A output voltage will fluctuate between 3.0 V and 4.0 V. When you want to observe the fluctuations more closely, you can use the D/A zoom feature. If you set the D/A output range mode to Manual and set the minimum value to 0.6 and the maximum value to 0.8, this Instrument will produce -5 V when the measured current value is 0.6 A and +5 V when the measured current value is 0.8 A.



### Maximum (Max) and Minimum (Min) Range Values

When the range mode is Manual, you can set the maximum (Max) and minimum (Min) values within the following range.


–9.999 T to 9.999 T



- The output is 0 V if a measurement function is not selected or if there is no numeric data.
- If a scaling factor such as a VT ratio, CT ratio, or power coefficient is applied to a voltage, current, or power value and scaling is enabled, this Instrument produces 100% output (5 V) when the scaled measured value is the same as the scaled rated value (measurement range × scaling factor).
- For  $\Sigma$  functions, this Instrument produces 100% output (5 V) when the measured value is equivalent to the value that is measured when all of the elements in the group are at their rated values. When the elements have different scaling factors, this Instrument produces 100% output (5 V) when the scaled measured values are the same as the scaled rated values (measurement range × scaling factor).

### Relationship between Output Items and D/A Output Voltage


Frequency (the figure is simplified)



### User-Defined Events


- When the event is occurring (True): +5 V
- When the event is not occurring (False): 0 V

## Integrated Values



t<sub>0</sub>: The rated time of integrated D/A output in manual integration mode.  
The timer time in normal or continuous integration mode.

## Other Items



- The outputs for  $\lambda$ ,  $\Phi$ , EaU, and Eal do not exceed  $\pm 5$  V. When the display format of  $\Phi$  is set to 360 degrees, the output for  $\Phi$  ranges from 0 V to +5 V. When the display format of  $\Phi$  is set to 180 degrees (lagging 180° to leading 180°), the output for  $\Phi$  ranges from -5 V to +5 V. However, when an error occurs, the output is approximately 7.5 V. Only the outputs for U-pk and I-pk are approximately -7.5 V when an error occurs.
- The outputs for  $\eta^1$  to  $\eta^4$ , Uhdf, lhdf, Phdf, Uthd, lthd, Pthd, Uthf, lthf, hvf, hcf, and Slip\* are +5 V at 100%.
- The outputs for Utif and Itif are +5 V at 100%.
- The output for an analog torque signal is +5 V when the torque reaches the value of the input range  $\times$  the torque scaling factor  $\times$  the input signal slope (this is the rated value).<sup>1</sup> For example, when the input range is 10 V, if the scaling factor is set to 1 N·m of torque per 1 V of input voltage, the output is +5 V when the torque is 10 N·m.
- The output for an analog rotating speed signal is +5 V when the rotating speed reaches the value of the input range  $\times$  the revolution scaling factor  $\times$  the input signal slope (this is the rated value).<sup>1</sup> For example, when the input range is 10 V, if the scaling factor is set to 100 rpm per 1 V of input voltage, the output is +5 V when the rotating speed is 1000 rpm.
- The output for a pulse rotating speed signal is -5 V when the rotating speed reaches the value specified for Pulse Range Upper  $\times$  -1 (this is the rated value), and the output is +5 V when the rotating speed reaches the value specified for Pulse RangeUpper.<sup>1</sup>
- The output for a pulse torque signal is -5 V when the torque reaches the value specified for Pulse Range Upper  $\times$  -1 (this is the rated value), and the output is +5 V when the torque reaches the value specified for Pulse RangeUpper.<sup>1</sup>
- The output for SyncSp is +5 V when SyncSp is at the rated value for Speed.<sup>1</sup>
- The output for Pm is +5 V when Pm reaches the motor output value obtained from the rated values for the torque and rotating speed.<sup>1</sup>
- The output for Aux1 or Aux2 is +5 V when Aux1 or Aux2 reaches the value of the input range  $\times$  the scaling factor for Aux1 or Aux2  $\times$  the input signal slope (this is the rated value).<sup>2</sup>

<sup>1</sup> Speed and torque waveforms are available on models with the motor evaluation option.

<sup>2</sup> Aux1 and Aux2 waveforms are available on models with the auxiliary input option.



## Self-Test (Selftest)

You can test the keyboard and memory operations.

### Test Items (Test Item)

You can perform the following tests.

#### Memory Test (Memory)

You can test the internal memory to determine whether it is functioning normally. If “Pass” is displayed, it is functioning normally. If an error occurs, “Failed” appears. After the test is completed, “Test Completed” appears.

#### Key Test (Key Board)

- Tests whether or not the front-panel keys are operating properly. If the name of the key that you press is displayed, the key is operating properly.
- If the indicators on the front panel turn on and off in order when you press the left and right cursor keys, they are operating properly.
- To exit the key test, press ESC twice.

#### Keyboard Test (Soft Key)

This test appears when you set Test Item to Key Board. You can test whether the keyboard displayed on the screen is functioning properly. If the characters that you type appear correctly in the keyboard’s input box, the keyboard is functioning properly.

### Executing a Test (Test Exec)

The selected self-test starts.

### If an Error Occurs during a Self-Test

If an error occurs even after you perform self-tests numerous times, contact your nearest YOKOGAWA dealer.

## 23 Other Features

You can set the following items.

- [Zero-level compensation \(CAL\)](#)
- [NULL feature \(NULL SET\)](#)
- [Enabling and Disabling the NULL Feature \(NULL\)](#)
- [Clearing Remote Mode \(LOCAL\)](#)
- [Key lock \(KEY LOCK\)](#)

### Zero-Level Compensation (CAL)

Zero-level compensation is the process of creating a zero-input condition using the internal circuit of this Instrument and setting the level at that point to the zero level. It must be performed to meet the specifications of this instrument.

- Pressing CAL executes zero level compensation.
- This Instrument automatically performs zero-level compensation after you change the measurement range or input filter.



- To make accurate measurements, we recommend that you execute zero-level compensation after warming up the instrument for at least 30 minutes. Also, the ambient temperature should be stable and within the specified range (see chapter 6 in the getting started guide, IM WT1801E-03EN).
- If the measurement range and input filter remain the same for a long period of time, the zero level may change due to the changes in the environment surrounding this Instrument. If this happens, we recommend that you execute zero-level compensation.
- There is a feature that automatically performs zero-level compensation during integration (integration auto calibration).
  - ▶ [Click here.](#)
- Zero-level compensation is not executed when the measurement range is changed by the auto range feature during integration.

### NULL Feature (NULL SET)

You can use the NULL feature to subtract the DC offset while a measurement cable or external sensor is connected.

#### Items to Configure NULL Settings for (Target Element)

##### All

Each time you press NULL, you can enable or disable the NULL feature for all the following input signals.

- U and I signals of each element
- Speed and Torque signals (on models with the motor evaluation option)
- Aux1 and Aux2 (on models with the auxiliary input option)

##### Select

Press NULL to select the input signals that you want to enable, hold, or disable the NULL feature for.

#### Voltage (U)

- All: You can enable or disable the NULL feature for the voltage signals of all elements at the same time.
- U1 to 6: You can enable or disable the NULL feature for the voltage signals of each element separately.

#### Current (I)

- All: You can enable or disable the NULL feature for the current signals of all elements at the same time.
- I1 to 6: You can enable or disable the NULL feature for the current signals of each element separately.

#### Motor (Motor)

- All: You can enable or disable the NULL feature for the Speed and Torque signals at the same time.
- Speed, Torque: You can enable or disable the NULL feature for the Speed and Torque signals separately.

### Auxiliary Input (Aux)

- All: You can enable or disable the NULL feature for the Aux1 and Aux2 signals at the same time.
- Aux1, Aux2: You can enable or disable the NULL feature for the Aux1 and Aux2 signals separately.

### NULL Status (Status)

Enable or disable the NULL feature for each input signal

- ON: When you press NULL, this Instrument sets or updates the NULL value. Afterwards, the NULL value is used to correct the measurement function values.
- Hold: The function of this key varies depending on whether the NULL value has yet to be set or has already been set.
  - When the NULL value has yet to be set  
When you press NULL and enable the NULL feature, this Instrument sets the NULL value. Afterwards, the NULL value is used to correct the measurement function values. If you press NULL again, the NULL feature is disabled, but this Instrument saves the specified NULL value.
  - When the NULL value has already been set  
Even if you press NULL and enable the NULL feature, the NULL value is not updated. The saved NULL value discussed above is used to correct the measurement function values.

For example, if you turn on the power and then immediately enable the NULL feature, the NULL value has not yet been set, so the value measured then is used as the NULL value. If you press NULL again afterwards, the NULL feature is disabled. This Instrument saves the NULL value. Even if you press NULL and enable the NULL feature, the NULL value is not updated. The saved NULL value discussed above is used to correct the measurement function values.

- OFF: Even if you press NULL, the NULL feature is not enabled. Measurement function values are produced with no NULL correction.

The held NULL value is cleared under the following circumstances.

- Operations that cause the NULL values of all inputs to be cleared
  - Turning on the power (the NULL values are not backed up when you turn off the power)
  - Initializing the settings
  - Loading a setup data file
- Operations that cause the NULL value of the input whose settings were changed to be cleared
  - Switching between direct current input and external current sensor input
  - Changing the Sense Type setting for the Speed or Torque motor evaluation input signal

### NULL Values

When you enable the NULL feature, the following measurement values are used as the NULL values.

- Udc and Idc (the voltage and current simple averages)
- Speed and Torque signals (on models with the motor evaluation option)
- Aux1 and Aux2 (on models with the auxiliary input option)

### Measurement Functions Affected by the NULL Feature


All measurement functions are affected by the NULL values.



- If there are no previously measured values for Udc, Idc, Speed, Torque, Aux1, or Aux2, because for example the NULL feature has been turned on before any measurements have been made, the NULL values are set to zero.
  - For measurement functions that are computed based on an element's voltage and current values, the NULL values are subtracted from the sampled voltage and current values.
  - For motor evaluation measurement functions and auxiliary input measurement functions, the NULL values are subtracted from the computed numeric data.
-

## Enabling and Disabling the NULL Feature (NULL)

- Enable the NULL feature. The NULL key illuminates. The NULL indicator illuminates as described below depending on how the Target Element setting has been set.
- All: The NULL indicator illuminates in the upper right of the screen.
- Select: The NULL indicator illuminates to the left of the element, motor or AUX inputs, which are located on the right side of the screen.



- If you press NULL while the NULL feature is enabled, the NULL key light and NULL indicators turn off, and the NULL feature is disabled.



- To make accurate measurements, we recommend that you execute zero-level compensation before enabling the NULL feature.
- The NULL feature is disabled when:
  - The power is turned on.
  - The settings are initialized.
  - A setup data file is loaded.
  - You switch between direct current input and external current sensor input.
  - You change the Sense Type setting for the Speed or Torque motor evaluation input signal.
- If the NULL feature is enabled or disabled while the display is held, the NULL indicator will illuminate or turn off, but the held data will not be affected. Also, the NULL indicator will be highlighted.
- The DC values that the NULL value is based on when the NULL feature is ON are held, but the upper limit of the NULL value is  $\pm 10\%$  of the range when the crest factor is set to CF3. The upper limit of the NULL value is  $\pm 20\%$  of the range when the crest factor is set to CF6 or CF6A.
- When the range is changed, the NULL value upper limit will be determined by the new range. The NULL value upper limit will also be adjusted when the range is decreased by the auto range feature.

## Clearing Remote Mode (LOCAL)

Use this key to switch from remote mode (the REMOTE indicator will illuminate) to local mode (in which front panel key operations are valid). This key is invalid when this Instrument is in local lockout mode.

## Key Lock (KEY LOCK)

When you enable the key lock, this Instrument behaves as described below. You can use the key lock to prevent unintentional operations.

- All key operations are disabled except for those of the power switch and SHIFT+LOCAL (KEY LOCK).
- The key lock indicator ("LOCK") appears in the upper right of the screen.



The key lock remains on or off even after the power is turned off.

# Index

## Symbols

	Page
$\Delta$ Measure .....	2-5
$\Delta$ Measure Mode .....	2-7
$\Delta$ Measure Type .....	2-5
$\eta$ Formula .....	2-3
$\Sigma$ functions .....	1-6
16 Items .....	7-1
16-value display .....	7-1
3P3W>3V3A .....	2-5
4 Items .....	7-1
4-value display .....	7-1
8 Items .....	7-1
8-value display .....	7-1

## A

	Page
advanced waveform display settings .....	10-7
aliasing .....	10-4
all items .....	7-1
All Items display .....	7-1
ampere hours .....	9-1
amplitude .....	10-4
analog auto range .....	4-3, 5-1
analog range .....	4-3, 5-1
anti-aliasing filter .....	3-4
apparent power and reactive power, equation types .....	8-8
apparent power equation .....	8-8
assignment method .....	10-8
attenuation constant .....	2-23
Auto Cal .....	9-11
auto CSV conversion .....	16-8, 17-5
auto enter correction .....	4-8
automatic CSV conversion .....	16-8, 17-5
automatic printing .....	20-2
auto naming .....	18-4
auto off .....	22-6
auto print settings .....	20-2
auto range, auxiliary input .....	5-1
auto range, current .....	2-11
auto range, motor evaluation .....	4-3
auto range, voltage .....	2-9
auto range for the external current sensor range .....	2-12
auxiliary input .....	5-1
aux name .....	5-1
average active power .....	8-5
average count .....	2-23
averaging .....	2-22
averaging type .....	2-22
AVG .....	2-22

## B

	Page
background color .....	22-7
background file .....	7-10
bar .....	12-1
bar graph display .....	12-1
bar graph display range .....	12-2
bar graph display scale .....	12-2
bar graph display windows, number of .....	12-1
bar graph number .....	12-2

## C

	Page
C1+ Position .....	15-2

C1+ Trace .....	15-1
C2x Position .....	15-2
C2x Trace .....	15-1
CAL .....	23-1
calculation .....	4-4, 5-2
capture control settings .....	16-5
capture count .....	16-4
Clear Trend Exec .....	11-2
color .....	19-1, 22-6
Column No .....	7-7, 16-11
Column Num .....	7-7, 16-11
column number .....	7-7, 16-11
columns .....	7-7
columns, number of .....	7-7, 16-11
column settings .....	7-7
comment .....	18-5
config .....	2-16
continuous integration mode .....	9-8
control settings .....	16-5, 17-2
corrected power .....	8-9
correction value .....	4-8
count .....	2-23
crest factor .....	2-17
CSV convert .....	16-9, 17-6
CT scaling .....	2-14
CT ratio .....	2-14
current auto range .....	2-11
current mode for current integration .....	9-11
current range .....	2-11
cursor .....	15-1
cursor 1 .....	15-1
cursor 2 .....	15-1
cursor measurement .....	15-1
cursor movement, linking .....	15-2
cursor movement, path of .....	15-2
cursor path .....	15-2
custom .....	7-3
custom display .....	7-3

## D

	Page
D/A output items .....	22-9
D/A output rated time .....	9-12
D/A output .....	22-9
data, saving .....	18-1
data update interval .....	2-21
date/time .....	22-5
date and time settings .....	22-5
decimal point .....	22-7
decimal point for CSV File .....	22-7
delta-star transformation .....	2-6
Delta>Star .....	2-6
delta computation .....	2-5
delta computation mode .....	2-7
delta computation type .....	2-5
dey lock .....	23-3
DHCP .....	21-2
difference .....	2-5
differential current .....	2-5
differential voltage .....	2-5
DIRECT/MEASURE .....	2-14
display configuration file .....	7-10
display digits .....	22-7
displayed numeric items .....	17-4, 18-3

## Index

display format, bar graph.....	12-1
display format, numeric data .....	7-1, 7-4
display format, trend .....	11-2
display format, vector .....	13-2
display format, waveform.....	10-2
display frame .....	7-6
display interpolation.....	10-7
display item.....	11-3
display items, bar graph .....	12-2
display items, high speed data capturing .....	16-11
display items, vector .....	13-2
display items, waveform .....	10-8
display resolution .....	7-4
display settings .....	10-7
distortion factor .....	3-3
DNS .....	21-2
DNS server .....	21-2
domain suffix .....	21-2
dual harmonics list.....	7-2

## E

Page

efficiency.....	2-3
electrical angle.....	4-8
electrical angle correction.....	4-8
ELEMENT, measurement range of.....	2-8
ELEMENT, numeric data display .....	7-6
element independent.....	2-4
element object .....	9-4
elements .....	1-6
element settings .....	3-3
ending harmonic order.....	12-2
end order .....	12-2
environment settings .....	22-7
Ethernet communication.....	21-1
event-synchronized storage mode .....	17-2
event name.....	8-6
Event No.....	8-6
event synchronization print mode.....	20-2
exponential average .....	2-22
expression .....	8-2, 8-6
external current sensor conversion ratio .....	2-13
external current sensor range.....	2-12
external current sensor range display format .....	2-14
external sync .....	16-6
EXT SENSOR .....	2-12

## F

Page

falling .....	10-5
file name .....	18-4
file operations .....	18-6
file recording state .....	16-2
file save condition .....	17-5, 18-3
file settings.....	16-8, 17-5
font color.....	7-11
font size .....	7-11
FORM, high speed data capturing.....	16-4
FORM, numeric data .....	7-1
FORM, trend.....	11-2
FORM, bar graph.....	12-1
FORM, waveform .....	10-2
FORM, vector .....	13-2
format .....	10-2, 12-1
FREQ FILTER .....	2-20
FREQ MEASURE .....	8-11
frequency filter.....	2-20
frequency measurement.....	8-11
frequency measurement source .....	4-7

FTP server.....	21-3
FU/Fl/η.....	7-5

## G

Page

GP-IB.....	22-3
graticule .....	10-7
Greenwich Mean Time.....	21-7, 22-5
grid.....	10-7
grid intensity .....	22-7

## H

Page

harmonic measurement.....	3-1
high speed data capturing .....	16-1
high speed data capturing state .....	16-1
hold.....	6-1
Hrm1 .....	3-3
Hrm2 .....	3-3
Hrm List Dual .....	7-2
Hrm List Single .....	7-2
HS filter .....	16-5

## I

Page

I Mag.....	13-2
Independent Control .....	9-4
independent input element configuration.....	2-4
independent integration .....	9-4
initialization .....	22-2
Initialize Settings.....	22-2
input element groups .....	3-3
input info .....	2-24
input signal name .....	5-1
input signal type.....	4-2
integrated power .....	9-1
integration, resetting .....	9-6
integration, starting .....	9-5
integration, stopping .....	9-5
integration-synchronized storage mode .....	17-2
integration auto calibration .....	9-11
integration mode .....	9-7
integration synchronization print mode.....	20-2
integration timer.....	9-10
Integ Set .....	9-7
Integ Timer.....	9-10
internal RAM disk .....	18-1
interpolate.....	10-7
interval .....	17-3
interval print mode .....	20-2
ITEM, high speed data capturing.....	16-11
ITEM, numeric data .....	7-4
ITEM, trend.....	11-3
ITEM, bar graph.....	12-2
ITEM, waveform .....	10-8
ITEM, vector .....	13-2
item settings .....	16-8, 17-4

## J

Page

judgment condition .....	8-6
--------------------------	-----

## K

Page

key lock.....	23-3
---------------	------

## L

Page

language.....	22-6
LCD .....	22-6
LCD adjustment.....	22-6
level .....	10-5

linear scale .....	4-3, 5-2
linear scale, motor evaluation .....	4-3
linear scaling, auxiliary input .....	5-2
line filter .....	2-20, 4-4, 5-3
line filter, auxiliary input .....	5-3
line filter, motor evaluation .....	4-4
linkage .....	15-2
Load Bmp .....	7-10
load items .....	7-10
load setup .....	18-5
local .....	22-4, 23-3
lower scale .....	11-3

<b>M</b>	Page
manual CSV conversion .....	16-9, 17-6
manual integration mode .....	9-7
manual storage mode .....	17-2
master .....	8-10
matrix .....	7-1
matrix display .....	7-1
max hold .....	8-5
maximum capturing count .....	16-4
maximum harmonic to be measured .....	3-2
maximum storage count .....	17-2
max order .....	3-2
measured harmonic order .....	3-2
measurement function .....	1-6
measurement period .....	2-18
menu font size .....	22-7
menu language .....	22-6
message language .....	22-6
minimum harmonic to be measured .....	3-2
min order .....	3-2
mode .....	9-7
motor .....	4-1
motor efficiency .....	4-9
motor poles .....	4-7
moving average .....	2-23

<b>N</b>	Page
name .....	8-1
net drive .....	21-6
network .....	21-1, 22-4
network drive .....	18-1, 21-6
normal integration mode .....	9-8
normal mode (Trg) .....	10-1
NULL .....	23-1, 23-3
NULL SET .....	23-1
NULL values .....	23-2
NULL status .....	23-2
numbering .....	18-4
number of displayed items .....	17-4, 18-3
numeric data display .....	7-1
numeric data display, turning on and off .....	13-2

<b>O</b>	Page
offset value, auxiliary input .....	5-2
offset value, motor evaluation .....	4-3
optimization .....	16-4, 17-2
optimize count .....	16-4, 17-2
order .....	1-4
other displays .....	11-1
OTHERS .....	11-1
overview .....	22-2

<b>P</b>	Page
p-p compression .....	10-3
PAGE DOWN .....	7-3
PAGE END .....	7-3
PAGE TOP .....	7-3
PAGE UP .....	7-3
paper feeding .....	20-3
Pc formula .....	8-9
peak over-range jump .....	2-16
peak over status .....	16-11
phase .....	8-10
phase difference .....	8-10
PLL source .....	3-1
pole .....	4-7
power coefficient .....	2-15
power range .....	2-12
preference .....	22-7
preset items .....	7-6
PRINT .....	20-6
Print At Start .....	20-3
print conditions .....	20-1
print count .....	20-2
printing .....	20-1
printing, execution of .....	20-6
print interval .....	20-2
PRINT MENU .....	20-1
print modes .....	20-2
pulse input range .....	4-5
pulse N .....	4-7
pulse range lower .....	4-5
pulse range upper .....	4-5
pulse rating .....	4-5
pulses .....	4-7

<b>Q</b>	Page
q mode .....	9-11

<b>R</b>	Page
RAM-0 .....	18-1
range, auxiliary input .....	5-1
range, motor evaluation .....	4-3
raster .....	10-3
Rated Freq Lower .....	4-6
Rated Freq Upper .....	4-6
Rated Lower .....	4-5
rated time of integrated D/A output .....	9-12
Rated Upper .....	4-5
real-time continuous integration mode .....	9-9
real-time Control .....	9-10
real-time normal integration mode .....	9-9
real-time print mode .....	20-2
real-time storage mode .....	17-2
real time control .....	17-3, 20-3
record to file .....	16-7
remote control .....	22-3
remote mode, clearing .....	22-4, 23-3
Reset Pattern .....	7-6
Resolution .....	22-7
rising .....	10-5
Rounding to Zero .....	22-8

<b>S</b>	Page
S,Q Formula .....	8-8
S/Q/∠Φ .....	7-5
sampling frequency .....	8-9

## Index

save conditions .....	16-8
saved items .....	16-8
save numeric .....	18-2
save setup .....	18-2
save wave .....	18-2
saving numeric data .....	18-2
scale mode .....	12-2
scale value .....	10-7
Scaling .....	4-1, 5-1, 11-3
scaling .....	2-14
scaling, auxiliary input .....	5-1
scaling, motor evaluation .....	4-1
scheduled storage time .....	17-3
scheduled times .....	9-10, 20-3
screen image colors .....	19-1
screen image data formats .....	19-1
screen images, saving .....	19-1
selected items .....	17-4, 18-3
self-test .....	22-12
sense type .....	4-2
sensor ratio .....	2-13
separator .....	22-7
sequence number .....	18-4
setup data, loading .....	18-5
setup data, saving .....	18-2
setup parameter list .....	2-24
S formula .....	8-8
SF scaling .....	2-15
SINGLE .....	6-1
single-shot storage mode .....	17-2
single harmonics list .....	7-2
single measurement .....	6-1
slave .....	8-10
slip .....	4-8
slope .....	10-5
slope, auxiliary input .....	5-2
slope, motor evaluation .....	4-3
SNTP .....	21-7
source .....	4-7
split display .....	14-1
star-delta transformation .....	2-6
Star>Delta .....	2-6
starting harmonic order .....	12-2
starting high speed data capturing .....	16-9
start order .....	12-2
stopping high speed data capturing .....	16-9
storage .....	17-1
storage, resetting .....	17-7
storage, starting .....	17-6
storage, stopping .....	17-7
storage conditions .....	17-1
storage control .....	17-2
storage count .....	17-2
storage interval .....	17-3
storage mode .....	17-2
store at start .....	17-3
stored items .....	17-4
store reset .....	17-7
store set .....	17-1
store start .....	17-6
store stop .....	17-7
string .....	7-11
synchronization source, motor evaluation .....	4-5
synchronized measurement .....	8-10
synchronous speed .....	4-7
sync measure .....	8-10
Sync Source .....	4-5

sync source .....	2-18
sync speed .....	4-7
system config .....	22-5
system overview .....	22-2
system settings .....	22-5

## T

	Page
TCP/IP .....	21-2
test items .....	22-12
Thd formula .....	3-3
time/div .....	10-2, 11-2
time axis .....	10-2, 11-2
time difference from GMT .....	22-5
total efficiency .....	4-9
trademarks .....	ii
trend .....	11-1
trend display .....	11-1
trend display scale .....	11-3
trend display windows, number of .....	11-2
trend number .....	11-3
trends, restarting .....	11-2
trigger .....	10-5, 16-6
triggered mode .....	10-5
trigger event .....	17-3, 20-3
trigger level .....	10-5
trigger point .....	10-6
trigger settings .....	10-5, 16-6
trigger slope .....	10-5
trigger source .....	10-5
Type 1 .....	8-8
Type 2 .....	8-8
Type 3 .....	8-9

## U

	Page
U/I/P .....	7-5
U/I measuring mode .....	16-5
U/I MODE .....	7-5
U Mag .....	13-2
unit .....	4-2, 5-1, 8-1
unit, auxiliary input .....	5-1
unit, motor evaluation .....	4-2
unit, user-defined function .....	8-1
update rate .....	2-21
upper limit .....	12-2
upper scale .....	11-3, 12-2
USB .....	22-3
USB-0 .....	18-1
USB-1 .....	18-1
USB keyboard .....	22-7
USB keyboard language .....	22-7
USB memory .....	18-1
user-defined event name .....	8-6
user-defined event number .....	8-6
user-defined events .....	8-6
user-defined functions .....	8-1
user defined event .....	8-6
user defined function .....	8-1
utility .....	18-6, 22-1

## V

	Page
valid measurement range .....	2-16
var hours .....	9-1
vector .....	13-1
vector display .....	13-1
vector display windows, number of .....	13-2



vector number.....	13-2
vector zoom.....	13-2
vertical axis.....	10-4
vertical position.....	10-9
vertical scale.....	12-2
vertical scale type.....	12-2
vertical zoom.....	10-8
volt-ampere hours.....	9-1
voltage and current measurement modes.....	16-5
voltage auto range.....	2-10
voltage range.....	2-9
VT ratio.....	2-14
VT scaling.....	2-14

## **W** Page

watt hour integration method for each polarity .....	9-11
watt hours.....	9-1
waveform display.....	10-1
waveform display data, saving .....	18-2
waveform display windows, number of.....	10-2
waveform labels.....	10-7
waveform mapping .....	10-8
waveforms, methods for assigning to screens .....	11-2
waveform sampling data.....	10-3
wave label.....	10-7
wave mapping .....	10-8
Web server .....	21-4
Wiring .....	2-1
wiring .....	2-1
wiring system.....	1-6, 2-1
wiring system combination .....	2-1
wiring unit .....	1-6, 2-1
WP/q/TIME .....	7-5
WP± Type.....	9-11

## **X** Page

X-axis position .....	12-2
X Pos.....	7-11

## **Y** Page

Y Pos.....	7-11
------------	------

## **Z** Page

zero-level compensation.....	23-1
------------------------------	------

**WT1801E, WT1802E, WT1803E,  
WT1804E, WT1805E, WT1806E  
Precision Power Analyzer**

**U S E R ' S M A N U A L**

---

Thank you for purchasing the WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, or WT1806E Precision Power Analyzer. This User's Manual explains how to use this instrument. To ensure correct use, please read this manual thoroughly before beginning operation.

Keep this manual in a safe place for quick reference in the event a question arises.

## List of Manuals

The following manuals, including this one, are provided as manuals for this instrument. Please read all the manuals.

Manual Title	Manual No.	Description
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer Features Guide	IM WT1801E-01EN	The supplied CD contains the PDF file of this manual. This manual explains all the features of this instrument other than the communication interface features.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer User's Manual	IM WT1801E-02EN	This manual. The supplied CD contains the PDF file of this manual. The manual explains how to operate this instrument.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer Getting Started Guide	IM WT1801E-03EN	This guide explains the handling precautions and basic operations of this instrument.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer Communication Interface User's Manual	IM WT1801E-17EN	The supplied CD contains the PDF file of this manual. This manual explains the communication interface features of this instrument and how to use them.
WT1801E, WT1802E, WT1803E, WT1804E, WT1805E, WT1806E Precision Power Analyzer	IM WT1801E-92Z1	Document for China

The "EN" and "Z1" in the manual numbers are the language codes.

Contact information of Yokogawa offices worldwide is provided on the following sheet.

Document No.	Description
PIM 113-01Z2	List of worldwide contacts

## Notes

- The contents of this manual are subject to change without prior notice as a result of continuing improvements to the instrument's performance and functionality. The figures given in this manual may differ from those that actually appear on your screen.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without the permission of YOKOGAWA is strictly prohibited.
- The TCP/IP software of this product and the documents concerning it have been developed/created by YOKOGAWA based on the BSD Networking Software, Release 1 that has been licensed from the Regents of the University of California.

## Trademarks

- Microsoft, Internet Explorer, MS-DOS, Windows, Windows Vista, Windows 7, Windows 8, Windows 8.1, and Windows 10 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are either registered trademarks or trademarks of Adobe Systems Incorporated.
- Modbus is a registered trademark of AEG Schneider.
- In this manual, the ® and TM symbols do not accompany their respective registered trademark or trademark names.
- Other company and product names are registered trademarks or trademarks of their respective holders.

## Revisions

- 1st Edition: September 2016
- 2nd Edition: June 2017
- 3rd Edition: October 2017

# Symbols and Notation Used in This Manual

## Notes and Cautions

The notes and cautions in this manual are categorized using the following symbols.



Improper handling or use can lead to injury to the user or damage to the instrument. This symbol appears on the instrument to indicate that the user must refer to the user's manual for special instructions. The same symbol appears in the corresponding place in the user's manual to identify those instructions. In the manual, the symbol is used in conjunction with the word "WARNING" or "CAUTION."

### **WARNING**

Calls attention to actions or conditions that could cause serious or fatal injury to the user, and precautions that can be taken to prevent such occurrences.

### **CAUTION**

Calls attention to actions or conditions that could cause light injury to the user or damage to the instrument or user's data, and precautions that can be taken to prevent such occurrences.

French

### **AVERTISSEMENT**

Attire l'attention sur des gestes ou des conditions susceptibles de provoquer des blessures graves (voire mortelles), et sur les précautions de sécurité pouvant prévenir de tels accidents.

### **ATTENTION**

Attire l'attention sur des gestes ou des conditions susceptibles de provoquer des blessures légères ou d'endommager l'instrument ou les données de l'utilisateur, et sur les précautions de sécurité susceptibles de prévenir de tels accidents.

### **Note**

Calls attention to information that is important for proper operation of the instrument.

## Units

k	Denotes 1000. Example: 100 kHz
K	Denotes 1024. Example: 720 KB (file size)

# Key Operation and Functions

## Key Operation

### How to Use Setup Menus That Appear When Keys Are Pressed

The operation after you press a key varies depending on the key that you press.



- A: Press the soft key to use the cursor keys to configure this setting. Use the cursor keys to set the value or select an item.
- B: A related setup menu appears when you press the soft key.
- C: The selected setting switches each time you press the soft key.
- D: A dialog box or the keyboard appears when you press the soft key.  
Use the cursor keys and the SET key to configure the settings.
- E: Press the soft key to display a selection menu.  
Press the soft key that corresponds to the appropriate setting.
- F: Press the soft key to use the cursor keys to configure this setting. After you configure the setting, the status of the selected setting switches each time you press the soft key.
- G: Press the soft key to execute the specified feature.
- H: Press the soft key to apply the value assigned to the key.

### How to Display the Setup Menus That Are Written in Purple below the Keys

In the explanations in this manual, "SHIFT+key name (written in purple)" is used to indicate the following operation.

1. Press **SHIFT**. The SHIFT key lights to indicate that the keys are shifted.  
Now you can select the setup menus written in purple below the keys.
2. Press the key that you want to display the setup menu of.

### ESC Key Operation

If you press **ESC** when a setup menu or available options are displayed, the screen returns to the menu level above the current one. If you press **ESC** when the highest level menu is displayed, the setup menu disappears.

## RESET Key Operation

If you press **RESET** when you are using the cursor keys to set a value or select an item, the setting is reset to its default value (depending on the operating state of this instrument, the setting may not be reset).

## SET Key Operations

The operation varies as indicated below depending on what you are setting.

- For a setup menu that has two values that you use the cursor keys to adjust  
Press **SET** to switch the value that the cursor keys adjust.
- For a menu that has the cursor keys + SET mark (◀+SET) displayed on it  
Press **SET** to confirm the selected item.

## Cursor Keys Operations

The operation varies as indicated below depending on what you are setting.


- When setting a value  
Up and down **cursor** keys: Increases and decreases the value  
Left and right **cursor** keys: Changes which digit to set
- When selecting the item to set  
Up and down **cursor** keys: Moves the cursor between settings

## How to Enter Values in Setup Dialog Boxes

- Use the keys to display the appropriate setup dialog box.
- Use the **cursor** keys to move the cursor to the item that you want to set.
- Press **SET**. The operation varies as indicated below depending on what you are setting.
  - A selection menu appears.
  - A check box is selected or cleared.
  - An item is selected.
  - A table of settings is selected.


### Displaying a Selection Menu and Selecting an Item

Select OFF or ON.




Displays the selection menu

After selecting an item with the cursor keys, press **SET** to confirm it.




### Setting Items in a Table



After moving the cursor to the table, press **SET** to select the setting that you want to change.

Use the cursor keys and the SET key to select a table entry.



## How to Clear Setup Dialog Boxes

Press **ESC** to clear the setup dialog box from the screen.

# Entering Values and Strings

## Entering Values

### Using the Cursor Keys to Enter Values

Select the appropriate item using the soft keys, and change the value using the cursor keys and the SET key. This manual sometimes describes this operation simply as “using the cursor keys.”



### Note

Some items that you can set using the cursor keys are reset to their default values when you press the RESET key.

## Entering Character Strings

Use the keyboard that appears on the screen to enter character strings such as file names and comments. Use the cursor keys and the SET key to operate the keyboard and enter a character string.

### How to Operate the Keyboard


1. After bringing up the keyboard, use the **cursor** keys to move the cursor to the character that you want to enter.
2. Press **SET** to enter the character.
  - If a character string has already been entered, use the arrow soft keys (< and >) to move the cursor to the position you want to insert characters into.
  - To switch between uppercase and lowercase letters, move the cursor to **CAPS** on the keyboard, and then press **SET**.
  - To delete the previous character, press the **Back Space** soft key.
  - To delete all the characters, press the **All Clear** soft key.
3. Repeat steps 1 and 2 to enter all the characters in the string.
  - Select  on the keyboard or press the **History** soft key to display a list of character strings that you have entered previously. Use the cursor keys to select a character string, and press **SET** to enter the selected character string.
  - Select  on the keyboard to display a list of preset character strings. The following operands and equations, which are used with user-defined functions, are included as preset character strings.

ABS(	PPK(	HVF(	RMS(
SQR(	MPK(	HCF(	MN(
SQRT(	CF	KFACT(	RMN(
LOG(	TI(	EAU(	DC(
LOG10(	THD(	EAI(	AC(
EXP(	THF(	PLLFRQ(	PC(
NEG(	TIF(		


Use the **cursor** keys to select a character string, and press **SET** to enter the selected character string.

4. Press the **ENTER** soft key, or move the cursor to ENTER on the keyboard, and press **SET** to confirm the character string and clear the keyboard.





**Input History: A List of Previously Entered Character Strings**



After selecting an item with the cursor keys, press SET to confirm it.

**Note**

- @ cannot be entered consecutively.
- File names are not case-sensitive. Comments are case-sensitive. The following file names cannot be used due to MS-DOS limitations:  
AUX, CON, PRN, NUL, CLOCK, COM1 to COM9, and LPT1 to LPT9
- For details on file name limitations, see the features guide, IM WT1801E-01EN.

---

# Contents

List of Manuals.....	i
Symbols and Notation Used in This Manual.....	iii
Key Operation and Functions.....	iv
Entering Values and Strings.....	vi

## Chapter 1 Basic Measurement Conditions

1.1	Configuring the Wiring System Settings.....	1-1
1.2	Setting the Voltage and Current Ranges.....	1-2
1.3	Setting the External Current Sensor Range (Option).....	1-4
1.4	Setting the External Current Sensor Conversion Ratio (Option).....	1-5
1.5	Setting the Display Format of the External Current Sensor Range (Option).....	1-6
1.6	Setting the Scaling Feature When Using a VT or CT.....	1-7
1.7	Setting the Valid Measurement Range.....	1-9
1.8	Setting the Efficiency Equation.....	1-12
1.9	Turning the Independent Input Element Configuration On and Off.....	1-13
1.10	Setting Delta Computation.....	1-14
1.11	Setting the Crest Factor.....	1-15
1.12	Setting Measurement Periods.....	1-16
1.13	Setting Line Filters.....	1-17
1.14	Setting Frequency Filters.....	1-18
1.15	Setting the Data Update Interval.....	1-19
1.16	Setting Averaging.....	1-20
1.17	Displaying the Menu for Configuring All Elements.....	1-21
1.18	Displaying the Setup Parameter List.....	1-22

## Chapter 2 Harmonic Measurement Conditions (Option)

2.1	Setting Harmonic Measurement Conditions.....	2-1
-----	--	-----

## Chapter 3 Motor Evaluation Conditions (Option)

3.1	Setting Motor Evaluation Conditions.....	3-1
-----	--	-----

## Chapter 4 Auxiliary Input Conditions (Option)

4.1	Setting Auxiliary Input Conditions.....	4-1
-----	---	-----

## Chapter 5 Holding Measured Values and Performing Single Measurements

5.1	Holding Measured Values.....	5-1
5.2	Performing Single Measurements.....	5-2

## Chapter 6 Power Measurement (Numeric Data Display)

6.1	Setting the Display Format.....	6-1
6.2	Switching the Displayed Page.....	6-2
6.3	Changing the Displayed Items on the 4 Items, 8 Items, and 16 Items Displays.....	6-4
6.4	Changing the Displayed Items on the Matrix Display.....	6-6
6.5	Changing the All Items Display.....	6-9
6.6	Changing the Harmonics List Display (Option).....	6-10
6.7	Setting the Custom Display.....	6-12

**Chapter 7 Computations**

7.1	Setting User-Defined Functions .....	7-1
7.2	Setting User-Defined Events .....	7-2
7.3	Setting Apparent Power, Reactive Power, and Corrected Power Equations.....	7-3
7.4	Setting the Sampling Frequency .....	7-4
7.5	Setting the Phase Difference Display Format.....	7-5
7.6	Setting Master and Slave Synchronized Measurement .....	7-6
7.7	Setting the Voltages or Currents Whose Frequencies Will Be Measured .....	7-7

**Chapter 8 Integrated Power (Watt hour)**

8.1	Setting Independent Integration .....	8-1
8.2	Setting Integration Conditions .....	8-2
8.3	Starting, Stopping, and Resetting Integration.....	8-5
8.4	Integration Resume Action at Power Failure Recovery .....	8-6

**Chapter 9 Waveform Display**

9.1	Setting the Display Format .....	9-1
9.2	Turning the Display of Waveforms On and Off and Setting the Vertical Zoom Factors and Vertical Positions .....	9-3

**Chapter 10 Trend Display**

10.1	Setting the Display Format .....	10-1
10.2	Turning the Trend Display On and Off and Setting the Measurement Functions to Display and the Vertical Scales .....	10-3

**Chapter 11 Bar Graph Display (Option)**

11.1	Setting the Display Format .....	11-1
11.2	Setting the Measurement Function to Display and the Vertical Scale .....	11-2

**Chapter 12 Vector Display (Option)**

12.1	Setting the Display Format .....	12-1
12.2	Setting the Element and Wiring Unit to Display and the Zoom Factor .....	12-2

**Chapter 13 Split Display**

13.1	Configuring the Split Display .....	13-1
------	-------------------------------------	------

**Chapter 14 Cursor Measurements**

14.1	Performing Cursor Measurements on Waveforms .....	14-1
14.2	Performing Cursor Measurements on Trends .....	14-2
14.3	Performing Cursor Measurements on Bar Graphs .....	14-3

**Chapter 15 High Speed Data Capturing**

15.1	Setting the Number of Data Captures and Configuring the Capture Control Settings ...	15-1
15.2	Configuring the Save Conditions of Captured Numeric Data .....	15-4
15.3	Changing the Displayed Items for High Speed Data Capturing .....	15-6
15.4	Starting and Stopping High Speed Data Capturing.....	15-9

**Chapter 16 Storing Data**

16.1	Configuring Storage Control .....	16-1
16.2	Setting the Numeric Data Items to Store .....	16-4
16.3	Configuring the Save Conditions of Stored Numeric Data .....	16-5
16.4	Starting, Stopping, and Resetting Storage .....	16-6


**Chapter 17 Saving and Loading Data**

17.1	Connecting USB Memory Devices .....	17-1
17.2	Saving Setup Parameters .....	17-3
17.3	Saving Waveform Display Data .....	17-5
17.4	Saving Numeric Data .....	17-6
17.5	Loading Setup Parameters .....	17-8
17.6	File Operations .....	17-9

**Chapter 18 Saving Screen Images**

18.1	Saving Screen Images .....	18-1
------	----------------------------	------

**Chapter 19 Printing Screen Images and Numeric Data (Option)**

 19.1	Loading Roll Paper into the Built-In Printer (Option) .....	19-1
19.2	Printing Using the Built-in Printer (Option) .....	19-5

**Chapter 20 Ethernet Communication**

20.1	Connecting this instrument to a Network .....	20-1
20.2	Configuring TCP/IP Settings .....	20-3
20.3	Accessing this instrument from a PC (FTP Server) .....	20-4
20.4	Monitoring the display of this instrument from a PC (Web Server) .....	20-5
20.5	Connecting to a Network Drive .....	20-8
20.6	Using SNTP to Set the Date and Time .....	20-9

**Chapter 21 Other Features**

21.1	Viewing System Information (Overview) .....	21-1
21.2	Initializing Settings .....	21-2
21.3	Setting the Message, Menu, and USB Keyboard Languages .....	21-3
21.4	Setting the Screen Brightness and Configuring the Display Color Settings .....	21-4
21.5	Configuring the Environment Settings .....	21-5
21.6	Configuring D/A Output Items (Option) .....	21-6
21.7	Carrying Out Self-Tests (Selftest) .....	21-7
21.8	Performing Zero-Level Compensation .....	21-9
21.9	Using the NULL Feature .....	21-10
21.10	Locking the Keys .....	21-11

**Appendix**

Appendix 1	Messages and Corrective Actions .....	App-1
------------	---------------------------------------	-------

**Index**

## 1.1 Configuring the Wiring System Settings

This section explains the following settings for wiring systems:

- Wiring system
- Wiring unit
- Wiring pattern


► “Wiring System (Wiring)” in the features guide

### Wiring Settings (Wiring Settings)

Press **WIRING** and then the **Wiring** soft key to display the following screen.

**Set the wiring system (1P2W, 1P3W, 3P3W, 3P4W, 3P3W(3V3A)).**

When you select an input element, the wiring systems that you can select are displayed. Select the wiring system from those displayed.



#### Wiring System Pattern

- If you select 1P3W, 3P3W, 3P4W, or 3P3W(3V3A) for the wiring system, the wiring unit is set with the two or three input elements adjacent to the selected element whose element numbers are larger than the selected element.
- On models that have six input elements installed, up to three wiring units ( $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$ ) are automatically set. The wiring unit symbols  $\Sigma A$ ,  $\Sigma B$ , and  $\Sigma C$  are attached to the element numbers in order, starting with the smallest number.

#### Note

- Because the wiring system with the largest element number is automatically determined according to the settings of the wiring systems with smaller element numbers, the element with the largest element number cannot be selected.
- You cannot set the wiring units for larger element numbers before the wiring units for smaller element numbers.
- To measure voltage, current, and active power  $\Sigma$  functions using high speed data capturing, set the wiring system to 3P4W or 3P3W (3V3A). When the wiring system is set to 1P3W or 3P3W, voltage, current, and active power  $\Sigma$  functions are not measured.

## 1.2 Setting the Voltage and Current Ranges

This section explains the following settings for the voltage and current ranges:

- Input element
- Auto range
- Fixed range
  - ▶ “Voltage Range (RANGE UP/DOWN (V))” and “Current Range (RANGE UP/DOWN (A))” in the features guide

### Voltage Range (VOLTAGE RANGE)

1. Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the voltage range of.
  - While the setup menu is displayed, press **ESC**. Information corresponding to the input elements or wiring units will be displayed highlighted on the menu. You can also use the soft keys corresponding to the highlighting to select the input element or wiring unit.
  - Press **SHIFT**+the **ELEMENT** (ALL) key for setting ranges to collectively configure all the input elements for which the following conditions are met.  
The input element type (for 5 A or for 50 A) is the same.  
The valid measurement range setting (see section 1.7) is the same.
2. Follow the instructions below to set the voltage range.

#### Auto Range Setting


Press the voltage range's **AUTO** key.

#### Setting the Fixed Range

Press the voltage range's **fixed range** keys (▲ and ▼) to set the voltage range.

#### Available Voltage Range Options

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
1.5 V, 3 V, 6 V, 10 V, 15 V, 30 V, 60 V, 100 V, 150 V, 300 V, 600 V, 1000 V	0.75 V, 1.5 V, 3 V, 5 V, 7.5 V, 15 V, 30 V, 50 V, 75 V, 150 V, 300 V, 500 V



#### Note

When Element Independent (see section 1.9) is set to OFF, the voltage ranges of input elements that are assigned to the same wiring unit are set to the same range. When Element Independent is set to ON, you can set the voltage range of input elements that are assigned to the same wiring unit separately.

## Current Range (CURRENT RANGE)

- Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the current range of.
  - While the setup menu is displayed, press **ESC**. Information corresponding to the input elements or wiring units will be displayed highlighted on the menu. You can also use the soft keys corresponding to the highlighting to select the input element or wiring unit.
  - Press **SHIFT+the ELEMENT** (ALL) key for setting ranges to collectively configure all the input elements for which the following conditions are met.  
 The input element type (for 5 A or for 50 A) is the same.  
 The valid measurement range setting (see section 1.7) is the same.
- Follow the instructions below to set the current range.

### Auto Range Setting

Press the current range's **AUTO** key.

### Setting the Fixed Range

Press the current range's **fixed range** keys (**▲** and **▼**) to set the current range.


### Available Current Range Options

#### • 5 A Input Element

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
10 mA, 20 mA, 50 mA, 100 mA, 200 mA, 500 mA, 1 A, 2 A, 5 A	5 mA, 10 mA, 25 mA, 50 mA, 100 mA, 250 mA, 500 mA, 1 A, 2.5 A

#### • 50 A Input Element

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
1 A, 2 A, 5 A, 10 A, 20 A, 50 A	500 mA, 1 A, 2.5 A, 5 A, 10 A, 25 A



### Note

When Element Independent (see section 1.9) is set to OFF, the current ranges of input elements that are assigned to the same wiring unit are set to the same range. When Element Independent is set to ON, you can set the current range of input elements that are assigned to the same wiring unit separately.

## 1.3 Setting the External Current Sensor Range (Option)

This section explains the following settings for external current sensor ranges (current ranges that are used when external current sensors are being used). This feature is available on models with the /EX1 to /EX6 option.

- Input element
- External current sensor
- Auto range
- Fixed range

► “External Current Sensor Range (EXT SENSOR; option)” in the features guide

1. Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the external current sensor range of.
  - While the setup menu is displayed, press **ESC**. Information corresponding to the input elements or wiring units will be displayed highlighted on the menu. You can also use the soft keys corresponding to the highlighting to select the input element or wiring unit.
  - Press **SHIFT+the ELEMENT (ALL)** key for setting ranges to collectively configure all the input elements for which the following conditions are met.  
The input element type (for 5 A or for 50 A) is the same.  
The valid measurement range setting (see section 1.7) is the same.
2. Press **EXT SENSOR** to illuminate the EXT SENSOR key.  
Press **EXT SENSOR** again to turn the EXT SENSOR key off. In this state, you can set the current range that is used when current is applied directly to this instrument (see section 1.2).
3. Follow the instructions below to set the external current sensor range.

### Auto Range Setting

Press the current range's **AUTO** key.


### Setting the Fixed Range

Press the current range's **fixed range** keys (▲ and ▼) to set the external current sensor range.

### Available External Current Sensor Range Options

When the display format of the external current sensor range is set to DIRECT, you can select the range from the available options shown in the following table (the unit is mV or V). When the display format is set to MEAS, the setup range is set to the value from the following table divided by the external current sensor conversion ratio (the unit is A). For instructions on how to set the display format of the external current sensor range, see section 1.5.

When the crest factor is set to 3	When the crest factor is set to 6 or 6A
50 mV, 100 mV, 200 mV, 500 mV, 1 V, 2 V, 5 V, 10 V	25 mV, 50 mV, 100 mV, 250 mV, 500 mV, 1 V, 2.5 V, 5 V



### Note

When Element Independent (see section 1.9) is set to OFF, the external current sensor ranges of input elements that are assigned to the same wiring unit are set to the same range. When Element Independent is set to ON, you can set the external current sensor range of input elements that are assigned to the same wiring unit separately.



## 1.4 Setting the External Current Sensor Conversion Ratio (Option)


This section explains the following settings for the external current sensor conversion ratio. This feature is available on models with the /EX1 to /EX6 option.

- Conversion ratio
- Copying the conversion ratio

► “External Current Sensor Conversion Ratio (SENSOR RATIO; option)” in the features guide

### Sensor Ratio Menu

Press **SHIFT+EXT SENSOR** (SENSOR RATIO) to display the following menu.



### Note

When using the dedicated shunt box, you can select an external current sensor conversion ratio preset in the menu for configuring all elements (see section 1.17).

#### External Current Sensor Range and Conversion Ratio Configuration Example

When measuring a current with a maximum value of 100 A using a current sensor that produces 10 mV when 1 A of current is flowing, the maximum voltage that the current sensor produces is  $10 \text{ mV/A} \times 100 \text{ A} = 1 \text{ V}$ .

Therefore, configure the settings as indicated below.

- External current sensor range: 1 V
- External current sensor conversion ratio: 10 mV/A


## 1.5 Setting the Display Format of the External Current Sensor Range (Option)

This section explains the following setting for the external current sensor range. This feature is available on models with the /EX1 to /EX6 option.

- Display format

► “External Current Sensor Range Display Format (DIRECT/MEASURE; option)”  
in the features guide

1. Press the **ELEMENT** key for setting ranges to select the input element or wiring unit that you want to set the external current sensor range of.
  - If you press **ESC** to clear the setup menu from the screen, soft keys corresponding to the input elements or wiring units will be displayed on the menu. You can use these soft keys to select the input element or wiring unit.
  - Press **SHIFT+the ELEMENT** (ALL) key for setting ranges to collectively configure all the input elements for which the following conditions are met.
    - The input element type (for 5 A or for 50 A) is the same.
    - The valid measurement range setting (see section 1.7) is the same.
2. Press **EXT SENSOR** to illuminate the EXT SENSOR key.  
Press **EXT SENSOR** again to turn the EXT SENSOR key off.
3. Press **SHIFT+the current range's CONFIG** (DIRECT/MEASURE) key. The DIRECT indicator or MEAS indicator, which indicates the display format, illuminates. The external current sensor range is displayed in the indicated display format.  
  
Press **SHIFT+the current range's CONFIG** (DIRECT/MEASURE) key again to switch the display format. The indicators illuminate and turn off appropriately.



## 1.6 Setting the Scaling Feature When Using a VT or CT


This section explains the following settings for measuring voltage through an external VT (voltage transformer) and current that through an external CT (current transformer):

- Turning the scaling feature on and off
- VT ratio
- CT ratio
- Power coefficient

► “Scaling (SCALING)” in the features guide


### Scaling Menu

Press **SCALING** to display the following menu.



### Setting the VT Ratio (VT Scaling)

Press the **VT Scaling** soft key to display the following menu.



### Setting the CT Ratio (CT Scaling)

Press the **CT Scaling** soft key to display the following menu.

CT Scaling

◊ Element 1

3.0000

◊ Element 2

1.0000

◊ Element 3

1.0000

◊ Element 4

1.0000

◊ Element 5

1.0000

◊ Element 6

1.0000

Exec Copy Σ

Cursor (use the ◀▶ cursor keys to move it)

Set the CT ratio.

Copies the CT ratio

The CT ratio of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

**Note**

When using the dedicated CT, you can select a CT ratio preset in the menu for configuring all elements (see section 1.17).

### Setting the Power Coefficient (SF Scaling)

Press the **SF Scaling** soft key to display the following menu.

SF Scaling

◊ Element 1

3.0000

◊ Element 2

1.0000

◊ Element 3

1.0000

◊ Element 4

1.0000

◊ Element 5

1.0000

◊ Element 6

1.0000

Exec Copy Σ

Cursor (use the ◀▶ cursor keys to move it)

Set the power coefficient.

Copies the power coefficient

The power coefficient of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

## 1.7 Setting the Valid Measurement Range

This section explains the following settings for the valid measurement range:

- Valid measurement range
- Measurement ranges that this instrument can switch to when a peak over-range occurs
  - ▶ [“Valid Measurement Range \(CONFIG \(V\)/CONFIG \(A\)\)” in the features guide](#)

### Setting the Valid Voltage Measurement Range (Voltage Range Configuration)

Press the voltage range's **CONFIG** key to display the following screen.

**Valid measurement range**

- The measurement range switches (in order) between the ranges whose check boxes are selected.
- Ranges whose check boxes are not selected are skipped.
- When Element Independent (see section 1.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

**Available voltage range options**

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).

If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in yellow.

For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which an input element is not installed

**Available options for the measurement ranges that this instrument can switch to when a peak over-range occurs**


**Measurement range to switch to when a peak over-range occurs**

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing **AUTO**), this instrument operates as follows:
  - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
  - When the measurement range to switch to when a peak over-range occurs is set to OFF, the measurement range increases in the order specified by the measurement ranges whose check boxes have been selected.

Voltage Range Configuration						
	Element1	Element2	Element3	Element4	Element5	Element6
1000V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
600V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
300V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
150V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
100V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
60V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
30V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
15V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
10V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
6V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1.5V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Peak Over Jump	OFF	1000V	1000V	OFF	OFF	OFF

## Setting the Valid Current Measurement Range (Current Range Configuration)

Press the current range's **CONFIG** key to display the following menu.



## Setting the Valid Measurement Range of 50 A Input Elements (50A Input Element)—Direct Input Range

### Valid measurement range

- The measurement range switches (in order) between the ranges whose check boxes are selected.
- Ranges whose check boxes are not selected are skipped.
- When Element Independent (see section 1.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

### Available current range options

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).



If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in yellow.


Current Range Configuration						
	Element1	Element2	Element3	Element4	Element5	Element6
50A	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
20A	-	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
10A	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
5A	-	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
2A	-	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	-
1A	-	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	-
Peak Over Jump	-	50A	50A	OFF	OFF	-



For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which a 50 A input element is not installed

Available options for the measurement ranges that this instrument can switch to when a peak over-range occurs



### Measurement range to switch to when a peak over-range occurs

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing AUTO), this instrument operates as follows:
  - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
  - When the measurement range to switch to when a peak over-range occurs is set to OFF, the measurement range increases in the order specified by the measurement ranges whose check boxes have been selected.

## Setting the Valid Measurement Range of 5 A Input Elements (5A Input Element)—Direct Input Range

### Valid measurement range

- The measurement range switches (in order) between the ranges whose check boxes are selected.
- Ranges whose check boxes are not selected are skipped.
- When Element Independent (see section 1.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

### Available current range options

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).



Current Range Configuration

	Element1	Element2	Element3	Element4	Element5	Element6
5A	<input checked="" type="checkbox"/>	-	-	-	-	-
2A	<input type="checkbox"/>	-	-	-	-	-
1A	<input checked="" type="checkbox"/>	-	-	-	-	-
500mA	<input checked="" type="checkbox"/>	-	-	-	-	-
200mA	<input type="checkbox"/>	-	-	-	-	-
100mA	<input checked="" type="checkbox"/>	-	-	-	-	-
50mA	<input type="checkbox"/>	-	-	-	-	-
20mA	<input type="checkbox"/>	-	-	-	-	-
10mA	<input type="checkbox"/>	-	-	-	-	-
Peak Over Jump	5A	-	-	-	-	-

50A 5A ExtSensor

If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in yellow.



For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which a 5 A input element is not installed

Available options for the measurement ranges that this instrument can switch to when a peak over-range occurs



### Measurement range to switch to when a peak over-range occurs

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing **AUTO**), this instrument operates as follows:
  - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
  - When the measurement range to switch to when a peak over-range occurs is set to OFF, the measurement range increases in the order specified by the measurement ranges whose check boxes have been selected.

## Setting the Valid Measurement Range of External Current Sensors (Ext Sensor Input Element)

### Valid measurement range

- The measurement range switches (in order) between the ranges whose check boxes are selected.
- Ranges whose check boxes are not selected are skipped.
- When Element Independent (see section 1.9) is set to OFF, the input elements that are assigned to the same wiring unit are set to the same status.

### Available external current sensor range options

For each range, you can set whether the range is a valid measurement range for all input elements (All ON) or not (All OFF).



Current Range Configuration

	Element1	Element2	Element3	Element4	Element5	Element6
10V	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
5V	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
2V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
1V	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
500mV	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
200mV	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
100mV	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	-
50mV	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	-
Peak Over Jump	OFF	10V	10V	OFF	OFF	-

50A 5A ExtSensor

If the measurement range to switch to when a peak over-range occurs has been selected, the range background is displayed in yellow.



For each input element or wiring unit, you can set all ranges as valid measurement ranges (All ON).

Slot in which an input element is not installed

Available options for the measurement ranges that this instrument can switch to when a peak over-range occurs



### Measurement range to switch to when a peak over-range occurs

- When Element Independent is set to OFF, the input elements that are assigned to the same wiring unit are set to the same range.
- If auto range is on (you can turn it on by pressing **AUTO**), this instrument operates as follows:
  - When a peak over-range occurs, the measurement range increases to the range specified here, skipping the ranges in between.
  - When the measurement range to switch to when a peak over-range occurs is set to OFF, the measurement range increases in the order specified by the measurement ranges whose check boxes have been selected.

## 1.8 Setting the Efficiency Equation

This section explains the following settings for the efficiency equation:

- Efficiency equation
- Summation of the active power and motor output<sup>3</sup>

► “Efficiency Equation ( $\eta$  Formula)” in the features guide

### Setting the Efficiency Equation ( $\eta$ Formula)

Press **WIRING** and then the  **$\eta$  Formula** soft key to display the following screen.

The screenshot shows the **η Formula** screen with the following elements:

- Element**: A row of six buttons labeled [ 1 ], [ 2 ], [ 3 ], [ 4 ], [ 5 ], [ 6 ].
- Installed input elements**: A row of six buttons labeled [ 1P2W ], [ 3P3W:Σ A ], [ 1P2W ], [ 1P3W:Σ B ], [ 1P2W ], [ 1P3W:Σ B ].
- The set wiring systems**: A row of six buttons labeled [ OFF ], [ OFF ], [ OFF ], [ OFF ], [ OFF ], [ OFF ].
- Set the denominator and numerator of the efficiency equation to the active power and motor power measurement functions.**: A row of six buttons labeled (P1 to P6, <sup>1</sup> PΣA to PΣC, <sup>2</sup> Pm, <sup>3</sup> Udef1, Udef2).
- You can set up to four equations: η1 to η4.**: A row of six buttons labeled η1 =, η2 =, η3 =, η4 =, η1 =, η2 =.
- Define Udef1 and Udef2**: A row of six buttons labeled Udef1 =, Udef2 =, Udef1 =, Udef2 =, Udef1 =, Udef2 =.

The screen also displays the following text:

η1 =  \* 100[%] η2 =  \* 100[%]

η3 =  \* 100[%] η4 =  \* 100[%]

Udef1 =  +  +  +

Udef2 =  +  +  +

To add active powers and motor output and use them in  $\eta_1$  to  $\eta_4$ , use Udef1 and Udef2.

- 1 Can be set within the range of the installed input elements.
- 2 Can be set within the range of the wiring unit that is automatically determined by the installed input elements.
- 3 Can be set on models with the /MTR option.



## 1.9 Turning the Independent Input Element Configuration On and Off

This section explains how to turn the independent input element configuration on and off.

► [“Independent Input Element Configuration \(Element Independent\)” in the features guide](#)

### Wiring Menu

Press **WIRING** to display the following menu.



Turns independent input element configuration on and off

## 1.10 Setting Delta Computation

- Delta computation type
- Delta computation mode

► “Delta Computation ( $\Delta$  Measure)” in the features guide

### Delta Computation Settings ( $\Delta$ Measure)

Press **WIRING** and then the  $\Delta$  **Measure** soft key to display the following screen.

Δ Measure						
Element	[ 1 ]	[ 2 ]	[ 3 ]	[ 4 ]	[ 5 ]	[ 6 ]
	[ 1P2W ]	[ 3P3W:Σ A ]		[ 3P3W(3V3A):Σ B ]		
ΔMeasure Type	[ ---- ]	[ 3P3W:3V3A ]		[ DeltaStar ]		
ΔMeasure Mode	[ ms ]	[ mean ]	[ dc ]	[ r-mean ]		[ ac ]

## Installed input elements

## The set wiring systems

**Set the delta computation type.**

The available options vary depending on the set wiring systems.

**Set the delta computation mode (rms, mean, dc, r-mean, ac).**

Wiring System	Delta Computation Type
1P3W	Difference, 3P3W > 3V3A
3P3W	Difference, 3P3W > 3V3A
3P4W	Star > Delta
3P3W(3V3A)	Delta > Star

## 1.11 Setting the Crest Factor

This section explains how to set the crest factor.

► [“Crest Factor \(Crest Factor\)” in the features guide](#)

### System Config Menu

Press **UTILITY** and then the **System Config** soft key to display the following menu.

System Config
□ Date/Time
< Language
< LCD
USB Keyboard Japanese English
< Preference
Crest Factor CF3 CF6 CF6A

Set the crest factor (CF3, CF6, CF6A).


## 1.12 Setting Measurement Periods

This section explains how to set the synchronization sources that determine the measurement period.

► [“Measurement Period \(SYNC SOURCE\)” in the features guide](#)

### Sync Src Menu

Press **SYNC SOURCE** to display the following menu.



### Setting the Synchronization Source for When the Data Update Interval is Auto (Sync Source Setting)

Press **SYNC SOURCE** and then the **Sync Src Setting** soft key to display the following screen.

To set all elements to the same setting at once, change the settings in the All column.

Turn on or off the synchronization source rectifier for voltage, current, and external current sensor signals.

The screenshot shows a table titled "Sync Source Settings" with columns for "All", "Element 1", "Element 2", "Element 3", "Element 4", "Element 5", and "Element 6". The rows are: "Voltage Rectifier" (all OFF), "Voltage Level" (all 0.0%), "Current Rectifier" (all OFF), "Current Level" (all 0.0%), "Ext. Sensor Rectifier" (all OFF), and "Ext. Sensor Level" (all 0.0%). Annotations with lines point to the "All" column for "Voltage Rectifier", "Current Rectifier", and "Ext. Sensor Rectifier".

	All	Element 1	Element 2	Element 3	Element 4	Element 5	Element 6
Voltage Rectifier	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Voltage Level	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%
Current Rectifier	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Current Level	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%
Ext. Sensor Rectifier	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Ext. Sensor Level	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%	0.0%

Set the synchronization source level for voltage, current, and external current sensor signals.

- When the rectifier function is off: -100.0% to 100.0%
- When the rectifier function is on: 0.0% to 100.0% (absolute value)

## 1.13 Setting Line Filters


This section explains the following settings for line filters:

- Turning line filters on and off
- Cutoff frequency

► “Line Filter (LINE FILTER)” in the features guide

### Line Filter Menu

Press **LINE FILTER** to display the following menu.



The screenshot shows the 'Line Filter' menu with six elements. Each element has a status indicator (OFF/ON), a 'Cutoff' label, and a frequency value (0.5kHz). A cursor is positioned over the 'Cutoff' field of Element 2. Below the elements is an 'Exec Copy Σ' button.

**Cursor (use the ◀▶ cursor keys to move it)**

**Configure the line filter settings:**

- Turn the line filter on or off.
- Set the cutoff frequency (0.1kHz to 100.0kHz in steps of 0.1 kHz, 300kHz, 1MHz).

**Copies the line filter setting**  
The line filter setting of the input element that is indicated by the cursor is copied to all the input elements in that element's wiring unit.

## 1.14 Setting Frequency Filters


This section explains how to set the frequency filter.

► “Frequency Filter (FREQ FILTER)” in the features guide

### Freq Filter Menu

When the data update interval is not Auto


Press **SHIFT+LINE FILTER** (FREQ FILTER) to display the following menu.



### Freq Filter (A) Menu

When the data update interval is Auto

Press **SHIFT+LINE FILTER** (FREQ FILTER) and then the **Freq Filter at Update Rate Auto** soft key to display the following menu.



\* The menu item is displayed, but the function is invalid.


## 1.15 Setting the Data Update Interval

This section explains how to set the data update interval.

► [“Data Update Interval \(UPDATE RATE\)” in the features guide](#)

### Update Rate Menu

Press **UPDATE RATE** to display the following menu.



1 You can set this when the data update interval is not Auto.

2 You can set this when the data update interval is Auto.

## 1.16 Setting Averaging

This section explains the following settings for averaging:

- Turning averaging on and off
- Averaging type
- Attenuation constant
- Average count

► [“Averaging \(AVG\)” in the features guide](#)

### Averaging Menu

Press **AVG** to display the following menu.

Averaging	
Averaging	Turns averaging on and off
OFF ON	
Type	Set the averaging type (Exp, Lin).
Exp Lin	
Count	Set the attenuation constant or average count.
8	• When Type is set to Exp: Set the attenuation constant (2 to 64).
	• When Type is set to Lin: Set the average count (8 to 64).



## 1.17 Displaying the Menu for Configuring All Elements

This section explains how to set the settings for all elements.

► [“Settings of All Elements \(All Elements Setup\)” in the features guide](#)

### All Elements Setup Menu

1. Press **WIRING** and then the **All Elements Setup** soft key to display the following menu.  
Use the **cursor** keys to select the setting that you want to change, and then press **SET** to display the available options or an input box.

All Elements Setup						
Element	[ 1 ]	[ 2 ]	[ 3 ]	[ 4 ]	[ 5 ]	[ 6 ]
	3P4W:Σ A			3P4W:Σ B		
U Auto Range	OFF	OFF	OFF	OFF	OFF	OFF
U Range	1000V	1000V	1000V	1000V	1000V	1000V
Ext Sensor	OFF	OFF	OFF	OFF	OFF	OFF
I Auto Range	OFF	OFF	OFF	OFF	OFF	OFF
I Range	5A	5A	5A	50A	50A	50A
Sensor Preset	Others	Others	Others	Others	Others	Others
Sensor Ratio (mV/A (mΩ))	10.0000	10.0000	10.0000	10.0000	10.0000	10.0000
CT Preset	Others	Others	Others	Others	Others	Others
Scaling	OFF	OFF	OFF	OFF	OFF	OFF
VT Scaling	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
CT Scaling	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
SF Scaling	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
Line Filter	OFF	OFF	OFF	OFF	OFF	OFF
- Cutoff	0.5kHz	0.5kHz	0.5kHz	0.5kHz	0.5kHz	0.5kHz
Freq Filter	OFF	OFF	OFF	OFF	OFF	OFF
Freq Filter (A)	OFF	OFF	OFF	OFF	OFF	OFF
- Cutoff	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz
Sync Source	I1	I1	I1	I4	I4	I4

Use the cursor keys to select the item that you want to set.

## 1.18 Displaying the Setup Parameter List

This section explains how to display a list of setup parameters.

► “Displaying the Setup Parameter List (INPUT INFO)” in the features guide

### Info Form Menu

1. Press **INPUT INFO**. The INPUT INFO key illuminates and the split display appears.  
The top half of the screen displays the setup parameter list. Press INPUT INFO again to clear the setup parameter list and display the previous screen.
2. Hold down **FORM** until the Info Form menu appears.  
Input element or measurement range settings are displayed.

#### Input Element Settings List

Power Element Settings						
	Element 1 [1000V-50A]	Element 2 [1000V-50A]	Element 3 [1000V-50A]	Element 4 [1000V-50A]	Element 5 [1000V-50A]	Element 6 [1000V-50A]
Wiring	1P2W	± A (3P3W)	± A (3P3W)	1P2W	± B (1P3W)	± B (1P3W)
Voltage Range	1000V	1000V	1000V	1000V	1000V	1000V
Current Range	5A	50A	50A	50A	50A	50A
Sensor Ratio [mV/A (mΩ)]	10.0000	10.0000	10.0000	10.0000	10.0000	10.0000
Scaling	Off	Off	Off	Off	Off	Off
VT Ratio	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
CT Ratio	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
Scaling Factor	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000
Sync Source	I1	I2	I2	I4	I5	I5
Line Filter	Off	Off	Off	Off	Off	Off
Freq Filter	Off	Off	Off	Off	Off	Off

Press INPUT INFO to exit this display.

Info Form

Power Element Settings

Range Settings

Select Power Element Settings.

#### Measurement Range Settings List

Voltage Range Settings						Current Range Settings					
U1	U2	U3	U4	U5	U6	I1	I2	I3	I4	I5	I6
1000	1000	1000	1000	1000	1000	5	50	50	50	50	50
600	600	600	600	600	600	2	20	20	20	20	20
300	300	300	300	300	300	1	10	10	10	10	10
150	150	150	150	150	150	500m	5	5	5	5	5
100	100	100	100	100	100	200m	2	2	2	2	2
60	60	60	60	60	60	100m	1	1	1	1	1
30	30	30	30	30	30	50m					
15	15	15	15	15	15	20m					
10	10	10	10	10	10	10m					
6	6	6	6	6	6						
3	3	3	3	3	3						
1.5	1.5	1.5	1.5	1.5	1.5						

Press INPUT INFO to exit this display.

Info Form

Power Element Settings

Range Settings

Select Range Settings.

## Info Items Menu

3. Press **ITEM** to display the Info Items menu.

Info Items
Display Frame
OFF <input checked="" type="checkbox"/>

— Turns the display frame on and off

## 2.1 Setting Harmonic Measurement Conditions

This section explains the following settings for harmonic measurement conditions. This feature is available on models with the /G5 or /G6 option.


- Input element group
- PLL source
- Measured harmonic order
- Distortion factor equation

► “Harmonic Measurement Conditions (Option)” in the features guide



### Harmonics Menu

Press **HRM SET** to display the following menu.

Menu on a Model with the /G6 Option  
(Dual harmonic measurement)



Menu on a Model with the /G5 Option



1 You can set this when the data update interval is not Auto.

2 You can set this when the data update interval is Auto.

Setting the Input Element Group (Element Settings)

Press the **Element Settings** soft key to display the following menu.

Element Settings

Element 1

Hrm1

Hrm2

Element 2  
( Σ A )

Hrm1

Hrm2

Element 3  
( Σ A )

Hrm1

Hrm2

Element 4

Hrm1

Hrm2

Element 5  
( Σ B )

Hrm1

Hrm2

Element 6  
( Σ B )

Hrm1

Hrm2

**Set the group of the input element (Hrm1, Hrm2).**  
Input elements that are assigned to the same wiring unit are set to the same group.

## 3.1 Setting Motor Evaluation Conditions

This section explains the following settings for motor evaluation conditions. This feature is available on models with the /MTR option.

- Scaling factor
- Unit
- Input signal type
- Analog input range
- Analog input linear scale
- Line filter
- Synchronization source
- Pulse input range
- Torque signal pulse rating
- Number of pulses per revolution of the revolution signal
- Motor's number of poles for computing the synchronous speed
- Voltage or current whose frequency is measured to compute the synchronous speed
- Electrical angle measurement
- Motor efficiency and total efficiency computations

► “Motor Evaluation Conditions (Option)” in the features guide

### Setting Motor Evaluation Conditions (MOTOR Settings)

Press **SHIFT+SCALING** (MOTOR/AUX SET) to display the following screen.

On models with the /AUX option, the auxiliary input conditions setup screen is displayed. See section 4.1.

#### Set the scaling factor (0.0001 to 99999.9999).

Set the scaling factor that is used to convert the signal from the revolution sensor or torque meter to speed (rotating speed), torque, and Pm (motor output).

#### Set the unit (up to 8 characters).

Set the speed, torque, and Pm units.

#### Set the input signal type (Analog, Pulse).

Set the type of revolution sensor for Speed and the type of the torque meter for Torque.

The screenshot shows the 'MOTOR Settings' screen with the following fields and values:

Parameter	Speed	Torque	Pm
Scaling	1.0000	1.0000	1.0000
Unit	rpm	Nm	W
Sense Type	Analog	Analog	
Analog Auto Range	OFF	OFF	
Analog Range	20V	20V	
Linear Scale A	1.000	1.000	
Linear Scale B	0.000	0.000	
	Calculation	Calculation	
Line Filter	OFF		
Sync Source	None		
Pulse Range Upper	10000.0000	50.0000	
Pulse Range Lower	0.0000	-50.0000	
Rated Upper		50.0000	15000Hz
Rated Lower		-50.0000	5000Hz
Pulse N	60		
Pole	2		
Source		I1	
Electrical Angle Measurement	ON		
Electrical Angle Correction			

Turns electrical angle measurement on and off

#### Configure the electrical angle correction.

You can configure the electrical angle correction when Electrical Angle Measurement is set to ON.

#### When Sense Type is set to Analog:

- Turns the auto range on and off
- Set the fixed range (20V, 10V, 5V, 2V, 1V).
- Set the linear scale (A: 1.000 m to 1.000 M; B: -1.000 M to 1.000M).  
Set A (the slope) and B (the offset).
- Computes A and B
- Set the line filter (OFF, 100Hz, 1kHz).
- Set the synchronization source (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk, None).  
Even if Sense Type is set to Pulse, correctly setting the synchronization source improves measurement accuracy.

#### When Sense Type is set to Pulse:

- Set the upper and lower limits.  
Revolution signal: 0.0000 to 99999.9999 [rpm]  
Torque signal: -10000.0000 to 10000.0000 [N·m]
- Set the positive and negative rated torque signal pulse frequencies (1 to 100000000 [Hz]).
- Set the positive and negative rated torque signal values (-10000.0000 to 10000.0000 [N·m]).

Set the number of pulses per revolution of the revolution signal (1 to 9999).

Set the voltage or current whose frequency will be measured to compute the synchronous speed (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6).

Set the number of motor poles that will be used to compute the synchronous speed (1 to 99).

## Computing A and B (Calculation)

Compute A (the slope) and B (the offset) from two points on the characteristics graph of a revolution sensor or torque meter.

### Rotating Speed's A and B

On the motor evaluation conditions setup screen, select **Calculation** under Speed to display the following screen.

Calculation

$Y=AX+B[\text{rpm}/\text{V}]$

Point1X[V] 0.000

Point1Y[rpm] 0.000

Point2X[V] 0.000

Point2Y[rpm] 0.000

Cancel Execute

Set the first X-axis value [V] and Y-axis value [rpm] (–1.000 T to 1.000 T).

Set the second X-axis value [V] and Y-axis value [rpm] (–1.000 T to 1.000 T).

Computes A and B

Cancels the computation

### Torque's A and B

On the motor evaluation conditions setup screen, select **Calculation** under Torque to display the following screen.

Calculation

$Y=AX+B[\text{Nm}/\text{V}]$

Point1X[V] 0.000

Point1Y[Nm] 0.000

Point2X[V] 0.000

Point2Y[Nm] 0.000

Cancel Execute

Set the first X-axis value [V] and Y-axis value [Nm] (–1.000 T to 1.000 T).

Set the second X-axis value [V] and Y-axis value [Nm] (–1.000 T to 1.000 T).

Computes A and B

Cancels the computation

## Setting the Electrical Angle Correction Value (Electrical Angle Correction)

On the motor evaluation conditions setup screen, select **Electrical Angle Correction** to display the following screen.

Electrical Angle Correction

Correction Value 0.00

Clear Correction

Auto Enter Correction Execute

Auto Enter Target U1

Set the correction value (–180.00 to 180.00).

Clears the correction value

Automatically computes the correction value

Correction Value is set to the computed value.

Set the voltage or current to automatically compute the correction value of (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6).

## Computing the Motor Efficiency and Total Efficiency

This instrument can compute the motor efficiency (the ratio of motor output to the power consumed by the motor) and total efficiency from the measured active power and motor output. For information on how to set expressions, see section 1.8.

## 4.1 Setting Auxiliary Input Conditions

This section explains the following settings for auxiliary input conditions. This feature is available on models with the /AUX option.

- Input signal name
- Scaling factor
- Unit
- Input signal range
- Input signal linear scale
- Line filter

► “Auxiliary Input Conditions (Option)” in the features guide

### Setting Auxiliary Input Conditions (Aux Settings)

Press **SHIFT+SCALING** (MOTOR/AUX SET) to display the following screen.

On models with the /MTR option, the motor evaluation conditions setup screen is displayed. See section 3.1.

You can configure up to two input signals.

The screenshot shows the 'Aux Settings' screen with the following fields and options:

- Aux Name:** AUX1, AUX2
- Scaling:** 1.0000, 1.0000
- Unit:** kW/m2, kW/m2
- Analog Auto Range:** ON, OFF
- Analog Range:** 20V, 20V
- Linear Scale A:** 1.000, 1.000
- Linear Scale B:** 0.00, 0.000
- Calculation:** Calculation, Calculation
- Line Filter:** OFF

Annotations for the Aux Settings screen:

- Set the input signal name (up to 8 characters).
- Set the scaling factor (0.0001 to 99999.9999).
- Set the unit (up to 8 characters).
- Turns the auto range on and off
- Set the fixed range (20V, 10V, 5V, 2V, 1V, 500mV, 200mV, 100mV, 50mV).
- Set the linear scale (A: 1.000 m to 1.000 M; B: -1.000 M to 1.000M).
- Set A (the slope) and B (the offset).
- Computes A and B
- Set the line filter (OFF, 100Hz, 1kHz).

### Computing A and B (Calculation)

Compute A (the slope) and B (the offset) from two points on the characteristics graph of the input signal.

On the auxiliary input conditions setup screen, select **Calculation** to display the following screen.

The screenshot shows the 'Calculation' screen with the formula  $Y=AX+B[\text{Unit}/V]$  and the following fields:

- Point1X[V]:** 0.000
- Point1Y[Unit]:** 0.000
- Point2X[V]:** 0.000
- Point2Y[Unit]:** 0.000
- Buttons:** Cancel, Execute

Annotations for the Calculation screen:

- Set the first X-axis value [V] and Y-axis value [Unit] (-1.000 T to 1.000 T).
- Set the second X-axis value [V] and Y-axis value [Unit] (-1.000 T to 1.000 T).
- Computes A and B
- Cancels the computation



## 5.1 Holding Measured Values


This section explains how to hold measured values.

► [“Holding Measured Values \(HOLD\)” in the features guide](#)

Press **HOLD**. The HOLD key illuminates, and the displayed measured value is held.

- Values such as D/A output, the list of numeric data that is being printed on the built-in printer, and communication output are also held.
- Press **HOLD** again to turn the HOLD key off. This releases the hold feature. The measured data is then updated at the specified data update rate (see section 1.15).

If you hold the measured value, the data update count in the lower left of the screen stops increasing.



---

## 5.2 Performing Single Measurements

This section explains how to perform single measurements.

► [“Single Measurement \(SINGLE\)” in the features guide](#)

1. Press **HOLD**. The HOLD key illuminates, and the displayed measured value is held.
2. Press **SINGLE**. A single measurement is performed at the specified data update rate, and this instrument then holds the measured value.

---

### **Note**

- If, while the HOLD key is illuminated, you press **HOLD** again, the HOLD key will turn off, and the hold feature will be released. If you press **SINGLE** while the hold feature is released, the measured value is updated (re-measured) when the time specified by the data update rate elapses after you press the key.
  - When the data update interval is set to Auto, single measurement is not possible.
-

# 6.1 Setting the Display Format

This section explains how to set the numeric data display format. To set the display format, you can:

- Select it from the Numeric Form menu.
- Set it directly by pressing NUMERIC.

► [“Numeric Data Display Format” in the features guide](#)

## Numeric Form Menu

Press **NUMERIC** and then **FORM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **FORM** again.

Numeric Form	
4 Items	Select the 4 Items display.
8 Items	Select the 8 Items display.
16 Items	Select the 16 Items display.
Matrix	Select the matrix display. You can select four or six columns (see section 6.4).
All Items	Select the All Items display.
Hrm List	Select the harmonics list display (/G5 or /G6 option). This instrument switches between the single and dual list displays each time you press this soft key.
Single Dual	
Custom	Select the custom display. You can load the background and customize the numeric data display (see section 6.7).

## NUMERIC Key

Each time that you press **NUMERIC**, the display format switches, in order, between 4 Items, 8 Items, 16 Items, Matrix, All Items, Hrm List Single, Hrm List Dual, and Custom.

## 6.2 Switching the Displayed Page

This section explains how to switch the displayed numeric data page.

► [“Switching the Displayed Page \(PAGE UP/PAGE DOWN\)” in the features guide](#)

1. Follow the procedure in section 6.1 to select the numeric data display format.

### 4 Items, 8 Items, 16 Items, Matrix, All Items, and Custom Displays

2. Press **PAGE▲** to display the previous page.


Press **PAGE▼** to display the next page.

Press **SHIFT+PAGE▲** (**▲**) to jump to the first page.

Press **SHIFT+PAGE▼** (**▼**) to jump to the last page.

- You can switch the displayed page separately for the 4 Items, 8 Items, 16 Items, Matrix, All Items, and Custom displays.
- For the All Items display, the first page is always displayed in the top half of the screen, and the currently selected page from pages 2 to 12 is displayed in the bottom half of the screen. On the split display, you can switch between pages 1 to 12.
- For the Custom display, you can switch between pages when the display is set so that the total number of displayed items is more than the number of items that can be displayed on one page (see section 6.7).

#### Example of the 4 Items Display




## Hrm List Single and Hrm List Dual Displays (/G5 or /G6 options)

2. Press **ESC** to clear the menu.
3. Press the **cursor** keys (◀▶) to select either the measurement function side (the left side of the screen) or the harmonic order data side (the right side of the screen).
4. Press **PAGE▲** to display the previous page.  
Press **PAGE▼** to display the next page.

Press **SHIFT+PAGE▲** (▲) to jump to the first page.

Press **SHIFT+PAGE▼** (▼) to jump to the last page.



### Note

If you do not perform step 2 to clear the menu, you cannot switch between the measurement function and the harmonic order data sides.

## 6.3 Changing the Displayed Items on the 4 Items, 8 Items, and 16 Items Displays

This section explains the following settings for the displayed items on the 4 Items, 8 Items, and 16 Items displays:

- Item number
- Measurement function
- Element and wiring unit
- Harmonic order
- Resetting the displayed items
- Turning the display frame on and off

To change the displayed items, you can:

- Set the items on the Numeric (4), Numeric (8), or Numeric (16) menu.
  - Set items directly by pressing the function select keys and ELEMENT.
- “4-, 8-, and 16-Value Displays (4 Items/8 Items/16 Items)” in the features guide

1. Follow the procedure in section 6.1 to set the numeric data display format to the 4 Items, 8 Items, or 16 Items display.







### Numeric (4), Numeric (8), and Numeric (16) Menus

2. Press **ITEM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the Numeric (4), Numeric (8), or Numeric (16) menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**.

#### Example of the Numeric (4) Menu


	— Select the item number that you want to set.	$\left( \begin{array}{ll} \text{4 Items display:} & 1 \text{ to } 48 \\ \text{8 Items display:} & 1 \text{ to } 96 \\ \text{16 Items display:} & 1 \text{ to } 192 \end{array} \right)$
	— Set the measurement function (None, other functions—for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).	
	— Set the element and wiring unit (Element 1 to Element 6, $\Sigma A$ to $\Sigma C$ ).	
	— Set the harmonic order (Total, 0 to 500; /G5 or /G6 option). You can set this setting only when you have selected a measurement function that includes a harmonic order.	
	— Set the resetting of displayed items.	
	— Turns the display frame on and off	

### Switching the Page

To set items on pages that aren't currently displayed, switch to these pages. For details on how to switch pages, see section 6.2.

## Reset Items Menu

Press the **Reset Items** soft key to display the following menu.



## Function Select Keys and the ELEMENT Key

Follow steps 1 and 2 on the previous page to display the Numeric (4), Numeric (8), or Numeric (16) menu.


3. Press **ESC** to clear the menu.

### Example of the 8 Items Display

Displayed in the upper left of the numeric data display screen



4. Press the **cursor** keys, the **PAGE**  $\blacktriangle$   $\blacktriangledown$  keys, or the **SHIFT+PAGE**  $\blacktriangle$   $\blacktriangledown$  ( $\blacktriangle$  and  $\blacktriangledown$ ) keys to select the item that you want to change.
5. Press the function select key that corresponds to the measurement function that you want to display.  
Function select keys: **U/I/P** key, **S/Q/A/ $\Phi$**  key, **WP/q/TIME** key, **FU/Fl/ $\eta$**  key, and **U/I MODE** key
6. Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.
  - Press **SHIFT+the ELEMENT** (ALL) key for displaying numeric data to illuminate the indicator below the ELEMENT key and change all elements of the measurement functions on the displayed page to the same element and wiring unit at once.
  - Press **SHIFT+the ELEMENT** (ALL) key for displaying numeric data again to turn the indicator off and stop setting all elements at once.



## 6.4 Changing the Displayed Items on the Matrix Display

This section explains the following settings for the displayed items on the Matrix display:

- Item number
- Measurement function
- Element and wiring unit
- Harmonic order
- Resetting the displayed items
- Display column
- Turning the display frame on and off

To change the displayed items, you can:

- Set the items on the Matrix Items menu.
- Set items directly by pressing the function select keys and ELEMENT.

► [“Matrix Display \(Matrix\)” in the features guide](#)







1. Follow the procedure in section 6.1 to set the numeric data display format to the Matrix display.

### Matrix Items Menu

2. Press **ITEM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the Matrix Items menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**.

	— <b>Select the item number that you want to set (1 to 81).</b>
	— <b>Set the measurement function (None, other functions—for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).</b>
	— <b>Set the harmonic order (Total, 0 to 500; /G5 or /G6 option).</b> You can set this setting only when you have selected a measurement function that includes a harmonic order.
	— <b>Set the resetting of displayed items.</b>
	— <b>Configure the columns to display.</b>
	— <b>Turns the display frame on and off</b>

### Switching the Page

To set items on pages that aren't currently displayed, switch to these pages. For details on how to switch pages, see section 6.2.



## Reset Items Menu

Press the **Reset Items** soft key to display the following menu.

Matrix Items	
Item No.	1
Function	Units
Reset Items	
Reset Pattern	Element Origin
Reset Items Exec	
Column Settings	
Display Frame	OFF ON

Set the reset pattern (Element Origin, Function Origin, Clear Current Page, Clear All Pages).

Resets the items using the specified reset pattern

## Column Settings Menu

Press the **Column Settings** soft key to display the following menu.

Column Settings	
Column Num	4 6
Column No.	2
Element/ $\Sigma$	Element 2
Reset Items Exec	

Set the number of columns (4, 6).

Set the column number (1 to 6).

Set the element and wiring unit (None, Element 1 to Element 6,  $\Sigma A$  to  $\Sigma C$ ).


Resets items to the default values

### Function Select Keys and the ELEMENT Key

Follow steps 1 and 2 on page 6-6 to display the Matrix Items menu.

3. Press **ESC** to clear the menu.

Displayed in the upper left of the numeric data display screen




#### Changing the Measurement Function (Vertical direction)

4. Press the **cursor** keys (**▲▼**), the **PAGE▲▼** keys, or the **SHIFT+PAGE▲▼** (**⏮** and **⏭**) keys to select the row that you want to change.
5. Press the function select key that corresponds to the measurement function that you want to display.

Function select keys: **U/I/P** key, **S/Q/A/Φ** key, **WP/q/TIME** key, **FU/FI/η** key, and **U/I MODE** key

#### Changing the Element and Wiring Unit (Horizontal direction)

4. Use the **cursor** keys (**◀▶**) to select the column that you want to change.
5. Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.



## 6.5 Changing the All Items Display

This section explains the following All Items display settings:

- Harmonic order
- Turning the display of all element and all wiring unit data on and off
- Turning the display frame on and off

► “All Display (All Items)” in the features guide

1. Follow the procedure in section 6.1 to set the numeric data display format to the All Items display.

### Numeric (All) Menu

2. Press **ITEM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the Numeric (All) menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**.

The screenshot shows a vertical menu titled "Numeric (All)". It contains three main settings, each with a label and a value:

- Order(\*)**: The value is "0".
- Display All Elements**: The value is "OFF".
- Display Frame**: The value is "ON".

**Set the harmonic order (Total, 0 to 500; /G5 or /G6 option).**

You can set this setting only when you have selected the page of a measurement function includes a harmonic order. For details on how to switch pages, see section 6.2.

**Turns the display of numeric data of all elements or all wiring units on and off**

If the total number of elements or wiring units is 7 or more, set this to ON when you want to display the numeric data of all elements or all wiring units.

**Turns the display frame on and off**

### Note

On the All Items display, you cannot select individual display items and change their measurement function, element, or wiring unit. If you switch to the Matrix display, you can change the measurement functions, elements, and wiring units using the displayed table (see section 6.4).

## 6.6 Changing the Harmonics List Display (Option)

This section explains the following settings for the harmonics list display (Hrm List). This feature is available on models with the /G5 or /G6 option.

- List number
- Measurement function
- Element and wiring unit
- Turning the display frame on and off

To change the displayed items, you can:

- Set the items on the List Items menu.
- Set items directly by pressing the function select keys and ELEMENT.

► [“Single Harmonics and Dual Harmonics Lists \(Hrm List Single/Dual; option\)”](#)  
in the features guide

1. Follow the procedure in section 6.1 to set the numeric data display format to the harmonics list display (Hrm List).

### List Items Menu

2. Press **ITEM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Items menu may be displayed. If this happens, press **ITEM** again.

In step 1, you can also display the List Items menu by pressing **NUMERIC**, **ITEM**, and then repeatedly pressing **NUMERIC**. There is a List Items menu for the single harmonics list and the dual harmonics list. When you repeatedly press **NUMERIC**, the menu for the single harmonics list is displayed after the All Items display, and the menu for the dual harmonics list is displayed after the menu for the single harmonics list.

List Items	
List Item No.	Select the list number that you want to set (1, 2).
Function	Function, element, and wiring unit settings that you make for list number 2 are also reflected in the right column of the harmonic order data of the dual harmonics list.
Element/Σ	Set the measurement function (U, I, P, S, Q, λ, Φ, ΦU, ΦI, Z, Rs, Xs, Rp, Xp).
Display Frame	Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC).
OFF ON	Turns the display frame on and off

### Note

On the harmonics list displays, you can change the measurement function, element, and wiring unit for the selected list, but you cannot change these settings for each individual display item.

## Function Select Keys and the ELEMENT Key

Follow steps 1 and 2 on page 6-10 to display the List Items menu.


3. Press **ESC** to clear the menu.
4. Use the **cursor** keys (**◀▶**) to select the harmonic order data side (the right side of the screen).  
If you are displaying the dual harmonics list, you can set the left or right column of the harmonic order data, whichever you have selected.

### Example of the Single Harmonics List

Displayed in the upper left of the numeric data display screen



5. Press the function select key that corresponds to the measurement function that you want to display.  
Function select keys: **U/I/P** key and **S/Q/A/Φ** key  
(The **WP/q/TIME** key, **FU/FI/η** key, and **U/I MODE** key are disabled.)
6. Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.
  - If you are displaying the dual harmonics list, press **SHIFT+the ELEMENT (ALL)** key for displaying numeric data to illuminate the indicator below the ELEMENT key and change all elements of the left and right columns of the harmonic order data to the same element and wiring unit at once.
  - Press **SHIFT+the ELEMENT (ALL)** key for displaying numeric data again to turn the indicator off and stop setting all elements at once.



## 6.7 Setting the Custom Display

This section explains the following Custom display settings:

- Loading of display configuration files
- Loading of background files
- Display configuration

Total items, items per page, custom items (item number, measurement function, element and wiring unit, harmonic order, display position, font size, font color), saving custom display configuration files

- Turning the display frame on and off


► [“Custom Display \(Custom\)” in the features guide](#)

1. Follow the procedure in section 6.1 to set the numeric data display format to Custom.

### Custom Items Menu

2. Press **ITEM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Items menu may be displayed. If this happens, press **ITEM** again.



You can load files for the custom display.  
Display configuration files: .txt files  
Background files: .bmp files

- You can use the “Edit Items” menu described below to change the display configuration that you have loaded.
- To load both a display configuration file and background file at the same time, load the display configuration file.

## Setting the Display Configuration (Edit Items)

Press the **Edit Items** soft key to display the following menu.

Edit Items	
Total Items 4	Set the total number of items (1 to 192).
Items Per Page 4	Set the number of items per page (1 to 192). <ul style="list-style-type: none"> <li>Any changes made to Total Items will change the Items Per Page setting, and vice-versa.</li> <li>For details on how to switch pages, see section 6.2.</li> </ul>
Custom Items	Customize display items.
Save Custom Items	Saves the display configuration file

### Customizing Display Items (Custom Items)

Press the **Custom Items** soft key to display the following screen.

(X, Y)				Custom Items	
<b>Element 1</b> Voltage rms 0.0000 k Current rms 0.000 Power 0.141 k mean 0.0000 k, dc 0.1412 k, r-mn 0.0000 k, ac 0.0000 k, max 0.0000 k, min 0.0000 k, CF Error Voltage frequency Error, Current frequency Error Ah -----, Ah+ -----, Ah- -----, Wh -----, Wh+ -----, Wh- -----				Item No. 2 Function Urms Element/Σ Element 1 Order 1000 X Pos 20 Y Pos 100 Font Size 48 Font Color Yellow	
Numeric data box				Select the item number that you want to set (1 to the Total Items setting). Set the measurement function (None, other functions—for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide). Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC). When Function is set to None: Set the character string (up to 15 characters). When the measurement function includes a harmonic order: Set the harmonic order (Total, 0 to 500; /G5 or /G6 option). Set the display position. • X Pos: 0 (left edge of the screen) to 800 (right edge of the screen) • Y Pos: 0 (top of the screen) to 671 (bottom of the screen) Set the font size (14, 16, 20, 24, 32, 48, 64, 96, 128).	
Set the font color (Yellow, Green, Magenta, Cyan, Red, Orange, Light Blue, Purple, Blue, Pink, Light Green, Dark Blue, Blue Green, Salmon Pink, Mid Green, Gray, White, Dark Gray, Blue Gray, Black).				Set the font color	

**Saving Display Configuration Files (Save Custom Items)**

Press the **Save Custom Items** soft key to display the following menu.

Save Items

<

File List

Auto Naming

Numbering

File Name

Save Exec

Set the save destination. ▶ section 17.2

Set auto naming. ▶ section 17.2

Set the file name. ▶ section 17.2

Saves the display configuration  
Note that if a file with the same name exists in the destination folder, it will be overwritten without warning.  
File names are not case-sensitive.

**Loading Display Configuration and Background Files at the Same Time (Load Items & Bmp)**

Follow the procedure on page 6-12 to display the Custom Items menu, and then press the **Load Items & Bmp** soft key to display the following screen.

File List

Path = USB-0/CustomNumeric/Solar  
Space : 480MB (502,894,592Bytes) | Num Of Files : 1

Sort To

Filter \*.TXT

Change Drive

Delete

Rename

Make Dir

Copy

Move

File Name | Size | Date | Attr

RAM-0

Network

USB-0

CustomNumeric

Solar

Solar\_Power.txt 605 2009/06/03 16:41:14 r/w

Please press < key to move ControlMenuArea.

Load Items & Bmp

Items & Bmp  
Load Exec


Select the file that you want to load.  
Select a custom display file.  
Display configuration files: .txt files  
Background files: .bmp files

Loads the file

To load both a display configuration file and background file at the same time, load the display configuration file.  
However, an error will occur if a background file that has the same name as the display configuration file is not present in the save destination folder of the display configuration file.  
For the operating procedure, see section 17.6.



## Example of Loading a File for the Custom Display

**Note**

After you properly load a display configuration file and a background file, if you restart this instrument and the same background file is not in the same location, the background will return to its default.

## 7.1 Setting User-Defined Functions

This section explains the following settings for user-defined functions:

- Turning computations on and off
- Computation name
- Unit
- Expressions
- Turning max hold on and off

► “User-Defined Functions (User Defined Function)” in the features guide

### Setting User-Defined Functions (User Defined Function)

Press **MEASURE** and then the **User Defined Function** soft key to display the following screen.

Set the expression.

User Defined Function Settings				User Defined
Function 1	<input type="checkbox"/> OFF <input type="checkbox"/> ON	Name Avg-W	Unit W	User Defined F01-F05
Expression	WH(E1)/(T1(E1)/3600)			User Defined F06-F10
Function 2	<input type="checkbox"/> OFF <input type="checkbox"/> ON	Name P-loss	Unit W	
Expression	P(E1)-P(E2)			
Function 3	<input type="checkbox"/> OFF <input type="checkbox"/> ON	Name U-ripple	Unit %	
Expression	(UPPK(E1)-UMPK(E1))/2/UDC(E1)*100			
Function 4	<input type="checkbox"/> OFF <input type="checkbox"/> ON	Name I-ripple	Unit %	User Defined F11-F15
Expression	(IPPK(E1)-IMPK(E1))/2/IDC(E1)*100			User Defined F16-F20
Function 5	<input type="checkbox"/> OFF <input type="checkbox"/> ON	Name D-UrmsR	Unit V	
Expression	DELTAU1RMS(E7)			Max Hold
				<input type="checkbox"/> OFF <input type="checkbox"/> ON
F01-F05 F06-F10 F11-F15 F16-F20				

Turns the computation on and off  
 Set the computation name (up to 8 characters).  
 Set the unit (up to 8 characters).

Displays the setup screen for user-defined functions F1 to F5  
 Displays the setup screen for user-defined functions F6 to F10  
 Displays the setup screen for user-defined functions F11 to F15  
 Displays the setup screen for user-defined functions F16 to F20  
 Turns max hold on and off

## 7.2 Setting User-Defined Events

This section explains the following settings for user-defined events:

- Event number
- Turning events on and off
- Event name
- Character string displayed when events occur or do not occur
- Judgment condition setup method
  - Using numeric data to perform judgment
    - Measurement function, element and wiring unit, harmonic order, comparison condition, comparison reference
  - Using logical AND and OR of events to perform judgment
    - Inversion of judgment conditions

► “User-Defined Events (User Defined Event)” in the features guide

### Setting User-Defined Events (User Defined Event)

Press **MEASURE** and then the **User Defined Event** soft key to display the following screen.

**Set the event number (1 to 8).**

**Turns the event on and off**

**Set the event name (up to 8 characters).**

**Set the character string that is displayed when events occur or do not occur (up to 6 characters).**

**Select the judgment condition setup method (Range, Condition).**

**Using numeric data to perform judgment (Range)**

- Set the measurement function (for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).
- Set the element and wiring unit (Element 1 to Element 6,  $\Sigma A$  to  $\Sigma C$ ).
- Set the harmonic order (Total, 0 to 500; /G5 or /G6 option). You can set this setting when the measurement function includes a harmonic order.
- Set the comparison condition (OFF, <, <=, =, >, >=, !=).
- Set the comparison reference (-9.999T to 9.999T).

**Using logical AND and OR of events to perform judgment (Condition)**

- Set the judgment condition inversion.
- Set AND, OR, or END.
- Set the events. You can select events whose event numbers are smaller than the number specified by Event No. for the current event.

When you turn an event on, the corresponding check box is selected.

The settings are displayed.

## 7.3 Setting Apparent Power, Reactive Power, and Corrected Power Equations

This section explains the following settings for the apparent power, reactive power, and corrected power equations:


- Apparent power equation
- Apparent power and reactive power equation types
- Corrected power equation

Applicable standard and coefficients

► [“Apparent Power, Reactive Power, and Corrected Power Equations \(Formula\)”](#)  
in the features guide


### Formula Menu

Press **MEASURE** and then the **Formula** soft key to display the following menu.



### Setting the Corrected Power Equation (Pc Formula)

Press the **Pc Formula** soft key to display the following screen.




## 7.4 Setting the Sampling Frequency

This section explains how to set the sampling frequency.

► [“Sampling Frequency \(Sampling Frequency\)” in the features guide](#)

### Measure Menu

Press **MEASURE** to display the following menu.



## 7.5 Setting the Phase Difference Display Format

This section explains how to set the phase difference display format.

► [“Phase Difference Display Format \(Phase\)” in the features guide](#)

### Measure Menu

Press **MEASURE** to display the following menu.

Measure
< User Defined Function
□ User Defined Event
< Formula
Sampling Frequency Auto
Phase 180 degrees
Sync Measure Master Slave

Set the phase difference display format (180 degrees, 360 degrees).

## 7.6 Setting Master and Slave Synchronized Measurement

This section explains the following setting for master and slave synchronized measurement.

- Master and slave

► [“Master/Slave Synchronized Measurement \(Sync Measure\)” in the features guide](#)

### Measure Menu

Press **MEASURE** to display the following menu.

Measure
< User Defined Function
□ User Defined Event
< Formula
Sampling Frequency Auto
Phase 180 degrees
Sync Measure Master Slave

— Select whether this is the master unit or a slave unit (Master, Slave).

---

## 7.7 Setting the Voltages or Currents Whose Frequencies Will Be Measured

This instrument can measure the frequencies of the voltages or currents of all elements, so the setup menu is not displayed even if you press **SHIFT+MEASURE** (FREQ MEASURE).




## 8.1 Setting Independent Integration

This section explains the following settings for independent integration. If you turn independent integration on, you can start, stop, and reset integration for each input element separately.

- Turning independent integration on and off
  - Element that independent integration will be performed on
- [“Enabling or Disabling Independent Integration \(Independent Control\)” in the features guide](#)


### Integ Menu

Press **INTEG** to display the following menu.



### Selecting the Element That Independent Integration Will Be Performed On (Element Object)

Press the **Element Object** soft key to display the following screen.



## 8.2 Setting Integration Conditions

This section explains the following settings for integration conditions:

- Integration mode
- Integration timer
- Scheduled times for real-time integration
- Turning integration auto calibration on and off
- Watt-hour integration method for each polarity
- Current mode for current integration
- Rated time of integrated D/A output (/DA option)

► [“Integration Conditions \(Integ Set\)” in the features guide](#)

### Integ Menu

Press **INTEG** and then the **Integ Set** soft key to display the following menu.

Integ Set	
Mode R-Normal	Set the integration mode (Normal, Continuous, R-Normal, R-Continuous). <sup>1</sup>
Integ Timer	Set the integration timer.
Real-time Control	Set the scheduled times for real-time integration. This soft key is displayed when Mode is set to R-Normal or R-Continuous.
Auto Cal OFF ON	Turns integration auto calibration on and off <sup>1</sup>
WP± Type	Set the watt-hour integration methods for each polarity. <sup>1</sup>
q Mode	Set the current modes for current integration.
D/A Output Rated Time	Set the rated time of integrated D/A output (/DA option).

<sup>1</sup> You can set this when the data update interval is not Auto.

### Setting the Integration Timer (Integ Timer)

Press the **Integ Timer** soft key to display the following screen.

#### When Independent Integration Is Off

Integ Timer	
Integ Timer	00000 : 00 : 00

Set the integration timer (00000 hours : 00 minutes : 00 seconds to 10000 hours : 00 minutes : 00 seconds).\*

#### When Independent Integration Is On

Integ Timer	
Setting	Each All
Element 1	00000 : 00 : 00
Element 2	00000 : 00 : 00
Element 3	00000 : 00 : 00
Element 4	00000 : 00 : 00
Element 5	00000 : 00 : 00
Element 6	00000 : 00 : 00

Select the integration timer's setup method (Each, All).  
When you select Each, you can set the integration timer for each input element.

\* When Mode is set to Normal and the integration timer is 00000 : 00 : 00, this instrument is in manual integration mode.

## Setting Scheduled Times for Real-Time Integration (Real-time Control)

Press the **Real-time Control** soft key to display the following screen.

The Real-time Control soft key is displayed when Mode is set to R-Normal or R-Continuous.

### When Independent Integration Is Off

Real-time Control	
Start	2011 / 01 / 01 00 : 00 : 00 <span>Now</span>
End	2011 / 01 / 01 01 : 00 : 00 <span>Copy</span>

Scheduled integration stop time

Scheduled integration start time

Sets the scheduled integration start time to the current time

Copies the scheduled integration start time to the scheduled integration stop time

Set the scheduled start and stop times (Year/month/day, 00 hours : 00 minutes : 00 seconds to 23 hours : 59 minutes : 59 seconds).

### When Independent Integration Is On

Real-time Control	
Setting	<span>Each</span> <span>All</span>
Element 1	Start 2011 / 01 / 01 00 : 00 : 00 <span>Now</span> End 2011 / 01 / 01 01 : 00 : 00 <span>Copy</span>
Element 2	Start 2011 / 01 / 01 00 : 00 : 00 <span>Now</span> End 2011 / 01 / 01 01 : 00 : 00 <span>Copy</span>
Element 3	Start 2011 / 01 / 01 00 : 00 : 00 <span>Now</span> End 2011 / 01 / 01 01 : 00 : 00 <span>Copy</span>
Element 4	Start 2011 / 01 / 01 00 : 00 : 00 <span>Now</span> End 2011 / 01 / 01 01 : 00 : 00 <span>Copy</span>
Element 5	Start 2011 / 01 / 01 00 : 00 : 00 <span>Now</span> End 2011 / 01 / 01 01 : 00 : 00 <span>Copy</span>
Element 6	Start 2011 / 01 / 01 00 : 00 : 00 <span>Now</span> End 2011 / 01 / 01 01 : 00 : 00 <span>Copy</span>

Select the schedule setup method (Each, All).

When you select Each, you can set the schedule for each input element.

## Setting the Watt-Hour Integration Method for Each Polarity (WP± Type)

Press the **WP± Type** soft key to display the following screen.

WP± Type	
Setting	<span>Each</span> <span>All</span>
Element 1	<span>Charge/Discharge</span> <span>Sold/Bought</span>
Element 2	<span>Charge/Discharge</span> <span>Sold/Bought</span>
Element 3	<span>Charge/Discharge</span> <span>Sold/Bought</span>
Element 4	<span>Charge/Discharge</span> <span>Sold/Bought</span>
Element 5	<span>Charge/Discharge</span> <span>Sold/Bought</span>
Element 6	<span>Charge/Discharge</span> <span>Sold/Bought</span>

Select the integration method setup method (Each, All).

When you select Each, you can set the integration method for each input element.

Set the integration method (Charge/Discharge, Sold/Bought).

Setting the Current Mode for Current Integration (q Mode)

Press the **q Mode** soft key to display the following screen.

q Mode					
Setting	<div>Each All</div>				
Element 1	rms	mean	dc	r-mean	ac
Element 2	rms	mean	dc	r-mean	ac
Element 3	rms	mean	dc	r-mean	ac
Element 4	rms	mean	dc	r-mean	ac
Element 5	rms	mean	dc	r-mean	ac
Element 6	rms	mean	dc	r-mean	ac

Select the current mode setup method (Each, All).  
When you select Each, you can set the current mode for each input element.

Set the current mode (rms, mean, dc, r-mean, ac).

Setting the Rated Time of Integrated D/A Output (D/A Output Rated Time, /DA option)

Press the **D/A Output Rated Time** soft key to display the following screen.

D/A Output Rated Time		
Rated Time	00001	: 00 : 00

Set the rated time of integrated D/A output  
(00000 hours : 00 minutes : 00 seconds to 10000 hours :  
00 minutes : 00 seconds).


## 8.3 Starting, Stopping, and Resetting Integration

This section explains how to start, stop, and reset integration.

► [“Starting, Stopping, and Resetting Integration \(Start/Stop/Reset\)” in the features guide](#)

### Integ Menu

Press **INTEG** to display the following menu.



#### Starts integration

This instrument starts integration using the integration mode that you have specified (see section 8.2).

- The START indicator to the right of the INTEG key illuminates. Integration has started; “Integ: Start” is displayed.\*
- The START indicator to the right of the INTEG key blinks. The integration operation is ready; “Integ: Ready” is displayed.\*

#### Stops integration

This instrument automatically stops integration according to the integration mode that you have specified. To force integration to stop, press this soft key. The integration time and integrated value are held.

- The STOP indicator to the right of the INTEG key blinks. Integration has stopped; “Integ: Stop” is displayed.\* If you press the Start soft key when “Stop” is displayed in yellow, you can resume integration from the point where you stopped integration.
- The STOP indicator to the right of the INTEG key illuminates. Integration has stopped automatically because the integration timer has expired; “Integ: TimeUp” is displayed.\* Integration has stopped automatically because of real-time control; “Integ: Stop” is displayed.\* “Stop” is displayed in orange.

#### Resets the integration time and integrated value.

All integration data is deleted, and the no-data display, “-----,” appears. The STOP indicator to the right of the INTEG key turns off.

\* Character strings are displayed in the upper-right section of the screen.

### Note

If you do not reset integration, you will not be able to start it again.

## 8.4 Integration Resume Action at Power Failure Recovery

This section explains how to set the Integration Resume Action at Power Failure Recovery.

► [“Integration Resume Action at Power Failure Recovery \(Integration Resume Action\)” in the features guide](#)

### Integration Resume Action Menu

Press **UTILITY**, the **System Config** soft key, and then the **Preference** soft key to display the following menu.

Preference	
Resolution	
5digits	
Freq Display at Frequency Low	
0	Error
Motor Display at Pulse Freq Low	
0	Error
Decimal Point for CSV File	
Period	Comma
Integration Resume Action	
Start	Stop Error
Menu Font Size	
Small	Large
Rounding to Zero	
OFF	ON

— Set the Integration Resume Action at Power Failure Recovery (Start, Stop, Error).

## 9.1 Setting the Display Format

This section explains the following settings for the waveform display format:

- Number of divisions of the waveform screen
- Time axis
- Trigger
- Advanced waveform display settings
- Waveform mapping

► “Display Format (FORM)—Waveform” in the features guide

### Wave Form Menu

Press **WAVE** and then **FORM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **FORM** again.

Wave Form	
Format	Set the number of divisions of the waveform screen (Single, Dual, Triad, Quad, Hexa). <sup>1</sup>
Time/div	Set the time axis (0.05 ms to $\frac{\text{the specified data update interval}}{10}$ ). <sup>2</sup>
Trigger Settings	Configure trigger settings. <sup>3</sup>
Display Settings	Configure the advanced waveform display settings.
Wave Mapping	Set waveform mapping.

<sup>1</sup> In addition to using this Format soft key, you can repeatedly press **WAVE** to change the order and the number of divisions.

<sup>2</sup> For information on how to set the data update interval, see section 1.15.

<sup>3</sup> You can set this when the data update interval is not Auto.


### Configuring Trigger Settings (Trigger Settings)

Press the **Trigger Settings** soft key to display the following menu.

Wave Form	
Format	
Time/div	
Trig Settings	
Mode	Set the trigger mode (Auto, Normal, OFF).
Source	Set the trigger source (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk).
Slope	Set the trigger slope (f, $\uparrow$ , $\downarrow$ ).
Level	Set the trigger level (0.0% to $\pm 100.0\%$ ).

## Configuring Advanced Waveform Display Settings (Display Settings)

Press the **Display Settings** soft key to display the following menu.




### Note

Changes that you make to the waveform display settings on the Display Settings menu are also reflected in the advanced trend display settings (see section 10.1).

## Setting Waveform Mapping (Wave Mapping)

Press the **Wave Mapping** soft key to display the following screen.





## 9.2 Turning the Display of Waveforms On and Off and Setting the Vertical Zoom Factors and Vertical Positions

This section explains the following waveform display settings:

- Turning the display of waveforms on and off
- Vertical zoom factor
- Vertical position

► “Display Items (ITEM)—Waveform” in the features guide

### Configuring the Waveform Display

Press **WAVE** and then **ITEM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **ITEM** again.

Select the waveforms that you want to display.

Set the vertical zoom factor

( $\times 0.1$ ,  $\times 0.2$ ,  $\times 0.25$ ,  $\times 0.4$ ,  $\times 0.5$ ,  $\times 0.75$ ,  $\times 0.8$ ,  $\times 1$ ,  $\times 1.14$ ,  $\times 1.25$ ,  $\times 1.33$ ,  $\times 1.41$ ,  $\times 1.5$ ,  $\times 1.6$ ,  $\times 1.77$ ,  $\times 2$ ,  $\times 2.28$ ,  $\times 2.66$ ,  $\times 2.83$ ,  $\times 3.2$ ,  $\times 3.54$ ,  $\times 4$ ,  $\times 5$ ,  $\times 8$ ,  $\times 10$ ,  $\times 12.5$ ,  $\times 16$ ,  $\times 20$ ,  $\times 25$ ,  $\times 40$ ,  $\times 50$ ,  $\times 100$ ).

Set the vertical position (0.000% to  $\pm 130.000\%$ ).

Wave			Items	Wave		Items
Display ON/OFF	Vertical Zoom	Vertical Position		All ON		
<input checked="" type="checkbox"/> U1	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>		<input type="button" value="All ON"/>	Turns the display of all waveforms on	
<input checked="" type="checkbox"/> I1	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> U2	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>		<input type="button" value="All OFF"/>	Turns the display of all waveforms off	
<input checked="" type="checkbox"/> I2	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> U3	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> I3	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> U4	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> I4	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> U5	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> I5	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> U6	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> I6	<input type="text" value="x 1"/>	<input type="text" value="0.000%"/>				
<input checked="" type="checkbox"/> Speed	Speed and Torque are displayed on models with the /MTR option.					
<input checked="" type="checkbox"/> Torque						
<input checked="" type="checkbox"/> Aux1	Aux1 and Aux2 are displayed on models with the /AUX option.					
<input checked="" type="checkbox"/> Aux2						

## 10.1 Setting the Display Format

This section explains the following settings for the trend display format:

- Number of divisions of the trend screen
- Time axis
- Restarting trends
- Advanced trend display settings

► “Display Format (FORM)—Trend” in the features guide

### Others Menu

Press **OTHERS** to display the following menu.



Select Trend.

Even if you select one of these settings, you can still show the trend display. You can split the screen into top and bottom halves, and show the trend display in one half and another display in the other half. ► chapter 13

### Trend Form Menu

Press **FORM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **FORM** again.



Set the number of divisions on the trend screen (Single, Dual, Triad, Quad).

Set the time axis (3s, 6s, 10s, 30s, 1min, 3min, 6min, 10min, 30min, 1hour, 3hour, 6hour, 12hour, 1day).

Restarts the trend

Configure the advanced trend display settings.

Configuring Advanced Trend Display Settings (Display Settings)

Press the **Display Settings** soft key to display the following menu.

Trend Form

Format

Dual

Trend T/div

3s/div

Clear Trend Exec

Disp Settings

Interpolate

Graticule

Scale Value

OFF

Wave Label

OFF ON

Set the display interpolation (· · · , ^ · · ).

Set the grid ( , , ).

Turns the display of scale values on and off

Turns the display of trend labels on and off

**Note** Changes that you make to the trend display settings on the Display Settings menu are also reflected in the advanced waveform display settings (see section 9.1).

## 10.2 Turning the Trend Display On and Off and Setting the Measurement Functions to Display and the Vertical Scales

This section explains the following trend display settings:

- Turning the trend display on and off
- Measurement function
- Element and wiring unit
- Harmonic order
- Vertical scale

Vertical scale mode and upper and lower limits of vertical scales

► “Display Items (ITEM)—Trend” in the features guide

1. Follow the procedure in section 10.1 to select Trend on the Others menu.

### Configuring the Trend Display

2. Press **ITEM** to display the following screen.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **ITEM** again.

**Select the trends that you want to display.**

If you move the cursor to Display, and then press SET, you can select all the trends (All ON) and clear all the selections (All OFF).

**Set the measurement function (for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).**

**Set the element and wiring unit (Element 1 to Element 6,  $\Sigma$ A to  $\Sigma$ C).**

**Set the harmonic order (Total, 0 to 500; /G5 or /G6 option).**

You can set this setting when the measurement function includes a harmonic order.

**Select the vertical scale’s setup method (Auto, Manual).**

**Set the upper and lower limits (–9.999 T to 9.999 T).**  
These settings can be set when Scaling is set to Manual.

Trend Items						
Display	Function	Element/Z	Order	Scaling	Upper Scale	Lower Scale
<input checked="" type="checkbox"/> T1	Urms	Element 1	–	Manual	100.0	–100.0
<input checked="" type="checkbox"/> T2	Irms	Element 1	–	Auto	–	–
<input checked="" type="checkbox"/> T3	P	Element 1	–	Auto	–	–
<input checked="" type="checkbox"/> T4	S	Element 1	–	Auto	–	–
<input checked="" type="checkbox"/> T5	Q	Element 1	–	Auto	–	–
<input checked="" type="checkbox"/> T6	$\lambda$	Element 1	–	Auto	–	–
<input checked="" type="checkbox"/> T7	$\phi$	Element 1	–	Auto	–	–
<input checked="" type="checkbox"/> T8	FreqU	Element 1	–	Auto	–	–
<input type="checkbox"/> T9	Urms	Element 1	–	Auto	–	–
<input type="checkbox"/> T10	Urms	Element 1	–	Auto	–	–
<input type="checkbox"/> T11	Urms	Element 1	–	Auto	–	–
<input type="checkbox"/> T12	Urms	Element 1	–	Auto	–	–
<input type="checkbox"/> T13	Urms	Element 1	–	Auto	–	–
<input type="checkbox"/> T14	Urms	Element 1	–	Auto	–	–
<input type="checkbox"/> T15	Urms	Element 1	–	Auto	–	–
<input type="checkbox"/> T16	Urms	Element 1	–	Auto	–	–

## 11.1 Setting the Display Format


This section explains the following settings for the bar graph display format. This feature is available on models with the /G5 or /G6 option.

- Number of divisions of the bar graph screen
- Bar graph display range (displayed harmonic orders)

► “Display Format (FORM)—Bar Graph” in the features guide

### Others Menu


Press **OTHERS** to display the following menu.



### Bar Form Menu

Press **FORM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **FORM** again.



## 11.2 Setting the Measurement Function to Display and the Vertical Scale

This section explains the following bar graph display settings. This feature is available on models with the /G5 or /G6 option.

- Bar graph number
- Measurement function
- Element
- Vertical scale

Vertical scale mode, vertical scale type, vertical scale upper limit, and X-axis position

► [“Display Items \(ITEM\)—Bar Graph” in the features guide](#)

1. Follow the procedure in section 11.1 to select Bar on the Others menu.

### Bar Items Menu

2. Press **ITEM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **ITEM** again.

Bar Items	
Item No. 11	— Select the bar graph number that you want to set (1, 2, 3).
Function U	— Set the measurement function (U, I, P, S, Q, $\lambda$ , $\Phi$ , $\Phi U$ , $\Phi I$ , Z, Rs, Xs, Rp, Xp).
Element Element 1	— Set the element (Element 1 to Element6).
Scale Mode Fixed Manual	— Select the vertical scale's setup method (Fixed, Manual).
Vertical Scale Linear Log	— Set the vertical scale type (Linear, Log). This soft key is displayed when you set Scale Mode to Manual.
Upper Scale 100.0	— Set the upper limit (0 to 9.999 T). This soft key is displayed when you set Scale Mode to Manual.
X Axis Position Bottom Center	— Set the X-axis position (Bottom, Center). This soft key is displayed when you set Scale Mode to Manual and Vertical Scale to Linear.

# 12.1 Setting the Display Format

This section explains the following settings for the vector display format. This feature is available on models with the /G5 or /G6 option.

- Number of divisions of the vector screen
- Turning the numeric data display on and off

► “Display Format (FORM)—Vector” in the features guide

## Others Menu

Press **OTHERS** to display the following menu.

Others

Trend

Bar

Vector

Numeric  
+  
\*\*\*

Wave  
+  
\*\*\*

Trend  
+  
\*\*\*

Select Vector.

Even if you select one of these settings, you can still show the vector display. You can split the screen into top and bottom halves, and show the vector display in one half and another display in the other half. ► chapter 13

## Vector Form Menu

Press **FORM** to display the following menu.

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **FORM** again.

Vector Form

Format

Single

Numeric

OFF ON

Set the number of divisions on the vector screen (Single, Dual).

Turns the numeric data display on and off

## 12.2 Setting the Element and Wiring Unit to Display and the Zoom Factor

This section explains the following vector display settings. This feature is available on models with the /G5 or /G6 option.

- Vector number
- Element and wiring unit
- Zoom factor

► “Display Items (ITEM)—Vector” in the features guide

1. Follow the procedure in section 12.1 to select Vector on the Others menu.

### Vector Items Menu

2. Press **ITEM** to display the following menu.
  - If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the Info Form menu may be displayed. If this happens, press **ITEM** again.
  - If setup parameter list is being displayed, the vector that you have set to vector number 1 is displayed in the bottom half of the screen.

The screenshot shows a vertical menu titled "Vector Items". It contains several rows of settings, each with a small icon to its left. The settings are: "Item No." with a value of "1", "Object" with a value of "Σ A", "U Mag" with a value of "1.000", and "I Mag" with a value of "1.000". Below these are four empty rows.

Select the vector number that you want to set (1, 2).

Set the element and wiring unit (Element 1 to Element 6, ΣA to ΣC).

Set the zoom factor (0.100 to 100,000).

- Set the zoom factor of fundamental wave U (1) or I (1). The value that indicates the size of the vector display's peripheral circle changes according to the zoom factor, and the size of the vectors that indicate U (1) and I (1) change accordingly as well.
- If you press this soft key to select both U Mag and I Mag, you can link the zoom factors of both settings and change them at the same time.



## 13.1 Configuring the Split Display


This section explains the following split display settings:

- The two screens to display
- Switching between Form menus
- Switching between Items menus

► “Split Display” in the features guide

### Others Menu

Press **OTHERS** to display the following menu.



### Form Menu

Press **FORM** to switch between the Form menus of the two screens that you set on the Others menu. Configure the settings on each menu.

Display	For Instructions on How to Use the Form Menu, See:
Numeric	Sections 6.1 and 6.2
Wave	Section 9.1
Trend	Section 10.1
Bar	Section 11.1
Vector	Section 12.1

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the setup parameter list is displayed in the top half of the screen and the screen that you set to display in the top half of the split screen on the Others menu is displayed in the bottom half of the screen. Additionally, if you repeatedly press **FORM**, you can switch between the Info Form menu and the menu of the screen that is displayed in the bottom half of the screen.

### Items Menu

Press **ITEM** to switch between the Items menus of the two screens that you set on the Others menu. Configure the settings on each menu.

Display	For Instructions on How to Use the Items Menu, See:
Numeric	Sections 6.3 to 6.7
Wave	Section 9.2
Trend	Section 10.2
Bar	Section 11.2
Vector	Section 12.2

If the setup parameter list is being displayed (the INPUT INFO key is illuminated), the setup parameter list is displayed in the top half of the screen and the screen that you set to display in the top half of the split screen on the Others menu is displayed in the bottom half of the screen. Additionally, if you repeatedly press **ITEM**, you can switch between the Info Form menu and the menu of the screen that is displayed in the bottom half of the screen.

## 14.1 Performing Cursor Measurements on Waveforms

This section explains the following settings for performing cursor measurements on waveforms:

- Turning the cursor display on and off
- The waveforms to perform cursor measurements on
- Cursor movement path
- Cursor position
- Turning linked cursor movement on and off

► [“Cursor Measurement” in the features guide](#)

1. Follow the procedures in chapter 9 to display waveforms.

### Wave Cursor Menu

2. Press **SHIFT+FORM** (CURSOR) to display the following menu.

Wave Cursor	
Cursor	Turns the cursor display on and off
OFF ON	
C1+ Trace	Set the waveform to measure with cursor 1 (+) (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Speed, <sup>1</sup> Torque, <sup>1</sup> Aux1, <sup>2</sup> Aux2 <sup>2</sup> ).
U1	
C2× Trace	Set the waveform to measure with cursor 2 (×) (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Speed, <sup>1</sup> Torque, <sup>1</sup> Aux1, <sup>2</sup> Aux2 <sup>2</sup> ).
I1	
Cursor Path	Set the cursor movement path (Max, Min, Mid).
Max	
C1+ Position	Set the positions of cursor 1 (+) and cursor 2 (×) (0, which is the left edge of the screen to 800, which is the right edge of the screen)
160	
C2× Position	
640	
Linkage	Turns linked cursor movement on and off
OFF ON	

1 This feature is available on models with the /MTR option.

2 This feature is available on models with the /AUX option.

## 14.2 Performing Cursor Measurements on Trends

This section explains the following settings for performing cursor measurements on trends:

- Turning the cursor display on and off
- The trends to perform cursor measurements on
- Cursor position
- Turning linked cursor movement on and off

► [“Cursor Measurement” in the features guide](#)

1. Follow the procedures in chapter 10 to display trends.

### Trend Cursor Menu

2. Press **SHIFT+FORM** (CURSOR) to display the following menu.

Trend Cursor	
Cursor	Turns the cursor display on and off
OFF ON	
C1+ Trace	Set the trend to measure with cursor 1 (+) (T1 to T16).
T1	
C2× Trace	Set the trend to measure with cursor 2 (×) (T1 to T16).
T2	
C1+ Position	Set the positions of cursor 1 (+) and cursor 2 (×) (0, which is the left edge of the screen to 1601, which is the right edge of the screen)
100	
C2× Position	
900	
Linkage	Turns linked cursor movement on and off
OFF ON	

## 14.3 Performing Cursor Measurements on Bar Graphs

This section explains the following settings for performing cursor measurements on bar graphs:


- Turning the cursor display on and off
- Cursor position
- Turning linked cursor movement on and off

► [“Cursor Measurement” in the features guide](#)

1. Follow the procedures in chapter 11 to display bar graphs.

### Bar Cursor Menu

2. Press **SHIFT+FORM** (CURSOR) to display the following menu.



## 15.1 Setting the Number of Data Captures and Configuring the Capture Control Settings

This section explains the following settings concerning the number of data captures for high speed data capturing and the capture control settings.

- Number of data captures
- Confirming and optimizing the maximum capturing count
- Capture control settings

Voltage and current measurement modes, turning the HS filter on and off, setting the HS filter cutoff frequency, triggering, performing synchronized measurement using an external signal

- Selecting whether to save to a file

► **“Capture Count (Capture Count)” and “Capture Control Settings (Control Settings)”**  
in the features guide


### Others Menu

Press **OTHERS** to display the following menu.



### HS Settings Menu

Press **FORM** to display the following menu.



## Confirming and Optimizing the Maximum Capturing Count (Optimize Count)

Press the **Optimize Count** soft key to display the following screen.

The screen displays 'Optimize Count' at the top. Below it, 'Maximum Capturing Count' is shown with the value '506811' in a text box. To the right of the text box is a 'Set' button.

**Set the number of data captures.**

The capturing count is set to the maximum capturing count displayed to the left.

### Maximum capturing count (0 to the maximum number of captures)

\* The maximum number of times that data can be captured depends on the number of numeric data items that you have set to be saved and the free space at the save destination. For instructions on how to set the save destination and the numeric data items to be saved, see section 15.2.

Even if you have specified a USB memory device as the save destination, if you remove the USB memory device, the save destination switches automatically to the internal RAM disk. If you close this screen and then open it again by pressing the Optimize Count soft key, the maximum capturing count changes to the value determined by the internal RAM disk's free space.

## Configuring Capture Control Settings (Control Settings)

Press the **Control Settings** soft key to display the following menu.

The 'Control Settings' menu is shown with several options: 'U/I Measuring Mode', 'HS Filter' (with 'OFF' and 'ON' buttons and a 'Cutoff' frequency of '100 Hz'), 'Trigger Settings', and 'External Sync' (with 'OFF' and 'ON' buttons). There are also three empty slots at the bottom.

**Configure the voltage and current measurement modes.**

**Set the HS Filter.**

- Turn the HS filter on or off.
- Set the cutoff frequency (1 Hz to 1000 Hz in steps of 1 Hz)

**Configure trigger settings.**

**Turn external signal synchronization on or off.**

- OFF: This instrument captures data every 5 ms.
- ON: This instrument captures data in sync with an external signal.

## Configuring the Voltage and Current Measurement Modes

Press the **U/I Measuring Mode** soft key to display the following menu.

The 'U/I Measuring Mode' screen shows a table of settings for 16 channels. At the top, there are two tabs: 'Each' and 'All'. The table has columns for 'Setting', 'rms', 'mean', 'dc', and 'r-mean'. The channels are listed as U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6.

**Select the measurement mode setup method (Each, All).**


When you select Each, you can set the measurement mode separately for the current and voltage of each input element.

**Set the measurement mode (rms, mean, dc, r-mean).**

### Note

If the voltage and current measurement mode settings differ for elements assigned to the same wiring unit, the measurement data ( $\Sigma$  function) for the wiring unit is displayed as "-----" (no data).

### Configuring Trigger Settings



The screenshot shows the 'Control Settings' menu with the 'Trigger Settings' section expanded. The 'Trigger Settings' section includes four sub-menus: 'Mode', 'Source', 'Slope', and 'Level'. Each sub-menu is highlighted with a blue border and contains a list of options. To the right of each sub-menu, a text label explains the function of the settings.

Setting	Options	Description
Mode	Auto, Normal, OFF	Set the trigger mode (Auto, Normal, OFF).
Source	U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk	Set the trigger source (U1, I1, U2, I2, U3, I3, U4, I4, U5, I5, U6, I6, Ext Clk).
Slope	F, T, fT	Set the trigger slope (F, T, fT).
Level	0.0%	Set the trigger level (0.0% to $\pm 100.0\%$ ).



## 15.2 Configuring the Save Conditions of Captured Numeric Data

This section explains the following settings for the save conditions of captured numeric data.


- Save destination
- Selecting whether to perform automatic CSV conversion when capturing stops
- Numeric data items to save
- Auto naming
- File name
- Comment

► [“Save Conditions \(File Settings\)” in the features guide](#)

1. Follow the procedure in section 15.1 to select High Speed Data Capturing on the Others menu.


### File Settings Menu

2. Press **FORM** and then the **File Settings** soft key to display the following menu.



## Setting the Save Destination and Performing Manual CSV Conversion


Press the **File List** soft key to display the following screen.



## Setting the Numeric Data Items to Save

Press the **Item Settings** soft key to display the following screen.

The numeric data items in this screen whose check boxes are selected are saved.



### Note

Even if you select the check box for wiring unit ΣA, ΣB, or ΣC, the wiring unit's numeric data will not be saved under the following circumstances.

- When the wiring system has not been set
- When the wiring system is set to 1P3W or 3P3W
- When input elements assigned to the same wiring unit have different voltage or current measurement mode settings

For information on how to set the wiring system, see section 1.1.

## 15.3 Changing the Displayed Items for High Speed Data Capturing

This section explains the following settings concerning the displayed items for high speed data capturing.

- Number of columns
- Column number
- Element and wiring unit
- Resetting the displayed items
- Peak over-range information
- Turning the display frame on and off

► “Display Items (ITEM)—High Speed Data Capturing” in the features guide

1. Follow the procedure in section 15.1 to select High Speed Data Capturing on the Others menu.

### HS Items Menu

2. Press **ITEM** to display the following menu.

HS Items	
Column Num 4 6	Set the number of columns (4, 6).
Column No. 11	Set the column number (1 to 6).
Element/Σ Element 1	Set the element or wiring unit (None, Element 1 to Element 6, ΣA to ΣC).
Reset Items Exec	Resets items to the default values
Display Peak Over Status OFF ON	Peak over-range information
Display Frame OFF ON	Turns the display frame on and off

### Switching the Page

You can switch between page 1 and 2 (pages 1 to 4 on models with the /MTR or /AUX option). The items are arranged for high speed data capturing, and the displayed measurement functions are fixed for every page. For details on how to switch pages, see section 6.2.

#### Page 1 Example

		Element 1	Element 2	Element 3	Element 4	PAGE
U	Voltage	100Vrms	1000Vrms	1000Vrms	1000Vrms	1
	Current	1Arms	5Arms	5Arms	50Arms	2
I	[V ]	98.93	0.0000 k	0.0000 k	0.0000 k	3
	[A ]	0.6907	0.0000	0.0000	0.000	4
P	[W ]	68.23	-0.0000 k	0.0000 k	-0.000 k	

## Page 2 Example

		Element 1 100Vrms 1Arms	Element 2 1000Vrms 5Arms	Element 3 1000Vrms 5Arms	Element 4 1000Vrms 50Arms
Voltage					
U	[V]	98.93	0.0000 k	0.0000 k	0.0000 k
MaxU		98.93	0.0000 k	0.0000 k	0.0000 k
MinU		91.97	0.0000 k	0.0000 k	0.0000 k
Current					
I	[A]	0.6907	0.0000	0.0000	0.000
MaxI		0.7913	0.0000	0.0000	0.000
MinI		0.6591	0.0000	0.0000	0.000
Power					
P	[W]	68.23	-0.0000 k	0.0000 k	-0.000 k
MaxP		75.82	0.0000 k	0.0000 k	0.000 k
MinP		62.35	-0.0000 k	-0.0000 k	-0.000 k

## Page 3 Example

(Page 3 can only be selected on models with the /MTR or /AUX option.)

		Element 1 100Vrms 1Arms	Element 2 1000Vrms 5Arms	Element 3 1000Vrms 5Arms	Element 4 1000Vrms 50Arms
Voltage					
U	[V]	98.93	0.0000 k	0.0000 k	0.0000 k
Current					
I	[A]	0.6907	0.0000	0.0000	0.000
Power					
P	[W]	68.23	-0.0000 k	0.0000 k	-0.000 k
Speed	[rpm]	--OF--			
Torque	[Nm]	--OF--			
Pm	[W]	--OF--			

Speed, Torque, and Pm are displayed on models with the /MTR option.

Aux1	[kW/m2]	-0.000
Aux2	[kW/m2]	0.000

Aux1 and Aux2 are displayed on models with the /AUX option.

## Page 4 Example

(Page 4 can only be selected on models with the /MTR or /AUX option.)

		Element 1 100Vrms 1Arms	Element 2 1000Vrms 5Arms	Element 3 1000Vrms 5Arms	Element 4 1000Vrms 50Arms
Voltage					
U	[V]	98.93	0.0000 k	0.0000 k	0.0000 k
MaxU		98.93	0.0000 k	0.0000 k	0.0000 k
MinU		91.97	0.0000 k	0.0000 k	0.0000 k
Current					
I	[A]	0.6907	0.0000	0.0000	0.000
MaxI		0.7913	0.0000	0.0000	0.000
MinI		0.6591	0.0000	0.0000	0.000
Power					
P	[W]	68.23	-0.0000 k	0.0000 k	-0.000 k
MaxP		75.82	0.0000 k	0.0000 k	0.000 k
MinP		62.35	-0.0000 k	-0.0000 k	-0.000 k
Speed	[rpm]	--OF--			
MaxSpd		--OF--			
MinSpd		--OF--			
Torque	[Nm]	--OF--			
MaxTrq		--OF--			
MinTrq		--OF--			
Pm	[W]	--OF--			
MaxPm		--OF--			
MinPm		--OF--			

Speed, Torque, and Pm are displayed on models with the /MTR option.


Aux1	[kW/m2]	-0.000
MaxAux1		0.000
MinAux1		-0.000
Aux2	[kW/m2]	0.000
MaxAux2		0.001
MinAux2		-0.000

Aux1 and Aux2 are displayed on models with the /AUX option.

ELEMENT Key

3. Press **ESC** to clear the menu.


Displayed in the upper left of the numeric data display screen



Changing the Element and Wiring Unit (Horizontal direction)

4. Use the **cursor keys** (◀▶) to select the column that you want to change.
5. Press the **ELEMENT** key for displaying numeric data to select the element and wiring unit that you want to display.

In high speed data capturing, the elements and wiring unit configurations are the same on all four pages. If you change the element and wiring unit configuration on one page, the configuration changes on the other pages as well.



---


## 15.4 Starting and Stopping High Speed Data Capturing

This section explains how to start and stop high speed data capturing.

► [“Starting and Stopping High Speed Data Capturing \(Start/Stop\)” in the features guide](#)

---

### CAUTION

During high speed data capturing and when captured data is being saved, the storage medium is constantly being accessed, even though the icon that indicates this () is not displayed. Do not remove the USB memory device or turn the power off. Doing so may damage the storage medium and corrupt its data.


During high speed data capturing, “HS State: Start” appears in the upper right of the screen. While the captured data is being saved, “File State: Rec” appears in the upper left of the screen.

---

French

---

### ATTENTION

Pendant la collecte de données haute vitesse et lorsque les données collectées sont enregistrées, le système a constamment accès au support de stockage, même si l'icône qui l'indique () n'est pas affichée. Ne retirez pas le support de stockage USB et ne coupez pas l'alimentation. Vous risqueriez d'endommager le support de stockage et les données qu'il contient.

Lors de la collecte des données haute vitesse, « HS State: Start » s'affiche dans l'angle supérieur droit de l'écran.

Lorsque les données collectées sont enregistrées, « File State: Rec » s'affiche dans l'angle supérieur gauche de l'écran.

---


## 15.4 Starting and Stopping High Speed Data Capturing

---

1. Follow the procedure in section 15.1 to select High Speed Data Capturing on the Others menu.

### HS Settings Menu

2. Press **FORM** to display the following menu.



**Starts high speed data capturing**

High speed data capturing starts according to the specified number of data captures (see section 15.1), the capture control settings (see section 15.1), and the save conditions (see section 15.2).

- When high speed data capturing is started, “HS State: Start” appears in the upper right of the screen.
- When the captured data is being saved, “File State: Rec” appears in the upper left of the screen.

**Stops high speed data capturing**

After the specified number of data captures have been made, high speed data capturing automatically stops. To force high speed data capturing to stop, press this soft key.

When high speed data is stopped, “HS State: Ready” appears in the upper right of the screen.

---

### Note

- You cannot restart high speed data capturing without first stopping high speed data capturing.
  - After you stop high speed data capturing and then change the settings or restart high speed data capturing, the data captured up to that point is deleted.
-

## 16.1 Configuring Storage Control

This section explains the following settings for storage control:


- Storage mode
- Storage count
- Confirming and optimizing the maximum storage count
- Storage interval
- Scheduled times for real-time storage
- Trigger event (synchronization to a user-defined event)
- Storage of numeric data when storage starts

► “Storage Control (Control Settings)” in the features guide

### Control Settings Menu


Press **SHIFT+STORE START** (STORE SET) and then the **Control Settings** soft key to display one of the menus shown below. The menu that appears varies depending on the storage mode setting that you have specified.

### Manual Storage Mode



### Confirming and Optimizing the Maximum Storage Count

Press the **Optimize Count** soft key to display the following screen.




**Maximum storage count (0 to the maximum number of times that data can be stored to the save destination)\***

\* The maximum number of times that storage can be performed depends on the number of stored items that you have set and the free space at the save destination.  
For details on how to set the stored items, see section 16.2. For details on how to set the save destination, see section 16.3.

Even if you have specified a USB memory device as the save destination, if you remove the USB memory device, the save destination switches automatically to the internal RAM disk. If you close this screen and then open it again by pressing the Optimize Count soft key, the maximum storage count changes to the value determined by the internal RAM disk's free space.


### Setting the Storage Interval

Press the **Interval** soft key to display the following screen.





## Scheduled Times for Real-Time Storage Mode



Control Settings

Store Mode  
**Real Time** — Set Store Mode to Real Time.

Store Count  
100 — Set the storage count (Infinite, 1 to 9999999).

Optimize Count — Confirms and optimizes the maximum storage count ► previous page


Interval — Set the storage interval. ► previous page

Real-time Control — Set the scheduled times for real-time storage.

Store at Start  
OFF ON — Select whether to store numeric data when storage starts.  
This soft key is displayed when Interval is set to a value other than 00 : 00 : 00.

### Setting Scheduled Times for Real-Time Storage

Press the **Real-time Control** soft key to display the following screen.



Real-time Control

Start 2011 / 01 / 01 00 : 00 : 00 — Set the scheduled start and stop times (Year/month/day, 00 hours : 00 minutes : 00 seconds to 23 hours : 59 minutes : 59 seconds).

End 2011 / 01 / 01 01 : 00 : 00


Scheduled storage stop time

Scheduled storage start time

Now — Sets the scheduled storage start time to the current time

Copy — Copies the scheduled storage start time to the scheduled storage stop time

## Integration-Synchronized Storage Mode



Control Settings

Store Mode  
**Integ Sync** — Set Store Mode to Integ Sync.

Store Count  
100 — Set the storage count (Infinite, 1 to 9999999).

Optimize Count — Confirms and optimizes the maximum storage count ► previous page

Interval — Set the storage interval. ► previous page

Store at Start  
OFF ON — Select whether to store numeric data when storage starts.

Event-Synchronized Storage Mode

Control Settings

Store Mode

Event

Store Count

100

Optimize Count

Trigger Event

Event1

Set Store Mode to Event.

Set the storage count (Infinite, 1 to 9999999).

Confirms and optimizes the maximum storage count ▶ page 16-1

Select the trigger event (Event 1 to Event 8).

When measured data is updated, storage is started if the conditions of the specified user-defined event are met.

Single-Shot Storage Mode

Control Settings

Store Mode

Single Shot

Store Count

100

Optimize Count

Set Store Mode to Single Shot.

Set the storage count (Infinite, 1 to 9999999).

Confirms and optimizes the maximum storage count ▶ page16-1


## 16.2 Setting the Numeric Data Items to Store

This section explains how to set the numeric data items to store.

- Numeric data items to store
    - Numeric data items that are displayed on the screen
    - Numeric data items specified on the stored item setup screen
- “Stored Items (Item Settings)” in the features guide

### Item Settings Menu

Press **SHIFT+STORE START** (STORE SET) and then the **Item Settings** soft key to display the following menu.



### Setting Stored Items (Items)

Press the **Items** soft key to display the following screen.

When you press the Selected Items soft key on the Item Settings menu, the numeric data items that you have specified on the following screen are stored.

Selects all the numeric data items

Clears the selection of all the numeric data items

Selects the preset numeric data items

The screenshot shows the "Item Settings" screen with a grid of checkboxes for selecting numeric data items to store. The grid is organized into columns for Preset, Element, and Function. The "Preset" column has checkboxes for "All ON", "All OFF", "Preset1", and "Preset2". The "Element" column has checkboxes for "Element1" through "Element6". The "Function" column has checkboxes for "Urms", "Urmn", "Udc", "Umn", "Uac", "FreqU", "Gfu", "Irms", "Irmn", "Idc", "Imn", "Iac", "FreqI", "Gfi", "P", "S", "Q", "λ", "φ", "Pc", "U+peak", "U-peak", "I+peak", "I-peak", "P+peak", "P-peak", "WP", "WP+", "WP-", "q", "q+", "q-", "Time", "WS", "WQ", "F1", "F2", "F3", "F4", "F5", "F6", "F7", "F8", "F9", "F10", "F11", "F12", "F13", "F14", "F15", "F16", "F17", "F18", "F19", "F20", "Event1", "Event2", "Event3", "Event4", "Event5", "Event6", "Event7", "Event8", "FreqPLL1", "FreqPLL2", "U(k)", "I(k)", "P(k)", "S(k)", "Q(k)", "λ(k)", "φ(k)", "ΦU(k)", "ΦI(k)", "Z(k)", "Rs(k)", "Xs(k)", "Rp(k)", "Xp(k)", "Uthd", "Ithd", "Pthd", "Uhd(k)", "Ihd(k)", "Phd(k)", "Uthf", "Ithf", "Uhf", "Ihf", "hvf", "hcf", "K-factor", "ΦU-Uj", "ΦI-Uk", "ΦU-Ii", "ΦU-Ij", "ΦU-Ik", "ΔU1", "ΔU2", "ΔU3", "ΔUΣ", "ΔI", "ΔP1", "ΔP2", "ΔP3", "ΔPΣ", "Speed", "Torque", "SyncSp", "Slip", "Pm", "EaU", "EaI".

Select the check boxes for the numeric items that you want to store.

## 16.3 Configuring the Save Conditions of Stored Numeric Data


This section explains the following settings for the save conditions of stored numeric data:

- Save destination
- Selecting whether to perform automatic CSV conversion when storage stops
- Auto naming
- File name
- Comment

► “Save Conditions (File Settings)” in the features guide


### File Settings Menu

Press **SHIFT+STORE START** (STORE SET) and then the **File Settings** soft key to display the following menu.



### Setting the Save Destination and Performing Manual CSV Conversion

Press the **File List** soft key to display the following screen.




## 16.4 Starting, Stopping, and Resetting Storage

This section explains how to start, stop, and reset storage.

- ▶ [“Starting, Stopping, and Resetting Storage \(STORE START, STORE STOP, and STORE RESET\)”](#)  
in the features guide


### CAUTION

During storage, the storage medium is constantly being accessed, even though the icon that indicates this () is not displayed. Do not remove the USB memory device or turn the power off. Doing so may damage the storage medium or corrupt its data.

Storage is in progress when the STORE START key is illuminated or blinking or when the STORE STOP key is blinking.

French

### ATTENTION

Pendant la collecte, le système a constamment accès au support de stockage, même si l'icône qui l'indique () n'est pas affichée. Ne retirez pas le support de stockage USB et ne coupez pas l'alimentation. Vous risqueriez d'endommager le support de stockage ou les données qu'il contient.

Le stockage est en cours quand la touche STORE START est éclairée ou quand elle clignote, ou bien quand la touche STORE STOP clignote.

## Starting the Storage Operation

Press **STORE START**. This instrument starts storage using the storage mode that you have specified (see section 16.1).

- The STORE START key is illuminated.  
Storage has started; “Store: Start” is displayed.\*
- The STORE START key is blinking.  
The storage operation is ready; “Store: Ready” is displayed.\*

\* Character strings are displayed in the upper left of the screen.

## Stopping the Storage Operation

This instrument automatically stops storage according to the storage mode that you have specified. To pause storage, press **STORE STOP**.

- The STORE STOP key is blinking.  
Storage has been paused; “Store: Stop” is displayed.\*  
If you press STORE START when “Stop” is displayed in yellow, you can resume the storage operation from the point where you stopped the storage operation.
- The STORE STOP key is illuminated.  
Storage has been automatically stopped; “Store: Close” is displayed, and then “Store:Cmpl” is displayed.\*

\* Character strings are displayed in the upper left of the screen.

## Resetting the Storage Operation

Press **SHIFT+STORE STOP** (STORE RESET). The STORE STOP key turns off.

- If the storage operation has been paused  
This instrument finishes writing stored data to a file and closes the file.
- If the storage operation has automatically stopped  
When the storage operation stops automatically, this instrument finishes writing stored data to a file and closes the file. Therefore, the reset operation performs no file operations.

### **Note**

---

If you do not reset storage, you will not be able to start it again.

---


## 17.1 Connecting USB Memory Devices

This section explains how to connect USB memory devices to save and load data.

If you want to use a storage device on your network (a network drive), you have to use an Ethernet cable to connect this instrument to the network. For details, see section 20.4.


► [“Storage Media” in the features guide](#)

### CAUTION

- Do not remove the USB memory device or turn off the power when the USB memory device is being accessed. Doing so may damage the storage medium or corrupt its data.
- When the USB memory device is being accessed,  is displayed in the center of the top part of the screen and the USB memory device indicator blinks.

French

### ATTENTION


- Lorsque le dispositif accède au support de stockage USB, ne retirez pas ce dernier et ne mettez pas l'alimentation hors tension. Vous risqueriez d'endommager le support de stockage ou les données qu'il contient.
- Quand le système accède au support de stockage USB,  s'affiche au centre, dans la partie supérieure de l'écran, et le voyant du support de stockage USB clignote.

## USB Memory Devices That Can Be Used and How to Connect USB Memory Devices

Use portable USB memory devices that are compatible with USB Mass Storage Class version 1.1. Connect USB memory devices directly to the USB ports (type A) for connecting peripheral devices on the front panel.

Hot-plugging is supported: you can connect or disconnect the USB device at any time, regardless of whether this instrument is on or off. When the power is on, this instrument automatically detects the USB memory device after it is connected.

This instrument has two USB ports: USB-0 and USB-1. The port numbers are not fixed. The port at which the first USB memory device is detected becomes USB-0. The port at which the second USB memory device is detected becomes USB-1.



## 17.1 Connecting USB Memory Devices

---

### **Note**

- Connect USB memory devices directly to the USB ports (type A) for connecting peripheral devices. Do not connect them through a hub.
  - Use portable USB memory devices that are compatible with USB Mass Storage Class version 1.1. Do not connect an incompatible USB memory device.
  - You cannot use protected USB memory devices (such as those that contain encrypted content).
  - Do not connect and disconnect the two USB devices repetitively. Provide at least a 10-second interval between removal and connection.
- 

### **General USB Handling Precautions**

Follow the general handling precautions that are included with your USB memory.



## 17.2 Saving Setup Parameters


This section explains the following settings for saving setup parameters:

- Save destination
- Auto naming
- File name
- Comment

► “Saving Setup Data (Save Setup)” in the features guide


### Save Setup Menu

Press **FILE** and then the **Save Setup** soft key to display the following menu.



### Setting the Save Destination (File List)

Press the **File List** soft key to display the following screen.



### Note

For details on how to move between the operation menu and the file list and how to operate the operation menu, see section 17.6.

### Setting Auto Naming (Auto Naming)

- OFF: The auto naming feature is not used. The name that you specified for the File Name setting is used. If there is a file with the same name in the save destination folder, you cannot save the data.
- Numbering: This instrument automatically adds a four-digit number from 0000 to 0999 after the common name that you specified for the File Name setting and saves the file.
- Date: The file name is the date and time (down to seconds) when the file is saved. The file name that you specified for the File Name setting is ignored.

**20100930\_121530\_0 (2010/09/30 12:15:30)**

**Y M D H Min S**

The sequence number (0-9, A-Z) that is appended if a file name with the exact same date and time (down to seconds) exists.

The sequence number that comes after the date and time is appended if a file name with the exact same date and time (down to seconds) exists. The sequence number is incremented by one (0 to 9 and then A to Z) each time a file is added.

### Setting the File Name (File Name)

You can set the file name that is used when Auto Naming is set to OFF. This is also used as the common file name when Auto Naming is set to Numbering. The maximum number of characters that you can use for file names and folder names is 32 characters. However, there are limitations on the type of characters and the character strings that you can use.

### Setting the Comment (Comment)

You can add a comment that consists of up to 30 characters when saving files. You do not have to enter a comment. All characters, including spaces, can be used in comments.

## 17.3 Saving Waveform Display Data

This section explains the following settings for saving waveform display data:

- Save destination
- Auto naming
- File name
- Comment

► “Saving Waveform Display Data (Save Wave)” in the features guide

### Save Wave Menu

Press **FILE** and then the **Save Wave** soft key to display the following menu.

Save Wave	
◀ File List	Set the save destination. ► section 17.2
Auto Naming Numbering	Set auto naming. ► section 17.2
File Name	Set the file name. ► section 17.2
Comment	Set a comment. ► section 17.2
Save Exec	Saves the data

## 17.4 Saving Numeric Data


This section explains the following settings for saving numeric data:

- Save destination
- Numeric data items to save
- Auto naming
- File name
- Comment

► [“Saving Numeric Data \(Save Numeric\)” in the features guide](#)


### Save Numeric Menu

Press **FILE** and then the **Save Numeric** soft key to display the following menu.



### Setting the Numeric Data Items to Save (Item Settings)

Press the **Item Settings** soft key to display the following menu.



Setting Items to Save (Items)

Press the **Items** soft key to display the following screen.

When you press the Selected Items soft key on the menu on the previous page, the numeric data items that you have specified on the following screen are saved.

Selects all the numeric data items

Clears the selection of all the numeric data items

Selects the preset numeric data items

Item Settings

Preset	All ON	All OFF	Preset1	Preset2			
Element	<input checked="" type="checkbox"/> Element1	<input type="checkbox"/> Element2	<input type="checkbox"/> Element3	<input type="checkbox"/> Element4	<input type="checkbox"/> Element5	<input type="checkbox"/> Element6	
	<input type="checkbox"/> $\Sigma$ A	<input type="checkbox"/> $\Sigma$ B	<input type="checkbox"/> $\Sigma$ C				
Function	<input checked="" type="checkbox"/> Urms	<input type="checkbox"/> Umn	<input type="checkbox"/> Udc	<input type="checkbox"/> Umn	<input type="checkbox"/> Uac	<input checked="" type="checkbox"/> FreqU	<input type="checkbox"/> GfU
	<input checked="" type="checkbox"/> Irms	<input type="checkbox"/> Imn	<input type="checkbox"/> Idc	<input type="checkbox"/> Imn	<input type="checkbox"/> Iac	<input checked="" type="checkbox"/> FreqI	<input type="checkbox"/> GfI
	<input checked="" type="checkbox"/> P	<input checked="" type="checkbox"/> S	<input checked="" type="checkbox"/> Q	<input checked="" type="checkbox"/> $\lambda$	<input checked="" type="checkbox"/> $\phi$	<input type="checkbox"/> Pc	
	<input type="checkbox"/> U+peak	<input type="checkbox"/> U-peak	<input type="checkbox"/> I+peak	<input type="checkbox"/> I-peak	<input type="checkbox"/> P+peak	<input type="checkbox"/> P-peak	
	<input type="checkbox"/> WP	<input type="checkbox"/> WP+	<input type="checkbox"/> WP-	<input type="checkbox"/> q	<input type="checkbox"/> q+	<input type="checkbox"/> q-	
	<input type="checkbox"/> Time	<input type="checkbox"/> WS	<input type="checkbox"/> WQ				
	<input type="checkbox"/> Q1	<input type="checkbox"/> Q2	<input type="checkbox"/> Q3	<input type="checkbox"/> Q4			
	<input type="checkbox"/> F1	<input type="checkbox"/> F2	<input type="checkbox"/> F3	<input type="checkbox"/> F4	<input type="checkbox"/> F5	<input type="checkbox"/> F6	<input type="checkbox"/> F7
	<input type="checkbox"/> F8	<input type="checkbox"/> F9	<input type="checkbox"/> F10	<input type="checkbox"/> F11	<input type="checkbox"/> F12	<input type="checkbox"/> F13	<input type="checkbox"/> F14
	<input type="checkbox"/> F15	<input type="checkbox"/> F16	<input type="checkbox"/> F17	<input type="checkbox"/> F18	<input type="checkbox"/> F19	<input type="checkbox"/> F20	
	<input type="checkbox"/> Event1	<input type="checkbox"/> Event2	<input type="checkbox"/> Event3	<input type="checkbox"/> Event4			
	<input type="checkbox"/> Event5	<input type="checkbox"/> Event6	<input type="checkbox"/> Event7	<input type="checkbox"/> Event8			
	<input type="checkbox"/> FreqPLL1	<input type="checkbox"/> FreqPLL2					
	<input type="checkbox"/> U(k)	<input type="checkbox"/> I(k)	<input type="checkbox"/> P(k)	<input type="checkbox"/> S(k)	<input type="checkbox"/> Q(k)	<input type="checkbox"/> A(k)	<input type="checkbox"/> $\phi$ (k)
	<input type="checkbox"/> $\phi$ U(k)	<input type="checkbox"/> $\phi$ I(k)	<input type="checkbox"/> Z(k)	<input type="checkbox"/> Rs(k)	<input type="checkbox"/> Xs(k)	<input type="checkbox"/> Rp(k)	<input type="checkbox"/> Xp(k)
	<input type="checkbox"/> Uthd	<input type="checkbox"/> Ithd	<input type="checkbox"/> Pthd	<input type="checkbox"/> Uhdff(k)	<input type="checkbox"/> Ihdff(k)	<input type="checkbox"/> Phdff(k)	
	<input type="checkbox"/> Uthf	<input type="checkbox"/> Ithf	<input type="checkbox"/> Uthf	<input type="checkbox"/> Itif	<input type="checkbox"/> hvf	<input type="checkbox"/> hcf	<input type="checkbox"/> K-factor
	<input type="checkbox"/> $\phi$ U-Uj	<input type="checkbox"/> $\phi$ U-Uk	<input type="checkbox"/> $\phi$ U-I	<input type="checkbox"/> $\phi$ U-Uj	<input type="checkbox"/> $\phi$ U-Ik		
	<input type="checkbox"/> $\Delta$ U1	<input type="checkbox"/> $\Delta$ U2	<input type="checkbox"/> $\Delta$ U3	<input type="checkbox"/> $\Delta$ U $\Sigma$	<input type="checkbox"/> $\Delta$ I		
	<input type="checkbox"/> $\Delta$ P1	<input type="checkbox"/> $\Delta$ P2	<input type="checkbox"/> $\Delta$ P3	<input type="checkbox"/> $\Delta$ P $\Sigma$			
	<input type="checkbox"/> Speed	<input type="checkbox"/> Torque	<input type="checkbox"/> SyncSp	<input type="checkbox"/> Slip	<input type="checkbox"/> Pm	<input type="checkbox"/> EaU	<input type="checkbox"/> EaI

Select the check boxes for the numeric items to save.


## 17.5 Loading Setup Parameters

This section explains how to load setup parameters.

► [“Loading Setup Data \(Load Setup\)” in the features guide](#)

### Load Setup Menu

Press **FILE** and then the **Load Setup** soft key to display the following screen.



#### Note

- This instrument cannot load setup parameters that have been saved by a product with an incompatible firmware version.
- This instrument cannot load setup parameters that were saved by an instrument with a different element configuration or with different options.

## 17.6 File Operations

This section explains the file list's operation menu and the FILE\_Utility menu.

- Sorting the file list
- Display format
- Type of file to list
- Changing storage media (drives)
- Deleting files and folders
- Renaming files and folders
- Making folders (directories)
- Copying files and folders
- Moving files and folders
- Selecting files and folders (All Set, All Reset, and Set/Reset)

► “File Operations (Utility)” in the features guide

### The File List (File List)

**Operation menu cursor**  
Use the **cursor** keys (▲▼) to move the cursor.

**Sorts the file list**  
**Set the display format.**  
**Set the type of file to list.**

**Changes the storage medium (drive)**  
**Deletes the selected files and folders**  
**Renames files and folders**  
**Makes folders (directories)**  
**Copies the selected files and folders**  
**Moves the selected files and folders**

**Selection mark**  
If you want to perform an operation on a group of files at the same time, move the cursor to a file that you want to select, and then press **SET** to display this mark next to the file. To select multiple folders, press the **Set/Reset** soft key on the FILE\_Utility menu to display this mark next to the selected folder.

If you want to perform an operation on a single file, move the cursor to the file you want to select to display this mark next to the file.

File Name	Size	Date	Attr
0000.CSV	3.06K	2010/09/30 11:09:42	r/w
0000.PNG	160K	2010/09/30 11:09:42	r/w
0000.SET	59.2K	2010/09/30 11:09:42	r/w
0001.CSV	3.06K	2010/09/30 11:09:44	r/w
0001.PNG	162K	2010/09/30 11:09:44	r/w

**Total number of files and folders that are contained within the storage medium or folder indicated by the path**


**File list cursor**  
Use the **cursor** keys (▲▼) to move the cursor.

**Operation menu** ← Use the **cursor** keys (◀▶) to switch between operation areas.

**File list**

## Sorting the File List (Sort To)


Select **Sort To** on the operation menu to display the following screen.




## Setting the Display Format (≡, 田)

Select ≡ or 田 on the operation menu to display the following screen.

### List Display (≡)




### Thumbnail Display (田)





## Setting the Type of Files to List (Filter)

Select **Filter** on the operation menu to display the following screen.




### File Type

*.*	All files
*.SET	Setup parameter files
*.CSV	Numeric data files (ASCII format), storage data files (ASCII format), and waveform display data files (ASCII format)
*.WTS	Storage data files (binary format)
*.HDS	Storage header files (binary format)
*.BMP	Screen image data files (BMP format) and custom display background files
*.PNG	Screen image data files (PNG format)
*.JPG	Screen image data files (JPEG format)
*.TXT	Custom display configuration files

## Changing the Storage Medium or Drive (Change Drive)

Select **Change Drive** on the operation menu to display the following screen.



### Storage Medium (Drive) Type


RAM-0	Internal RAM disk of this instrument
USB-0	USB memory device that was detected first
USB-1	USB memory device that was detected second
Network	Network drive

### Note

You can also change the storage medium by highlighting the storage medium (drive) you want to change to in the file list and pressing SET.

## Deleting Files and Folders (Delete)

1. Select the file or folder in the file list that you want to delete.
2. Select **Delete** on the operation menu to display the following screen.




### Note

- To delete multiple files or folders that are in the file list at the same time, move the cursor to the file or folder that you want to delete, and then carry out the following operations.  
Files: Press SET or the Set/Reset soft key on the Utility menu.  
Folders: Press the Set/Reset soft key on the Utility menu. If you press SET, all the files and folders that you have selected up to that point will be cleared.
- You cannot delete folders on network drives.


## Renaming Files and Folders (Rename)

1. Select the file or folder in the file list that you want to rename.
2. Select **Rename** on the operation menu to display the following screen.




## Making Folders (Directories; Make Dir)

1. Select the drive or folder in the file list that you want to make the new folder in.
2. Select **Make Dir** on the operation menu to display the following screen.




## Copying Files and Folders (Copy)

1. Select the file or folder in the file list that you want to copy.
2. Select **Copy** on the operation menu to display the following screen.



3. Select the drive or folder in the file list that you are copying to.
4. Select **Copy Exec** on the operation menu to display the following screen.




### Note

- The procedure for selecting multiple files or folders at the same time to copy them is the same as the procedure for selecting multiple files or folders at the same time to delete them. For more details, see the note on page 17-11.
- You cannot copy folders on a network drive.
- You can perform file operations on the file list that you are copying to as well.

## Moving Files and Folders (Move)

1. Select the file or folder in the file list that you want to move.
2. Select **Move** on the operation menu to display the following screen.



3. Select the drive or folder in the file list that you are moving to.
4. Select **Move Exec** on the operation menu to display the following screen.




### Note

- The procedure for selecting multiple files or folders at the same time to move them is the same as the procedure for selecting multiple files or folders at the same time to delete them. For more details, see the note on page 17-11.
- You cannot move folders on a network drive.
- You can perform file operations on the file list that you are moving data to as well.

## FILE Utility Menu

Press **FILE** and then the **Utility** soft key to display the following menu.



## Setting the File Operation (Operation, More)

You can perform the same file operations as those that you can perform from the operation menu described on pages 17-8 to 17-13.

## Select/Clear (Set/Reset)

This soft key selects the file or folder in the file list that is highlighted or clears the selection. The selection marks (see page 17-8) are displayed to the left of the selected files.

## Select All and Clear All (All Set and All Reset)

**All Set:** In the file list, when a drive is highlighted or a file or folder in a drive or folder is highlighted, pressing this soft key selects all the files and folders in the corresponding drive or folder. The selection marks (see page 17-8) are displayed to the left of the selected files and folders.

**All Reset:** Pressing this soft key clears all the selected files and folders.

## Jump to the Specified File or Folder (Jump To)

Press this soft key to move the cursor to the file or folder in the file list that you specify by its position number. The top-most position in the file list is number 0.

**Range:** 0-999. However, if you specify a position whose number is larger than the total number of files and folders in the file list, the cursor will move to the bottom-most file or folder in the file list.

## 18.1 Saving Screen Images


This section explains the following settings for saving screen images:

- Save destination
- File format
- Color
- Auto naming
- File name
- Comment

► [“Saving Screen Images” in the features guide](#)

### Image Save Menu

Press **SHIFT+IMAGE SAVE** (MENU) to display the following menu.



### Saving Screen Captures

Press **IMAGE SAVE** to save the screen image with the save conditions that you specified on the Image Save menu.

## 19.1 Loading Roll Paper into the Built-In Printer (Option)

This section explains how to load roll paper into the optional built-in printer.

### Printer Roll Paper

Only use roll paper specifically made for use with this instrument. When you first use the printer, use the included roll paper. When you need a new supply of roll paper, contact your nearest YOKOGAWA dealer.

Part Number: B9316FX  
Specifications: Heat sensitive paper, 10 m  
Minimum Quantity: 10 rolls

### Handling Roll Paper

The roll paper is made of heat sensitive paper that changes color thermochemically. Please read the following information carefully.

#### Storage Precautions

When in use, the heat-sensitive paper changes color gradually at temperatures of approximately 70° C or higher. The paper can be affected by heat, humidity, light, and chemicals, whether something has been recorded on it or not. As such, please follow the guidelines listed below.

- Store the paper in a cool, dry, and dark place.
- Use the paper as quickly as possible after you break its protective seal.
- If you attach a plastic film that contains plasticizing material, such as vinyl chloride film or cellophane tape, to the paper for a long time, the recorded sections will fade due to the effect of the plasticizing material. Use a holder made of polypropylene to store the roll paper.
- When pasting the record paper to another material, do not use paste that contains organic solvents such as alcohol or ether. Doing so will change the paper's color.
- We recommend that you make copies of the recordings if you intend to store them for a long period of time. Because of the nature of heat-sensitive paper, the recorded sections may fade.

#### Handling Precautions

- Use genuine, YOKOGAWA-supplied roll paper.
- If you touch the roll paper with sweaty hands, there is a chance that you will leave fingerprints on the paper, thereby blurring the recorded sections.
- If you rub something against the surface of the roll paper, the paper may change color due to frictional heat.
- If the roll paper comes into contact with products such as chemicals or oil, there is a chance that the paper will change color or that the recorded sections will disappear.

## Loading the Roll Paper



### WARNING

A roll paper cutter is present inside the printer unit cover. Be careful of the cutter so as to avoid injuring your fingers or hands.

- Do not insert your fingers into the opening on the printer unit (the roll paper ejection hole).
- When you have opened the printer unit cover to place roll paper in the holder, avoid touching the cutter with your fingers and hands.

Do not touch the print head and print motor. If you do, you may burn yourself.

French




### AVERTISSEMENT

Un dispositif de coupe de papier en rouleau est fixé sur le couvercle de l'imprimante. Prendre garde de se blesser les mains ou les doigts avec le dispositif de coupe.


- Ne pas insérer de doigt dans l'ouverture de sortie du papier en rouleau de l'imprimante.
- Ne pas laisser une main ou des doigts entrer en contact avec le dispositif de coupe lors de l'ouverture du couvercle de l'imprimante et de la charge du papier en rouleau dans son logement.

Ne touchez pas la tête d'impression ni le moteur d'impression. Vous pourriez vous brûler.


1. Slide the lever to the right to make the printer unit protrude from this instrument.




2. Insert your finger into the groove on the right side of the printer unit.



3. Hold the top, bottom, and right side of the printer unit, and then pull it toward you until it stops (pull the unit approximately 5 cm).




4. Hold the left and right sides of the printer unit's tray with your hands, and push the right and left sides of the front of the cover with your thumbs to raise it.







## 19.1 Loading Roll Paper into the Built-In Printer (Option)


5. Pull approximately 10 cm of the roll paper out, and load the roll paper in the holder so that the thermal side of the paper is facing up. Load the paper so that it passes through the guides.




6. Lower the cover while you push the stopper to the left to release the latch. Hold the tray from underneath with both hands, and close the cover until you hear a click.



7. Push the printer unit (push the area to the left of the lever on the front panel) back into this instrument until you hear a click.



This completes the procedure for loading the roll paper.



### Feeding Paper

Press **SHIFT+PRINT** (MENU) to display the following menu.



— **Feeds paper**

Each time that you press this soft key, this instrument feeds approximately 3 cm of the roll paper.

### Cutting Roll Paper

After you load roll paper and close the cover or after you print measured data, to cut the roll paper, pull the paper up against the top of the cover.

#### Note

---

- If you open the printer cover immediately after you cut the roll paper, repeat steps 5 to 7 on pages 19-2 and 19-3.
  - After you load roll paper and close the cover, check whether the paper feeds correctly. If the roll paper does not feed straight, repeat steps 1 to 7 on pages 19-2 and 19-3.
  - If you load the roll paper backwards, the paper may not feed properly or data may not be printed. This is because the print head doesn't come into contact with the thermal side of the paper. Load the roll paper into the holder in the proper orientation.
-

## 19.2 Printing Using the Built-in Printer (Option)


This section explains the following settings for printing on the optional built-in printer:

- Output format
- Executing auto printing
- Auto printing
  - Print mode, print count, print interval, scheduled times for real-time printing, trigger event (synchronized to a user-defined event), and printing data when printing starts
- Comment
- Feeding paper

► [“Printing Screen Images and Numeric Data \(Option\)” in the features guide](#)

### Print Menu Menu

Press **SHIFT+PRINT** (MENU) to display the following menu.



Configuring Auto Printing

Press the **Auto Print Settings** soft key to display one of the menus shown below. The menu that appears varies depending on the Print Mode setting that you have specified.

Interval Print Mode

Auto Print Settings

Print Mode

Interval

Set Print Mode to Interval.

Print Count

Infinite

Set the print count (Infinite, 1 to 9999).

Print Interval

Set the print interval.

Print at Start

OFF ON

Select whether to print the data at print start

Setting the Print Interval

Press the **Print Interval** soft key to display the following screen.

Interval

Interval 00 : 01 : 00

Set the print interval  
(00 hours : 00 minutes : 10 seconds to 99 hours : 59 minutes : 59 seconds).

Scheduled Times for Real-Time Print Mode

Auto Print Settings

Print Mode

Real Time

Set Print Mode to Real Time.

Print Count

Infinite

Set the print count (Infinite, 1 to 9999).

Print Interval

Set the print interval ► “Interval Print Mode” above

Real-time Control

Set the scheduled times for real-time printing.

Print at Start

OFF ON

Select whether to print the data at print start

### Setting Scheduled Times for Real-Time Printing

Press the **Real-time Control** soft key to display the following screen.

**Real-time Control**

Start: 2011 / 01 / 01 00 : 00 : 00

End: 2011 / 01 / 01 01 : 00 : 00

Now Copy

**Scheduled print stop time**

**Scheduled print start time**

Set the scheduled start and stop times (Year/month/day, 00 hours : 00 minutes : 00 seconds to 23 hours : 59 minutes : 59 seconds).

Sets the scheduled print start time to the current time

Copies the scheduled print start time to the scheduled print stop time

### Integration-Synchronized Print Mode

**Auto Print Settings**

Print Mode: **Integ Sync** — Set Print Mode to Integ Sync.

Print Interval: — Set the print interval ► “Interval Print Mode” on the previous page

Print at Start: **ON** — Select whether to print the data at print start

### Event-Synchronized Print Mode

**Auto Print Settings**

Print Mode: **Event** — Set Print Mode to Event.

Print Count: **Infinite** — Set the print count (Infinite, 1 to 9999).

Trigger Event: **Event1** — Set the trigger event (Event 1 to Event 8).  
When measured data is updated, data is printed each time the conditions of the specified user-defined event are met.

### Printing

Press **Print** to print data according to the conditions specified in the Print Menu menu.


## 20.1 Connecting this instrument to a Network

This section explains how to connect this instrument to a network.

### Ethernet Interface Specifications

There is a 1000BASE-T port located on the rear panel of the instrument.

Item	Specifications
Ports	1
Electrical and mechanical specifications	IEEE802.3
Transmission system	Ethernet (1000BASE-T, 100BASE-TX, 10BASE-T)
Communication protocol	TCP/IP
Supported services	FTP server, DHCP, DNS, remote control (VXI-11), SNMP, FTP client, Modbus/TCP server, and Web server
Connector type	RJ-45 connector



### Items Required to Connect this instrument to a Network

#### Cable


Use one of the following types of network cables that supports the data rate of your network.

- A UTP (Unshielded Twisted-Pair) cable
- An STP (Shielded Twisted-Pair) cable

### Connection Procedure


#### To Connect to a PC over a Network

1. Turn off this instrument.
2. Connect one end of a UTP (or STP) cable to the ETHERNET 1000BASE-T port on the rear panel.
3. Connect the other end of the UTP (or STP) cable to a hub or router.
4. Turn on this instrument.



#### To Connect to a PC through a Hub or Router

1. Turn off this instrument and the PC.
2. Connect one end of a UTP (or STP) cable to the ETHERNET 1000BASE-T port on the rear panel.
3. Connect the other end of the UTP (or STP) cable to a hub or router.
4. Connect the PC to the hub or router in the same way.
5. Turn on this instrument.



#### Note

- Use a hub or router that supports the data rate of your network.
  - When you connect a PC to this instrument through a hub or router, the PC must be equipped with an auto switching 1000BASE-T/100BASE-TX/10BASE-T network card.
  - Do not connect this instrument to a PC directly. Direct communication without a hub or router is not guaranteed to work.
-



## 20.2 Configuring TCP/IP Settings

This section explains the following TCP/IP settings for connecting this instrument to a network:

- DHCP  
IP address, subnet mask, and default gateway
- DNS  
Domain name, DNS server IP address, and domain suffix

► “TCP/IP (TCP/IP)” in the features guide

### Configuring TCP/IP Settings (TCP/IP)

Press **UTILITY**, the **Network** soft key, and then the **TCP/IP** soft key to display the following screen.

**Set the DHCP (OFF, ON).**

The screenshot shows a 'Network' configuration window. At the top, it says 'Set the DHCP (OFF, ON)'. Below this, there's a 'DHCP' section with a toggle switch set to 'ON'. Underneath, there are four input fields for 'IP Address' (0.0.0.0), 'Net Mask' (255.255.255.255), and 'Gate Way' (0.0.0.0). Below these is a 'DNS' section with a toggle switch set to 'OFF'. Underneath, there are four input fields for 'Domain Name', 'DNS Server1' (0.0.0.0), 'DNS Server2' (0.0.0.0), 'Domain Suffix1', and 'Domain Suffix2'. At the bottom right, there is a 'Bind' button. The bottom of the screen shows a row of soft keys: 'TCP/IP', 'ET/ Web Server', 'Net Drive', and 'SNTP'.

**Set these when DHCP is set to OFF.**

- IP address
- Subnet mask
- Default gateway

**These are displayed when DNS is set to ON or Auto.**

- Domain name
- DNS server IP address (1: primary, 2: secondary)
- Domain suffix (1: primary, 2: secondary)

**Applies the settings**

**Set the DNS (OFF, ON, Auto).**

- OFF: The DNS is disabled.
- ON: The DNS is enabled. Set the domain name, and the DNS server's primary and secondary IP addresses and domain suffixes.
- Auto: The DNS is enabled. Set the domain suffixes. The domain name and the DNS server IP addresses are set automatically. The Auto option is only displayed when DHCP is set to ON.

## 20.3 Accessing this instrument from a PC (FTP Server)

This section explains the following settings for accessing this instrument from a PC on a network:

- User name
- Password
- Timeout
- FTP client software

► “FTP Server (FTP Server)” in the features guide

### Configuring FTP Server Settings (FTP/Web Server)

Press **UTILITY**, the **Network** soft key, and then the **FT/WebP Server** soft key to display the following menu.

The screenshot shows a menu titled "Network" with the following fields and buttons:

- User Name:** A text field containing "anonymous". A callout points to this field with the text: "Set the user name (up to 32 characters)."
- Password:** A text field. A callout points to this field with the text: "Set the password (up to 32 characters)."
- Time Out(sec):** A text field containing "900". A callout points to this field with the text: "Set the timeout value (30 to 3600 s)."
- Entry:** A button. A callout points to this button with the text: "Applies the settings"

At the bottom of the menu, there are four soft keys: "TCP/IP", "FTP/Web Server", "Net Drive", and "SNTP". The "FTP/Web Server" key is highlighted.

### FTP Client Software

Start an FTP client on a PC.

Enter the user name and password that you entered on the screen shown above to connect to this instrument.

#### **Note**

If you set the user name to "anonymous," you can access this instrument without entering a password.

## 20.4 Monitoring the display of this instrument from a PC (Web Server)

This section explains the following settings for accessing this instrument from a PC over a network to show the instrument's display on the PC and remotely controlling the instrument from the PC.

- User name
- Password
- Connecting to the DLM4000 from a PC

► [“Web Server \(Web Server\)” in the features guide](#)

### Configuring Web Server Settings (FTP/Web Server)

Press **UTILITY**, the **Network** soft key, and then the **FTP/Web Server** soft key to display the following menu.

The screenshot shows a 'Network' menu with the following fields and controls:

- User Name:** A text field containing 'anonymous'. A callout points to it with the text: 'Set the user name (up to 32 characters).'
- Password:** A text field. A callout points to it with the text: 'Set the password (up to 32 characters).'
- Time Out(sec):** A text field containing '900'.
- Entry:** A button. A callout points to it with the text: 'Applies the settings'.

At the bottom of the menu, there are four tabs: 'TCP/IP', 'FTP/Web Server' (which is selected), 'Net Drive', and 'SNTP'.

#### Note

Time Out is a setting used by the FTP server feature. It is not necessary for the Web server feature.

## Connecting to this instrument from a PC


1. Open a Web browser\* on a PC that is connected to the network.  
\* Recommended browser: Internet Explorer 9.0 or later
2. Enter the following address.  
http://xxx.xxx.xxx.xxx/  
(Type the IP address of this instrument for xxx.xxx.xxx.xxx.)
3. Enter the user name and password that you set on the network setup screen of this instrument, which is shown on the previous page, and connect to this instrument.  
The following screen appears.

### Note

If you set the user name to "anonymous," you can access this instrument without entering a password.


## Home Screen

Information about the instrument is displayed.

YOKOGAWA  Precision Power Analyzer WT1800E Series		© Copyright 2016 Yokogawa Meters & Instruments Corporation
Home	Control	
Instrument Model	WT1806E	Precision Making
Manufacturer	Yokogawa Meters & Instruments Corporation	
Serial Number	XXXXXXXX	
Description	Precision Power Analyzer WT1800E Series	
Host Name	XXX.XXX.XXX.XXX	
MAC Address	00:00:64:XX:XX:XX	
TCP/IP Address	XXX.XXX.XXX.XXX	
Firmware Revision	3.01	
VISA resource string	TCP/IP::XXX.XXX.XXX.XXX::inst0::INSTRs	

## Control Screen

4. Click the Control tab.  
The following screen appears.



**Resolution** LOW

**Refresh screen button**

**Message**


**Set the screen refresh interval.**  
Set in the range of 5 to 60 s.

**Auto refresh start/stop button**

**Set the resolution.**  
Select LOW (512×384) or HIGH (1024×768).

## Links Screen

5. Click the Link tab.  
The following screen appears.



## 20.5 Connecting to a Network Drive

This section explains the following settings for saving and loading various data of this instrument from a network drive (FTP server):

- FTP server (file server)
- Login name
- Password
- Turning FTP passive mode on and off
- Timeout
- Connecting to and disconnecting from a network drive

► [“Network Drive \(Net Drive\)” in the features guide](#)

### Configuring Network Drive (Net Drive) Settings and Connecting to It

Press **UTILITY**, the **Network** soft key, and then the **Net Drive** soft key to display the following menu.

The screenshot shows a menu titled "Network" with the following settings and controls:

Setting	Value	Description
FTP Server	[Empty text box]	Set the FTP server's host name.
Login Name	anonymous	Set the login name (up to 32 characters).
Password	[Empty text box]	Set the password (up to 32 characters).
FTP Passive	OFF ON	Turns FTP passive mode on and off
Time Out(sec)	15	Set the timeout value (1 to 3600 s).
[Connect] [Disconnect]		Disconnects this instrument from the network drive (FTP server) Connects this instrument to the network drive (FTP server)

At the bottom of the screen, there are four soft keys: TCP/IP, FTP/Web Server, Net Drive, and SNTP. The "Net Drive" key is highlighted.

## 20.6 Using SNTP to Set the Date and Time

This section explains how to use SNTP to set the date and time of this instrument.

- SNTP server
- Timeout
- Turning automatic adjustment on and off
- Time difference from Greenwich Mean Time (setting shared with the date and time on the System Config menu)
- Time adjustment

► [“SNTP \(SNTP\)” in the features guide](#)

### Configuring SNTP Settings (SNTP)

Press **UTILITY**, the **Network** soft key, and then the **SNTP** soft key to display the following menu.

The screenshot shows the 'Network' menu with the 'SNTP' sub-menu selected. The settings are as follows:

Setting	Value
SNTP Server	[Empty text box]
Time Out(sec)	3
Adjust at Power On	OFF
Time Difference From GMT	Hour: 9, Minute: 0
Adjust	[Button]

Annotations on the right side of the screen:

- Configure the SNTP server settings (IP address; host name and domain name can be set when DNS is enabled).
- Set the timeout value (1 to 60 s).
- Turns automatic adjustment on and off
- Set the time difference from Greenwich Mean Time (-12 hours and 0 minutes to 13 hours and 0 minutes).
- Executes time adjustment

At the bottom of the screen, there are tabs for 'TCP/IP', 'FTP/Web Server', 'Net Drive', and 'SNTP'.

## 21.1 Viewing System Information (Overview)

This section explains how to view system information of this instrument.

► [“Overview \(System Overview\)” in the features guide](#)

### System Information List (System Overview)

Press **UTILITY** and then the **System Overview** soft key to display the following screen.

System Overview

Model : WT1806E

Suffix : -5A3-50A3-HE-D/EX6/B5/G6/Y1/DA/AUX/PD

No. : 123456789 (MAC:000054-9432\_0006)

Version : 3.01 (PMB:0.05,C10:0.09,GDC:0.51,WATT:1.01,HRM:0.30)

-Element Configuration-

Element	Type	Calibration Date	Status
Element 1:	1000V-5A	2015/10/23 02:52:40	OK OK
Element 2:	1000V-5A	2015/10/23 02:52:40	OK OK
Element 3:	1000V-5A	2015/10/23 02:52:40	OK OK
Element 4:	1000V-50A	2015/10/23 02:53:50	OK OK
Element 5:	1000V-50A	2015/10/23 02:53:50	OK OK
Element 6:	1000V-50A	2015/10/23 02:53:50	OK OK

-Options-

Ext Sensor Input [/EX6]:Yes

Built-in Printer [/B5]:Yes

2ch Harmonic Measure[/G6]:Yes

Delta Computation :Yes

Add-on Freq Measure :Yes

RGB Output [/Y1]:Yes

20Ch DA Outputs [/DA]:Yes 2015/10/23 02:58:44 OK OK

Auxiliary Input [/AUX]:Yes 2015/10/23 02:55:50 OK OK

High Speed Capturing :Yes

6ch Sensor Power [/PD]:Yes

Link Date : Jun 22 2016 14:22:49

Product ID: ESP00000000

### Displayed Contents

Model	Model
Suffix	Suffix code
No.	Instrument number
Version	Firmware version
Element Configuration	Input element types
Options	Options
Link Date	Date and time that the firmware was created
Product ID	Unique number assigned to each instrument (necessary for the purchase of additional options)




## 21.2 Initializing Settings

This section explains how to initialize this instrument settings to their factory default values.

► [“Initializing Settings \(Initialize Settings\)” in the features guide](#)

### Utility Menu

Press **UTILITY** to display the following menu.



### Note

Only initialize this instrument if you are sure that it is okay for all of the settings to be returned to their initial values. You cannot undo an initialization. We recommend that you save the setup parameters before you initialize this instrument.


## 21.3 Setting the Message, Menu, and USB Keyboard Languages

This section explains the settings that you can use to change the message, menu, and USB keyboard languages.

► “Language (Language)” and “USB Keyboard Language (USB Keyboard)”  
in the features guide


### System Config Menu

Press **UTILITY** and then the **System Config** soft key to display the following menu.



### Configuring the Language Settings

Press the **Language** soft key to display the following menu.



#### Note

Even if you set the menu or message language to a language other than English, some terms will be displayed in English.


## 21.4 Setting the Screen Brightness and Configuring the Display Color Settings

This section explains how to set the screen brightness and configure the display color settings.

► [“Adjusting the LCD \(LCD\)” in the features guide](#)


### LCD Menu

Press **UTILITY**, the **System Config** soft key, and then the **LCD** soft key to display the following menu.



### Configuring the Display Color Settings

Press the **Color Settings** soft key to display the following menu.



## 21.5 Configuring the Environment Settings

This section explains the following environment settings:

- Number of digits of numeric data to display
- Frequency display value when the measured frequency is less than the lower limit
- Motor display value (/MTR option) when the measured pulse frequency is less than the lower limit
- Decimal point and separator to use when data is saved in ASCII format (.CSV)
- Integration resume action at power failure recovery
- Menu font size
- Rounding to zero

► [“Environment Settings \(Preference\)” in the features guide](#)

### Preference Menu

Press **UTILITY**, the **System Config** soft key, and then the **Preference** soft key to display the following menu.

Preference	
Resolution 5digits	Set the number of digits of numeric data to display (4digits, 5digits).
Freq Display at Frequency Low 0 Error	Set the frequency display value when the measured frequency is less than the lower limit (0, Error).
Motor Display at Pulse Freq Low 0 Error	On models with the /MTR option, set the motor display value when the measured pulse frequency is less than the lower limit (0, Error).
Decimal Point for CSV File Period Comma	Set the decimal point and separator to use when data is saved in ASCII format as a .CSV file (Period, Comma).
Integration Resume Action Start Stop Error	Set the integration resume action at power failure recovery (Start, Stop, Error).
Menu Font Size Small Large	Set the menu font size (Small, Large).
Rounding to Zero OFF ON	Turns rounding to zero on and off

## 21.6 Configuring D/A Output Items (Option)

This section explains the following settings for D/A output. This feature is available on models with the /DA option.

- Measurement function
- Element and wiring unit
- Harmonic order
- D/A output range
  - Range mode, range maximum, and range minimum

► “D/A Output (D/A Output Items; option)” in the features guide

### Configuring D/A Output Items

Press **UTILITY** and then the **D/A Output Items** soft key to display the following screen.

#### D/A output signal name

For details on the connector pinout and the D/A output signal assignment, see section 4.6 in the getting started guide, IM WT1801E-03EN.

#### Output item

This display changes according to the Function, Element/ $\Sigma$ , and Order settings.

#### Set the measurement function

(None, other functions—for details on the various measurement functions, see “Items That This Instrument Can Measure” in the features guide).

Set the element and wiring unit (Element 1 to Element 6,  $\Sigma A$  to  $\Sigma C$ ).

Set the harmonic order (Total, 0 to 500; /G5 or /G6 option).

You can set this setting when the measurement function includes a harmonic order.

D/A Output Items							
Ch	Item	Function	Element/ $\Sigma$	Order	Range Mode	Max	Min
1	Urms1	Urms	Element 1	–	Manual	100.0	–100.0
2	Irms1	Irms	Element 1	–	Fixed	–	–
3	P1	P	Element 1	–	Fixed	–	–
4	S1	S	Element 1	–	Fixed	–	–
5	Q1	Q	Element 1	–	Fixed	–	–
6	$\lambda 1$	$\lambda$	Element 1	–	Fixed	–	–
7	$\phi 1$	$\phi$	Element 1	–	Fixed	–	–
8	fU1	FreqU	Element 1	–	Fixed	–	–
9	fI1	FreqI	Element 1	–	Fixed	–	–
10	Urms1	Urms	Element 1	–	Fixed	–	–
11	Urms1	Urms	Element 1	–	Fixed	–	–
12	Urms1	Urms	Element 1	–	Fixed	–	–
13	Urms1	Urms	Element 1	–	Fixed	–	–
14	Urms1	Urms	Element 1	–	Fixed	–	–
15	Urms1	Urms	Element 1	–	Fixed	–	–
16	Urms1	Urms	Element 1	–	Fixed	–	–
17	Urms1	Urms	Element 1	–	Fixed	–	–
18	Urms1	Urms	Element 1	–	Fixed	–	–
19	Urms1	Urms	Element 1	–	Fixed	–	–
20	Urms1	Urms	Element 1	–	Fixed	–	–

Select the mode of the D/A output range (Fix, Manual).

Set the maximum and minimum values of the range (–9.999 T to 9.999 T).

These settings can be set when Range Mode is set to Manual.

## 21.7 Carrying Out Self-Tests (Selftest)

This section explains the following settings for testing whether the memory and keys of this instrument are functioning properly:

- Test item
    - Memory test
    - Key test
- Operation keys, indicators, and keyboard

► [“Self-Test \(Selftest\)” in the features guide](#)

### Selftest Menu


Press **UTILITY** and then the **Selftest** soft key to display the following menu.

Selftest	
Test Item	
Memory	Set the item to test (Memory, Key Board).
Test Exec	

### Executing the Memory Test

Selftest	
Test Item	
Memory	Set the item to test to Memory.
Test Exec	Executes the test

Executing the Key Test



---

## 21.8 Performing Zero-Level Compensation

This section explains how to perform zero-level compensation.

► [“Zero-Level Compensation \(CAL\)” in the features guide](#)

Press **SHIFT+SINGLE** (CAL) to execute zero-level compensation.

---

### **Note**

- This instrument automatically performs zero-level compensation after you change the measurement range or input filter.
  - To make accurate measurements, we recommend that you execute zero-level compensation after warming up the instrument for at least 30 minutes.
  - If the measurement range and input filter remain the same for a long period of time, the zero level may change due to the changes in the environment. If this happens, we recommend that you execute zero-level compensation.
  - The integration feature includes an auto calibration feature that automatically performs zero-level compensation.
-



## 21.9 Using the NULL Feature

This section explains the following settings for the NULL feature:

- NULL feature setup method
- All the signals of a given signal type or the selected signals
- Enabling and disabling the NULL feature

► “NULL Feature (NULL SET)” in the features guide

### Configuring NULL Feature Settings

Press **SHIFT+NULL** (NULL SET) to display the following screen.

**Select the setup method of the NULL feature (All, Select).**  
If you select All, the NULL feature is turned on for all the input signals that you can use this screen to set.

**Set the state of the NULL feature for all the signals of a given signal type (ON, Hold, OFF).**

- For the voltage signals of the installed input elements
- For the current signals of the installed input elements
- For motor evaluation input signals
- For external signals

**Set the state of the NULL feature for each signal (ON, Hold, OFF).**

The motor evaluation input signal setup screen is displayed on models with the /MTR option.

The external signal setup screen is displayed on models with the /AUX option.

### Enabling and Disabling the NULL Feature

Press **NULL** to illuminate the NULL key and enable the NULL feature.

- The NULL value for each signal is used for those signals that have been configured to use the NULL feature.
- Press **NULL** again to turn the NULL key off and disable the NULL feature.

---

## 21.10 Locking the Keys

This section explains how to lock the panel keys, which prevents you from unintentionally changing the current state of this instrument.

► [“Key Lock \(KEY LOCK\)” in the features guide](#)

### Key Lock (KEY LOCK)

Press **SHIFT+LOCAL** (KEY LOCK). “LOCK” is displayed in the upper right of the screen, and the operation keys are locked.

- The key lock disables all keys of this instrument except for the power switch, SHIFT key, and LOCAL key.
- Press **SHIFT+LOCAL** (KEY LOCK) again to release the key lock.

---

#### **Note**

When the keys are locked, you cannot use a USB mouse or keyboard to operate this instrument either.

---

# Appendix 1 Messages and Corrective Actions

## Messages

Error messages may appear on the screen while you are using this instrument. This section describes the error messages and how to respond to them. You can display the messages in the language that you specify through the operations explained in section 21.3. If servicing is necessary to solve the problem indicated by a message, contact your nearest YOKOGAWA dealer.

In addition to the following error messages, there are also communication error messages. These messages are explained in the communication interface user's manual, IM WT1801E-17EN.

## Warning Messages (1 to 99)

Code	Message	Chapter or Section
3	Turned on pressing the RESET key. The system has been initialized.	3.6 <sup>1</sup>
11	Cannot measure PLL frequency. Check input level.	2.1
12	File access slow. Too many files in directory or medium read/write speed slow.	17.6
64	File access is aborted.	—
80	System Configuration was changed. The system has been initialized.	—
84	Key lock is enabled. To release the lock, press the KEY LOCK (SHIFT+LOCAL) key.	21.10
85	In remote control mode, all keys are locked except LOCAL key. Please hit LOCAL key to exit the remote control mode.	Chapters 1 to 3 <sup>2</sup>
86	In Local Lockout mode, all keys are locked. Please cancel the local lockout.	Chapters 1 to 3 <sup>2</sup>
87	Firmware was changed. The system has been initialized.	—
88	Integration has started and measurement ranges of the MOTOR/AUX are switched to fixed ranges. Even if the Data Update Interval setting is Auto, Voltage/Current measurement range are also switched to fixed ranges.	1.2 and 1.15
89	Processing system settings change. Please wait for a moment.	—
90	This model has no external current sensor. Check the specifications to see whether or not the optional external current sensor is provided.	21.1
91	This model has no built-in printer. Check the specifications to see whether or not the optional built-in printer is provided.	21.1
92	This model has no harmonics measurement. Check the specifications to see whether or not the optional harmonics measurement is provided.	21.1
93	This model has neither motor evaluation function or auxiliary input. Check the specifications to see whether or not the optional motor evaluation function and the optional auxiliary input are provided.	21.1
95	Be careful not to exceed a current supply limit value to use the power supply for a current sensor.	2.11 <sup>1</sup>
96	If the S or Q computation is set to type 1 or 2, the following is applied to elements with the rectifier set to on. <ul style="list-style-type: none"> <li>• <math>\Phi</math> is fixed to lag (G). Displayed in the range of 0 to 180°(360 degrees format).</li> <li>• The sign of Q is fixed to positive. For QΣ that includes elements with the rectifier set to on, type 2 is used.</li> </ul>	Chapter 7
97	There are measure conditions which make sigma functions unmeasurable. All or part of sigma functions will not be measured.	1.1 and 15.1
98	External Sync interval has gone out of range. Check External Sync (MEAS START) input.	4.4 <sup>1</sup>

1 Getting started guide, IM WT1801E-03EN

2 Communication interface user's manual, IM WT1801E-17EN

## Setup Error Messages (500 to 899)

Code	Message	Chapter or Section
600	File access failure.	—
601	Invalid file name. Check the file name.	17.2
602, 603	No USB device or no storage media inserted. Check the USB device connection, and the existence of a storage medium in the drive.	17.1
604	Media failure. Check the storage medium.	17.1
605	File not found. Check the filename and the storage medium.	—
606	Media is protected. Set the disk's(medium's) write protect switch to OFF.	—
607	Media was removed while accessing. Check the storage medium.	17.1
608, 609	File already exists.	—
610	Contains invalid characters.	17.2
611, 612	Media full. Delete unnecessary file(s) or use another disk.	17.6
613	Cannot delete a directory if there are files in the directory.	17.6
614	File is protected.	—
615	Physical format error. Reformat the medium. If the same error occurs, the instrument is probably unable to execute a format on this medium.	—
616 to 620, 622 to 641	File system failure. Check using another disk. If the same message still appears, maintenance service is required.	—
621	File is damaged. Check the file.	—
643 to 653	Media failure. Check the medium.	—
657	File operation is interrupted.	—
658	File unknown format. Check the file format.	17.5 and 17.6
662	Cannot load this bitmap file. Use file of 16bit Color or 24bit Color Mode with less or equal size 800x672.	6.7
663	Cannot load this text file. Confirm the contents of file.	6.7
665	Cannot load this file format. File was stored on other models or other versions.	—
666	File is now being accessed. Execute after access is made.	—
675	Cannot load this file. Model/options do not conform.	—
676	Writing prohibited in this file.	—
677	An error occurred while network access. Confirm network conditions.	Chapter 20
679	Printer error. Maintenance service is required.	—
680	Close the printer cover.	19.1
681	Paper empty. Load a roll chart.	19.1
682	The printer head temperature is abnormality. Printing will be aborted. Printing will not be possible until the printe head temperature comes normal.	—
683	Printer over heat. Power off immediately.	—
685	Printer time out. Maintenance service is required.	—
686	Printer error.	—
690	Cannot execute for the directory depth is 10 or more.	—
691	Cannot execute because of source and destination are overrapped.	—

Code	Message	Chapter or Section
692	Cannot execute for the media itself.	—
693	Cannot store at Network Drive.	16.3
694	Trigger Event is Off.	7.2
695	File version is new. Update firmware.	—
696	The file may be damaged or an unsuccessful file close could have occurred.	—
697	Abnormal data file. Unsuccessful finish of file save is detected.	—
705	Can not operate while accessing medium. Wait until access has completed.	—
706	Can not operate during hard copy. Wait until output has completed.	—
711	File operation not allowed during hard copy. Wait until the hard copy completes.	—
713	Cannot execute for All or Custom display mode.	—
720	Over Run had occurred.	—
721	Can not set or execute because store is processing. Try Again.	—
722	No target Element for integration execution.	8.1
723	Can not set or execute when Integ Independent Control is on.	8.1
724	Can not set or execute because recording is processing. Try again.	—
725	File creation stopped. File size exceeded 2G bytes.	—
750, 751	Unable to connect to the server. Check the network settings and configuration.	Chapter 20
752	This ftp function is not supported.	—
753	FTP Error: Client Handle Confirm the network settings and connection.	Chapter 20
758	Failed to acquire time from SNTP server. Confirm the network settings and connection.	20.5
759	Failed to initialize network. Confirm the network settings.	Chapter 20
800	Illegal date-time. Set the correct date and time.	3.5*
801	Illegal file name. The file name contains characters which are not allowed or the file name is not a valid MS-DOS file name. Enter another file name.	17.2
802	Cannot be set or executed in the Normal measurement mode. Usable measurement mode are as follows.	—
811	Cannot be set to this display mode. Harmonics option is necessary.	—
812	Cannot be set or executed while storing data.	—
813	Cannot be set while integration is running. Reset Integration.	8.3
814	Cannot be set or executed when NULL is on. Please turn NULL off.	21.9
815	Cannot be set or executed when the Data Update Interval is Auto.	1.15
823	Cannot change during CAL. Wait until CAL is completed.	21.8
827	Illegal math expression. Input a correct computing equation.	8.1
831	Processing now. Retry setting or execution again.	—
841	Attempted to start integration after integration time has reached its preset value.	8.3
842	Attempted to start integration while integration is in progress.	8.3
843	Measurement stopped due to overflow during integration or due to a power failure.	8.3
844	Attempted to stop integration even though integration was not in progress.	8.3
845	Attempted to reset integration even though integration was in progress or integration mode was not selected.	8.3
846	Attempted to start integration while measurement of peak overflow was in progress.	—
847	Attempted to start integration in continuous integration mode when integration preset time was set to "0".	8.2
848	Attempted made to start integration in real time counting integration mode when the end time had already passed.	8.2
849	Attempted made to start storing in real time counting storing mode when the end time had already passed.	16.1

\* Getting started guide, IM WT1801E-03EN

## Appendix 1 Messages and Corrective Actions

Code	Message	Chapter or Section
850	Cannot be set or executed at current store state. To set or execute, reset store.	16.4
852	Stored file is illegal. Initialize memory before storing.	16.4
854	Waveform display data not found.	—
855	Data destination memory is full. Saving has been stopped.	—
856	An error has occurred while storing. Storing has been stopped.	—
857	Cannot be set while Master/Slave Synchronized Measurement is set to Slave.	7.6
858	Store process is in progress now. Execute or set setting again.	—
859	Cannot convert selected file. Select a file with an extension of WTS or HDS.	16.3
862	Numeric data not found.	—
863	Cannot be set or executed when different types of elements are installed.	—
864	This wiring cannot be set as the first selected element.	1.1
865	Cannot be set while integration is running. Stop or reset Integration.	8.3
866	Cannot be set or executed while Auto Print is operating. Turn off Auto Print from the [PRINT MENU] (SHIFT+PRINT) menu.	19.2
867	Auto Print is not in operation. Start Auto Print from the [PRINT MENU] (SHIFT+PRINT).	19.2
868	Print out destination must be set to Built-in Printer in order to start Auto Print. Set [Print to] to Built-in from the [PRINT MENU] (SHIFT+PRINT) menu.	19.2
869	Auto Print function is not supported in the current measurement mode or settings.	19.2
870	Auto Print [Interval] setting is invalid. Set [Interval] time to an appropriate amount from the [PRINT MENU](SHIFT+PRINT) ->[Auto Print Settings] menu.	19.2
871	Attempted made to start Auto Print when the end time had already passed. Set [End Time] to a future date & time from the [PRINT MENU](SHIFT+PRINT) ->[Auto Print Settings] menu.	19.2
872	Auto print's print-out has been canceled. The printer or file system is in action.	19.2
874	Sync source, PLL source or trigger source cannot be set to Ext Clk, while Master/Slave Synchronization Measurement is set to Slave.	7.6
875	Master/Slave Synchronization Measurement cannot be set to Slave, while sync source, PLL source or trigger source is set to Ext Clk.	7.6
876	Can not calculate from present point value.	3.1 or 4.1
877	Can not set 0 to count.	15.1 or 16.1
879	Can not set or execute while recording high speed data. Stop measurement and wait for file status "Ready".	15.4
880	Cannot be set or executed while initialization. Wait until status changes to "Ready".	15.4
881	Cannot be set or executed while measurement is in progress. To set or execute, "Stop" measurement.	15.4
882	Stopped measurement. Detection error of measuring interval signal. Check External Sync (MEAS START) input.	4.4*
883	Cannot be set or executed in High Speed Data Capturing Mode.	—
884	Can not set wiring to 1P3W/3P3W in High Speed Data Capturing Mode. Select a different wiring.	1.1
885	Cannot be set or executed in High Speed Data Capturing Mode. Set or execute in Normal Measurement Mode.	Appendix 10*
886	Cannot be set or executed to same current ranges, due to different types of elements are installed or external current sensor settings are not same.	1.3
887	Cannot start integration. Turn off Independent Element setting by the [WIRING] menu, or switch the measurement ranges to fixed ranges.	1.1
888	Cannot start the integration. Turn off Independent control by the [INTEG] menu or turn off Auto of the Data Update Interval by the [UPDATE RATE] menu.	8.1 or 1.15
889	Setting and execution is not available when auto-ranging is set to ON.	1.2

\* Getting started guide, IM WT1801E-03EN

Code	Message	Chapter or Section
890	Cannot start the store. Change store mode from synchronize with integration or set store interval to zero by the [STORE SET] menu. Otherwise, turn off Auto of the Data Update Interval by the [UPDATE RATE] menu.	16.1 or 1.15
891	Cannot start the auto print. Change print mode from synchronize with integration by the [STORE SET] menu. Otherwise, turn off Auto of the Data Update Interval by the [UPDATE RATE] menu.	19.2 or 1.15
892	Cannot start the integration. Set S and Q Formula to another expecting for Type 3 by the [MEASURE] menu, or fix measurement ranges.	7.3, 1.2, or 1.3

## System Error Messages (900 to 999)

Code	Message	Chapter or Section
901	Failed to backup setup data. The system has been initialized. Maintenance service is required.	—
902	System RAM failure. Maintenance service is required.	—
903	System ROM failure. Maintenance service is required.	—
905	System failure. Install the input modules and the options correctly.	—
906	Fan stopped. Power off immediately. Maintenance service is required.	—
907	Backup battery is flat. Maintenance service is required to replace the back-up battery.	—
909	Illegal SUM value. Maintenance service is required.	—
910	This operation is prohibited for EEPROM protection.	—
915	EEPROM SUM error. EEPROM may be damaged. Maintenance service is required.	—
919	Module installation condition and setup parameters do not match. The system has been initialized. Maintenance service is required.	—
920	SUM error of NULL value. The Null value is reset to 0.	—
921	System Failed to Draw Display. Maintenance service is required.	—
922	Failed in communication with devices. Maintenance service is required.	—
923	Transmit data abnormality from devices. Maintenance service is required.	—
926	The USB device's power consumption exceeded the capacity of the USB hub.	—
927	Disconnected USB device port 1, because overcurrent was detected.	—
928	Disconnected USB device port 2, because overcurrent was detected.	—
929	A USB mass storage device that is greater than 137 GB in capacity has been connected. Be careful in using this device. If an area exceeding 137 GB is accessed, the storage device may break.	—
931	Hardware configuration error occurred. Restart this machine. If it occurred again, maintenance service is required.	—
932	Error occurred while ImageFile process.	—

# Index

## Symbols

	Page
4, 8, and 16 Items displays .....	6-4
1000BASE-T port .....	20-1

## A

	Page
A and B computation, auxiliary input .....	4-1
A and B computation, motor evaluation .....	3-2
All Items display .....	6-9
analog input, motor evaluation .....	3-1
AND .....	7-2
apparent power equation .....	7-3
applicable standards, corrected power .....	7-3
auto calibration .....	8-2
AUTO key, current range .....	1-3
AUTO key, voltage range .....	1-2
automatic CSV conversion, high speed data capturing .....	15-4
automatic CSV conversion, storage .....	16-5
auto naming .....	17-4
auto off .....	21-4
auto print .....	19-6
auxiliary input .....	4-1
averaging .....	1-20
AVG key .....	1-20

## B

	Page
background .....	6-12
background color, screen .....	21-4
backlight .....	21-4
bar graph display .....	11-1
built-in printer .....	19-1

## C

	Page
cable, network .....	20-1
capture control .....	15-1
capturing count .....	15-1
character strings, entering .....	vi
color, screen .....	21-4
color, screen image .....	18-1
column, high speed data capturing .....	15-6
column, matrix display .....	6-6
comment .....	17-4
common name, files .....	17-4
compensation, zero-level .....	21-9
CONFIG (DIRECT/MEASURE) key .....	1-6
CONFIG key, current range .....	1-10
CONFIG key, voltage range .....	1-9
connection procedure, network .....	20-2
conventions used in this manual .....	iii
corrected power .....	7-3
crest factor .....	1-15
CT ratio .....	1-8
current integration .....	8-4
current, measurement mode of high speed data capturing ..	15-1
current mode, current integration .....	8-4
current range .....	1-3
cursor keys, operating .....	v
cursor measurement, bar graph .....	14-3
cursor measurement, trend .....	14-2
cursor measurement, waveform .....	14-1
custom display .....	6-12
customizing .....	6-12

cutoff frequency, high speed data capturing .....	15-1
cutoff frequency, normal measurement .....	1-17

## D

	Page
D/A output .....	21-6
D/A output, rated time .....	8-4
data, storing .....	16-1
data update count .....	5-1
data update interval .....	1-19
decimal point .....	21-5
delete, files .....	17-12
delta computation .....	1-14
DHCP .....	20-3
display brightness .....	21-4
display, changing high speed data capturing .....	15-6
display, changing the 4, 8, and 16 Items displays .....	6-4
display, changing the All Items display .....	6-9
display, changing the matrix display .....	6-6
display color, screen .....	21-4
display configuration .....	6-12
displayed harmonic orders .....	11-1
displayed page, switching .....	6-2
display format, bar graph .....	11-1
display format, external current sensor range .....	1-6
display format, files .....	17-10
display format, numeric data .....	6-1
display format, phase difference .....	7-5
display format, trend .....	10-1
display format, vector .....	12-1
display format, waveform .....	9-1
display frame .....	6-4, 6-6, 6-9, 6-10, 15-6
display, harmonics list .....	6-10
display interpolation .....	9-2, 10-2
display position .....	6-12
distortion factor equation .....	2-1
divisions, bar graph screen .....	11-1
divisions, trend screen .....	10-1
divisions, vector screen .....	12-1
divisions, waveform screen .....	9-1
DNS .....	20-3

## E

	Page
efficiency equation .....	1-12
electrical angle .....	3-1
electrical angle correction .....	3-2
ELEMENT (ALL) key, numeric data .....	6-5, 6-11
ELEMENT (ALL) key, range .....	1-2, 1-3, 1-4, 1-6
ELEMENT key, numeric data .....	6-5, 6-8, 6-11, 15-8
ELEMENT key, range .....	1-2, 1-3, 1-4, 1-6
environment settings .....	21-5
error message .....	App-2
ESC key, operating .....	iv
ethernet communication .....	20-1
event .....	7-2
event-synchronized printing .....	19-7
event-synchronized storage .....	16-3
expression .....	7-1, 7-3
extension .....	17-11
external current sensor conversion ratio .....	1-5
external current sensor range .....	1-4
external VT/CT .....	1-7
EXT SENSOR key .....	1-4, 1-6
EXT SENSOR (SENSOR RATIO) key .....	1-5



## Index

<b>F</b>	<b>Page</b>
feeding paper.....	19-4
file format, screen image .....	18-1
FILE key .....	17-3, 17-5, 17-6, 17-8, 17-15
file list.....	17-9
file name .....	17-4
file operation .....	17-9, 17-15
files, copying.....	17-13
files, deleting.....	17-12
files, moving.....	17-14
files, renaming .....	17-12
file type .....	17-11
folders, making .....	17-13
font color.....	6-12
font size.....	6-12
font size, menu .....	21-5
FORM (CURSOR) key .....	14-1, 14-2, 14-3
FORM key .....	1-22, 6-1, 9-1, 10-1, 11-1, 12-1, 13-1, 15-1, 15-4, 15-10
frequency display value when measured frequency is less than lower limit.....	21-5
frequency filter.....	1-18
FTP server, feature this instrument .....	20-4
FTP server, network .....	20-8
FU/Fl/!et! key.....	6-5, 6-8
function select keys .....	6-5, 6-8, 6-11
<b>G</b>	<b>Page</b>
graph color.....	21-4
Greenwich Mean Time, time difference .....	20-9
grid.....	9-2, 10-2
grid brightness .....	21-4
<b>H</b>	<b>Page</b>
harmonic measurement.....	2-1
harmonics list.....	6-10
HOLD key .....	5-1, 5-2
hold, measured value .....	5-1
HRM SET key .....	2-1
HS filter .....	15-1
<b>I</b>	<b>Page</b>
IMAGE SAVE key .....	18-1
IMAGE SAVE (MENU) key .....	18-1
independent input element configuration.....	1-13
independent integration.....	8-1
initialization to factory default settings.....	21-2
INPUT INFO key.....	1-22
INTEG key .....	8-1, 8-2, 8-5
integrated D/A output, rated time .....	8-4
integration, auto calibration of .....	8-2
integration condition .....	8-2
integration mode.....	8-2
integration, scheduled times for.....	8-3
integration; starting, stopping, resetting.....	8-5
integration-synchronized printing.....	19-7
integration-synchronized storage .....	16-2
integration timer.....	8-2
interval printing .....	19-6
ITEM key ...	1-23, 6-4, 6-6, 6-9, 6-10, 6-12, 9-3, 10-3, 11-2, 12-2, 13-2, 15-6
<b>J</b>	<b>Page</b>
judgment condition .....	7-2

<b>K</b>	<b>Page</b>
k and K .....	iii
keyboard, operating.....	vi
key lock.....	21-11
keys, operating .....	iv
key test .....	21-8
<b>L</b>	<b>Page</b>
language.....	21-3
linear scale, auxiliary input .....	4-1
linear scale, motor evaluation.....	3-1
line filter .....	1-17
line filter, auxiliary input .....	4-1
LINE FILTER (FREQ FILTER) key .....	1-18
LINE FILTER key .....	1-17
line filter, motor evaluation.....	3-1
list number.....	6-10
LOCAL (KEY LOCK) key .....	21-11
lock .....	21-11
<b>M</b>	<b>Page</b>
manual.....	i
master and slave synchronization .....	7-6
matrix display.....	6-6
max hold.....	7-1
measured harmonic order .....	2-1
MEASURE key .....	7-1, 7-2, 7-3, 7-4, 7-5, 7-6
measurement mode, high speed data capturing .....	15-1
measurement period.....	1-16
memory access icon.....	17-1
memory test.....	21-7
menu language.....	21-3
message.....	App-1
message language .....	21-3
motor display value when measured pulse frequency is less than lower limit .....	21-5
motor efficiency .....	3-2
motor evaluation .....	3-1
movement path.....	14-1
<b>N</b>	<b>Page</b>
network connection.....	20-1
network drive .....	20-8
notes and cautions .....	iii
NULL feature .....	21-10
NULL key .....	21-10
NULL (NULL SET) key .....	21-10
number of digits to display.....	21-5
numeric data, display of high speed data capturing .....	15-6
numeric data, display of normal measurement.....	6-1
numeric data, saving .....	17-6
numeric data, saving of high speed data capturing .....	15-4
numeric data, storage.....	16-4
NUMERIC key .....	6-1
<b>O</b>	<b>Page</b>
optimization, high speed data capturing.....	15-1
optimization, storage .....	16-1
OR .....	7-2
OTHERS key .....	10-1, 11-1, 12-1, 13-1, 15-1
output items, D/A output .....	21-6
overview .....	21-1

<b>P</b>	<b>Page</b>
PAGE ▲ key.....	6-2, 6-3
PAGE ▼ key.....	6-2, 6-3
page, switching.....	6-2
phase difference.....	7-5
PLL source.....	2-1
poles, number of.....	3-1
position.....	9-3
power coefficient.....	1-8
power measurement.....	6-1
print count.....	19-6
printer roll paper.....	19-1
printing.....	19-5
printing, scheduled times for.....	19-6
print interval.....	19-6
Print key.....	19-8
PRINT (MENU) key.....	19-4, 19-5
pulse input, motor evaluation.....	3-1
<b>R</b>	<b>Page</b>
range, auxiliary input.....	4-1
range, D/A output.....	21-6
rated time.....	8-4
reactive power equation type.....	7-3
renaming, files.....	17-12
reset; 4, 8, and 16 Items displays.....	6-4
reset; high speed data capturing display.....	15-6
RESET key, operating.....	v
reset, matrix display.....	6-6
restart, storage.....	16-6
revisions.....	ii
revolution signal.....	3-1
roll paper.....	19-1
roll paper, cutting.....	19-4
roll paper, loading.....	19-2
Rounding to zero.....	21-5
<b>S</b>	<b>Page</b>
sampling frequency.....	7-4
save conditions, high speed data capturing.....	15-4
save conditions of captured data, high speed data capturing.....	15-4
save conditions of storage data.....	16-5
save conditions, storage.....	16-5
save destination.....	17-3
scale value.....	9-2, 10-2
scaling factor, auxiliary input.....	4-1
scaling factor, motor evaluation.....	3-1
scaling feature.....	1-7
SCALING key.....	1-7
SCALING (MOTOR/AUX SET) key.....	3-1, 4-1
schedule, integration.....	8-3
schedule, printing.....	19-7
schedule, storage.....	16-2
screen image, saving.....	18-1
self-tests.....	21-7
separator.....	21-5
sequence number, files.....	17-4
SET key, operating.....	v
setup dialog box values, entering.....	v
setup menus, operating.....	iv
setup parameter list, displaying.....	1-22
setup parameters, loading.....	17-8
setup parameters, saving.....	17-3
SINGLE (CAL) key.....	21-9
SINGLE key.....	5-2
single measurement.....	5-2

	<b>Index</b>
single-shot storage.....	16-3
SNTP.....	20-9
sort, files.....	17-10
split display.....	13-1
S/Q/I/Φ key.....	6-5, 6-8, 6-11
standard, corrected power.....	7-3
storage count.....	16-1
storage interval.....	16-1
storage media (drive), files.....	17-11
storage mode.....	16-1
storage, numeric data.....	16-4
storage, scheduled times for.....	16-2
storage; starting, stopping, resetting.....	16-6
STORE START key.....	16-6
STORE START (STORE SET) key.....	16-1, 16-4, 16-5
STORE STOP key.....	16-6
STORE STOP (STORE RESET) key.....	16-7
synchronization source, motor evaluation.....	3-1
synchronized measurement, high speed data capturing.....	15-1
synchronized measurement, master and slave.....	7-6
synchronous speed.....	3-1
SYNC SOURCE key.....	1-16
system information.....	21-1

<b>T</b>	<b>Page</b>
TCP/IP.....	20-3
test.....	21-7
time axis, trend.....	10-1
time axis, waveform.....	9-1
time difference.....	20-9
torque signal.....	3-1
total efficiency.....	3-2
trademarks.....	ii
trend display.....	10-1
trend label.....	10-2
trigger.....	9-1, 15-1
type A.....	17-1

<b>U</b>	<b>Page</b>
U/I MODE key.....	6-5, 6-8
U/I/P key.....	6-5, 6-8, 6-11
UPDATE RATE key.....	1-19
USB keyboard language.....	21-3
USB memory device, connecting.....	17-1
USB port.....	17-1
user-defined event.....	7-2
user-defined function.....	7-1
UTILITY key.....	1-15, 20-3, 20-6, 20-8, 20-9, 21-1, 21-2, 21-3, 21-4, 20-5, 21-5, 8-6

<b>V</b>	<b>Page</b>
valid measurement range.....	1-9
values, entering.....	vi
vector display.....	12-1
vertical position.....	9-3
vertical scale, bar graph.....	11-2
vertical scale, trend.....	10-3
vertical zoom factor.....	9-3
voltage, measurement mode of high speed data capturing.....	15-1
voltage range.....	1-2
VT ratio.....	1-7

<b>W</b>	<b>Page</b>
watt hours.....	8-1
watt hours for each polarity.....	8-3
waveform display.....	9-1
waveform display data, saving.....	17-5

**Index**

---

waveform label ..... 9-2

waveform mapping ..... 9-2

WAVE key..... 9-1, 9-3

Web Server..... 20-5

WIRING key..... 1-1, 1-12, 1-13, 1-14

wiring pattern..... 1-1

wiring system..... 1-1

wiring unit ..... 1-1

WP/q/TIME key..... 6-5, 6-8

**Z** **Page**

---

zero-level compensation..... 21-9

zoom factor, vector ..... 12-2

zoom factor, waveform ..... 9-3