
**User's
Manual**

**Voltage Fluctuation/Flicker
Measurement Software
for WT5000
(with Power Supply Control Function,
IEC 61000-3-11 Compliant)**

Harmonic/Flicker Measurement Software for WT5000 (with Power Supply Control Function) consists of the following software applications.

- IEC 61000-3-2 Harmonic Measurement Software
- IEC 61000-3-3 Voltage Fluctuation and Flicker Measurement Software
- IEC 61000-3-11 Voltage Fluctuation and Flicker Measurement Software
- IEC 61000-3-12 Harmonic Measurement Software

Of these applications, this user's manual explains **the power control features and operating procedures** of the **IEC 61000-3-11 Voltage Fluctuation and Flicker Measurement Software**. To ensure correct use, please read this manual thoroughly before operation.

After reading this manual, keep it in a safe place for quick reference in the event that a question arises.

The manuals for the Harmonic/Flicker Measurement Software for WT5000 (with Power Supply Control Function) are listed on the next page. Please read all manuals.

For **the handling precautions, features, and operating procedures** of the IEC 61000-3-11 Voltage Fluctuation and Flicker Measurement Software, see IM D024-03EN.

Notes

- The contents of this manual are subject to change without prior notice as a result of continuing improvements to the instrument's performance and functionality. The figures given in this manual may differ from those that actually appear on your screen.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without the permission of YOKOGAWA is strictly prohibited.
- The TCP/IP software of this product and the documents concerning it have been developed/created by YOKOGAWA based on the BSD Networking Software, Release 1 that has been licensed from the Regents of the University of California.

Trademarks

- Microsoft, Windows, Windows 8.1, and Windows 10 are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are registered trademarks or trademarks of Adobe Systems Incorporated.
- Other company and product names are trademarks or registered trademarks of their respective companies.
- In this manual, the ® and TM symbols do not accompany their respective registered trademark or trademark names.

Revisions

1st Edition: February 2020

Manuals

The following manuals, including this one, are provided as manuals for the **Harmonic/Flicker Measurement Software for WT5000 (with Power Supply Control Function)**.

PDF Data of Manuals

The downloaded zip file contains the following PDF data files. The zip file also contains Japanese manuals.

File Name	Manual Title	Manual No.
Manuals explaining the power supply control features and operating procedures of each software		
IEC 61000-3-2 NFPower Users manual.pdf	Harmonic Measurement Software for WT5000 (with Power Supply Control Function, IEC 61000-3-2 Compliant) User's Manual	IM D025-01EN
IEC 61000-3-3 NFPower Users manual.pdf	Voltage Fluctuation/Flicker Measurement Software for WT5000 (with Power Supply Control Function, IEC 61000-3-3 Compliant) User's Manual	IM D025-02EN
IEC 61000-3-11 NFPower Users manual.pdf	This manual. Voltage Fluctuation/Flicker Measurement Software for WT5000 (with Power Supply Control Function, IEC 61000-3-11 Compliant) User's Manual	IM D025-03EN
IEC 61000-3-12 NFPower Users manual.pdf	Harmonic Measurement Software for WT5000 (with Power Supply Control Function, IEC 61000-3-12 Compliant) User's Manual	IM D025-04EN
Manuals explaining the handling precautions, features, and operating procedures of each software		
IEC 61000-3-2 Users Manual.pdf	Harmonic Measurement Software for WT5000 (IEC 61000-3-2 Compliant) User's Manual	IM D024-01EN
IEC 61000-3-3 Users Manual.pdf	Voltage Fluctuation/Flicker Measurement Software for WT5000 (IEC 61000-3-3 Compliant) User's Manual	IM D024-02EN
IEC 61000-3-11 Users Manual.pdf	Voltage Fluctuation/Flicker Measurement Software for WT5000 (IEC 61000-3-11 Compliant) User's Manual	IM D024-03EN
IEC 61000-3-12 Users Manual.pdf	Harmonic Measurement Software for WT5000 (IEC 61000-3-12 Compliant) User's Manual	IM D024-04EN

Online Help

The above user's manuals are incorporated in the software as help files.
For instructions on how to use the help feature, see section 3.8.

* You can also view the WT5000 User's Manual from the online help.

Manual Title	Manual No.
WT5000 Precision Power Analyzer Features Guide	IM WT5000-01EN
WT5000 Precision Power Analyzer User's Manual	IM WT5000-02EN
WT5000 Precision Power Analyzer Getting Started Guide	IM WT5000-03EN
WT5000 Precision Power Analyzer Communication Interface User's Manual	IM WT5000-17EN

Software License Agreement

Yokogawa Test & Measurement Corporation

Harmonic/Flicker Measurement Software for WT5000 (with Power Supply Control Function) Software License Agreement

Important: Read the following terms and conditions carefully.

By installing or using Harmonic/Flicker Measurement Software for WT5000 (with Power Supply Control Function) (hereafter referred to as This Software), you accept all terms and conditions in this license agreement. All rights pertaining to the software—including property rights, ownership rights, and intellectual property rights—belong to Yokogawa Test & Measurement Corporation (hereafter referred to as YOKOGAWA), YOKOGAWA's affiliated company, or original proprietor that has granted rights for licensing the software to customers based on this agreement (hereafter referred to as the original proprietor). Customers do not have any other rights other than the right to use the software in accordance with this agreement. This Software is provided for free on an “as-is” basis. You are liable for all responsibilities arising from using This Software and all responsibilities arising from referring to This Software. Regardless of whether This Software is used, you are entirely responsible for its quality, technical requirements, and regulatory requirements or regulatory conformance.

This software may contain open source software (hereafter referred to as OSS) in addition to the software that YOKOGAWA holds the rights to or the software that YOKOGAWA has been authorized to license. License terms appropriate for each OSS component are applicable in place of the terms of this license. If there is a discrepancy between the terms of the OSS license and the terms of this license, the license terms of the corresponding OSS take precedence.

Article 1: No Warranty

1. This Software is provided for free on an “as-is” basis without any warranty. YOKOGAWA will not be liable for defects or non-fulfillment of any kind. YOKOGAWA gives no guarantee that (1) the functions included in This Software will meet your requirements or your customer's requirements, (2) This Software will run without errors (e.g., bugs) or interruptions, (3) the defects and errors (e.g., bugs) in This Software will be corrected, (4) there will be no inconsistencies, mutual interference, or other effects between This Software and other software, (5) This Software or the product of This Software is correct, accurate, reliable, or up-to-date, (6) This Software is compatible with specific software required for This Software to run, or (7) This Software will not be accessed illegally or attacked through its vulnerability or the like.
2. YOKOGAWA is not always able to repair defects in or respond to questions or inquiries about This Software. Further, the contents of the software are subject to change without prior notice as a result of continuing improvements to the software's performance and functions.

Article 2: Your Responsibilities

The following acts are prohibited unless YOKOGAWA agrees or stipulates otherwise in writing.

- (1) Duplicate This Software.
- (2) Sell, lend, distribute, transfer, pledge, or re-license This Software or the right to use This Software or transmit it to the public or make it transmittable.
- (3) Share This Software in a virtual environment (regardless of the technical method such as physical computers, virtual computers, etc.).
- (4) Convert or copy This Software to any human readable form (e.g., source program) by dumping, reverse assembling, reverse compiling, reverse engineering, or the like. Modify or attempt to modify This Software into another form by correcting or translating into another language.
- (5) Remove or attempt to remove the protection mechanism (copy protection) used on or added to This Software.
- (6) Delete the copyright, trademarks, logos, and other indications displayed on This Software.
- (7) Unless YOKOGAWA has agreed otherwise in writing, create derivative software or other computer programs or allow the creation of such works.

Article 3: Restriction on Use

1. Unless a separate written agreement is drawn between you and YOKOGAWA, This Software is not designed, manufactured, or licensed to be used for aircraft operation, ship navigation, or the planning, construction, maintenance, operation, or use of on-ground support equipment or nuclear facilities.
2. If you are using This Software for a purpose described in the previous clause, YOKOGAWA will not be held liable for any claim or damage incurred as a result of using This Software, and you will take full responsibility in resolving the issue.

Article 4: Limitation of Liability

YOKOGAWA will not be held liable for any damages incurred in relation to This Software.

Article 5: Court with Jurisdiction

Should a dispute arise as a result of using This Software or in regards to this license agreement, both parties agree to discuss the issue in good faith. If an agreement cannot be reached, the Tokyo District Court shall be the exclusive agreement jurisdictional court of the first hearing.

Contents

Manuals	ii
Software License Agreement	iii

Chapter 1 Features

1.1 Features	1-1
1.2 PC System Requirements	1-3

Chapter 2 System Configuration

2.1 System Configuration	2-1
2.2 Connecting the WT5000 to the PC and Starting the Software	2-2

Chapter 3 Power Supply Functions

3.1 Power Supply Functions	3-1
3.2 Loading Power Supply Setting Information	3-2
3.3 Configuring a New Set of Power Supply to PC Communication Parameters (New connection)	3-3
3.4 Configuring the Power Supply	3-5
3.5 Executing Voltage Fluctuation/Flicker Measurements	3-11
3.6 Printing Reports	3-17
3.7 Saving the Power Supply Setting Information	3-18
3.8 Using the Help Feature	3-19
3.9 Closing the Software	3-20

1.1 Features

The Harmonic/Flicker Measurement Software for WT5000 (with Power Supply Control Function) has the following feature added to the Harmonic/Flicker Measurement Software for WT5000.

- NF Corporation's power supply (hereafter referred to as the NF power supply) control

Compatible Instruments

This software is dedicated to YOKOGAWA's WT5000 Precision Power Analyzers.

For the handling precautions, features, and operating procedures of the WT5000, see the WT5000 User's Manual.

This user's manual (IM D025-03EN) explains the case in which the IEC 61000-3-11 Voltage Fluctuation and Flicker Measurement Software (one of the applications of this software) and the WT5000 (hereafter referred to as the WT) are used in combination.

This software can be used with the following power supplies and reference impedance networks (RINs) made by NF Corporation.

ES series

Power Supply	Reference Impedance Network (RIN)
ES2000S	ES4152
ES2000U	ES4153

DP series

• Power Supply

DP $\square\square\square\square$ (E)³
1 2

- 1 Output capacity 015 (1.5 kVA) to 480 (48 kVA)
- 2 Output format
S/SL: single-phase, D: single-phase three-wire, T: three-phase, M: multi-phase
- 3 If you specify CEE7 (outlet for Europe), an "E" is appended to the model (except for DP240S/DP360S/D420LS/DP480LS).

• Reference Impedance Network (RIN)

Model	Capacity	Wiring
DP4162	20A	Single-phase two-wire
DP4163	20A	Single-phase two-wire, single-phase three-wire, three-phase three-wire, three-phase four-wire
DP4164	30A	Single-phase two-wire, single-phase three-wire
DP4165	30A	Single-phase two-wire, single-phase three-wire, three-phase three-wire, three-phase four-wire
DP4166	50A	Single-phase two-wire, single-phase three-wire
DP4167	50A	Single-phase two-wire, single-phase three-wire, three-phase three-wire, three-phase four-wire
DP4168	75A	Single-phase two-wire, single-phase three-wire
DP4169	75A	Single-phase two-wire, single-phase three-wire, three-phase three-wire, three-phase four-wire

DP4164 to DP4169 are displayed on the software as follows:

- Single-phase: DP4162
- Three-phase: DP4163

Power Supply Control Function

Power Supply Configuration

From the dialog box of this software, you can turn the power supply output on and off and set various parameters, such as voltage and frequency.

Power Supply Quality Check Function

When the power supply output is turned on, this function checks the voltage, frequency, total harmonic distortion of the voltage, and so on.

Saving and Loading Power Supply's Setting Information

The power supply model and setting information can be saved to a file. And setting information saved in a file can be loaded into the software. Further, when online, the power supply settings can be loaded from the power supply into the software.

Inclusion of the Power Supply Name in Reports

The name of the power supply used in testing is included in voltage fluctuation/flicker measurement reports.

1.2 PC System Requirements

For the PC system requirements of this software, see section 1.2 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN). However, the Ethernet requirement of the communication board is as follows:

Communication Interface


Between the WT and PC

USB, GP-IB, or Ethernet can be used. A 100BASE-TX or 1000BASE-T Ethernet port is required to use Ethernet.

Between the NF Power Supply and PC

Only GP-IB can be used.

2.1 System Configuration



To increase the power supply capacity, you need to connect a booster to the power supply unit.

For a three-phase power supply, you add a slave to the master power supply.

For details on how to connect the cables of each device, see the user's manual for the device.

2.2 Connecting the WT5000 to the PC and Starting the Software


Connecting the WT to the PC and Installing the Software

See sections 2.1 to 2.4 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN)

Starting the Software

Start the software according to section 3.1 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN). Also, note the following:

- If you are using the ES2000U, set the single-phase/three-phase slide switch appropriately before starting the software.
- If you are using the multi-phase model of the DP series power supply, set the phase mode switch appropriately before starting the software.












To connect using the same settings as the last time, select "Same Condition as Last Execution" in the software startup connection conditions.

When you start the software for the first time, default settings according to the power supply type described in section 3.4 are used.

Note

If you manually change the power supply settings, such as the voltage range and output voltage, after starting or closing the software, those settings are not reflected, and the settings of connection condition (default, loaded conditions, or conditions used the last time) are used. In such a case, check or change the power supply settings on the software before turning the output on.

3.1 Power Supply Functions

Icon	Function	Power Supply Function
	Start	None
	Open	Load power supply model and setting information from a file.
	Connect	Establish a connection between the PC and power supply using the GP-IB interface.
	Setting	Set various power supply parameters, such as voltage and frequency.
	Test	<ul style="list-style-type: none"> • Turn the power output on and off. • When the power output is turned on, this function checks the voltage, frequency, total harmonic distortion of the voltage, and so on. (Power supply quality check function)
	Analyze	None
	Print	The name of the power supply used in testing is included in harmonic measurement reports.
	Save	Save the power supply model and setting information to a file.
	Close	When you close the software, the power is turned off, regardless of whether the power is on or off.

3.2 Loading Power Supply Setting Information


Power supply setting information is saved in .ini files. Load the setting information according to the procedure in section 5.1, "Loading Setting Information and Measured Data" in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN). An .ini file contains the following power supply parameters.


- Power supply model
- Power supply ROM version
- Wiring system
- Voltage range
- Voltage limit
- Rated voltage (phase)
- Rated frequency
- Impedance¹
- Setting mode (basic/advanced)
- Power supply quality check availability
- Phase voltage/line voltage
- GP-IB address of the power supply
- Reference impedance network (RIN) usage

¹ This information is saved regardless of whether reference impedance network (RIN) connection is present.

3.3 Configuring a New Set of Power Supply to PC Communication Parameters (New connection)

Procedure


1. Click  in the menu area. The detailed connection menu appears.



Power supply connection
Configure the connection to the NF power supply.

Configuring the Connection to the Power Supply

2. For NF Power Connection, select **Use** or **Not Used**.
3. If you select Use, select the GP-IB address of the target power supply.



Note

- GP-IB address 0 is reserved for the PC, so you cannot select it.
- To control the WT and NF power supply using GP-IB, set different addresses for each. If the addresses overlap, an error dialog box will appear.

3.3. Configuring a New Set of Power Supply to PC Communication Parameters (New connection)

Explanation

Configuring the Connection to the Power Supply

Select the GP-IB address of the target power supply.


Selectable range: 1 to 30

Connection Condition and Connection Status Display

The connection conditions on the detailed menu and the current connection status are shown in the setting and display area.

- **When Disconnected (offline)**


Illustration of both the ES series power supply and DP series power supply is shown.




- **When Connected (online)**

Illustration of either the ES series power supply and DP series power supply, whichever is connected, is shown.

- **When connected to an ES series power supply**





- **When connected to a DP series power supply**





3.4 Configuring the Power Supply

Procedure

1. Click  in the menu area. The detailed setting menu appears.



1. In the setting and display area, select the **NF Power Supply** tab. An NF power supply setting dialog box appears.
2. Click the basic settings  or advanced settings  button.
3. Specify the settings.

3.4 Configuring the Power Supply

In basic setting mode, the following dialog box appears.

In basic setting mode, when you set the wiring system, these boxes are set automatically.
For details, see the next page.

To view or change these settings, select advanced setting mode.

The screenshot shows the 'Wiring system' dialog box with the following settings and annotations:

- Wiring system** (Title)
- Wiring Pattern**: For 1P2W 230V Devices
- Voltage Range**: 200V (setting range: 0.0~300.0 V)
- Voltage Limit**: 300.0 V
- Phase Voltage** (Selected): ☐ Phase Voltage, ☐ Line Voltage
- Rated Voltage**: 230.0 V
- Rated Frequency**: 50.00 Hz
- Reference Impedance Network(RIN) is used**: ☒ (Annotated: "Select this check box to prohibit changes to the settings when the power output is on.")
- Impedance**: 230V
- Connection Information**: ES2000S + ES4152 (Annotated: "Power supply and reference impedance network (RIN) information. The power supply and RIN model are obtained automatically and displayed.*")
- Defaults** button
- Diagram**: A circuit diagram showing a single-phase two-wire AC power source (Hi, Lo) connected to a load (L1, L2, L3, N) through a power supply and RIN model. The diagram includes labels for "Line Voltage 230.0V", "Phase Voltage 230.0V", and "INPUT/OUTPUT".

Annotations:

- Select this check box to check the power supply quality before measurement.** (Points to the "The power supply quality is checked before compliance test" checkbox)
- In the state of power supply ON, the setting change cannot be done.** (Points to the "In the state of power supply ON, the setting change cannot be done" checkbox)
- Rated frequency**
Select 50 Hz or 60 Hz from the drop-down list.
If you click the box, you can set the frequency in the range of 45.00 to 66.00.
You can select values that have been entered recently from the drop-down list.
- Illustration of the setting information** (Points to the circuit diagram)

* If any of the models from DP4164 to DP4169 is connected for the RIN, the software displays it as follows:

- Single-phase: DP4162
- Three-phase: DP4163

Wiring System

Depending on the type of power supply that is connected, the following wiring system is selected automatically. In addition, voltage range and other parameters are set to the following values.

When an ES2000S (Single-Phase Model) Is Connected

Wiring System	Voltage Range	Voltage Limit	Phase Voltage/ Line Voltage	Rated Voltage
Single-phase two-wire 230 V, 50 Hz device	200	300.0	Phase voltage	230.0

When an ES2000U (Three-Phase Model) Is Connected with the Slide Switch Set to Single-Phase Mode

Wiring System	Voltage Range	Voltage Limit	Phase Voltage/ Line Voltage	Rated Voltage
Single-phase two-wire 230 V, 50 Hz device	200	300.0	Phase voltage	230.0

When an ES2000U (three-phase model) Is Connected with the Slide Switch Set to Three-Phase Mode

Wiring System	Voltage Range	Voltage Limit	Phase Voltage/ Line Voltage	Rated Voltage
Three-phase four-wire 400 V, 50 Hz device	200	300.0	Line voltage	400.0

When a DP Power Supply Single-Phase Model Is Connected or Multi-Phase Model with the Phase Mode Set to Single-Phase Two-Wire Output

Wiring System	Voltage Range	Voltage Limit	Phase Voltage/ Line Voltage	Rated Voltage
Single-phase two-wire 230 V device	200	300.0	Phase voltage	230.0

When a DP Power Supply Multi-Phase Model Is Connected or Multi-Phase Model with the Phase Mode Not Set to Single-Phase Two-Wire Output

Wiring System	Voltage Range	Voltage Limit	Phase Voltage/ Line Voltage	Rated Voltage
Three-phase four-wire 400 V device	200	300.0	Phase voltage	230.9

3.4 Configuring the Power Supply

In advanced setting mode, the following dialog box appears.

NF Power Supply | WT Measurement Instrument | Standard | Option

Wiring Pattern: For 1P2W 230V Devices

Voltage Range: 200V (setting range: 0.0 ~ 300.0 V)

Voltage Limit: 300.0 V

☒ Phase Voltage

☐ Line Voltage

Rated Voltage: 230.0 V

Rated Frequency: 50.00 Hz

☒ Reference Impedance Network(RIN) is used

Impedance: 230V

Connection Information: ES2000S + ES4152

☒ In the state of power supply ON, the setting change cannot be done.

☒ The power supply quality is checked before compliance test.

Defaults

Single phase two wire AC power

Phase Voltage 230.0V

Line Voltage 230.0V

0.24Ω + j0.15Ω

0.24Ω + j0.15Ω

0.24Ω + j0.15Ω

0.16Ω + j0.1Ω

INPUT

OUTPUT

Voltage Range

Select 100 V or 200 V. The range of values that you can set for the rated voltage and voltage limit is displayed.

Voltage Limit

You can select the following values from the drop-down list for the voltage limit depending on the voltage range.

Voltage Range	Voltage Limit
100 V	150.0 V
200 V	300.0 V

By clicking the box, you can set the value down to the first decimal place within the range shown in the Voltage Range box.

Output Voltage Setting

Set the output voltage to **Phase Voltage** or **Line Voltage**.

Rated Voltage

You can select the following values from the drop-down list for the rated voltage output depending on the Phase Voltage/Line Voltage setting and voltage range.

Voltage Range		Phase Voltage/Line Voltage	
		Phase Voltage	Line Voltage
100 V	100 V	100.0 V or 115.0 V	200.0 V or 230.0 V
	200 V	200.0 V or 230.0 V	200.0 V or 400.0 V

By clicking the box, you can set the value down to the first decimal place within the range shown in the Voltage Range box.

If the phase voltage of the rated voltage exceeds the value in the voltage limit table, the following values are set depending on the power supply type and voltage range.

Voltage limit:	The value in the voltage limit table
Phase voltage/line voltage:	Phase voltage
Rated voltage:	Same value as the voltage range

Note

If the rated voltage is set using a line voltage, the line voltage is converted into phase voltage according to the wiring system and compared to the value in the voltage limit table.

Impedance

If you select the "Reference Impedance Network (RIN) is used" check box, you can set the following impedances according to the connected RIN. If you do not select the check box, DEFEAT appears in the box.

When an ES4152 is connected

Or when the RIN under Connection Information in the upper right of the tab sheet is DP4162*

- DEFEAT
- 100 V
- 200 V
- 230 V

When an ES4153 is connected

Or when the RIN under Connection Information in the upper right of the tab sheet is set to DP4163*

- DEFEAT
- JPN 1φ
- JPN 3φ
- EU 1φ/3φ

* For the connection information when any of the models from DP4164 to DP4169 is connected for the RIN, see page 3-6.

Depending on the connected power supply type and compatibility condition, the impedance is set to the following default values.

		Power Supply Type	
Compatibility Condition		<ul style="list-style-type: none"> • ES2000S • DP series 	<ul style="list-style-type: none"> • ES2000U • DP series
		- Single-phase model	- Three-phase model
		- When phase mode on a multi-phase model is set to single-phase two-wire	- When phase mode on a multi-phase model is not set to single-phase two-wire
		230 V	EU1φ/3φ
	Service Current	DEFEAT	DEFEAT
	Capacity 100A		
	Impedance Zmax	DEFEAT	DEFEAT

3.4 Configuring the Power Supply

If the RIN for the DP series power supply is not connected, you cannot select the "Reference Impedance Network (RIN) is used" check box. Consequently, you cannot change the impedance setting.

Defaults

The settings are reset to the following conditions (default values).

Setting mode: basic

Wiring system

The wiring system is set as follows according to the connected power supply.

- When an ES2000S (single-phase model) is connected
For 1P2W 230 V, 50 Hz Device
- When an ES2000U (three-phase model) is connected with the slide switch set to single-phase mode
For 1P2W 230 V, 50 Hz Device
- When an ES2000U (three-phase model) is connected with the slide switch set to three-phase mode
For 3P4W 400 V, 50 Hz Device
- When a DP series power supply single-phase model is connected or multi-phase model with the phase mode set to single-phase two-wire output
For 1P2W 230 V Device
- When a DP series power supply multi-phase model is connected or multi-phase model with the phase mode not set to single-phase two-wire output
For 3P4W 400 V Device

Voltage ranges: As shown in the table on page 3-7 according to the connected power supply and wiring system.

Voltage limit: As shown in the table on page 3-7 according to the connected power supply and wiring system.

Phase voltage/line voltage: As shown in the table on page 3-7 according to the connected power supply and wiring system.

Rated voltage: As shown in the table on page 3-7 according to the connected power supply and wiring system.

Rated frequency: 50 Hz

The power supply quality is checked before compliance test: Selected

Reference Impedance Network (RIN) is used

- When an ES2000S or ES2000U is connected: Selected
- When a DP series power supply is connected
 - When DP series RIN is connected: Selected
 - When DP series RIN is not connected: Not selected

Impedance: As shown in the table on page 3-9 according to the connected power supply and compatibility condition.


Settings at Startup


The above settings when the software is started are set as follows depending on the connection conditions.

Connection Condition	Settings
New connection	Default values
Same conditions as those of the loaded file	Settings of the loaded file
Same conditions as the last time	Settings used the last time

3.5 Executing Voltage Fluctuation/Flicker Measurements

Procedure

- Click  in the menu area. A detailed measurement menu appears according to the compatibility condition settings of section 7.1 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN).
 - If Compatibility Condition is set to Impedance Zmax, the detailed measurement menu shown in the following figure appears.
 - If Compatibility Condition is set to Compliance with IEC61000-3-3 or Service Current Capacity 100A, the detailed measurement menu shown on the next page appears.
- When the compatibility condition is Impedance Zmax



Measure

Selection of mode

☒ General ☒ Manual

Power Supply to EUT

Power On

Check the selection of Ztest

Voltage Drop caused by the equipment shall be within the range 3% to 5% of the Test Supply

Test Time 1 min

Start Voltage Drop Test

Start Test (General)

Initialization

Start Test (Manual)

☐ Time setting to turn EUT off 50 sec

Initialization

Stop Power Supply to EUT After Test


Power Off

Turn on the power supply to the EUT.

Turn off the power supply to the EUT.


3.5 Executing Voltage Fluctuation/Flicker Measurements

- When the compatibility condition is Compliance with IEC 61000-3-3 or Service Current Capacity 100A



  in the setting and display area is an power supply output on/off icon.


* Unavailable icons appear dimmed.



Turning the Power Output On and Off

The following methods are available for turning the power output on and off.

- Click Power On or Power Off in the detailed menu area.



- Click  (Power On) or  (Power Off) in the setting and display area.

Whether the Power On, Power Off, Initialize, Start, Reset, and Move buttons are enabled or disabled in each of the software states are as follows:

Flicker Measurement

Software State	Power Supply State	Power On	Power Off	Initialize	Start	Reset
Before measurement initialization (Reset)	Power On	Disabled	Enabled	Enabled	Disabled	Disabled
	Power Off	Enabled	Disabled	Disabled	Disabled	Disabled
Measurement initialization complete (Ready)	Power On	Disabled	Enabled	Disabled	Enabled	Enabled
	Power Off	Enabled	Disabled	Disabled	Disabled	Enabled
Measuring (Start)	Power On	Disabled	Enabled	Disabled	Disabled	Enabled
Measurement complete (Complete)	Power On	Disabled	Enabled	Disabled	Disabled	Enabled
	Power Off	Enabled	Disabled	Disabled	Disabled	Enabled
Offline		Disabled	Disabled	Disabled	Disabled	Disabled

WT states are indicated in parentheses.

Manual dmax Measurement


Software State	Power Supply State	Power On	Power Off	Initialize	Start	Reset	Move
Before measurement initialization (Reset)	Power On	Disabled	Enabled	Enabled	Disabled	Disabled	Disabled
	Power Off	Enabled	Disabled	Disabled	Disabled	Disabled	Disabled
Measurement initialization complete (Ready)	Power On	Disabled	Enabled	Disabled	Enabled	Enabled	Enabled
	Power Off	Enabled	Disabled	Disabled	Disabled	Disabled	Disabled
Measuring (Start)	Power On	Disabled	Enabled	Disabled	Disabled	Enabled	Disabled
Measurement complete (Complete)	Power On	Disabled	Enabled	Disabled	Disabled	Enabled	Enabled
	Power Off	Enabled	Disabled	Disabled	Disabled	Disabled	Disabled
Offline		Disabled	Disabled	Disabled	Disabled	Disabled	Disabled

WT states are indicated in parentheses.

Note

- In the measurement initialization complete (Power Off) or measurement complete (Power Off) states, if the state is changed from Power Off to Power On, a power supply quality check is not performed regardless of whether the check box is selected.
- If the software is in the Power On state and the software is switched from online to offline, the software switches to the Power Off state.
- If the software is switched from offline to online, the software is set to the Power Off state regardless of whether the software is in the Power On or Power Off state.
- When the software is closed, the software is set to the Power Off state regardless of whether the software is in the Power On or Power Off state.

If problems are found in the power supply quality, an error message appears. The item that resulted in error is displayed.



Starting Voltage Fluctuation/Flicker Measurements

Start a voltage fluctuation/flicker measurement according to section 8.1 or 8.2 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN). However, note the following:

Voltage Range Validity Check


When a voltage fluctuation/flicker measurement is started, the software checks whether the NF power supply, WT, and Voltage Fluctuation/Flicker Measurement Software are configured as shown in the following table.

- Check items when the NF Power Connection is set to Use in the NF power supply communication setting dialog box (section 3.3)

Wiring System	NF Power Supply Setting Dialog Box		WT Voltage Range ¹
	Rated Voltage	Rated Frequency	
Single-phase two-wire 230 V, 50 Hz device	100 to 230 V	45 to 66 Hz	CF3: 100 V to 300 V
Three-phase four-wire 400 V, 50 Hz device	220 to 240 V	45 to 66 Hz	CF3: 300 V to 600 V

¹ "CF3" in the table indicates that the crest factor is set to 3.

If the settings are different from those in the table, an error message will appear. The item that resulted in error is displayed.



3.5 Executing Voltage Fluctuation/Flicker Measurements

Measured Element

The measured element is determined by the WT measurement target (Object) setting.¹


- 1 See section 7.2 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN).

For example, even when a three-phase power supply is being measured, if the WT measurement target (Object) is set only to Element 1, only input element 1 will be measured.

Also, when a single-phase power supply is being measured, if the WT measurement target (Object) is set to Element 1 and 2, input element 2 (which is not receiving any signal) will also be measured, and the total judgment may indicate Fail.

Power Supply Error Check during Measurement

This software checks whether an error is occurring in the power supply during measurement. If an error is found, an error message appears. For example, if an overload occurs, the following error message will appear.



Note

The power output remains on even if the voltage fluctuation/flicker measurement is ended or aborted. (It is not automatically turned off.)


3.6 Printing Reports

You can print reports by following the procedure in section 10.4 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN). If the NF Power Connection is set to Use in the NF power supply communication setting dialog box (section 3.3), the following items are included in the report.

- Power: The type of power supply and reference impedance network (RIN)¹
- Impedance: Reference impedance network (RIN) setting¹

¹ This is displayed if you select the "Reference Impedance Network (RIN) is used" check box in the power supply setting dialog box.

Report printout example



3.7 Saving the Power Supply Setting Information

Power supply setting information is saved in .ini files. Save the setting information according to the procedure in section 11.1, "Saving Setting Information and Measured Data" in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN).

The following power supply parameters are included in .ini files.


- Power supply model
- Power supply ROM version
- Wiring system¹
- Voltage range¹
- Voltage limit¹
- Rated voltage (phase)¹
- Rated frequency¹
- Impedance^{*1*2}
- Setting mode (basic/advanced)¹
- Power supply quality check availability¹
- Phase voltage/line voltage¹
- GP-IB address of the power supply
- Reference impedance network (RIN) usage¹

1 Set in the NF power supply dialog box in section 3.4

2 This information is saved regardless of whether reference impedance network (RIN) connection is present.

3.8 Using the Help Feature

Follow the procedure in section 12.3 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN). The following PDF document will open.



Obtaining the Latest User's Manual and Alteration Notices

Download the user's manual and alteration notices for the software from the YOKOGAWA manual download webpage. If there are alteration notices, they are downloaded as file attachments to the user's manual.

Change the file name of the manual or alteration notice to that shown below, and overwrite the existing files in the software installation folder.

Latest User's Manual or Alteration Notice	File Name
Document explaining the NF power supply control functions (IM D025-03EN) (this manual)	IMD025-03EN.pdf
Alteration notice for this manual	Alterations-S01CE.pdf

3.9 Closing the Software

Close the software according to the procedure in section 4.2 in the IEC 61000-3-11 Voltage Fluctuation/Flicker Measurement Software User's Manual (IM D024-03EN). When you close the software, the power is turned off, regardless of whether the power is on or off.