

When Using Version 4 of the WE Control Software

1. Changes in the Current Version of the WE7000 Control Software (Version 4.0.1.X)

In version 4.0.1.X, waveform monitor settings for the waveform display method and calculations are only saved if you choose **File > Save Current Condition to Another File** on the menu bar. Therefore you must perform this procedure before closing the waveform monitor if you want to save any setting changes.

2. Standby Power and Saving Settings

If the standby power on the measuring station is turned OFF when you try to save the settings, the save will not work. For example, if after opening a setting file and changing the settings for each module on the measuring station while the standby power to the measuring station is OFF, when you choose Save Current Condition... to try to save the settings shown under System > Configuration Settings, a file is created but it does not contain the changes you made for each module.

3. Automatic Saving

If a check mark appears next to *Save settings to Default.wes on exit* under System > Configuration Settings, the current settings are automatically written to the Default.wes file when you exit.

4. When Using the Setting Converter

No changes are made to monitor color information when using the setting converter.

5. When Using Windows 95 with Ethernet Connections

Note that the WE7000 Control Software startup option must be changed from *ethernet* to *ethernet95*. To make this change, right-click the WE7000 shortcut icon, then choose **Properties > Shortcut**. In the **Target** box, change *ethernet* to *ethernet95*. If you do not make this change, the message "Communications Error" will appear when you start up the WE7000 Control Software. This change is not necessary when using an operating system other than Windows 95.