User's Manual

WT1800 Precision Power Analyzer Features Guide

Notice of Alterations

Please make the following alterations to the User's Manual IM WT1801-01EN on the included CD-ROM.

■ 16-3 page "Wiring System during High Speed Data Capturing"

Please change the followings

-
 - 1P2W: Single-phase, two-wire system (DC signal)
 - 3P4W: Three-phase, four-wire system
 - 3P3W (3V3A): Three-voltage, three-current method