

1. Contents of the Package

The following items are included in the package. If some of the contents are not correct or missing or if there is physical damage, contact the dealer from which you purchased them.

Item	Quantity	Note
701992 Xviewer	1	Media: CD-ROM.
701992 Xviewer User's Manual	1	Explains the Xviewer's standard features and how to use these features. The manual is located on the CD included in your package (pdf format).
Xviewer DL850 Advanced Utility User's Manual	1	Explains DL850 Advanced Utility features and how to use these features. The manual is located on the CD included in your package (pdf format).
Xviewer EYE Video and Waveform Viewer Feature User's Manual	1	Explains the video and waveform viewer features and how to use these features. The manual is located on the CD included in your package (pdf format).
License seal	1	License number (Xviewer Math Edition)
This manual	1	

2. Installing the Xviewer Upgrade Edition


The following Xviewer must be installed before installing the Xviewer Upgrade Edition. If the version of Xviewer that you are using is old, uninstall it and then install the latest Xviewer.

Function	Xviewer version
Mathematical Upgrade Edition	Version 1.31 or later
DL850 Advanced Utility	Version 1.61 or later
Xviewer EYE Video and Waveform Viewer Feature	Version 1.63 or later

Note

- For the installation and uninstallation procedures, see page xii in IM701992-01E.
- To check the version, see section 9.2, "Viewing Version Information" in IM701992-01E.

1. Start Xviewer (standard version) that is already installed.
2. On the **Help** menu, choose **Add licenseNo**. The dialog box for registering the license number opens.
3. Enter the number indicated on the license seal, and click **Add**. If the upgrade completes successfully, a message appears prompting you to restart Xviewer.
4. Click **OK**.
5. Restart Xviewer.



6. On the **Help** menu, choose **About Xviewer**. Check the version information. For details, see section 9.2 in the Xviewer User's Manual (IM701992-01E).

3. User's Manual

For a description of the computation function, see section 4.6 in the Xviewer User's Manual (IM701992-01E).