


## 18.9 Using the DL850/DL850V as a USB Storage Device

This section explains the setting that enables you to use the DL850/DL850V as a USB storage device through a USB connection made between the USB port on the DL850/DL850V side panel and a PC.

► “USB Communication (USB Function)” in the Features Guide

### UTILITY System Config Menu

Press **UTILITY** and then the **System Config** soft key to display the following menu.



### Note

- When USB Function is set to Storage, only the internal hard disk of the DL850/DL850V can be used as a storage device. You cannot access any other storage media that are connected to the DL850/DL850V.
- When you access the internal hard disk of the DL850/DL850V from a PC, only perform read operation. Doing otherwise may damage the DL850/DL850V.
- When USB Function is set to Storage and files are being accessed, do not remove the USB cable or turn off the DL850/DL850V. Doing so may damage the DL850/DL850V.
- When USB Function is set to Storage, never access the DL850/DL850V internal hard disk from the DL850/DL850V menu.